

Hirschmann Automation and Control GmbH

RSPE HiOS-2A Rel. 10000

Reference Manual Graphical User Interface

User Manual Configuration



Reference Manual

Graphical User Interface Rail Switch Power Enhanced HiOS-2A The naming of copyrighted trademarks in this manual, even when not specially indicated, should not be taken to mean that these names may be considered as free in the sense of the trademark and tradename protection law and hence that they may be freely used by anyone.

© 2024 Hirschmann Automation and Control GmbH

Manuals and software are protected by copyright. All rights reserved. The copying, reproduction, translation, conversion into any electronic medium or machine scannable form is not permitted, either in whole or in part. An exception is the preparation of a backup copy of the software for your own use.

The performance features described here are binding only if they have been expressly agreed when the contract was made. This document was produced by Hirschmann Automation and Control GmbH according to the best of the company's knowledge. Hirschmann reserves the right to change the contents of this document without prior notice. Hirschmann can give no guarantee in respect of the correctness or accuracy of the information in this document.

Hirschmann can accept no responsibility for damages, resulting from the use of the network components or the associated operating software. In addition, we refer to the conditions of use specified in the license contract.

You find the latest user documentation for your device at: doc.hirschmann.com

Hirschmann Automation and Control GmbH Stuttgarter Str. 45-51 72654 Neckartenzlingen Germany

Contents

	Safety instructions
	About this Manual
	Key
	Notes on the Graphical User Interface
	Banner
	Menu pane
	Dialog area
1	Basic Settings
1.1	System
1.2	Modules
1.3	Network
1.3.1	Global
1.3.2	IPv4
1.3.3	IPv6
1.4	Software
1.5	Load/Save
1.6	External Memory
1.7	Port
1.8	Power over Ethernet
1.8.1	PoE Global
1.8.2	PoE Port
1.9	Restart
2	Time
2.1	Basic Settings
2.2	SNTP
2.2.1	SNTP Client
2.2.2	SNTP Server
2.3	PTP
2.3.1	PTP Global
2.3.2	PTP Boundary Clock
2.3.2.1	PTP Boundary Clock Global
2.3.2.2	PTP Boundary Clock Port
2.3.3	PTP Transparent Clock
2.3.3.1	PTP Transparent Clock Global
2.3.3.2	PTP Transparent Clock Port
2.4	802.1AS
2.4.1	802.1AS Global
2.4.2	802.1AS Port
2.4.3	802.1AS Statistics
3	Device Security
3.1	User Management

3.2	Authentication List	125
3.3	LDAP	127
3.3.1	LDAP Configuration	128
3.3.2	LDAP Role Mapping	134
3.4	Management Access	136
3.4.1	Server	137
3.4.2	IP Access Restriction	150
3.4.3	Web	154
3.4.4	Command Line Interface	155
3.4.5	SNMPv1/v2 Community	157
3.5	Pre-login Banner	159
3.6	SSH Known Hosts	160
4	Network Security	163
4.1	Network Security Overview	163
4.2	Port Security.	165
4.3	802.1X	170
4.3.1	802.1X Global	171
4.3.2	802.1X Port Configuration	174
4.3.3	802.1X Port Clients	
4.3.4	802.1X EAPOL Port Statistics	
4.3.5	802.1X Port Authentication History	
4.3.6	802.1X Integrated Authentication Server (IAS)	
4.4	RADIUS	
4.4.1	RADIUS Global	
4.4.2	RADIUS Authentication Server	
4.4.3	RADIUS Accounting Server	
4.4.4	RADIUS Authentication Statistics	
4.4.5	RADIUS Accounting Statistics	
4.5	DoS	
4.5.1	DoS Global.	
4.6	DHCP Snooping.	
4.6.1	DHCP Snooping Global	
4.6.2	DHCP Snooping Configuration	
4.6.3	DHCP Snooping Statistics	
4.6.4	DHCP Snooping Bindings	
4.7	Dynamic ARP Inspection	
4.7.1	Dynamic ARP Inspection Global	
4.7.2	Dynamic ARP Inspection Configuration	
4.7.3	Dynamic ARP Inspection ARP Rules	
4.7.4	Dynamic ARP Inspection Statistics	
4.8	ACL	
4.8.1	ACL IPv4 Rule	
4.8.2		
4.8.3	ACL Assignment	
4.8.4	ACL Time Profile	

5	Switching	241				
5.1	Switching Global	241				
5.2	Rate Limiter	244				
5.3	Filter for MAC Addresses					
5.4	IGMP Snooping	249				
5.4.1	IGMP Snooping Global					
5.4.2	IGMP Snooping Configuration					
5.4.3	IGMP Snooping Enhancements	256				
5.4.4	IGMP Snooping Querier	259				
5.4.5	IGMP Snooping Multicasts	262				
5.5	MRP-IEEE	263				
5.5.1	MRP-IEEE Configuration	264				
5.5.2	MRP-IEEE Multiple MAC Registration Protocol	265				
5.5.3	MRP-IEEE Multiple VLAN Registration Protocol	270				
5.6	GARP	273				
5.6.1	GMRP	274				
5.6.2	GVRP	276				
5.7	QoS/Priority	277				
5.7.1	QoS/Priority Global	278				
5.7.2	QoS/Priority Port Configuration	279				
5.7.3	802.1D/p Mapping	281				
5.7.4	IP DSCP Mapping	282				
5.7.5	Queue Management	284				
5.7.6	DiffServ	285				
5.7.6.1	DiffServ Overview	287				
5.7.6.2	DiffServ Global	288				
5.7.6.3	DiffServ Class	289				
5.7.6.4	DiffServ Policy	296				
5.7.6.5	DiffServ Assignment.	305				
5.8	VLAN	306				
5.8.1	VLAN Global	308				
5.8.2	VLAN Configuration	309				
5.8.3	VLAN Port	312				
5.8.4	VLAN Voice	314				
5.8.5	MAC Based VLAN	317				
5.8.6	Subnet-based VLAN	318				
5.8.7	Protocol Based VLAN	320				
5.9	L2-Redundancy	321				
5.9.1	MRP	323				
5.9.2	HIPER Ring					
5.9.3	DLR (depends on hardware)					
5.9.3.1	DLR Configuration (depends on hardware)					
5.9.3.2	DLR Statistics (depends on hardware)					
5.9.4	PRP (depends on hardware)					
5.9.4.1	PRP Configuration (depends on hardware)					
5.9.4.2	PRP DAN/VDAN Table (depends on hardware)					
5.9.4.3	PRP Proxy Node Table (depends on hardware)	342				

5.9.4.4	PRP Statistics (depends on hardware)	343
5.9.5	HSR (depends on hardware)	344
5.9.5.1	HSR Configuration (depends on hardware)	345
5.9.5.2	HSR DAN/VDAN Table (depends on hardware)	349
5.9.5.3	HSR Proxy Node Table (depends on hardware)	350
5.9.5.4	HSR Statistics (depends on hardware)	351
5.9.6	Spanning Tree	352
5.9.6.1	Spanning Tree Global	353
5.9.6.2	Spanning Tree MSTP	360
5.9.6.3	Spanning Tree Port	365
5.9.7	Link Aggregation	374
5.9.8	Link Backup	381
5.9.9	FuseNet	384
5.9.9.1	Sub Ring	386
5.9.9.2	Ring/Network Coupling	391
5.9.9.3	Redundant Coupling Protocol	397
6	Diagnostics	101
6 .1	-	
-	Status Configuration.	
6.1.1		
6.1.2	Security Status	
6.1.3		
6.1.3.1	Signal Contact 1 / Signal Contact 2	
6.1.4	MAC Notification	
6.1.5	Alarms (Traps)	
6.1.5.1	Trap V3 User Management	
6.1.5.2	Trap Destinations	
6.2	System	
6.2.1	System Information	
6.2.2		
6.2.3	Configuration Check	
6.2.4	IP Address Conflict Detection	
6.2.5	ARP	-
6.2.6	Selftest	
6.3		
6.3.1	Email Notification Global	
6.3.2	Email Notification Recipients	
6.3.3	Email Notification Mail Server	
6.4	Syslog	
6.5	Ports	
6.5.1	SFP	
6.5.2	TP cable diagnosis.	
6.5.3	Port Monitor	
6.5.4	Auto-Disable	
6.5.5	Port Mirroring	
6.5.6	RSPAN	
6.6	LLDP	481

6.6.1	LLDP Configuration	482
6.6.2	LLDP Topology Discovery	486
6.7	Loop Protection	490
6.8	SFlow	494
6.8.1	SFlow Configuration	495
6.8.2	SFlow Receiver	497
6.9	Report	498
6.9.1	Report Global	499
6.9.2	Persistent Logging	503
6.9.3	System Log	506
6.9.4	Audit Trail	507
7	Advanced	509
7.1	DHCP	509
7.1.1	DHCP Server	509
7.1.1.1	DHCP Server Global	510
7.1.1.2	DHCP Server Pool	512
7.1.1.3	DHCP Server Lease Table	517
7.2	DHCP L2 Relay	518
7.2.1	DHCP L2 Relay Configuration	519
7.2.2	DHCP L2 Relay Statistics	522
7.3	DNS	523
7.3.1	DNS Client	523
7.3.1.1	DNS Client Global	524
7.3.1.2	DNS Client Current	525
7.3.1.3	DNS Client Static	526
7.3.1.4	DNS Client Static Hosts	529
7.4	Industrial Protocols.	530
7.4.1	IEC61850-MMS	531
7.4.2	Modbus TCP	534
7.4.3	EtherNet/IP	536
7.4.4	OPC UA Server	538
7.4.5	Service Discovery	541
7.4.6	PROFINET	544
7.5	Tracking	547
7.5.1	Tracking Configuration	548
7.5.2	Tracking Applications	552
7.6	Command Line Interface	553
Α	Index	555
В	Technical support	561
С	Readers' Comments	562

Safety instructions

WARNING

UNCONTROLLED MACHINE ACTIONS

To avoid uncontrolled machine actions caused by data loss, configure all the data transmission devices individually.

Before you start any machine which is controlled via data transmission, be sure to complete the configuration of all data transmission devices.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

About this Manual

The "Configuration" user manual contains the information you need to start operating the device. It takes you step by step from the first startup operation through to the basic settings for operation in your environment.

The "Installation" user manual contains a device description, safety instructions, a description of the display, and the other information that you need to install the device.

The "Graphical User Interface" reference manual contains detailed information on using the graphical user interface to operate the individual functions of the device.

The "Command Line Interface" reference manual contains detailed information on using the Command Line Interface to operate the individual functions of the device.

The Industrial HiVision Network Management software provides you with additional options for smooth configuration and monitoring:

- Auto-topology discovery
- Browser interface
- Client/server structure
- Event handling
- Event log
- Simultaneous configuration of multiple devices
- Graphical user interface with network layout
- SNMP/OPC gateway

Key

The designations used in this manual have the following meanings:

	List
	Work step
Link	Cross-reference with link
Note:	A note emphasizes a significant fact or draws your attention to a dependency.
Courier	Representation of a CLI command or field contents in the graphical user interface

Execution in the Graphical User Interface

Execution in the Command Line Interface

Notes on the Graphical User Interface

The prerequisite to use the Graphical User Interface of the device is a web browser with HTML5 support.

The responsive Graphical User Interface automatically adapts to the size of your screen. Consequently, you can see more details on a large, high-resolution screen than on a small screen. For example, on a high-resolution screen, the buttons have a label next to the icon. On a screen with a small width, the Graphical User Interface displays only the icon.

Note: On a conventional screen, you click to navigate. On a device with a touchscreen, on the other hand, you tap. For simplicity, we only use "click" in our help texts.

The Graphical User Interface is divided as follows:

- Banner
- Menu pane
- Dialog area

Banner

The banner displays the following information:

Displays and hides the menu. When the web browser window is too narrow, the Graphical User Interface hides the menu pane. The banner displays the button instead.

Brand logo

Click the logo to open the website of the manufacturer of the device in a new window.

Dialog name

Displays the name of the dialog currently displayed in the dialog area.

(!5∕

Displays that the web browser cannot contact the device. The connection to the device is interrupted.

8

Displays if the settings in the volatile memory (RAM) differ from the settings of the "Selected" configuration profile in the non-volatile memory (NVM). The banner displays the icon if you have applied the settings, but not yet saved them in the non-volatile memory (NVM).

?

When you click the button, the online help opens in a new window.

Ų

When you click the button, a tooltip displays the following information:

- The summary of the Device status frame. See the Basic Settings > System dialog.
- The summary of the Security status frame. See the Basic Settings > System dialog.

A red dot next to the icon means that at least one of the values is greater than θ .



When you click the button, a submenu opens with the following menu items:

- User account name The account name of the user that is currently logged in. *Logout* button
 - When you click the button, this logs out the currently logged in user. Then the login dialog opens.

Menu pane

When the web browser window is too narrow, the Graphical User Interface hides the menu pane. To display the menu pane, click the \equiv button in the banner.

The menu pane is divided as follows:

- Icons bar
- Menu tree

Icons bar

The icons bar displays the following information:

Device software

Displays the version number of the currently running device software that the device loaded during the last system startup.

Q

Displays a text field to search for a keyword. When you enter a character or string, the menu tree displays a menu item only for those dialogs that are related to this keyword.

ር;

The menu tree displays a menu item only for those dialogs in which at least one parameter differs from the default setting (*Diff to default*). To display the complete menu tree again, click the button.

井는

Collapses the menu tree. The menu tree then displays only the menu items of the first level.

:3

Expands the menu tree. The menu tree then displays every menu item on every level.

Menu tree

The menu tree contains one item for each dialog in the Graphical User Interface. When you click a menu item, the dialog area displays the corresponding dialog. You can change the view of the menu tree by clicking the buttons in the icons bar at the top. Furthermore, you can change the view of the menu tree by clicking the following buttons:

+

Expands the current menu item to display the menu items of the next lower level. The menu tree displays the button next to each collapsed menu item that contains menu items on the next lower level.

—

Collapses the menu item to hide the menu items of the lower levels. The menu tree displays the button next to each expanded menu item.

Dialog area

The dialog area displays the dialog that you select in the menu tree, including its controls. Here, you can monitor and change the settings of the device depending on your access role.

Below you find useful information on how to use the dialogs.

- Control elements
- Modification mark
- Standard buttons
- Saving the settings
- Updating the display
- Working with tables

Control elements

The dialogs contain different control elements. These control elements are read-only or editable, depending on the parameter and your access role as a user.

The control elements have the following visual properties:

- Input fields
 - An editable input field has a line at the bottom.
 - A read-only input field has no special visual properties.
- Checkboxes
 - An editable checkbox has a bright color.
 - A read-only checkbox has a grey color.
- Radio buttons
 - An editable radio button has a bright color.
 - A read-only radio button has a grey color.

Modification mark

When you modify a value, the corresponding field or table cell displays a red triangle in its top-left corner. The red triangle indicates that you have not yet applied this modification. The modified settings are not yet effective.

Standard buttons

Here you find the description of the standard buttons. The special dialog-specific buttons are described in the corresponding dialog help text.

Applies the settings you modified to the device.

Information on how the device retains the modified settings even after a reboot you find in section "Saving the settings" on page 18.

C

Undoes the unsaved changes in the current dialog. Resets the values in the fields to the settings applied to the device.

Saving the settings

When applying settings, the device temporarily stores the modified settings. To do this, perform the following step:

 \Box Click the \checkmark button.

Note: Unintentional changes to the settings can terminate the connection between your PC and the device. To keep the device accessible, enable the *Undo configuration modifications* function in the *Basic Settings > Load/Save* dialog, before changing any settings. Using the function, the device continuously checks if it can still be reached from the IP address of your PC. If the connection is lost, then the device loads the configuration profile saved in the non-volatile memory (*NVM*) after the specified time. Afterwards, the device can be accessed again.

- To keep the modified settings even after restarting the device, perform the following steps:
- □ Open the *Basic Settings > Load/Save* dialog.
- \Box In the table, mark the checkbox far left in the table row of the desired configuration profile.
- □ Click the **□** button to save your current changes.

Updating the display

If a dialog remains open for a longer time, then the values in the device have possibly changed in the meantime.

 \Box To update the display in the dialog, click the C button. Unsaved information in the dialog is lost.

Working with tables

The dialogs display numerous settings in table form. You have the option of customizing the appearance of the tables to fit your needs.

You can find useful information on how to use the tables in the following sections:

- Filter rows
- Sort rows
- Select multiple table rows

Filter rows

The filter lets you reduce the number of displayed table rows.

Eq

Displays a second table row in the table header containing a text field for every column. When you enter a string in a field, the table displays only the table rows that contain this string in the corresponding column.

Sort rows

You can change the order of the table rows. When you click the table header, an icon displays the sorting status.

↑Ļ

Displays that the table rows are sorted by a criterion other than the values in this column.

Click the icon to sort the table rows in descending order based on the entries of the corresponding column. You might be able to restore the initial sorting in the table only after logging out and logging in again.

$\mathbf{1}$

Displays that the table rows are sorted in descending order based on the entries of the corresponding column.

Click the icon to sort the table rows in ascending order based on the entries of the corresponding column. You might be able to restore the initial sorting in the table only after logging out and logging in again.

$\mathbf{\uparrow}$

Displays that the table rows are sorted in ascending order based on the entries of the corresponding column.

Click the icon to sort the table rows in descending order based on the entries of the corresponding column. You might be able to restore the initial sorting in the table only after logging out and logging in again.

Select multiple table rows

You have the option of selecting multiple table rows at once and then apply an action to the selected table rows. This is useful for example, when you want to remove multiple table rows at the same time.

To select individual table rows, mark the leftmost checkbox in the desired table row.

To select every table row, mark the leftmost checkbox in the table header.

1 Basic Settings

The menu contains the following dialogs:

- System
- Modules
- Network
- Software
- Load/Save
- External Memory
- Port
- Power over Ethernet
- Restart

1.1 System

[Basic Settings > System]

This dialog displays information about the operating status of the device.

Device status

Device status

Displays the device status and the alarms that currently exist. When at least one alarm is present, the background color changes to red. Otherwise, the background color remains green.

You specify the parameters that the device monitors in the *Diagnostics > Status Configuration > Device Status* dialog. If a monitored parameter differs from the desired status, then the device triggers an alarm.

A tooltip displays the cause of the currently existing alarms and the time at which the device triggered each alarm. To display the tooltip, hover the mouse pointer over or tap the field. In the *Diagnostics > Status Configuration > Device Status* dialog, the *Status* tab displays an overview of the alarms.

Note: If you connect only one power supply unit to a device that supports 2 redundant power supply units, then the device triggers an alarm. To avoid this alarm, deactivate the monitoring of the missing power supply units in the *Diagnostics > Status Configuration > Device Status* dialog.

Security status

Security status

Displays the security status and the alarms that currently exist. When at least one alarm is present, the background color changes to red. Otherwise, the background color remains green.

You specify the parameters that the device monitors in the *Diagnostics* > *Status Configuration* > Security Status dialog. If a monitored parameter differs from the desired status, then the device triggers an alarm.

A tooltip displays the cause of the currently existing alarms and the time at which the device triggered each alarm. To display the tooltip, hover the mouse pointer over or tap the field. In the *Diagnostics > Status Configuration > Security Status* dialog, the *Status* tab displays an overview of the alarms.

Signal contact status

The device can contain several signal contacts.

Signal contact status

Displays the signal contact status and the alarms that currently exist. When at least one alarm is present, the background color changes to red. Otherwise, the background color remains green.

You specify the parameters that the device monitors in the *Diagnostics* > *Status Configuration* > *Signal Contact* > *Signal Contact* 1/*Diagnostics* > *Status Configuration* > *Signal Contact* 2 dialog. If a monitored parameter differs from the desired status, then the device triggers an alarm.

A tooltip displays the cause of the currently existing alarms and the time at which the device triggered each alarm. To display the tooltip, hover the mouse pointer over or tap the field. In the *Diagnostics > Status Configuration > Signal Contact > Signal Contact 1/Diagnostics > Status Configuration > Signal Contact 2 dialog*, the *Status* tab displays an overview of the alarms.

System data

The fields in this frame display operating data and information on the location of the device.

System name

Specifies the name by which the device is known in the network.

Possible values:

Alphanumeric ASCII character string with 0..255 characters The device accepts the following characters:

```
- 0..9
- a..z
- A..Z
- !#$%&'()*+,-./:;<=>?@[\\]^_`{}~
<device type name>-<MAC address> (default setting)
```

When generating an digital certificate, the application generating the certificate uses the specified value as the domain name and common name.

The following functions use the specified value as a hostname or Fully Qualified Domain Name (FQDN). For compatibility reasons, it is recommended to use only lowercase letters, as some systems differentiate uppercase from lowercase in the FQDN. Verify that this name is unique in the entire network.

- DHCP client
- Syslog
- IEC61850-MMS
- PROFINET

Note: Specify a device name that is compatible with PROFINET: max. 240 characters, not starting with a number. The participants in the network read the device name using SNMP and PROFINET DCP.

Location

Specifies the current or planned location.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Contact person

Specifies the contact person for this device.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Device type

Displays the product name of the basic device.

Power supply 1 Power supply 2

Displays the status of the power supply unit at the respective voltage supply connector.

Possible values:

- present
- defective
- not installed
- unknown

Uptime

Displays the time that has elapsed since the device was last restarted.

Possible values:

▶ Time in the format day(s), ...h ...m ...s

Temperature [°C]

Displays the current temperature in the device in °C.

You activate the monitoring of the temperature threshold values in the *Diagnostics > Status* Configuration > Device Status dialog.

Upper temp. limit [°C]

Specifies the upper temperature threshold value in °C.

Possible values:

-99..99 (integer)

If the temperature in the device exceeds the specified value, then the device displays an alarm.

Lower temp. limit [°C]

Specifies the lower temperature threshold value in °C.

Possible values:

▶ -99..99 (integer)

If the temperature in the device falls below the specified value, then the device displays an alarm.

LED status

For further information about the device status LEDs, see the "Installation" user manual.

Status

There is currently no device status alarm. The device status is OK.

There is currently at least one device status alarm. For details, see the *Device status* frame.



Device that supports 2 redundant power supply units: Only one supply voltage is active.

Device that supports one power supply unit: The supply voltage is active.

Device that supports 2 redundant power supply units: Both supply voltages are active.

RM

Redundancy Manager

- MRP ring manager
- DLR supervisor

The device does not operate as a Redundancy Manager.

The device operates as a Redundancy Manager. No redundancy exists.

The device operates as a Redundancy Manager. Redundancy exists.

ACA

No external memory is connected.

The external memory is connected but not ready for operation.

The external memory is connected and ready for operation.

Port status

This frame displays a simplified view of the device ports at the time of the last display update. You identify the port status from the indicator.

In the initial view, the frame only displays ports with an active link. When you click the **f** button, the frame displays every port.

- The port speed is displayed next to the port number.
- When you hover the mouse pointer over or tap the appropriate port icon, a tooltip displays detailed port state information.

Green background color

Port with an active link.

Gray background color

Port with an inactive link.

Yellow background color

Port on which the device detected an unsupported SFP transceiver or an unsupported data rate.

Dashed border

Port in a *Blocking* state due to a redundancy function.

1.2 Modules

[Basic Settings > Modules]

The device lets you install or remove the modules during operation (hot-plug).

As long as the *Ethernet module status* column displays the value *configurable*, you can set up the module and save its preferences.

- When you replace the module with an identical module, the device applies the settings to the new module immediately.
- When you replace the module with a different type of module, the device applies the factory settings to the new module.
- When you plug a module into an empty slot, the device sets up the module with its default settings. If the slot is inactive, then it remains inactive until you mark the checkbox in the *Active* column. With the port default settings loaded on the module, access to the network is possible.

Install an Ethernet module

Perform the following steps:

- Plug the module in the slot. The device automatically sets up the module with the default settings, and detects the module parameters.
- To update the Graphical User Interface, click the C button.
 The *Ethernet module status* column displays the value *physical* for the installed Ethernet module.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

Activate/Deactivate a slot

On an inactive slot, the device recognizes the installed module and lets you set up the ports. The module establishes no network connections on an inactive slot.

Perform the following steps:

- □ Select the table row of the module.
- □ To deactivate the slot and deny network access, unmark the *Active* checkbox.
- □ To activate the slot and allow network access, mark the *Active* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

Remove an Ethernet module

Perform the following steps:

- \Box Remove the module from the slot.
- \Box To update the Graphical User Interface, click the old C button.
- The *Ethernet module status* column displays the value *configurable* for the removed module.
- $\hfill\square$ Select the table row of the removed module.
- □ Click the 🔩 button.

The *Ethernet module status* column displays the value *remove* for the removed module. The *Type* column and some other columns display the value n/a. The marked *Active* checkbox indicates that the slot is still active.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Remove Ethernet module

Removes the selected Ethernet module from the table.

Ethernet module

Displays the number of the slot to which the table row relates.

Active

Possible values:

 marked (default setting) The slot is active. The device recognizes the module installed in this slot.
 unmarked The slot is inactive.

Туре

Displays the type of the installed module.

A value of n/a indicates that the slot is empty.

Description

S	pecifies	a short	descrin	otion of	the i	nstalled	module
	peomes	a 311011	acount		uic i	nstancu	mouulo.

Version

Displays the version of the installed module.

Ports

Displays the number of ports that are available on the installed module.

Serial number

Displays the serial number of the installed module.

A value of n/a indicates that the slot is empty.

Ethernet module status

Displays the status of the slot.

Possible values:

- physical A module is present in the slot.
- configurable The slot is empty and available for setup.
- remove The slot is empty and inactive.
- ▶ fix
 - The module cannot be removed.

1.3 Network

[Basic Settings > Network]

The menu contains the following dialogs:

- Global
- ► IPv4
- ► IPv6

1.3.1 Global

[Basic Settings > Network > Global]

This dialog lets you specify the VLAN and HiDiscovery settings required for the access to the device management through the network.

Management interface

This frame lets you specify the VLAN in which the device management can be accessed.

VLAN ID

Specifies the VLAN in which the device management is accessible through the network. The device management is accessible through ports that are members of this VLAN.

Possible values:

1..4042 (default setting: 1) The prerequisite is that in the Switching > VLAN > Configuration dialog the VLAN is already set up.

When you click the \checkmark button after changing the value, the *Information* window opens. Select the port, over which you connect to the device in the future. After clicking the *Ok* button, the new device management VLAN settings are assigned to the port.

- After that the port is a member of the VLAN and transmits the data packets without a VLAN tag (untagged). See the Switching > VLAN > Configuration dialog.
- The device assigns the port VLAN ID of the device management VLAN to the port. See the Switching > VLAN > Port dialog.

After a short time the device is reachable over the new port in the new device management VLAN.

MAC address

Displays the MAC address of the device. The device management is accessible through the network using the MAC address.

MAC address conflict detection

Enables/disables the MAC address conflict detection function.

Possible values:

marked

The *MAC address conflict detection* function is enabled. The device verifies that its MAC address is unique in the network.

unmarked (default setting) The MAC address conflict detection function is disabled.

HiDiscovery protocol v1/v2

This frame lets you specify settings for the access to the device using the HiDiscovery protocol.

On a PC, the HiDiscovery software displays the Hirschmann devices that can be accessed in the network on which the HiDiscovery function is enabled. You can access these devices even if they have invalid or no IP parameters assigned. The HiDiscovery software lets you assign or change the IP parameters in the device.

Note: With the HiDiscovery software you access the device only through ports that are members of the same VLAN as the device management. You specify which VLAN a certain port is assigned to in the *Switching* > *VLAN* > *Configuration* dialog.

Operation

Enables/disables the HiDiscovery function in the device.

Possible values:

- On (default setting) The HiDiscovery function is enabled. You can use the HiDiscovery software to access the device from your PC.
- ► Off
 - The HiDiscovery function is disabled.

Access

Enables/disables the write access to the device using for the HiDiscovery function.

Possible values:

readWrite (default setting)

The HiDiscovery function has write access to the device. The device lets you change the IP parameters in the device using the HiDiscovery function.

readOnLy

The HiDiscovery function has read-only access to the device. The device lets you view the IP parameters in the device using the HiDiscovery function.

Recommendation: Change the setting to the value *readOnLy* only after putting the device into operation.

Signal

Activates/deactivates the flashing of the port LEDs as does the function of the same name in the HiDiscovery software. The function lets you identify the device in the field.

Possible values:

marked

The flashing of the port LEDs is active. The port LEDs flash until you disable the function again.

unmarked (default setting) The flashing of the port LEDs is inactive.

1.3.2 IPv4

[Basic Settings > Network > IPv4]

This dialog allows you to specify the IPv4 settings required for the access to the device management through the network.

Management interface

IP address assignment

Specifies the source from which the device management receives its IP parameters.

Possible values:

🕨 Local

The device uses the IP parameters from the internal memory. You specify the settings for this in the *IP parameter* frame.

► BOOTP

The device receives its IP parameters from a BOOTP or DHCP server. The server evaluates the MAC address of the device, then assigns the IP parameters.

DHCP (default setting)

The device receives its IP parameters from a DHCP server.

The server evaluates the MAC address, the DHCP name, or other parameters of the device, then assigns the IP parameters.

When the server also provides the addresses of DNS servers, the device displays these addresses in the *Advanced* > *DNS* > *Client* > *Current* dialog.

Note: If there is no response from the BOOTP or DHCP server, then the device sets the IP address to 0.0.0.0 and makes another attempt to obtain a valid IP address.

IP parameter

This frame lets you assign the IP parameters manually. If you have selected the *LocaL* radio button in the *Management interface* frame, *IP address assignment* option list, then these fields can be edited.

IP address

Specifies the IP address under which the device management can be accessed through the network.

Possible values:

Valid IPv4 address

Netmask

Specifies the netmask.

Possible values:

Valid IPv4 netmask

Gateway address

Specifies the IP address of a router through which the device accesses other devices outside of its own network.

Possible values:

Valid IPv4 address

BOOTP/DHCP

Client ID

Displays the DHCP client ID that the device sends to the BOOTP or DHCP server. If the server is set up accordingly, then the server reserves an IP address for this DHCP client ID. Therefore, the device receives the same IP from the server every time it requests it.

The DHCP client ID that the device sends is the device name specified in the *System name* field in the *Basic Settings > System* dialog.

DHCP option 66/67/4/42

Enables/disables the DHCP option 66/67/4/42 function in the device.

Possible values:

- On (default setting)
 - The DHCP option 66/67/4/42 function is enabled.

The device loads the configuration profile and receives the time server information using the following DHCP options:

Option 66: TFTP server name
 Option 67: Boot file name

The device automatically loads the configuration profile from the DHCP server into the volatile memory (*RAM*) using the Trivial File Transfer Protocol (TFTP). The device uses the settings of the imported configuration profile in the running-config.

Option 4: Time Server
 Option 42: Network Time Protocol Servers
 The device receives the time server information from the DHCP server.

► Off

The DHCP option 66/67/4/42 function is disabled.

- The device does not load a configuration profile using DHCP Options 66/67.
- The device does not receive time server information using DHCP Options 4/42.

Remaining lease time

Lease time [s]

Displays the remaining time in seconds before the IP address, assigned to the device management by the DHCP server, expires.

To update the display, click the ${f C}$ button.

1.3.3 IPv6

[Basic Settings > Network > IPv6]

This dialog allows you to specify the IPv6 settings required for the access to the device management through the network.

Operation

Operation

Enables/disables the IPv6 protocol in the device.

You can operate IPv4 and IPv6 simultaneously in the device. This is possible with the use of the Dual IP Layer technique, also referred to as Dual Stack.

Possible values:

On (default setting) IPv6 is enabled.

▶ Off

IPv6 is disabled.

If you want the device to operate only using IPv4, then disable IPv6 in the device.

Configuration

Dynamic IP address assignment

Specifies the source from which the device management receives its IPv6 parameters.

Possible values:

None

The device receives its IPv6 parameters manually.

You can manually specify a maximum number of 4 IPv6 addresses. You cannot specify loopback, link-local, and Multicast addresses as static IPv6 addresses.

Auto (default setting)

The device receives its IPv6 parameters dynamically. The device receives a maximum of 2 IPv6 addresses.

An example here is the Router Advertisement Daemon (radvd). The radvd uses *Router Solicitation* and *Router Advertisement* messages to automatically set up an IPv6 address. The *Router Solicitation* and *Router Advertisement* messages are described in RFC 4861.

```
DHCPv6
```

The device receives its IPv6 parameters from a DHCPv6 server.

► ALL

If the *All* radio button is selected, then the device receives its IPv6 parameters using every alternative for both dynamic and manual assignments.

DHCP

Client ID

Displays the DHCPv6 client ID that the device sends to the DHCPv6 server. If the server is set up accordingly, then the client device receives an IPv6 address for this DHCPv6 client ID.

The IPv6 address received from the DHCPv6 server has the *PrefixLength* value 128. According to RFC 8415, a DHCPv6 server cannot currently be used to supply *Gateway address* or *PrefixLength* information.

The device can receive only one IPv6 address from the DHCPv6 server.

IP parameter

Gateway address

Specifies the IPv6 address of a router through which the device accesses other devices outside its own network.

Possible values:

Valid IPv6 address (except loopback and Multicast addresses)

Note: If the *Auto* radio button is selected and you use a Router Advertisement Daemon (radvd), then the device automatically receives a link-local type *Gateway address* with a higher metric than the manually set *Gateway address*.

Duplicate Address Detection

In this field you can specify the number of consecutive *Neighbor Solicitation* messages that the device sends for the *Duplicate Address Detection* function. This function is used to determine the uniqueness of an IPv6 unicast address on the interface.

Number of neighbor solicitants

Specifies the number of *Neighbor Solicitation* messages that the device sends for the *Duplicate Address Detection* function.

Possible values:

• 0

The function is disabled.

▶ 1..5 (default setting: 1)

If the *Duplicate Address Detection* function discovers that an IPv6 address is not unique on a link, then the device does not log this event in the log file (System Log).

Table

This table displays a list of the IPv6 addresses set up for the device management.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Prefix

Displays the prefix of the IPv6 address in a compressed format. The prefix shows the leftmost bits of an IPv6 address, also known as the network part of the address.

PrefixLength

Displays the prefix length of the IPv6 address.

Unlike an IPv4 address, an IPv6 address does not use a subnet mask to identify the subnet part of the address. This role is performed in IPv6 by the prefix length.

Possible values:

▶ 0..128

IP address

Displays the full IPv6 address in a compressed format.

The compressed format is automatically applied to every IPv6 address, regardless of the source from which the device management receives its IPv6 parameters.

Possible values:

Valid IPv6 address

To use an IPv6 address in a URL, use the following URL syntax: https://[<ipv6_address>].

For further information on IPv6 compression rules and address types, see the "Configuration" user manual.

EUI option

Specifies if the EUI option function is applied to the IPv6 address.

When you mark this checkbox, the Interface ID of the IPv6 address is automatically specified. The device uses the MAC address of its interface with the values ff and fe added between byte 3 and byte 4 to generate a 64 bit Interface ID.

You can only select this option for IPv6 addresses that have a prefix length equal to 64.

Possible values:

marked

The EUI option function is active.

unmarked (default setting) The EUI option function is inactive.

Origin

Specifies the way in which the device received its IPv6 parameters.

Possible values:

Autoconf

The device received the IPv6 address dynamically, when the Auto radio button is selected.

Manual

The device received the IPv6 address manually.

DHCP

The device received the IPv6 address from a DHCPv6 server.

Linklayer

The device automatically sets up a link-local type IPv6 address. The link-local address cannot be changed.

Status

Displays the current status of the IPv6 address.

Possible values:

active

The IPv6 address is active.

- notInService The IPv6 address is inactive.
- notReady

The IPv6 address is specified, but not currently active as some configuration parameters are still missing.

Note: When the IPv6 address is manually specified, you can manually change between *active* and *notInService* states. To do this, for the corresponding table row, select in the *Status* column the desired status from the drop-down list.

1.4 Software

[Basic Settings > Software]

This dialog lets you update the device software and display information about the device software.

You also have the option to restore a backup of the device software that is saved in the device.

Note: Before you update the device software, follow the version-specific notes in the Readme text file.

Version

Stored version

Displays the version number and creation date of the device software stored in the flash memory. The device loads the device software during the next system startup.

Running version

Displays the version number and creation date of the currently running device software that the device loaded during the last system startup.

Backup version

Displays the version number and creation date of the device software saved as a backup in the flash memory. The device copied this device software into the backup memory during the last software update or after you clicked the *Restore* button.

Restore

The device swaps the device software images and accordingly the values displayed in the fields *Stored version* and *Backup version*.

During the next system startup, the device loads the device software displayed in the *Stored version* field.

Bootcode

Displays the version number and creation date of the boot code.

Software update

The device lets you update the device software at this place, if a suitable device software image is available outside the device. If a suitable device software image is saved on the selected external memory, use the table in the *File system* tab below.

URL

Specifies the path and the file name of the device software image that you use to update the device software.

The device gives you the following options for updating the device software:

Software update from the PC

Drag and drop the file into the 1 area from your PC or network drive. As an alternative, click in the area to select the file.

- Software update from an FTP server This option is not recommended if you transmit data over untrusted networks. If the file is on an FTP server, then specify the URL in the following form: ftp://<user>:<password>@<IP address>[:port]/<file name>
- Software update from a TFTP server This option is not recommended if you transmit data over untrusted networks. If the file is on a TFTP server, then specify the URL in the following form: tftp://<IP address>/<path>/<file name>
- Software update from an SCP or SFTP server
 If the file is on an SCP or SFTP server, then specify the URL in one of the following forms:
 scp:// or sftp://<IP address>/<path>/<file name>
 - Click the *Start* button to open the *Credentials* window. In this window, you enter the *User name* and *Password* to log into the server.
 - scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name>

Remember to set up the SCP or SFTP server as an SSH known host before the device accesses the server for the first time. See the *Device Security* > *SSH Known Hosts* dialog.

Start

Updates the device software.

- To remain logged in to the device management during the software update, move the mouse pointer occasionally. As an alternative, before you start the software update, specify a sufficiently high value in the *Device Security* > *Management Access* > *Web* dialog, *Web interface session timeout* [*min*] field.
- The device transfers the previously used device software to the backup memory.
- The device transfers the selected file to the flash memory, replacing the previously used device software. During the next startup, the device boots with the device software that you have transferred.

Allow upload of unsigned device software

Activates/deactivates the option that the device allows to upload an unsigned device software. The purpose of this setting is to enable the upload of a device software that does not have a cryptographic signature.

Possible values:

marked

The device allows to upload an unsigned device software. Uploading an unsigned device software can be a security risk. If you trust the originator, then you can upload the unsigned device software.

unmarked (default setting) The device only allows to upload a signed device software.

[File system]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Updates the device software if a suitable device software image is saved on the selected external memory. The prerequisite is that a table row is selected for which the *File location* column displays the value *sd-card* or *usb*.

- Verify that the relevant external memory is selected from the Selected external memory drop-down list. See the Basic Settings > Load/Save dialog, External memory frame.
- To remain logged in to the device management during the software update, move the mouse pointer occasionally. As an alternative, before you start the software update, specify a sufficiently high value in the *Device Security* > *Management Access* > *Web* dialog, *Web interface session timeout* [*min*] field.
- The device transfers the previously used device software to the backup memory.
- The device transfers the selected file to the flash memory, replacing the previously used device software. During the next startup, the device boots with the device software that you have transferred.

File location

Displays the storage location of the device software.

Possible values:

- ram Volatile memory of the device
- fLash Non-volatile memory (NVM) of the device
- sd-card
 External SD memory (ACA31)
- usb External USB memory (ACA21/ACA22)

Index

Displays the index of the device software.

The index number of the device software in the flash memory has the following meaning:

▶ 1

During the next system startup, the device loads this device software.

2

The device copied this device software into the backup area during the last software update.

File name

Displays the device-internal file name of the device software.

Firmware

Displays the version number and creation date of the device software.

1.5 Load/Save

[Basic Settings > Load/Save]

This dialog lets you save the device settings permanently in a configuration profile.

The device can hold several configuration profiles. When you activate an alternative configuration profile, you change to other device settings. You have the option of exporting the configuration profiles to your PC or to a server. You also have the option of importing the configuration profiles from your PC or from a server to the device.

In the default setting, the device saves the configuration profiles unencrypted. If you enter a password in the *Configuration encryption* frame, then the device saves both the current and the future configuration profiles in an encrypted format.

Unintentional changes to the settings can terminate the connection between your PC and the device. To keep the device accessible, enable the *Undo configuration modifications* function before changing any settings. If the connection is lost, then the device loads the configuration profile saved in the non-volatile memory (*NVM*) after the specified time.

Note: Upgrading from Classic to HiOS? Convert your device configuration files using our online tool: https://convert.hirschmann.com

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Removes the configuration profile selected in the table from the non-volatile memory (NVM) or from the external memory.

If the configuration profile is designated as "Selected", then the device helps prevent you from removing the configuration profile.



Saves the temporarily applied settings in the configuration profile designated as "Selected" in the non-volatile memory (*NVM*).

When in the *Basic Settings > External Memory* dialog the checkbox in the *Backup config when saving* column is marked, then the device saves a copy of the configuration profile in the external memory.

Displays a context menu with further functions for the corresponding dialog.

Save as..

Opens the Save as.. window to copy the configuration profile selected in the table and saves it with a user-specified name in the non-volatile memory (*NVM*).

- □ In the *Profile name* field, enter the name under which you want to save the configuration profile.
 - \Box To save the configuration profile under a new name, click the + button.
 - □ To overwrite an existing configuration profile, select the corresponding item from the dropdown list.

If in the *Basic Settings > External Memory* dialog the checkbox in the *Backup config when saving* column is marked, then the device designates the configuration profile of the same name in the external memory as "Selected".

Note: Before adding additional configuration profiles, decide for or against permanently activated configuration encryption in the device. Save additional configuration profiles either unencrypted or encrypted with the same password.

Activate

Loads the settings of the configuration profile selected in the table to the volatile memory (RAM).

- The device terminates the connection to the Graphical User Interface. To access the device management again, perform the following steps:
 - □ Reload the Graphical User Interface.
 - Log in again.
- The device immediately uses the settings of the configuration profile on the fly.

Enable the *Undo configuration modifications* function before you activate another configuration profile. If the connection is lost afterwards, then the device loads the last configuration profile designated as "Selected" from the non-volatile memory (*NVM*). The device can then be accessed again.

If the configuration encryption is inactive, then the device loads an unencrypted configuration profile. If the configuration encryption is active and the password matches the password stored in the device, then the device loads an encrypted configuration profile.

When you activate an older configuration profile, the device takes over the settings of the functions contained in this software version. The device sets the values of new functions to their default value.

Select

Designates the configuration profile selected in the table as "Selected". In the *Selected* column, the checkbox is then marked.

When applying the *Undo configuration modifications* function or during the system startup, the device loads the settings of this configuration profile to the volatile memory (*RAM*).

- If the configuration encryption in the device is disabled, then designate an unencrypted configuration profile only as "Selected".
- If the configuration encryption in the device is enabled and the password of the configuration
 profile matches the password saved in the device, then designate an encrypted configuration
 profile only as "Selected".

Otherwise, the device is unable to load and encrypt the settings in the configuration profile the next time it restarts. For this case you specify in the *Diagnostics* > *System* > *Selftest* dialog if the device starts with the default settings or terminates the restart and stops.

Note: You only mark the configuration profiles saved in the non-volatile memory (NVM).

If in the *Basic Settings > External Memory* dialog the checkbox in the *Backup config when saving* column is marked, then the device designates the configuration profile of the same name in the external memory as "Selected".

Import...

Opens the Import... window to import a configuration profile.

The prerequisite is that you have exported the configuration profile using the *Export...* button or using the link in the *Profile name* column.

- □ From the *Select source* drop-down list, select from where the device imports the configuration profile.
 - ▶ PC/URL
 - The device imports the configuration profile from the local PC or from a remote server. *External memory*
 - The device imports the configuration profile from the selected external memory. See the *External memory* frame.
- □ When *PC/URL* is selected above, in the *Import profile from PC/URL* frame you specify the configuration profile file to be imported.
 - Import from the PC

If the file is on your PC or on a network drive, then drag and drop the file into the 1 area. As an alternative, click in the area to select the file.

- Import from an FTP server
 This option is not recommended if you transmit data over untrusted networks.
 If the file is on an FTP server, then specify the URL in the following form:
 ftp://<user>:<password>@<IP address>[:port]/<file name>
- Import from a TFTP server
 This option is not recommended if you transmit data over untrusted networks.
 If the file is on a TFTP server, then specify the URL in the following form: tftp://<IP address//cpath/<file name>
- Import from an SCP or SFTP server
 If the file is on an SCP or SFTP server, then specify the URL in one of the following forms: scp:// or sftp://<IP address>/<path>/<file name>
 Click the *Start* button to open the *Credentials* window. In this window, you enter the *User name* and *Password* to log into the server.
 scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name>
 Bromember to set up the SCP or SETP server as an SSH known host before the device.

Remember to set up the SCP or SFTP server as an SSH known host before the device accesses the server for the first time. See the *Device Security* > *SSH Known Hosts* dialog.

□ When *External memory* is selected above, in the *Import profile from external memory* frame you specify the configuration profile file to be imported.

From the *Profile name* drop-down list, select the name of the configuration profile to be imported.

□ In the *Destination* frame you specify where the device saves the imported configuration profile. In the *Profile name* field you specify the name under which the device saves the configuration profile.

In the *Storage* field you specify the storage location for the configuration profile. The prerequisite is that from the *Select source* drop-down list the *PC/URL* item is selected.

RAM

The device saves the configuration profile in the volatile memory (*RAM*) of the device. This replaces the running-config, the device uses the settings of the imported configuration profile immediately. The device terminates the connection to the Graphical User Interface. Reload the Graphical User Interface. Log in again.

► NVM

The device saves the configuration profile in the non-volatile memory (NVM) of the device.

When you import a configuration profile, the device takes over the settings as follows:

- If the configuration profile was exported on the same device or on an identically equipped device of the same type, then:
- The device takes over the settings completely.
- If the device uses modules, then also read the help text of the *Basic Settings > Modules* dialog.
- If the configuration profile was exported on an other device, then:
- The device takes over the settings which it can interpret based on its hardware equipment and software level.

The remaining settings the device takes over from its running-config configuration profile.

Regarding configuration profile encryption, also read the help text of the *Configuration encryption* frame. The device imports a configuration profile under the following conditions:

- The configuration encryption of the device is inactive. The configuration profile is unencrypted.
- The configuration encryption of the device is active. The configuration profile is encrypted with the same password that the device currently uses.

Export...

Exports the configuration profile selected in the table and saves it as an XML file on a remote server.

To save the file on your PC, click the link in the *Profile name* column to select the storage location and specify the file name.

The device gives you the following options for exporting a configuration profile:

- Export to an FTP server This option is not recommended if you transmit data over untrusted networks. To save the file on an FTP server, specify the URL for the file in the following form: ftp://<user>:<password>@<IP address>[:port]/<file name>
 Export to a TFTP server
- This option is not recommended if you transmit data over untrusted networks. To save the file on a TFTP server, specify the URL for the file in the following form: tftp://<IP address/<path>/<file name>
- Export to an SCP or SFTP server To save the file on an SCP or SFTP server, specify the URL for the file in one of the following forms:
 - scp:// or sftp://<IP address>/<path>/<file name> Click the Ok button to open the Credentials window. In this window, you enter the User name and Password to log into the server.
 - scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name>

Remember to set up the SCP or SFTP server as an SSH known host before the device accesses the server for the first time. See the *Device Security* > *SSH Known Hosts* dialog.

Save running-config as script

Saves the running config configuration profile as a script file on the local PC. This lets you backup your current device settings or to use them on various devices.

Load running-config from script

Imports a script file which modifies the current running config configuration profile.

The device gives you the following options to import a script file:

Import from the PC

If the file is on your PC or on a network drive, then drag and drop the file into the 1 area. As an alternative, click in the area to select the file.

- Import from an FTP server
 This option is not recommended if you transmit data over untrusted networks.
 If the file is on an FTP server, then specify the URL in the following form: ftp://<user>:<password>@<IP address>[:port]/<file name>
- Import from a TFTP server
 This option is not recommended if you transmit data over untrusted networks.
 If the file is on a TFTP server, then specify the URL in the following form: tftp://<IP address>/<path>/<file name>
- Import from an SCP or SFTP server
 If the file is on an SCP or SFTP server, then specify the URL in one of the following forms: scp://or sftp://<IP address>/<path>/<file name>
 Remember to set up the SCP or SFTP server as an SSH known host before the device accesses the server for the first time. See the *Device Security* > *SSH Known Hosts* dialog.

Back to factory ...

Resets the settings in the device to the default values.

- The device deletes the saved configuration profiles from the volatile memory (*RAM*) and from the non-volatile memory (*NVM*).
- The device deletes the digital certificate used by the web server in the device.
- The device deletes the RSA key (Host Key) used by the SSH server in the device.
- When an external memory is connected, the device deletes the configuration profiles saved in the external memory.
- After a short time, the device reboots and then uses the default settings.

Back to default

Deletes the current operating (running config) settings from the volatile memory (RAM).

Storage

Displays the storage location of the configuration profile.

Possible values:

RAM (volatile memory of the device) In the volatile memory, the device stores the settings for the current operation. *NVM* (non-volatile memory of the device)

When applying the *Undo configuration modifications* function or during the system startup, the device loads the "Selected" configuration profile from the non-volatile memory. The non-volatile memory provides space for multiple configuration profiles, depending on the

number of settings saved in the configuration profile. The device manages a maximum of 20 configuration profiles in the non-volatile memory.

You can load a configuration profile into the volatile memory (*RAM*). To do this, perform the following steps:

- $\hfill\square$ Select the table row of the configuration profile.
- \Box Click the \blacksquare button and then the *Activate* item.
- *ENVM* (external memory)

In the external memory, the device saves a backup copy of the "Selected" configuration profile. The prerequisite is that in the *Basic Settings > External Memory* dialog the *Backup config when saving* checkbox is marked.

Profile name

Displays the name of the configuration profile.

Possible values:

running-config

Name of the configuration profile in the volatile memory (RAM).

config

Name of the factory setting configuration profile in the non-volatile memory (NVM).

User-defined name

The device lets you save a configuration profile with a user-specified name. To do this, select

the table row of an existing configuration profile in the table, click the \equiv button and then the *Save as..* item.

To export the configuration profile as an XML file on your PC, click the link. Then you select the storage location and specify the file name.

To save the file on a remote server, click the \equiv button and then the *Export...* item.

Last modified (UTC)

Displays the Universal Time Coordinated (UTC) time a user last saved the configuration profile.

Selected

Displays if the configuration profile is designated as "Selected".

The device lets you designate another configuration profile as "Selected". To do this, select the desired configuration profile in the table, click the \equiv button and then the *Activate* item.

Possible values:

marked

The configuration profile is designated as "Selected".

- When applying the Undo configuration modifications function or during the system startup, the device loads the configuration profile into the volatile memory (RAM).
- When you click the button, the device saves the temporarily applied settings in this configuration profile.

unmarked

Another configuration profile is designated as "Selected".

Encryption

Displays if the configuration profile is encrypted.

Possible values:

marked

The configuration profile is encrypted.

unmarked The configuration profile is unencrypted.

You activate/deactivate the encryption of the configuration profile in the *Configuration encryption* frame.

Verified

Displays if the password of the encrypted configuration profile matches the password stored in the device.

Possible values:

marked

The passwords match. The device is able to unencrypt the configuration profile.

unmarked

The passwords are different. The device is unable to unencrypt the configuration profile.

Note: The device applies script files additionally to the current settings. Verify that the script file does not contain any parts that conflict with the current settings.

Software version

Displays the version number of the device software that the device ran while saving the configuration profile.

Fingerprint

Displays the checksum saved in the configuration profile.

When saving the settings, the device calculates the checksum and inserts it into the configuration profile.

Verified

Displays if the checksum saved in the configuration profile is valid.

The device calculates the checksum of the configuration profile marked as "Selected" and compares it with the checksum saved in this configuration profile.

Possible values:

marked

The calculated and the saved checksum match. The saved settings are consistent.

unmarked

For the configuration profile marked as "Selected" applies: The calculated and the saved checksum are different. The configuration profile contains modified settings. Possible causes:

- The file is damaged.
- The file system in the external memory is inconsistent.
- A user has exported the configuration profile and changed the XML file outside the device.
 For the other configuration profiles the device has not calculated the checksum.

The device verifies the checksum correctly only if the configuration profile has been saved before as follows:

- on an identical device
- with the same software version, which the device is running
- with a lower or the same level of the device software such as HiOS-2A or HiOS-3S on a device which runs HiOS-3S

Note: This function identifies changes to the settings in the configuration profile. The function does not provide protection against operating the device with modified settings.

External memory

Selected external memory

Specifies the external memory that the device uses for file operations.

This setting has the following effects:

- For example, the device stores a copy of the device configuration files on the selected external memory.
- The device lets you conveniently update the device software if a suitable device software image is saved on the selected external memory. See the *Basic Settings > Software* dialog.

Possible values:

- 🕨 sd
 - External SD memory (ACA31)
- usb
 External USB memory (ACA21/ACA22)

Status

Displays the operating state of the selected external memory.

Possible values:

notPresent

No external memory is connected.

removed

Someone has removed the external memory from the device during operation.

- 🕨 ok
 - The external memory is connected and ready for operation.
- outOfMemory The memory space is occupied in the external memory.
- genericErr The device has detected an error.

Configuration encryption

Active

Displays if the configuration encryption is active/inactive in the device.

Possible values:

- marked
 - The configuration encryption is active.

If the configuration profile is encrypted and the password matches the password stored in the device, then the device loads a configuration profile from the non-volatile memory (*NVM*).

unmarked

The configuration encryption is inactive.

If the configuration profile is unencrypted, then the device loads a configuration profile from the non-volatile memory (NVM) only.

If in the *Basic Settings > External Memory* dialog, the *Config priority* column has the value *first* or *second* and the configuration profile is unencrypted, then the *Security status* frame in the *Basic Settings > System* dialog displays an alarm.

In the *Diagnostics > Status Configuration > Security Status* dialog, *Global* tab, *Monitor* column you specify if the device monitors the *Load unencrypted config from external memory* parameter.

Set password

Opens the *Set password* window that helps you to enter the password needed for the configuration profile encryption. Encrypting the configuration profiles makes unauthorized access more difficult. To do this, perform the following steps:

- □ When you are changing an existing password, enter the existing password in the *Old password* field. To display the password in plain text instead of ***** (asterisks), mark the *Display content* checkbox.
- In the New password field, enter the password.
 To display the password in plain text instead of ***** (asterisks), mark the Display content checkbox.
- □ Mark the Save configuration afterwards checkbox to use encryption also for the "Selected" configuration profile in the non-volatile memory (*NVM*) and in the external memory.

Note: If a maximum of one configuration profile is stored in the non-volatile memory (*NVM*) of the device, then use this function only. Before adding additional configuration profiles, decide for or against permanently activated configuration encryption in the device. Save additional configuration profiles either unencrypted or encrypted with the same password.

If you are replacing a device with an encrypted configuration profile, for example due to an inoperable device, then perform the following steps:

- □ Restart the new device and assign the IP parameters.
- □ Open the *Basic Settings > Load/Save* dialog on the new device.
- □ Encrypt the configuration profile in the new device. See above. Enter the same password you used in the inoperable device.
- □ Install the external memory from the inoperable device in the new device.
- Restart the new device.

During the next system startup, the device loads the configuration profile with the settings of the inoperable device from the external memory. The device copies the settings into the volatile memory (*RAM*) and into the non-volatile memory (*NVM*).

Note: The prerequisite for loading a configuration profile from the external memory is that in the *Basic Settings > External Memory* dialog the *Config priority* column displays the value *first* or *second*. This value is set as the default setting.

Delete

Opens the *Delete* window which helps you to cancel the configuration encryption in the device. To cancel the configuration encryption, perform the following steps:

- In the Old password field, enter the existing password.
 To display the password in plain text instead of ***** (asterisks), mark the Display content checkbox.
- □ Mark the *Save configuration afterwards* checkbox to remove the encryption also for the "Selected" configuration profile in the non-volatile memory (*NVM*) and in the external memory.

Note: If you keep additional encrypted configuration profiles in the memory, then the device helps prevent you from activating or designating these configuration profiles as "Selected".

Undo configuration modifications

Operation

Enables/disables the *Undo configuration modifications* function. Using the function, the device continuously checks if it can still be reached from the IP address of your PC. If the connection is lost, after a specified time period the device loads the "Selected" configuration profile from the non-volatile memory (*NVM*). Afterwards, the device can be accessed again.

Possible values:

- ▶ On
 - The function is enabled.
 - You specify the time period between the interruption of the connection and the loading of the configuration profile in the *Timeout* [s] to recover after connection loss field.
 - When the non-volatile memory (NVM) contains multiple configuration profiles, the device loads the configuration profile designated as "Selected".
- Off (default setting)
 - The function is disabled.

Disable the function again before you close the Graphical User Interface. You thus help prevent the device from restoring the configuration profile designated as "Selected".

Note: Before you enable the function, save the settings in the configuration profile. The device thus maintains the current settings, that are only temporarily saved.

Timeout [s] to recover after connection loss

Specifies the time in seconds after which the device loads the "Selected" configuration profile from the non-volatile memory (*NVM*) if the connection is lost.

Possible values:

▶ 30..600 (default setting: 600)

Specify a sufficiently large value. Take into account the time when you are viewing the dialogs of the Graphical User Interface without changing or updating them.

Watchdog IP address

Displays the IP address of the PC on which you have enabled the function.

Possible values:

IPv4 address (default setting: 0.0.0.0)

Information

NVM in sync with running config

Displays if the settings in the volatile memory (*RAM*) differ from the settings of the "Selected" configuration profile in the non-volatile memory (*NVM*).

Possible values:

marked

The settings match.

unmarked

The settings differ. Additionally, the Banner displays the icon **T**.

External memory in sync with NVM

Displays if the settings of the "Selected" configuration profile in the external memory (ACA) differ from the settings of the "Selected" configuration profile in the non-volatile memory (*NVM*).

Possible values:

marked

The settings match.

unmarked

The settings differ.

Possible causes:

- No external memory is connected to the device.
- In the Basic Settings > External Memory dialog, the Backup config when saving function is disabled.

Backup config on a remote server when saving

Operation

Enables/disables the Backup config on a remote server when saving function.

Possible values:

Enabled

The *Backup config on a remote server when saving* function is enabled. When you save the configuration profile in the non-volatile memory (*NVM*), the device automatically backs up the configuration profile on the remote server specified in the *URL* field.

Disabled (default setting) The Backup config on a remote server when saving function is disabled.

URL

Specifies path and file name of the backed up configuration profile on the remote server.

Possible values:

Alphanumeric ASCII character string with 0..128 characters Example: tftp://192.9.200.1/cfg/config.xml

The device supports the following wildcards:

- %d
 System date in the format YYYY-mm-dd
- %t
- System time in the format HH_MM_SS
- %i
- IP address of the device
- %m
 - MAC address of the device in the format AA-BB-CC-DD-EE-FF
- %р
 - Product name of the device

Set credentials

Opens the *Credentials* window which helps you to enter the login credentials needed to authenticate on the remote server. To do this, perform the following steps:

□ In the *User name* field, enter the user name.

To display the user name in plain text instead of ***** (asterisks), mark the *Display content* checkbox.

Possible values:

- Alphanumeric ASCII character string with 1..32 characters
- □ In the *Password* field, enter the password.

To display the password in plain text instead of ***** (asterisks), mark the *Display content* checkbox.

Possible values:

- Alphanumeric ASCII character string with 6..64 characters The device accepts the following characters:
 - a..z A..Z 0..9 !#\$%&'()*+,-./:;<=>?@[\\]^_`{}~

1.6 External Memory

[Basic Settings > External Memory]

This dialog lets you activate functions that the device automatically executes in combination with the external memory. The dialog also displays the operating state and identifying characteristics of the external memory.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Туре

Displays the type of the external memory.

Possible values:

- sd External SD memory (ACA31)
- usb
 - External USB memory (ACA21/ACA22)

Status

Displays the operating state of the external memory.

Possible values:

- notPresent No external memory is connected.
- removed

Someone has removed the external memory from the device during operation.

🕨 ok

The external memory is connected and ready for operation.

outOfMemory

The memory space is occupied in the external memory.

genericErr The device has detected an error.

Writable

Displays if the device has write access to the external memory.

Possible values:

marked

The device has write access to the external memory.

unmarked

The device has read-only access to the external memory. Possibly the write protection is activated in the external memory.

Software auto update

Activates/deactivates the automatic device software update during the system startup.

Possible values:

marked (default setting)

The device updates the device software when the following files are located in the external memory:

- the device software image file
- a text file startup.txt with the content autoUpdate=<software_image_file_name>.bin
- unmarked

No automatic device software update during the system startup.

SSH key auto upload

Activates/deactivates the loading of the RSA key from an external memory during the system startup.

Possible values:

marked (default setting)

The loading of the RSA key is activated.

During the system startup, the device loads the RSA key from the external memory when the following files are located in the external memory:

- SSH RSA key file
- a text file startup.txt with the content autoUpdateRSA=<filename_of_the_SSH_RSA_key>
- The device displays messages on the system console of the serial interface.
- unmarked

The loading of the RSA key is deactivated.

Note: When loading the RSA key from the external memory (*ENVM*), the device overwrites the existing keys in the non-volatile memory (*NVM*).

Config priority

Specifies the memory from which the device loads the configuration profile upon reboot.

Possible values:

disable

The device loads the configuration profile from the non-volatile memory (NVM).

first, second

The device loads the configuration profile from the external memory designated as *first*. When the device does not find a configuration profile there, it loads the configuration profile from the external memory designated as *second*, and so on.

When the device does not find a configuration profile in the external memory, it loads the configuration profile from the non-volatile memory (*NVM*).

Note: When loading the configuration profile from the external memory (*ENVM*), the device overwrites the settings of the "Selected" configuration profile in the non-volatile memory (*NVM*).

If the *Config priority* column has the value *first* or *second* and the configuration profile is unencrypted, then the *Security status* frame in the *Basic Settings* > *System* dialog displays an alarm.

In the *Diagnostics > Status Configuration > Security Status* dialog, *Global* tab, *Monitor* column you specify if the device monitors the *Load unencrypted config from external memory* parameter.

Backup config when saving

Activates/deactivates saving a copy of the configuration profile in the external memory.

Possible values:

marked (default setting)

Saving a copy is activated. When you click in the *Basic Settings > Load/Save* dialog the **b**utton, the device saves a copy of the configuration profile on the active external memory.

unmarked Saving a copy is deactivated. The device does not save a copy of the configuration profile.

Manufacturer ID

Displays the name of the memory manufacturer.

Revision

	Displays the revision number specified by the memory manufacturer.
Version	Displays the version number specified by the memory manufacturer.
Name	Displays the product name specified by the memory manufacturer.

Serial number

Displays the serial number specified by the memory manufacturer.

1.7 Port

[Basic Settings > Port]

This dialog lets you specify settings for the individual ports. The dialog also displays the operating mode, connection status, bit rate and duplex mode for every port.

The dialog contains the following tabs:

- [Configuration]
- [Statistics]
- ▶ [Ingress Utilization]

[Configuration]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Name

Name of the port.

Possible values:

Alphanumeric ASCII character string with 0..64 characters The device accepts the following characters:

- <space>
- 0..9
- a..z
- A..Z
- !#\$%&'()*+,-./:;<=>?@[\\]^_`{}~

Port on

Activates/deactivates the port.

Possible values:

- marked (default setting) The port is active.
- unmarked

The port is inactive. The port does not send or receive any data.

State

Displays if the port is currently physically enabled or disabled.

Possible values:

marked

The port is physically enabled.

unmarked

The port is physically disabled.

When the *Port on* function is active, the *Auto-Disable* function has disabled the port. You specify the settings of the *Auto-Disable* function in the *Diagnostics > Ports > Auto-Disable* dialog. When the status of the tracking object changes, the device enables/disables the interface linked to the tracking object. You set up the tracking object in the *Advanced > Tracking > Configuration* dialog.

Autoneg

Activates/deactivates the automatic selection of the operating mode for the port.

Possible values:

marked (default setting)

The automatic selection of the operating mode is active.

The port negotiates the operating mode independently using auto-negotiation and automatically detects the assignment of the twisted-pair port connectors (auto cable crossing). This setting has priority over the manual setting of the port.

Elapse several seconds until the port has set the operating mode.

unmarked

The automatic selection of the operating mode is inactive.

The port operates with the values you specify in the *Manual configuration* column and in the *Manual cable crossing* column.

 Grayed-out display No automatic selection of the operating mode.

Manual configuration

Specifies the operating mode of the ports when the Autoneg function is disabled.

Possible values:

- 10M HDX Half-duplex connection
- ► 10M FDX Full-duplex connection
- 100M HDX Half-duplex connection
- 100M FDX Full-duplex connection
- ► 1G FDX Full-duplex connection

Note: The operating modes of the port actually available depend on the device hardware and the media module used.

Link/Current settings

Displays the operating mode which the port currently uses.

Possible values:

- -

No cable connected, no link.

▶ 10M HDX

Half-duplex connection

- 10M FDX Full-duplex connection
- 100M HDX Half-duplex connection
- 100M FDX Full-duplex connection
- IG FDX Full-duplex connection

Note: The operating modes of the port actually available depend on the device hardware and the media module used.

Manual cable crossing

Specifies the devices connected to a twisted-pair port.

The prerequisite is that the *Autoneg* function is disabled.

Possible values:

🕨 mdi

- The device interchanges the send- and receive-line pairs on the port.
- mdix (default setting on twisted-pair ports)
 - The device helps prevent the interchange of the send- and receive-line pairs on the port.
- ▶ auto-mdix

The device detects the send and receive line pairs of the connected device and automatically adapts to them.

Example: When you connect an end device with a crossed cable, the device automatically resets the port from *mdix* to *mdi*.

unsupported (default setting on optical ports or twisted-pair SFP ports) The port does not support this function. Flow control

Activates/deactivates the flow control on the port.

Possible values:

marked (default setting)

The Flow control on the port is active.

The sending and evaluating of pause packets (full-duplex operation) or collisions (half-duplex operation) is activated on the port.

□ To enable the flow control in the device, also activate the *Flow control* function in the *Switching* > *Global* dialog.

□ Activate the flow control also on the port of the device that is connected to this port. On an uplink port, activating the flow control can possibly cause undesired sending interruptions in the higher-level network segment ("wandering backpressure").

unmarked

The Flow control on the port is inactive.

If you are using a redundancy function, then you deactivate the flow control on the participating ports. If the flow control and the redundancy function are active at the same time, it is possible that the redundancy function operates differently than intended.

Send trap

Activates/deactivates the sending of SNMP traps when the device detects a change in the link up/ down status on the port.

Possible values:

marked (default setting) The sending of SNMP traps is active. The prerequisite is that in the *Diagnostics > Status Configuration > Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

When the device detects a link up/down status change, the device sends an SNMP trap.

unmarked

The sending of SNMP traps is inactive.

MTU

Specifies the maximum allowed size of Ethernet packets on the port in bytes.

Possible values:

1518..12288 (default setting: 1518)

With the setting 1518, the port transmits the Ethernet packets up to the following size:

- 1518 bytes without VLAN tag
- (1514 bytes + 4 bytes CRC)
- 1522 bytes with VLAN tag
 - (1518 bytes + 4 bytes CRC)

This setting lets you increase the max. allowed size of Ethernet packets that this port can receive or transmit.

The following list contains possible applications:

- When you use the PRP redundancy protocol, it is possible that you require an *MTU* that is larger by 6 bytes. (depends on hardware)
- When you use the device in the transfer network with double VLAN tagging, it is possible that you require an *MTU* that is larger by 4 bytes.

On other interfaces, you specify the maximum permissible size of the Ethernet packets as follows:

- HSR interfaces (depends on hardware) Switching > L2-Redundancy > HSR > Configuration dialog, Configuration frame, MTU field
- PRP interfaces (depends on hardware) Switching > L2-Redundancy > PRP > Configuration dialog, Configuration frame, MTU field
- Link Aggregation interfaces
 Switching > L2-Redundancy > Link Aggregation dialog, MTU column

Power state

Specifies if the port is physically switched on or off when you deactivate the port with the *Port on* function.

Possible values:

- marked
 - The port remains physically enabled. A connected device receives an active link.
- unmarked (default setting) The port is physically disabled.

Track name

Displays the name of the tracking object made up of the values displayed in the *Type* and *Track ID* columns.

Power save

Specifies how the port behaves when no cable is connected.

Possible values:

- no-power-save (default setting) The port remains activated.
- auto-power-down The port changes to the energy-saving mode.
- unsupported The port does not support this function and remains activated.

Signal

Activates/deactivates the port LED flashing. This function lets you identify the port in the field.

Possible values:

- marked The flashing of the port LED is active. The port LED flashes until you disable the function again.
- unmarked (default setting) The flashing of the port LED is inactive.

[Statistics]

This tab displays the following overview per port:

- Number of data packets/bytes received by the device
- Received packets
- Received octets
- Received unicasts
- Received multicasts
- Received broadcasts
- Number of data packets/bytes sent or forwarded by the device
 - Transmitted packets
 - Transmitted octets
 - Transmitted unicasts
 - Transmitted multicasts
 - Transmitted broadcasts
- Number of errors detected by the device
 - Received fragments
 - Detected CRC errors
 - Detected collisions
- Number of data packets per size category received by the device
 - Packets 64 bytes
 - Packets 65 to 127 bytes
 - Packets 128 to 255 bytes
 - Packets 256 to 511 bytes
 - Packets 512 to 1023 bytes
 - Packets 1024 to 1518 bytes
 - Number of data packets discarded by the device
 - Received discards
 - Transmitted discards

To sort the table by a specific criterion click the header of the corresponding column.

For example, to sort the table based on the number of received bytes in ascending order, click the header of the *Received octets* column once. To sort in descending order, click the header again.

To reset the counter for the port statistics in the table to 0, perform the following steps:

- □ In the *Basic Settings > Port* dialog, click the **b**utton.
- □ In the *Basic Settings* > *Restart* dialog, click the *Clear port statistics* button.

[Ingress Utilization]

This tab displays the ingress network load on the individual ports.

Table

or

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Utilization [%]

Displays the current utilization in percent in relation to the time interval specified in the *Control interval* [s] column.

The utilization is the relationship between the received data quantity and the maximum possible data quantity at the currently set data rate.

Lower threshold [%]

Specifies the lower notification threshold value for the network load. If the network load on the port falls below this value, then the status of the checkbox in the *Alarm* column changes to marked.

Possible values:

0.00..100.00 (default setting: 0.00)

The value 0 or 0.00 deactivates the lower notification threshold value.

Upper threshold [%]

Specifies the upper notification threshold value for the network load. If the network load on the port exceeds this value, then the status of the checkbox in the *Alarm* column changes to marked.

Possible values:

0.00..100.00 (default setting: 0.00)

The value 0 or 0.00 deactivates the upper notification threshold value.

Control interval [s]

Specifies the interval in seconds by which the device determines and possibly limits the network load.

Possible values:

1..3600 (default setting: 30)

Alarm

Displays the utilization alarm status.

Possible values:

marked

The network load on the port is below the value specified in the *Lower threshold* [%] column or above the value specified in the *Upper threshold* [%] column. The device sends an SNMP trap. The prerequisite is that in the *Diagnostics > Status Configuration > Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

unmarked

The network load on the port is between the lower and the upper notification threshold values.

1.8 Power over Ethernet

[Basic Settings > Power over Ethernet]

In Power over Ethernet (PoE), the Power Source Equipment (PSE) supplies current to powered devices (PD) such as IP phones through the twisted-pair cable.

The product code and the PoE-specific labeling on the PSE device housing indicates if your device supports *Power over Ethernet*. The PoE ports of the device support Power over Ethernet according to IEEE 802.3at.

The system provides an internal maximum power budget for the ports. The ports reserve power according to the detected class of a connected powered device. The real delivered power is equal to or less than the reserved power.

You manage the power output with the *Priority* parameter. When the sum of the power required by the connected devices exceeds the power available, the device turns off the power supplied to the ports according to the set-up priority. The device turns off the power supplied to the ports, starting with the ports set-up as low priority. When several ports have the same priority, the device turns off power, starting with the highest-numbered ports.

The menu contains the following dialogs:

PoE GlobalPoE Port

1.8.1 PoE Global

[Basic Settings > Power over Ethernet > Global]

Based on the settings specified in this dialog, the device provides power to the end-user devices. If the power consumption reaches the user-specified threshold value, then the device sends an SNMP trap.

Operation

Operation

Enables/disables the Power over Ethernet function.

Possible values:

▶ *On* (default setting)

The Power over Ethernet function is enabled.

► Off

The Power over Ethernet function is disabled.

Configuration

Send trap

Activates/deactivates the sending of SNMP traps. If the power consumption exceeds the userspecified threshold value, then the device sends an SNMP trap.

Possible values:

marked (default setting)

The device sends SNMP traps. The prerequisite is that in the *Diagnostics > Status Configuration >* Alarms (Traps) dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

unmarked The device does not send any SNMP traps.

Threshold [%]

Specifies the threshold value for the power consumption in percent.

If the power output exceeds this threshold value, then the device measures the total output power and sends an SNMP trap.

Possible values:

0..99 (default setting: 90)

System power

Budget [W]

Displays the sum of the power available for the global budget.

Reserved [W]

Displays the global reserved power. The device reserves power according to the detected classes of connected powered devices. Reserved power is equal to or less than the actual delivered power.

Delivered [W]

Displays the actual power delivered to the modules in watts.

Delivered [mA]

Displays the actual current delivered to the modules in milliamperes.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Module

Device module to which the table rows relate.

Configured power budget [W]

Specifies the power of the modules for the distribution at the ports.

Possible values:

0..n (default setting: n) Here, n corresponds to the value in the Max. power budget [W] column.

Max. power budget [W]

Displays the maximum power available for this module.

Reserved power [W]

Displays the power reserved for the module according to the detected classes of the connected powered devices.

Delivered power [W]

Displays the actual power in watts delivered to powered devices connected to this port.

Delivered current [mA]

Displays the actual current in milliamperes delivered to powered devices connected to this port.

Power source

Displays the power sourcing equipment for the device.

Possible values:

▶ internal

Internal power source

external External power source

Threshold [%]

Specifies the threshold value for the power consumption of the module in percent. If the power output exceeds this threshold value, then the device measures the total output power and sends an SNMP trap.

Possible values:

0..99 (default setting: 90)

Send trap

Activates/deactivates the sending of SNMP traps if the device detects that the threshold value for the power consumption exceeds.

Possible values:

marked (default setting)

The sending of SNMP traps is active. The prerequisite is that in the *Diagnostics > Status Configuration > Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

If the power consumption of the module exceeds the user-defined threshold value, then the device sends an SNMP trap.

unmarked

The sending of SNMP traps is inactive.

1.8.2 PoE Port

[Basic Settings > Power over Ethernet > Port]

When power consumption is higher than deliverable power, the device turns off power to the powered devices (PD) according to the priority levels and port numbers. When the PDs connected require more power than the device provides, the device deactivates the *Power over Ethernet* function on the ports. The device disables the *Power over Ethernet* function on the ports with the lowest priority first. When multiple ports have the same priority, the device first disables the *Power over Ethernet* function on the ports with the higher port number. The device also turns off power to powered devices (PD) for a specified time period.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

PoE enable

Activates/deactivates the PoE power provided to the port.

When the device activates or deactivates the function, the device logs an event in the System Log).

Possible values:

- marked (default setting) Providing PoE power to the port is active.
- unmarked Providing PoE power to the port is inactive.

Fast startup

Activates/deactivates the Power over Ethernet Fast Startup function on the port.

The prerequisite is that the checkbox in the *PoE enable* column is marked.

Possible values:

marked

The fast start up function is active. The device sends power to the powered devices (PD) immediately after turning the power to the device on.

unmarked (default setting) The fast start up function is inactive. The device sends power to the powered devices (PD) after loading its own configuration.

Priority

Specifies the Port priority.

To help prevent current overloads, the device disables ports with low priority first. To help prevent that the device disables the ports supplying necessary devices, specify a high priority for these ports.

Possible values:

- critical
- ▶ high
- Low (default setting)

Status

Displays the status of the port Powered Device (PD) detection.

Possible values:

disabled

- The device is in the DISABLED state and is not delivering power to the powered devices.
- deliveringPower
 - The device identified the class of the connected PD and is in the POWER ON state.
- ▶ fault
 - The device is in the TEST ERROR state.
- otherFault The device is in the IDLE state.
- searching

The device is in a state other than the listed states.

▶ test

The device is in the TEST MODE.

Detected class

Displays the power class of the powered device connected to the port.

Possible values:

CLass 0
 CLass 1
 CLass 2
 CLass 3
 CLass 4

Class 0 Class 1 Class 2 Class 3 Class 4

Activates/deactivates the current of the classes 0 to 4 on the port.

Possible values:

marked (default setting)

unmarked

Consumption [W]

Displays the current power consumption of the port in watts.

Possible values:

▶ 0,0..30,0

Consumption [mA]

Displays the current delivered to the port in milliamperes.

Possible values:

▶ 0..600

Power limit [W]

Specifies the maximum power in watts that the port outputs.

This function lets you distribute the power budget available among the PoE ports as required.

For example, for a connected device not providing a "Power Class", the port reserves a fixed amount of 15.4 W (class 0) even if the device requires less power. The surplus power is not available to any other port.

By specifying the power limit, you reduce the reserved power to the actual requirement of the connected device. The unused power is available to other ports.

If the exact power consumption of the connected powered device is unknown, then the device displays the value in the *Max. consumption* [*W*] column. Verify that the power limit is greater than the value in the *Max. consumption* [*W*] column.

If the maximum observed power is greater than the set power limit, then the device sees the power limit as invalid. In this case, the device uses the PoE class for the calculation.

Possible values:

0,0..30,0 (default setting: 0)

Max. consumption [W]

Displays the maximum power in watts that the device has consumed so far.

You reset the value when you disable PoE on the port or terminate the connection to the connected device.

Name

Specifies the name of the port.

Specify the name of your choice.

Possible values:

▶ Alphanumeric ASCII character string with 0..32 characters

Auto-shutdown power

Activates/deactivates the Auto-shutdown power function according to the settings.

Possible values:

marked

unmarked (default setting)

Disable power at [hh:mm]

Specifies the time at which the device disables the power for the port upon activation of the *Auto-shutdown power* function.

Possible values:

00:00..23:59 (default setting: 00:00)

Re-enable power at [hh:mm]

Specifies the time at which the device enables the power for the port upon activation of the *Auto-shutdown power* function.

Possible values:

00:00..23:59 (default setting: 00:00)

1.9 Restart

[Basic Settings > Restart]

This dialog lets you restart the device, reset port counters and the MAC address table (forwarding database), and delete log files.

Restart

Cold start...

Opens the *Restart* window to initiate an immediate or delayed restart of the device.

If the configuration profile in the volatile memory (*RAM*) and the "Selected" configuration profile in the non-volatile memory (*NVM*) differ, then the device displays the *Warning* window.

- □ To permanently save the settings, click the Yes button in the *Warning* window.
- □ To discard the changed settings, click the *No* button in the *Warning* window.

In the *Restart in* field you specify the delay time for the delayed restart. Possible values:

▶ 00:00:00..596:31:23 (default setting: 00:00:00)

Hour:Minute:Second

When the delay time elapses, the device restarts and goes through the following phases:

- If you activate the function in the *Diagnostics > System > Selftest* dialog, then the device performs a RAM test.
- The device starts the device software that the Stored version field displays in the Basic Settings > Software dialog.
- The device loads the settings from the "Selected" configuration profile. See the Basic Settings > Load/Save dialog.

Note: During the restart, the device does not transfer any data. During this time, the device cannot be accessed by the Graphical User Interface or other management systems.

Restart in

Displays the remaining time in days, hours, minutes, seconds until the device restarts.

To update the display of the remaining time, click the $\, C \,$ button.

Cancel

Aborts a delayed restart.

Buttons

Clear FDB

Removes the MAC addresses from the forwarding table that have in the *Switching* > *Filter for MAC Addresses* dialog the value *Learned* in the *Status* column.

Clear ARP table

Removes the dynamically set up addresses from the ARP table.

See the *Diagnostics* > System > ARP dialog.

Clear port statistics

Resets the counter for the port statistics to Ø.

See the Basic Settings > Port dialog, Statistics tab.

Clear management access statistics

Resets the counters for the device management access statistics to Ø.

See the Diagnostics > System > System Information dialog, Used Management Ports table.

Clear IGMP snooping data

Removes the IGMP Snooping entries and resets the counter in the Information frame to 0.

See the Switching > IGMP Snooping > Global dialog.

Clear log file

Removes the logged events from the log file.

See the *Diagnostics > Report > System Log* dialog.

Clear persistent log file

Removes the log files from the external memory.

See the *Diagnostics* > *Report* > *Persistent Logging* dialog.

Clear email notification statistics

Resets the counters in the Information frame to 0.

See the *Diagnostics > Email Notification > Global* dialog.

2 Time

The menu contains the following dialogs:

- Basic Settings
- SNTP
- ► PTP
- ▶ 802.1AS

2.1 Basic Settings

[Time > Basic Settings]

The device is equipped with a buffered hardware clock. This clock keeps the correct time if the power supply becomes inoperable, or you disconnect the device from the power supply. After the system startup, the correct time is available again, for example, for log entries.

The hardware clock bridges a power supply downtime of 3 hours. The prerequisite is that the power supply of the device has been connected continuously for at least 5 minutes beforehand.

In this dialog, you specify time-related settings independently of the time synchronization protocol specified.

The dialog contains the following tabs:

[Global]
 [Daylight saving time]

[Global]

In this tab, you specify the system time and the time zone.

Configuration

System time (UTC)

Displays the date and time in Universal Time Coordinated (UTC) format.

Set time from PC

The device takes over the time from your computer as the system time.

System time

Displays the local date and time: System time = System time (UTC) + Local offset [min] + Daylight saving time

Time source

Displays the time source from which the device obtains the time information.

The device automatically selects the available time source with the greatest accuracy.

Possible values:

Local

System clock of the device.

sntp

The *SNTP* client is enabled, and the device is synchronized by an *SNTP* server. See the *Time* > SNTP dialog.

▶ ptp

The *PTP* function is enabled, and the device clock is synchronized with a *PTP master clock*. See the *Time > PTP* dialog.

Local offset [min]

Specifies the difference in minutes between Universal Time Coordinated (UTC) and local time: Local offset [min] = System time – System time (UTC)

Possible values:

-780..840 (default setting: 60)

[Daylight saving time]

In this tab, you enable/disable the *Daylight saving time* function. You specify the start and end of summer time using a pre-defined profile. As an alternative, you specify these settings individually. During the summer time, the device advances the local time by one hour.

Operation

Daylight saving time

Enables/disables the Daylight saving time mode.

Possible values:

▶ On

The Daylight saving time mode is enabled.

The device automatically sets the clock forward to summer time and back again.

Off (default setting) The Daylight saving time mode is disabled.

You specify the daylight saving time settings in the Summertime begin and Summertime end frames.

Profile...

Opens the *Profile...* window to select a pre-defined profile for the start and end of summer time. Selecting a profile overwrites the settings specified in the *Summertime begin* and *Summertime end* frames.

Possible values:

► EU

Daylight saving time settings as applicable in the European Union.

► USA

Daylight saving time settings as applicable in the United States.

Summertime begin

In this frame, you specify the time at which the device sets the clock forward from standard time to summer time. In the first 3 fields, you specify the day for the start of summer time. In the last field, you specify the time.

Week

Specifies the week in the current month.

Possible values:

- (default setting)
- ▶ first
- second
- ▶ third
- ▶ fourth
- Last

Day

Specifies the day of the week.

Possible values:

- (default setting)
- Sunday
- Monday
- Tuesday
- ▶ Wednesday
- ► Thursday
- ▶ Friday
- Saturday

Month

Specifies the month.

Possible values:

- (default setting)
- January

February

- March
- 🕨 April
- May
- June
- ▶ July
- August
- September
- October
- November
- December

System time

Specifies the time at which the device sets the clock forward to summer time.

Possible values:

HH:MM> (default setting: 00:00)

Summertime end

In this frame, you specify the time at which the device resets the clock from summer time to standard time. In the first 3 fields, you specify the day for the end of summer time. In the last field, you specify the time.

Week

Specifies the week in the current month.

Possible values:

- (default setting)
- ▶ first
- second
- third
- ▶ fourth
- Last

Day

Specifies the day of the week.

Possible values:

- (default setting)
- Sunday
- Monday
- ▶ Tuesday
- Wednesday
- Thursday

- 🕨 Friday
- Saturday

Month

Specifies the month.

Possible values:

- (default setting)
- January
- ► February
- March
- 🕨 April
- 🕨 May
- 🕨 June
- July
- August
- September
- ▶ October
- November
- December

System time

Specifies the time at which the device resets the clock to standard time.

Possible values:

<HH:MM> (default setting: 00:00)

2.2 SNTP

[Time > SNTP]

The Simple Network Time Protocol (SNTP) is a procedure described in the RFC 4330 for time synchronization in the network.

With the SNTP client function, the device lets you synchronize the local system clock with an external NTP or SNTP server.

As the SNTP server, the device makes the time information available to other devices in the network.

The menu contains the following dialogs:

- SNTP Client
- SNTP Server

2.2.1 SNTP Client

[Time > SNTP > Client]

In this dialog, you specify the settings with which the device operates as an SNTP client. As an SNTP client, the device obtains time information from an external NTP or SNTP servers and synchronizes the local system clock with the time from the time server.

Operation

Operation

Enables/disables the *Client* function in the device. Note the setting in the *Disable client after successful sync* checkbox in the *Configuration* frame.

Possible values:

▶ On

The *Client* function is enabled. The device operates as an SNTP client.

Off (default setting)
 The *Client* function is disabled.

State

State

Displays the status of the *Client* function.

Possible values:

disabled

The SNTP client is not operating.

- notSynchronized The SNTP client is operating. The local system clock is not in sync with an external NTP or SNTP server.
- synchronizedToRemoteServer The SNTP client is not operating. The local system clock is in sync with an external NTP or SNTP server.

Configuration

Mode

Specifies if the device actively requests the time information from an external NTP or SNTP server set up in the device (*unicast* mode) or passively waits for the time information from a random NTP or SNTP server (*broadcast* mode).

Possible values:

unicast (default setting)

The device takes the time information only from one of the set-up NTP or SNTP servers. The device sends Unicast requests to the external SNTP or NTP server and evaluates the response of the server.

broadcast

The device obtains the time information from a random NTP or SNTP server. The device evaluates the Broadcasts or Multicasts from this server.

Request interval [s]

Specifies the interval in seconds at which the device requests time information from the external NTP or SNTP server.

Possible values:

5..3600 (default setting: 30)

Broadcast recv timeout [s]

Specifies the time in seconds the device operating in *broadcast* mode waits before changing the value in the *State* field from *syncToRemoteServer* to *notSynchronized* when it does not receive Broadcast packets. See the *State* frame.

Possible values:

128..2048 (default setting: 320)

Disable client after successful sync

Activates/deactivates the automatic disabling of the *SNTP Client* function after the device has successfully synchronized its local system clock.

Possible values:

marked

The automatic disabling of the SNTP Client function is active.

The device disables the *SNTP Client* function after it has successfully synchronized its local system clock.

unmarked (default setting)

The automatic disabling of the SNTP Client function is inactive.

The device keeps the *SNTP Client* function enabled after it has successfully synchronized its local system clock.

Table

In the table, you specify the settings for up to 4 external NTP or SNTP servers. After enabling the function, the device sends requests to the server set up in the first table row.

When the external NTP or SNTP server does not respond, the device sends its request to the server set up in the next table row. When the device does not receive a response, it cyclically sends requests to each set-up NTP or SNTP server until it receives a valid time from one of these servers. The device synchronizes its local system clock with the first responding NTP or SNTP server, even if an server ahead in the table will be reachable again later.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Adds a table row.

x Remove

Removes the selected table row.

Index

Displays the index number to which the table row relates.

The device automatically assigns the value when you add a table row. When you delete a table row, this leaves a gap in the numbering. When you add a table row, the device fills the first gap.

Name

Specifies a name for the external NTP or SNTP server.

Possible values:

Alphanumeric ASCII character string with 1..32 characters

IP address

Specifies the IP address of the external NTP or SNTP server.

Possible values:

- Valid IPv4 address (default setting: 0.0.0.0)
- Valid IPv6 address
- Hostname

Destination UDP port

Specifies the UDP port on which the external NTP or SNTP server listens for requests.

Possible values:

1..65535 (2¹⁶-1) (default setting: 123) Exception: Port 2222 is reserved for internal functions. Status

Displays the connection status between the device and the external NTP or SNTP server.

Possible values:

success

The device has successfully synchronized the local system clock with the external NTP or SNTP server.

badDateEncoded

Synchronization was unsuccessful. The time information received contains protocol errors.

▶ other

Synchronization was unsuccessful.

- The IP address 0.0.0.0 is specified for the external NTP or SNTP server.

or

- The device is using a different external NTP or SNTP server.
- requestTimedOut

Synchronization was unsuccessful. The device has not received a response from the external NTP or SNTP server.

serverKissOfDeath

Synchronization was unsuccessful. The external NTP or SNTP server is overloaded. The device is requested to synchronize its system clock with another NTP or SNTP server. When no other NTP or SNTP server is available, the device checks at intervals longer than the value in the *Request interval* [s] field, if the server is still overloaded.

serverUnsychronized

Synchronization was unsuccessful. The external NTP or SNTP server is not in sync with a reference time source.

versionNotSupported

Synchronization was unsuccessful. The SNTP versions of the client and server are incompatible.

Active

Activates/deactivates the connection to the external NTP or SNTP server.

Possible values:

marked

The connection to the external NTP or SNTP server is activated. The device has the option to access to the server.

unmarked (default setting)

The connection to the external NTP or SNTP server is deactivated. The device does not have the option to access to the server.

2.2.2 SNTP Server

[Time > SNTP > Server]

In this dialog, you specify the settings with which the device operates as an SNTP server. As the SNTP server, the device makes the time information available to other devices in the network. The device provides the Universal Time Coordinated (UTC) without considering local time differences.

If set accordingly, the SNTP server on the device operates in Broadcast mode. In Broadcast mode, the device makes the time information available to other devices in the network by sending Broadcasts or Multicasts.

Operation

Operation

Enables/disables the *Server* function in the device. Note the setting in the *Disable server at local time source* checkbox in the *Configuration* frame.

Possible values:

- ► On
 - The Server function is enabled.

The device operates as an SNTP server.

Off (default setting)
 The *Server* function is disabled.

State

State

Displays the state of the Server function on the device.

Possible values:

disabled

The SNTP server is not operating.

- notSynchronized The SNTP server is operating. The local system clock is not in sync with a reference time source.
- syncToLocal
 - The SNTP server is operating.

The local system clock is in sync with the hardware clock of the device.

- syncToRefcLock
 - The SNTP server is operating.

The local system clock is in sync with an external reference time source, like a PTP clock.

syncToRemoteServer

The SNTP server is operating.

The local system clock is in sync with an external NTP or SNTP server which is superordinate to the device in a cascade.

Configuration

UDP port

Specifies the UDP port on which the device listens for requests.

Possible values:

1..65535 (2¹⁶-1) (default setting: 123) Exception: Port 2222 is reserved for internal functions.

Broadcast admin mode

Activates/deactivates the Broadcast mode.

Possible values:

marked

The device sends SNTP packets as Broadcasts or Multicasts. The device also responds to SNTP requests in unicast mode.

unmarked (default setting)

The device responds to SNTP requests in unicast mode, but sends no Broadcast packets on its own.

Broadcast destination address

Specifies the destination IP address to which the device sends the SNTP packets in Broadcast mode.

Possible values:

Valid IPv4 address (default setting: 0.0.0.0) Broadcast and Multicast addresses are permitted.

Broadcast UDP port

Specifies the UDP port on which the device sends the SNTP packets in Broadcast mode.

Possible values:

```
1..65535 (2<sup>16</sup>-1) (default setting: 123)
Exception: Port 2222 is reserved for internal functions.
```

Broadcast VLAN ID

Specifies the VLAN to which the device sends the SNTP packets in Broadcast mode.

Possible values:

▶ 0

The device sends the SNTP packets in the same VLAN in which the device management access occurs. See the *Basic Settings > Network > Global* dialog.

1..4042 (default setting: 1)

Broadcast send interval [s]

Specifies the interval in seconds at which the device broadcasts SNTP packets.

Possible values:

64..1024 (default setting: 128)

Disable server at local time source

Activates/deactivates the automatic disabling of the *SNTP Server* function if the local system clock is not in sync with another external time reference.

Possible values:

marked

The automatic disabling of the SNTP Server function is active.

If the device has synchronized its local system clock to an external time reference, like a PTP clock, then it keeps the *SNTP Server* function enabled. Otherwise, the device disables the *SNTP Server* function.

unmarked (default setting)

The automatic disabling of the SNTP Server function is inactive.

The device keeps the *SNTP Server* function enabled, regardless of whether it has synchronized its local system clock to an external time reference.

If the local system clock is not in sync with an external time reference, then in the SNTP packet, the device informs the client that its system clock is synchronized locally.

2.3 PTP

[Time > PTP]

The menu contains the following dialogs:

- PTP Global
- PTP Boundary Clock
- PTP Transparent Clock

2.3.1 PTP Global

[Time > PTP > Global]

In this dialog, you specify basic settings for the PTP function.

The Precision Time Protocol (PTP) is a procedure defined in IEEE 1588-2008 that supplies the devices in the network with a precise time. The method synchronizes the clocks in the network with a precision of a few 100 ns. The protocol uses Multicast communication, so the load on the network due to the *PTP* synchronization messages is negligible.

PTP is significantly more accurate than SNTP. If the *SNTP* function and the *PTP* function are enabled in the device at the same time, then the *PTP* function has priority.

With the *Best Master Clock Algorithm*, the devices in the network determine which device has the most accurate time. The devices use the device with the most accurate time as the reference time source (*Grandmaster*). Subsequently the participating devices synchronize themselves with this reference time source.

If you want to transport PTP time accurately through the network, then use only devices with PTP hardware support on the transport paths.

The protocol differentiates between the following clocks:

- Boundary Clock (BC)
 - This clock has any number of PTP ports and operates as both *PTP* master and *PTP* slave. In its respective network segment, the clock operates as an Ordinary Clock.
 - As *PTP* slave, the clock synchronizes itself with a *PTP* master that is higher than the device in the cascade.
 - As *PTP* master, the clock forwards the time information through the network to *PTP* slaves that are higher than the device in the cascade.
- Transparent Clock (TC)

This clock has any number of PTP ports. In contrast to the *Boundary Clock*, this clock corrects the time information before forwarding it, without synchronizing itself.

Operation IEEE1588/PTP

Operation IEEE1588/PTP

Enables/disables the PTP function.

Possible values:

▶ On

The *PTP* function is enabled.

The device synchronizes its clock with PTP.

If the *SNTP* function and the *PTP* function are enabled in the device at the same time, then the *PTP* function has priority.

Off (default setting) The PTP function is disabled. The device transmits the PTP synchronization messages without any correction on every port.

Configuration IEEE1588/PTP

PTP mode

Specifies the PTP version and mode of the local clock.

Possible values:

- v2-transparent-clock (default setting)
- v2-boundary-cLock

Sync lower bound [ns]

Specifies the lower threshold value in nanoseconds for the path difference between the local clock and the reference time source (*Grandmaster*). If the path difference falls below this value once, then the local clock is classed as synchronized.

Possible values:

1..9999999999 (10⁹-1) (default setting: 30)

Sync upper bound [ns]

Specifies the upper threshold value in nanoseconds for the path difference between the local clock and the reference time source (*Grandmaster*). If the path difference exceeds this value once, then the local clock is classed as unsynchronized.

Possible values:

31..100000000 (10°) (default setting: 5000)

PTP management

Activates/deactivates the PTP management defined in the PTP standard.

Possible values:

marked

PTP management is activated.

unmarked (default setting) PTP management is deactivated.

Status

Is synchronized

Displays if the local system clock is synchronized with the reference time source (Grandmaster).

If the path difference between the local clock and the reference time source (*Grandmaster*) falls below the synchronization lower threshold value one time, then the local clock is synchronized. This status is kept until the path difference exceeds the synchronization upper threshold value one time.

You specify the synchronization threshold values in the Configuration IEEE1588/PTP frame.

Max. offset absolute [ns]

Displays the maximum path difference in nanoseconds that has occurred since the local system clock was synchronized with the reference time source (*Grandmaster*).

PTP time

Displays the date and time for the PTP time scale when the local clock is synchronized with the reference time source (*Grandmaster*). Format: Month Day, Year hh:mm:ss AM/PM

2.3.2 PTP Boundary Clock

[Time > PTP > Boundary Clock]

With this menu you can set up the Boundary Clock mode for the local clock.

The menu contains the following dialogs:

PTP Boundary Clock Global

▶ PTP Boundary Clock Port

2.3.2.1 PTP Boundary Clock Global

[Time > PTP > Boundary Clock > Global]

In this dialog, you specify general, cross-port settings for the *Boundary Clock* mode for the local clock. The *Boundary Clock (BC)* operates according to PTP version 2 (IEEE 1588-2008).

The settings are effective when the local clock operates as the *Boundary Clock (BC)*. For this, you select in the *Time* > *PTP* > *Global* dialog in the *PTP mode* field the value v2-boundary-clock.

Operation IEEE1588/PTPv2 BC

Priority 1

Specifies *priority 1* for the device.

Possible values:

0..255 (default setting: 128)

The *Best Master Clock* algorithm first evaluates *priority 1* among the participating devices to determine the reference time source (*Grandmaster*).

The lower you set this value, the more probable it is that the device becomes the reference time source (*Grandmaster*). See the *Grandmaster* frame.

Priority 2

Specifies priority 2 for the device.

Possible values:0..255 (default setting: 128)

When the previously evaluated criteria are the same for multiple devices, the *Best Master Clock Algorithm* evaluates *priority 2* of the participating devices.

The lower you set this value, the more probable it is that the device becomes the reference time source (*Grandmaster*). See the *Grandmaster* frame.

Domain number

Assigns the device to a *PTP* domain.

Possible values:

0..255 (default setting: 0)

The device transmits time information from and to devices only in the same domain.

Status IEEE1588/PTPv2 BC

Two step

Displays that the clock is operating in Two-Step mode.

Steps removed

Displays the number of communication paths passed through between the local clock of the device and the reference time source (*Grandmaster*).

For a *PTP* slave, the value 1 means that the clock is connected with the reference time source (*Grandmaster*) directly through one communication path.

Offset to master [ns]

Displays the measured difference (offset) between the local clock and the reference time source (*Grandmaster*) in nanoseconds. The *PTP* slave calculates the difference from the time information received.

In Two-Step mode the time information consists of 2 *PTP* synchronization messages each, which the *PTP* master sends cyclically:

- The first synchronization message (sync message) contains an estimated value for the exact sending time of the message.
- The second synchronization message (follow-up message) contains the exact sending time of the first message.

The *PTP* slave uses the two *PTP* synchronization messages to calculate the difference (offset) from the master and corrects its clock by this difference. Here the *PTP* slave also considers the *Delay to master* [*ns*] value.

Delay to master [ns]

Displays the delay when transmitting the *PTP* synchronization messages from the *PTP* master to the *PTP* slave in nanoseconds.

The *PTP* slave sends a "Delay Request" packet to the *PTP* master and thus determines the exact sending time of the packet. When it receives the packet, the *PTP* master generates a time stamp and sends this in a "Delay Response" packet back to the *PTP* slave. The *PTP* slave uses the two packets to calculate the delay, and considers this starting from the next offset measurement.

The prerequisite is that in the *Time > PTP > Boundary Clock > Port* dialog, *Delay mechanism* column, the value *e2e* is specified for the slave ports.

Grandmaster

This frame displays the criteria that the *Best Master Clock Algorithm* uses when evaluating the reference time source (*Grandmaster*).

The algorithm first evaluates *priority 1* of the participating devices. The device with the numerically lowest value for *priority 1* is designated as the reference time source (*Grandmaster*). When the value is the same for multiple devices, the algorithm takes the next criterion, and when this is also the same, the algorithm takes the next criterion after this one. When every value is the same for multiple devices, the numerically lowest value in the *Clock identity* field decides which device is designated as the reference time source (*Grandmaster*).

The device lets you influence which device in the network is designated as the reference time source (*Grandmaster*). To do this, modify the value in the *Priority 1* field or the *Priority 2* field in the *Operation IEEE1588/PTPv2 BC* frame.

Priority 1

Displays the *priority 1* value for the device that is currently the reference time source (*Grandmaster*).

Clock class

Displays the class of the reference time source (*Grandmaster*). Parameter for the *Best Master Clock Algorithm*.

Clock accuracy

Displays the estimated accuracy of the reference time source (*Grandmaster*). Parameter for the *Best Master Clock Algorithm*.

Clock variance

Displays the variance of the reference time source (*Grandmaster*), also known as the *Offset scaled log variance*. Parameter for the *Best Master Clock Algorithm*.

Priority 2

Displays the *priority* 2 value for the device that is currently the reference time source (*Grandmaster*).

Local time properties

Time source

Specifies the time source from which the local clock gets its time information.

Possible values:

- atomicClock
- 🕨 gps
- terrestrialRadio
- ▶ ptp
- ntp
- handSet
- ▶ other
- internalOscillator (default setting)

```
UTC offset [s]
```

Specifies the difference between the PTP time scale and the Universal Time Coordinated (UTC).

See the PTP timescale checkbox.

Possible values:

► -32768..32767 (2¹⁵-1)

Note: The default setting is the value valid on the creation date of the device software. For further information, see the "Bulletin C" of the Earth Rotation and Reference Systems Service (IERS): https://www.iers.org/IERS/EN/Publications/Bulletins/bulletins.html UTC offset valid

Specifies if the value specified in the UTC offset [s] field is correct.

Possible values:

- marked
- unmarked (default setting)

Time traceable

Displays if the device obtains the time from a primary UTC reference, for example from an NTP server.

Possible values:

- marked
- unmarked

Frequency traceable

Displays if the device obtains the frequency from a primary UTC reference, for example from an NTP server.

Possible values:

- marked
- unmarked

PTP timescale

Displays if the device uses the PTP time scale.

Possible values:

- marked
- unmarked

According to IEEE 1588, the PTP time scale is the TAI atomic time started on 01.01.1970.

In contrast to Universal Time Coordinated (UTC), TAI does not use leap seconds.

As of July 1, 2020, the TAI time is 37 s ahead of the Universal Time Coordinated (UTC).

Identities

The device displays the identities as byte sequences in hexadecimal notation.

The identification numbers (UUID) are made up as follows:

- The device identification number consists of the MAC address of the device, with the values ff and fe added between byte 3 and byte 4.
- The port UUID consists of the device identification number followed by a 16-bit port ID.

Clock identity

Displays the identification number (UUID) of the device.

Parent port identity

Displays the port identification number (UUID) of the directly superior master device.

Grandmaster identity

Displays the identification number (UUID) of the reference time source (Grandmaster) device.

2.3.2.2 PTP Boundary Clock Port

[Time > PTP > Boundary Clock > Port]

In this dialog, you specify the Boundary Clock (BC) settings on each individual port.

The settings are effective when the local clock operates as the *Boundary Clock (BC)*. For this, you select in the *Time* > *PTP* > *Global* dialog in the *PTP mode* field the value v_2 -boundary-clock.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

PTP enable

Activates/deactivates transmitting PTP synchronization messages on the port.

Possible values:

- marked (default setting) The transmission is activated. The port forwards and receives *PTP* synchronization messages.
 unmarked
 - The transmission is deactivated. The port blocks *PTP* synchronization messages.

PTP status

Displays the current status of the port.

Possible values:

- initializing Initialization phase
- faulty Faulty mode: error in the Precision Time Protocol (PTP).
- disabled PTP is disabled on the port.
- Listening Device port is waiting for PTP synchronization messages.
- pre-master PTP pre-master mode
- master PTP master mode
- passive PTP passive mode
- uncalibrated
 PTP uncalibrated mode
- sLave
 PTP slave mode

Network protocol

Specifies which protocol the port uses to transmit the PTP synchronization messages.

Possible values:

▶ 802.3 (default setting)

UDP/IPv4

Announce interval [s]

Specifies the interval in seconds at which the port transmits messages for the PTP topology discovery.

Assign the same value to every device of a PTP domain.

Possible values:

1
2 (default setting)
4
8
16

Announce timeout

Specifies the number of announce intervals.

Example:

For the default setting (Announce interval [s] = 2 and Announce timeout = 3), the timeout is $3 \times 2 s = 6 s$.

Possible values:

2..10 (default setting: 3)

Assign the same value to every device of a *PTP* domain.

Sync interval

Specifies the interval in seconds at which the port transmits *PTP* synchronization messages.

Possible values:

```
0.25
0.5
1 (default setting)
2
```

Delay mechanism

Specifies the mechanism with which the device measures the delay for transmitting the *PTP* synchronization messages.

Possible values:

disabled

The measurement of the delay for the *PTP* synchronization messages for the connected PTP devices is inactive.

e2e (default setting)

End-to-End: As the *PTP* slave, the port measures the delay for the *PTP* synchronization messages to the *PTP* master.

The device displays the measured value in the *Time* > *PTP* > *Boundary Clock* > *Global* dialog. n^{2n}

🕨 p2p

Peer-to-Peer: The device measures the delay for the *PTP* synchronization messages for the connected PTP devices, provided that these devices support P2P.

This mechanism spares the device from having to determine the delay again in the case of a reconfiguration.

P2P delay

Displays the measured Peer-to-Peer delay for the PTP synchronization messages.

The prerequisite is that in the *Delay mechanism* column the value *p2p* is specified.

P2P delay interval [s]

Specifies the interval in seconds at which the port measures the Peer-to-Peer delay.

The prerequisite is that in the *Delay mechanism* column the value p2p is specified for this port and for the port of the remote device.

Possible values:

1 (default setting)
2
4
8
16
32

E2E delay interval [s]

Displays the interval in seconds at which the port measures the End-to-End delay.

Possible values:

- When the port is operating as the *PTP* master, the device assigns to the port the value 8.
- When the port is operating as the PTP slave, the value is specified by the PTP master connected to the port.

Asymmetry

Corrects the measured delay value corrupted by asymmetrical transmission paths.

Possible values:

-2000000000..200000000 (default setting: 0)

The value represents the delay symmetry in nanoseconds.

A measured delay value of y ns corresponds to an asymmetry of y × 2 ns.

The value is positive if the delay from the *PTP* master to the *PTP* slave is longer than in the opposite direction.

VLAN

Specifies the VLAN ID that the device uses to tag the received *PTP* synchronization messages on this port.

Possible values:

none (default setting)

The device transmits *PTP* synchronization messages without a VLAN tag.

0..4042

You specify VLANs that you have already set up in the device from the list.

Verify that the port is a member of the VLAN.

See the Switching > VLAN > Configuration dialog.

VLAN priority

Specifies the priority with which the device transmits the *PTP* synchronization messages marked with a VLAN ID (Layer 2, IEEE 802.1D).

Possible values:

▶ 0...7 (default setting: 6)

If you specified in the VLAN column the value none, then the device ignores the VLAN priority.

2.3.3 PTP Transparent Clock

[Time > PTP > Transparent Clock]

With this menu you can set up the Transparent Clock mode for the local clock.

The menu contains the following dialogs:

PTP Transparent Clock Global

PTP Transparent Clock Port

2.3.3.1 PTP Transparent Clock Global

[Time > PTP > Transparent Clock > Global]

In this dialog, you specify general, cross-port settings for the *Transparent Clock* mode for the local clock. The *Transparent Clock (TC)* operates according to PTP version 2 (IEEE 1588-2008).

The settings are effective when the local clock operates as the *Transparent Clock (TC)*. For this, you select in the *Time* > *PTP* > *Global* dialog in the *PTP mode* field the value v2-transparent-clock.

Operation IEEE1588/PTPv2 TC

Delay mechanism

Specifies the mechanism with which the device measures the delay for transmitting the *PTP* synchronization messages.

Possible values:

e2e (default setting)

As the *PTP* slave, the port measures the delay for the *PTP* synchronization messages to the *PTP* master.

The device displays the measured value in the Time > PTP > Transparent Clock > Global dialog.

🕨 p2p

The device measures the delay for the *PTP* synchronization messages for every connected PTP device, provided that the device supports P2P.

This mechanism spares the device from having to determine the delay again in the case of a reconfiguration.

If you specify this value, then the value 802.3 is only available in the Network protocol column.

e2e-optimized

Like *e2e*, with the following special characteristics:

- The device transmits the delay requests of the *PTP* slaves only to the *PTP* master, even though these requests are multicast messages. The device thus spares the other devices from unnecessary multicast requests.
- If the master-slave topology changes, then the device relearns the port for the PTP master as soon as it receives a synchronization message from another PTP master.
- If the device does not know a *PTP* master, then the device transmits delay requests to the ports.

disabled

The delay measuring is disabled on the port. The device discards messages for the delay measuring.

Primary domain

Assigns the device to a PTP domain.

Possible values:

0..255 (default setting: 0)

The device transmits time information from and to devices only in the same domain.

Network protocol

Specifies which protocol the port uses to transmit the PTP synchronization messages.

Possible values:

- ieee8023 (default setting)
- udpIpv4

Multi domain mode

Activates/deactivates the PTP synchronization message correction in every PTP domain.

Possible values:

- marked
 - The device corrects *PTP* synchronization messages in every *PTP* domain.
- unmarked (default setting) The device corrects *PTP* synchronization messages only in the primary *PTP* domain. See the *Primary domain* field.

VLAN ID

Specifies the VLAN ID with which the device marks the PTP synchronization messages on this port.

Possible values:

- none (default setting)
 - The device transmits *PTP* synchronization messages without a VLAN tag.
- ▶ 0..4042

You specify VLANs that you have already set up in the device from the list.

VLAN priority

Specifies the priority with which the device transmits the *PTP* synchronization messages marked with a VLAN ID (Layer 2, IEEE 802.1D).

Possible values:

0..7 (default setting: 6)

If you specified the value *none* in the VLAN ID field, then the device ignores the specified value.

Local synchronization

Syntonize

Activates/deactivates the frequency synchronization of the Transparent Clock with the PTP master.

Possible values:

- marked (default setting) The frequency synchronization is active. The device synchronizes the frequency.
- unmarked The frequency synchronization is inactive. The frequency remains constant.

Synchronize local clock

Activates/deactivates the synchronization of the local system time.

Possible values:

- marked
 - The synchronization is active.

The device synchronizes the local system time with the time received using PTP. The prerequisite is that the *Syntonize* checkbox is marked.

unmarked (default setting) The synchronization is inactive. The local system time remains constant.

Current master

Displays the port identification number (UUID) of the directly superior master device on which the device synchronizes its frequency.

If the value contains only zeros, this is because:

- The *Syntonize* function is disabled. or
- The device cannot find a PTP master.

Offset to master [ns]

Displays the measured difference (offset) between the local clock and the *PTP* master in nanoseconds. The device calculates the difference from the time information received.

The prerequisite is that the Synchronize local clock function is enabled.

Delay to master [ns]

Displays the delay when transmitting the *PTP* synchronization messages from the *PTP* master to the *PTP* slave in nanoseconds.

Prerequisites:

- The Synchronize local clock function is enabled.
- In the *Delay mechanism* field, the value *e2e* is selected.

Status IEEE1588/PTPv2 TC

Clock identity

Displays the identification number (UUID) of the device.

The device displays the identities as byte sequences in hexadecimal notation.

The device identification number consists of the MAC address of the device, with the values ff and fe added between byte 3 and byte 4.

2.3.3.2 PTP Transparent Clock Port

[Time > PTP > Transparent Clock > Port]

In this dialog, you specify the Transparent Clock (TC) settings on each individual port.

The settings are effective when the local clock operates as the *Transparent Clock (TC)*. For this, you select in the *Time* > *PTP* > *Global* dialog in the *PTP mode* field the value v2-transparent-clock.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

PTP enable

Activates/deactivates transmitting PTP synchronization messages on the port.

Possible values:

- marked (default setting) The transmitting is active. The port forwards and receives *PTP* synchronization messages.
 unmarked
 - The transmitting is inactive. The port blocks *PTP* synchronization messages.

P2P delay interval [s]

Specifies the interval in seconds at which the port measures the Peer-to-Peer delay.

The prerequisite is that in the *Time* > *PTP* > *Transparent Clock* > *Global* dialog, *Delay mechanism* option list, the radio button p2p is selected for this port and for the port of the remote device.

Possible values:

1 (default setting)
2
4
8
16
32

P2P delay

Displays the measured Peer-to-Peer delay for the PTP synchronization messages.

The prerequisite is that in the *Time > PTP > Transparent Clock > Global* dialog, *Delay mechanism* option list, the radio button *p2p* is selected.

Asymmetry

Corrects the measured delay value corrupted by asymmetrical transmission paths.

Possible values:

-2000000000..200000000 (2× 10⁹) (default setting: 0)

The value represents the delay symmetry in nanoseconds.

A measured delay value of y ns corresponds to an asymmetry of y × 2 ns.

The value is positive if the delay from the *PTP* master to the *PTP* slave is longer than in the opposite direction.

2.4 802.1AS

[Time > 802.1AS]

The protocol 802.1AS is a procedure specified in IEEE 802.1AS-2020 that defines how to synchronize time accurately between devices in the network. When you use the protocol 802.1AS over the Ethernet, you can think of the protocol as a profile of IEEE 1588-2019.

With the *Best Master Clock Algorithm*, the devices in the network determine which device has the most accurate time. The devices use the device with the most accurate time as the reference time source (*Grandmaster*). Subsequently, the participating devices synchronize themselves with this reference time source.

The 802.1AS function has the following specifications:

- In the device, either the 802.1AS function or the PTP function can be enabled.
- If the *SNTP* function and the *802.1AS* function are enabled in the device at the same time, then the *802.1AS* function has priority.
- The 802.1AS function supports 2 PTP instances, each associated with a domain ID.

The menu contains the following dialogs:

- 802.1AS Global
- ▶ 802.1AS Port
- ▶ 802.1AS Statistics

2.4.1 802.1AS Global

[Time > 802.1AS > Global]

In this dialog, you specify basic settings for the 802.1AS function.

Operation

Operation

Enables/disables the 802.1AS function.

Possible values:

▶ On

The *802.1AS* function is enabled. The device synchronizes its clock using the *802.1AS* function. Consider activating the *802.1AS* function for each instance and also on the individual ports.

Off (default setting) The 802.1AS function is disabled.

Configuration

Sync lower bound [ns]

Specifies the lower threshold value in nanoseconds for the measured time difference between the local clock and the reference time source (*Grandmaster*). If the measured time difference falls below this value, then the device considers its local clock to be synchronized.

Possible values:

```
▶ 0..999999999 (10°-1) (default setting: 30)
```

Sync upper bound [ns]

Specifies the upper threshold value in nanoseconds for the measured time difference between the local clock and the reference time source (*Grandmaster*). If the measured time difference exceeds this value, then the device considers its local clock to be unsynchronized.

Possible values:

```
31..100000000 (10°) (default setting: 5000)
```

Status

This frame displays the synchronization settings of the device for Instance 0.

Offset to master [ns]

Displays the measured difference (offset) between the local clock and the reference time source (*Grandmaster*) in nanoseconds. The device calculates the difference from the received time information.

Steps removed

Displays the number of communication paths passed through between the local clock of the device and the reference time source (*Grandmaster*).

When the device operates in the *Slave* role, the value 1 means that the device is connected with the reference time source (*Grandmaster*) directly through one communication path.

Clock identity

Displays the clock identification number of the device.

The device displays the identification number as a byte sequence in hexadecimal notation.

The device identification number consists of the MAC address of the device followed by:

- 00:01 for Instance 0
- 00:02 for Instance 1

Max. offset absolute [ns]

Displays the maximum measured time difference in nanoseconds that has occurred since the device synchronized its local clock with the reference time source (*Grandmaster*).

Is synchronized

Displays if the local clock is synchronized with the reference time source (Grandmaster).

If the measured time difference between the local clock and the reference time source (*Grandmaster*) falls below the synchronization lower threshold value, then the device considers its local clock to be synchronized. The device keeps this status until the measured time difference exceeds the synchronization upper threshold value.

You specify the synchronization threshold values in the Configuration frame.

Grandmaster

This frame displays the criteria that the *Best Master Clock Algorithm* uses when determining the reference time source (*Grandmaster*) for *Instance 0*.

The device uses the *Best Master Clock Algorithm* of PTP to first evaluate the value in the *Priority 1* field of the participating devices. The device with the numerically lowest *Priority 1* value becomes the reference time source (*Grandmaster*). When these values are the same for multiple devices, the algorithm uses the second-highest criterion to make a decision. When these values are also the same for multiple devices, the algorithm uses the third-highest criterion. If these values are also the same for multiple devices, then the numerically lowest *Clock identity* value decides which device becomes the reference time source (*Grandmaster*).

The device lets you influence which device in the network is designated as the reference time source (*Grandmaster*). To do this, modify the value in the *Priority 1* field or the *Priority 2* field in the *Time > 802.1AS > Global* frame.

Priority 1

Displays the *priority 1* value for the device that is currently the reference time source (*Grandmaster*).

Clock class

Displays the class of the reference time source (*Grandmaster*). This is a parameter used by the *Best Master Clock Algorithm*.

Clock accuracy

Displays the estimated accuracy of the reference time source (*Grandmaster*). This is a parameter used by the *Best Master Clock Algorithm*.

Clock variance

Displays the variance of the reference time source (*Grandmaster*), also known as the *Offset scaled log variance*. This is a parameter used by the *Best Master Clock Algorithm*.

Priority 2

Displays the *priority* 2 value for the device that is currently the reference time source (*Grandmaster*).

Clock identity

Displays the identification number of the reference time source (Grandmaster) device.

The device identification number consists of the MAC address of the device followed by:

- 00:01 for Instance 0
- 00:02 for Instance 1

Parent

This frame displays the settings of the directly superior master device for Instance 0.

Clock identity

Displays the port identification number of the directly superior master device.

The device identification number consists of the MAC address of the device followed by:

- 00:01 for Instance 0
- 00:02 for Instance 1

Port

Displays the port number of the directly superior master device.

Cumulative rate ratio [ppm]

Displays the measured frequency difference of the local clock in ppm (parts per million) relative to the reference time source (*Grandmaster*).

2.4.2 802.1AS Port

[Time > 802.1AS > Port]

In this dialog, you specify the 802.1AS settings for each instance and on each individual port.

[Instance]

The 802.1AS function supports 2 instances: *Instance 0* and *Instance 1*, each associated with a separate *PTP domain*. The device can be part of multiple *PTP domains*.

You set up each instance separately:

- Instance 0 for synchronizing device clock
- Instance 1 for the transmission of time synchronization messages

Operation

Operation

Enables/disables the 802.1AS function for the respective instance.

Possible values:

▶ On

The *802.1AS* function is enabled. The device synchronizes its local clock using the *802.1AS* function. Consider activating the *802.1AS* function on the individual ports.

Off (default setting)
 The 802.1AS function is disabled.

Configuration

Priority 1

Specifies the priority 1 value for the instance.

Possible values:

0..255 (default setting: 248) Verify that you use the value 255 for a PTP instance that is not Grandmaster-capable.

Priority 2

Specifies the *priority 2* value for the instance.

Possible values:

0..255 (default setting: 247) Verify that you use the value 255 for a PTP instance that is not Grandmaster-capable. Domain number

Specifies the domain number.

If a port is part of the same domain for both *Instance 0* and *Instance 1*, then the dialog displays an error message.

Possible values:

▶ 0..127 (default settings: 0 for Instance 0 and 1 for Instance 1)

External port configuration

Activates/deactivates the manual setup of the port roles.

Possible values:

- marked Manual setup is active. You can select the desired port roles from the *Desired Role* drop-down list.
 unmarked (default setting)
- Manual setup is inactive. The device auto-negotiates port roles.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Active

Activates/deactivates the 802.1AS function on the port.

Possible values:

- marked (default setting) The 802.1AS function is active on the port. On the port, the device synchronizes its clock using the 802.1AS function. The prerequisite is that none of the following protocols are active on the port:
 PRP
 HSR
 - Link Aggregation
- unmarked

The 802.1AS function is inactive on the port.

Role

Displays the current role that the port operates in within the 802.1AS domain.

Possible values:

Disabled

The port is not 802.1AS-capable.

🕨 Master


The port operates in the *Master* role.

Passive

The port operates in the *Passive* role.

SLave

The port operates in the *SLave* role.



Inspired by: IEEE Std 802.1AS-2020

Desired Role

Specifies the desired role for the port. If the checkbox in the *External port configuration* column is marked, then auto-negotiation of port roles is disabled. You can then manually set the desired port role.

Possible values:

Disabled

The port is not 802.1AS-capable.

▶ Master

The port operates in the Master role.

Passive

The port operates in the *Passive* role.

Slave

The port operates in the *SLave* role.

AS capable

Displays if the device port and the neighboring are both *802.1AS*-capable and have the *802.1AS* function enabled.

Possible values:

marked

The connected ports are *802.1AS*-capable and have the *802.1AS* function enabled. The prerequisites are:

- The checkbox in the Measuring delay column is marked. The device measures the delay (Peer delay) on the port.
- The value you specify in the *Peer delay threshold [ns]* column is higher than the value in the *Peer delay [ns]* column.
- unmarked (default setting)

At least one of the connected ports is not 802.1AS-capable or does not have the 802.1AS function enabled.

Initial announce interval [s]

Specifies the interval in seconds at which the port, in the *Master* role, sends *Announce* messages for *802.1AS* topology discovery.

Possible values:

```
1..2 (default setting: 1)
```

Assign the same value to every device of an 802.1AS domain.

The port does not send Announce messages.

Settable announce interval [s]

Specifies the interval in seconds at which the port, in the *Master* role, sends *Announce* messages for *802.1AS* topology discovery.

If the checkbox in the *Use settable announce interval* column is marked, then the device uses this value instead of the value specified in the *Initial announce interval* [s] column. During the first synchronization, the device uses the value in the *Initial announce interval* [s] column even if the *Use settable announce interval* checkbox is marked.

Possible values:

▶ 1...2 (default setting: 1)

Assign the same value to every device of an 802.1AS domain.

The port does not transmit Announce messages.

Use settable announce interval

Activates/deactivates the use of the interval specified in the Settable announce interval [s] column for sending Announce messages. The device sends Announce messages for 802.1AS topology discovery.

Possible values:

marked (default setting)

The device sends *Announce* messages in the interval specified in the *Settable announce interval* [s] column.

unmarked

The device sends *Announce* messages in the interval specified in the *Initial announce interval* [s] column.

Announce timeout

Specifies the number of *Announce* intervals that the device waits for to receive an *Announce* message on this port from the neighboring port.

Example: In the default setting, where Settable announce interval [s] = 1 and Announce timeout = 3, the total timeout in seconds is $1 \le 3 \le 3 \le 3$.

When the specified interval elapses without receiving an *Announce* message, the device tries to find a new path to the reference time source (*Grandmaster*) using the *Best Master Clock Algorithm*. If the device finds a reference time source (*Grandmaster*), then it assigns the *SLave* role to the port through which the new path leads. If the device does not find a reference time source (*Grandmaster*), the device itself becomes the reference time source (*Grandmaster*) and assigns the *Master* role to its ports.

Possible values:

2..10 (default setting: 3)

Assign the same value to each port that belongs to the same 802.1AS domain.

Initial sync interval [s]

Specifies the interval in seconds at which the port, in the *Master* role, sends *Sync* messages for time synchronization.

Possible values:

0.125 (default setting)
0.250
0.5
1
-The port does not send *Sync* messages.

Settable sync interval [s]

Specifies the interval in seconds at which the port, in the *Master* role, sends *Sync* messages for time synchronization.

If the checkbox in the *Use settable sync interval* column is marked, then the device uses this value instead of the value specified in the *Initial sync interval* [s] column. During the first synchronization, the device uses the value in the *Initial sync interval* [s] column even if the *Use settable sync interval* checkbox is marked.

Possible values:

- 0.125 (default setting)
 0.250
- ▶ 0.5
- 1

The port does not send Sync messages.

Use settable sync interval

Activates/deactivates the use of the value in the Settable sync interval [s] column for sending Sync messages.

Possible values:

marked (default setting)

The device sends *Sync* messages in the interval specified in the *Settable sync interval* [s] column.

unmarked

The device sends Sync messages in the interval specified in the Initial sync interval [s] column.

Sync timeout

Specifies the number of *Sync* intervals the device waits for to receive a *Sync* message on this port from the neighboring port.

Example: In the default setting, where *Settable sync interval* [s] = 0.125 and *Sync timeout* = 3, the total timeout in seconds is 0.125 s × 3 = 0.375 s.

When the number of intervals elapses without receiving a *Sync* message, the device tries to find a new path to the reference time source using the *Best Master Clock Algorithm*. If the device finds a reference time source (*Grandmaster*), then it assigns the *SLave* role to the port through which the new path leads. Otherwise, the device itself becomes the reference time source (*Grandmaster*) and assigns the *Master* role to its ports.

Possible values:

```
2..10 (default setting: 3)
Assign the same value to each port that belongs to the same 802.1AS domain.
```

Initial pdelay interval [s]

Specifies the interval in seconds at which the port sends a *Peer delay request* message to the neighboring port to measure the *Peer delay*.

Possible values:

1 (default setting)
2
4
8
-The port does not send *Peer delay request* messages.

Settable pdelay interval [s]

Specifies the interval in seconds at which the port sends a *Peer delay request* message to the neighboring port to measure the *Peer delay*.

If the checkbox in the Use settable pdelay interval column is marked, then the devices uses this value instead of the value specified in the Initial pdelay interval [s] column. During the first synchronization, the device uses the value in the Initial pdelay interval [s] column even if the Use settable pdelay interval checkbox is marked.

Possible values:

- 1 (default setting)
- 2
- ▶ 4

8

The port does not send Peer delay request messages.

Use settable pdelay interval

Activates/deactivates the use of the value in the Settable pdelay interval [s] column for sending Peer delay request messages.

Possible values:

marked

The device sends *Peer delay request* messages in the interval specified in the *Settable pdelay interval* [s] column.

unmarked (default setting) The device sends *Peer delay request* messages in the interval specified in the *Initial pdelay interval* [s] column.

Initial GptpCapable interval [s]

Specifies the interval in seconds at which the port sends a message to the neighboring port about the device capability for time synchronization.

Possible values:

1 (default setting)
2
4
8
-The port does not send *gPTP-capable* messages.

Settable GptpCapable interval [s]

Specifies the interval in seconds at which the port sends a message to the neighboring port about the device capability for time synchronization.

If the checkbox in the *Use settable GptpCapable interval* column is marked, the device uses this value instead of the value specified in the *Initial GptpCapable interval* [s] column. During the first synchronization, the device uses the value in the *Initial GptpCapable interval* [s] column even if the *Use settable GptpCapable interval* checkbox is marked.

Possible values:

- 1 (default setting)
- 2
- ▶ 4
- ▶ 8

The port does not send gPTP-capable messages.

Use settable GptpCapable interval

Activates/deactivates the use of the value in the *Settable GptpCapable interval* [s] column for sending messages that contain *gPTP-capable* information.

Possible values:

marked

The device sends *gPTP-capable* messages in the interval specified in the *Settable GptpCapable interval* [s] column.

unmarked (default setting) The device sends gPTP-capable messages in the interval specified in the Initial GptpCapable interval [s] column.

GptpCapable timeout

Specifies the number of *gPTP-capable* intervals that the device waits for to receive a *gPTP-capable* message on this port from the neighboring port.

When the number of intervals elapses without receiving a *gPTP-capable* message, the device assigns the *Disabled* role to the port. The port is no longer *gPTP-capable*.

Possible values:

1..255 (default setting: 9)

Peer delay timeout

Specifies the number of *Peer delay* intervals that the device waits for to receive a *Peer delay* message from the neighboring port.

When the number of intervals elapses without receiving a *Peer delay* message, the device assigns the *Disabled* role to the port. The port is no longer *802.1AS*-capable. See the *AS capable* column.

Possible values:

1..255 (default setting: 9)

Allowed faults

Specifies the number of detected faults above which the device no longer considers the port as *802.1AS*-capable. The device assigns the *Disabled* role to the port.

Examples of such detected faults are:

- The Peer delay threshold [ns] value exceeds the upper threshold.
- The calculated Neighbor rate ratio [ppm] is invalid.

```
Possible values:
```

1..255 (default setting: 9)

Peer delay threshold [ns]

Specifies the upper threshold value for the *Peer delay* in nanoseconds. If the value in the *Peer delay* [*ns*] column is greater than this value, then the device assigns the *DisabLed* role to the port. The port is no longer 802.1AS-capable. See the AS capable column.

Possible values:

0..1000000 (10⁶) (default setting: 10000)

Measuring delay

Displays if the device measures the delay (Peer delay) on the port.

Possible values:

marked

The device measures the delay (*Peer delay*) on the port. You find the measured value in the *Peer delay* [ns] column.

unmarked

The device does not measure the delay (Peer delay) on the port.

Peer delay [ns]

Displays the *Peer delay* value in nanoseconds the device measured. The prerequisite is that the checkbox in the *Measuring delay* column is marked.

Asymmetry

Specifies the time difference in nanoseconds between the mean link delay value (*Peer delay [ns] /* 2) and the propagation time from the port to its neighbor.

Possible values:

-10000000000..1000000000 (10¹⁰) (default setting: 0)

Neighbor rate ratio [ppm]

Displays the measured frequency difference of the local clock in parts per million relative to the clock in the adjacent device.

2.4.3 802.1AS Statistics

[Time > 802.1AS > Statistics]

This dialog displays information about the number of messages received, sent, or discarded on the ports. The dialog also displays counters that increment every time a timeout event occurred.

[Instance]

The device displays information for each instance separately.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Received messages

Displays the counters for messages received on the ports.

Sync

Displays the number of Sync messages.

Sync follow-up

Displays the number of Sync follow-up messages.

Delay request

Displays the number of *Peer delay request* messages.

Delay response

Displays the number of Peer delay response messages.

Delay response follow-up

Displays the number of Peer delay response follow-up messages.

Announce

Displays the number of Announce messages.

Discarded

Displays the number of *Sync* messages that the device discarded on this port. The device discards a *Sync* message for example, in cases where the port does not receive a *Sync follow-up* message for a corresponding *Sync* message.

Sync timeout

Displays the number of times that a *Sync timeout* event occurred on the port. See the *Sync timeout* column in the *Time* > 802.1AS > Port dialog.

Announce timeout

Displays the number of times that the *Announce timeout* event occurred on this port. See the *Announce timeout* column in the *Time* > 802.1AS > Port dialog.

Delay timeout

Displays the number of times that the *Peer delay timeout* event occurred on this port. See the *Peer delay timeout* column in the *Time* > 802.1AS > Port dialog.

Transmitted messages

Displays the counters for messages transmitted on the ports:

Sync

Displays the number of Sync messages.

Sync follow-up

Displays the number of Sync follow-up messages.

Delay request

Displays the number of Peer delay request messages.

Delay response

Displays the number of *Peer delay response* messages.

Delay response follow-up

Displays the number of Peer delay response follow-up messages.

Announce

Displays the number of Announce messages.

3 Device Security

The menu contains the following dialogs:

- User Management
- Authentication List
- ► LDAP
- Management Access
- Pre-login Banner
- SSH Known Hosts

3.1 User Management

[Device Security > User Management]

If users log into the device management with valid login data, then the device lets them have access to its device management.

In this dialog, you manage the users of the local user management. You also specify the following settings here:

- Settings for the login
- Settings for saving the passwords
- Specify policy for valid passwords

The methods that the device uses for the authentication you specify in the *Device Security* > Authentication List dialog.

Configuration

This frame lets you specify settings for the login.

Login attempts

Specifies the number of possible consecutive unsuccessful login attempts when the user accesses the device management using the Graphical User Interface or the Command Line Interface.

Note: When accessing the device management using the Command Line Interface through the serial connection, the number of unsuccessful consecutive login attempts is unlimited.

Possible values:

0..5 (default setting: 0)

If the user makes one more consecutive unsuccessful login attempt, then the device locks access for the user.

The device lets only users with the *administrator* authorization remove the lock.

The value 0 deactivates the lock. The user has unlimited attempts to log into the device management.

Min. password length

The device accepts the password if it contains at least the number of characters specified here.

The device checks the password according to this setting, regardless of the setting for the *Policy check* checkbox.

Possible values:1..64 (default setting: 6)

Login attempts period (min.)

Displays the time period before the device resets the counter in the Login attempts field.

Possible values:0..60 (default setting: 0)

Password policy

This frame lets you specify the policy for valid passwords. The device checks every new password and password change according to this policy.

The settings effect the *Password* column. The prerequisite is that the checkbox in the *Policy check* column is marked.

Upper-case characters (min.)

The device accepts the password if it contains at least as many upper-case letters as specified here.

Possible values:0..16 (default setting: 1)

The value 0 deactivates this setting.

Lower-case characters (min.)

The device accepts the password if it contains at least as many lower-case letters as specified here.

Possible values:

▶ 0..16 (default setting: 1)

The value 0 deactivates this setting.

Digits (min.)

The device accepts the password if it contains at least as many numbers as specified here.

Possible values:

0..16 (default setting: 1)

The value 0 deactivates this setting.

Special characters (min.)

The device accepts the password if it contains at least as many special characters as specified here.

Possible values:0..16 (default setting: 1)

The value 0 deactivates this setting.

Table

Every user requires an active user account to gain access to the device management. The table lets you set up and manage user accounts. To change settings, click the desired parameter in the table and modify the value.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

- In the User name field, you specify the name of the user account.
 Possible values:
 - Alphanumeric ASCII character string with 1..32 characters



Removes the selected table row.

User name

Displays the name of the user account.

To add a user account, click the $\overset{\texttt{HH}}{+}$ button.

Active

Activates/deactivates the user account.

Possible values:

marked

The user account is active. The device accepts the login of a user, to the device management, with this user name.

unmarked (default setting) The user account is inactive. The device rejects the login of a user, to the device management, with this user name.

When one user account exists with the access role *administrator*, this user account is constantly active.

Password

Specifies the password that the user applies to access the device management using the Graphical User Interface or Command Line Interface.

Displays ***** (asterisks) instead of the password with which the user logs into the device management. To change the password, click the relevant field.

When you specify the password for the first time, the device uses the same password in the *SNMP auth password* and *SNMP encryption password* columns.

- The device lets you specify different passwords in the SNMP auth password and SNMP encryption password columns.
- If you change the password in the current column, then the device also changes the passwords for the SNMP auth password and SNMP encryption password columns, but only if they are not individually specified previously.

Possible values:

- Alphanumeric ASCII character string with 6..64 characters The device accepts the following characters:
 - a..z — A..Z
 - 0..9
 - $! \# \ () *+, -./:; <=> ?@[\]^_`{}~$

The minimum length of the password is specified in the *Configuration* frame. The device differentiates between upper and lower case.

If the checkbox in the *Policy check* column is marked, then the device checks the password according to the policy specified in the *Password policy* frame.

The device constantly checks the minimum length of the password, even if the checkbox in the *Policy check* column is unmarked.

Role

Specifies the access role that regulates the access of the user to the individual functions of the device.

Possible values:

unauthorized

The user is blocked, and the device rejects the user login to the device management. Assign this value to temporarily lock the user account. If the device detects an error when another access role is being assigned, then the device assigns this access role to the user account.

guest (default setting)

The user is authorized to monitor the device.

auditor

The user is authorized to monitor the device and to save the log file in the *Diagnostics* > *Report* > Audit Trail dialog.

operator

The user is authorized to monitor the device and to change the settings – with the exception of security settings for device access.

administrator

The user is authorized to monitor the device and to change the settings.

The device assigns the Service Type transferred in the response of a RADIUS server as follows to an access role:

- Administrative-User: administrator
- Login-User: operator
- NAS-Prompt-User: guest

User locked

Unlocks the user account.

Possible values:

marked

The user account is locked. The user has no access to the device management. If the user makes too many consecutive unsuccessful login attempts, then the device automatically locks the user.

unmarked (grayed out) (default setting) The user account is unlocked. The user has access to the device management.

Policy check

Activates/deactivates the password check.

Possible values:

- marked
 - The password check is activated.

When you set up or change the password, the device checks the password according to the policy specified in the *Password policy* frame.

unmarked (default setting) The password check is deactivated.

SNMP auth type

Specifies the authentication protocol that the device applies for user access using SNMPv3.

Possible values:

- hmacmd5 (default setting) For this user account, the device uses protocol HMACMD5.
- hmacsha

For this user account, the device uses protocol HMACSHA.

SNMP auth password

Specifies the password that the device applies for user access using SNMPv3.

Displays ***** (asterisks) instead of the password with which the user logs into the device management. To change the password, click the relevant field.

By default, the device uses the same password that you specify in the Password column.

- For the current column, the device lets you specify a different password than in the *Password* column.
- If you change the password in the *Password* column, then the device also changes the password for the current column, but only if it is not individually specified.

Possible values:

- Alphanumeric ASCII character string with 6..64 characters The device accepts the following characters:
 - a..z
 - A..Z
 - 0..9
 - !#\$%&'()*+,-./:;<=>?@[\]^_`{}~

SNMP encryption type

Specifies the encryption protocol that the device applies for user access using SNMPv3.

Possible values:

- none No encryption.
- des (default setting) DES encryption
- aesCfb128 AES128 encryption

SNMP encryption password

Specifies the password that the device applies to encrypt user access using SNMPv3.

Displays ***** (asterisks) instead of the password with which the user logs into the device management. To change the password, click the relevant field.

By default, the device uses the same password that you specify in the Password column.

- For the current column, the device lets you specify a different password than in the *Password* column.
- If you change the password in the *Password* column, then the device also changes the password for the current column, but only if it is not individually specified.

Possible values:

- Alphanumeric ASCII character string with 6..64 characters The device accepts the following characters:
 - a..z
 - A..Z
 - 0..9
 - !#\$%&'()*+,-./:;<=>?@[\]^_`{}~

3.2 Authentication List

[Device Security > Authentication List]

In this dialog, you manage the authentication lists. In an authentication list you specify which method the device uses for the authentication. You also have the option to assign pre-defined applications to the authentication lists.

If users log in with valid login data, then the device lets them have access to its device management. The device authenticates the users using the following methods:

- User management of the device
- LDAP
- RADIUS

With the port-based access control according to IEEE 802.1X, if connected end devices log in with valid login data, then the device lets them have access to the network. The device authenticates the end devices using the following methods:

- RADIUS
- IAS (Integrated Authentication Server)

In the default setting the following authentication lists are available:

- defaultDot1x8021AuthList
- defaultLoginAuthList
- defaultV24AuthList

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Note: If the table does not contain a list, then the access to the device management is only possible using the Command Line Interface through the serial interface of the device. In this case, the device authenticates the user by using the local user management. See the *Device Security > User Management* dialog.

Buttons



Opens the Create window to add a table row.

- In the *Name* field, you specify the name of the list. Possible values:
 - ▶ Alphanumeric ASCII character string with 1..32 characters

Remove

Removes the selected table row.

Allocate applications

Opens the *Allocate applications* window. The window displays the applications that you can designate to the selected list.

- Click and select an item to designate it to the currently selected list. An application that is already designated to a different list the device designates to the currently selected list, after you click the *Ok* button.
- Click and deselect an item to undo its designation to the currently selected list.
 If you deselect the application WebInterface, then the connection to the device is lost, after you click the Ok button.

Name

Displays the name of the list.

To add a list, click the $\stackrel{\textbf{III}}{+}$ button.

Policy 1 Policy 2 Policy 3

Policy 4

Policy 4 Policy 5

Specifies the authentication policy that the device uses for access using the application specified in the *Dedicated applications* column.

The device gives you the option of a fall-back solution. For this, you specify another policy in each of the policy fields. If the authentication with the specified policy is unsuccessful, then the device can use the next policy, depending on the order of the values entered in each policy.

Possible values:

Local (default setting)

The device authenticates the users by using the local user management. See the *Device Security* > *User Management* dialog.

You cannot assign this value to the authentication list defaultDot1x8021AuthList.

radius

The device authenticates the users with a RADIUS server in the network. You specify the RADIUS server in the *Network Security* > *RADIUS* > *Authentication Server* dialog.

reject

The device accepts or rejects the user logging into the device management depending on which policy you try first. The following list contains authentication scenarios:

- If the first policy in the authentication list is *LocaL* and the device accepts the login credentials
 of the user, then it logs the user into the device management without attempting the other
 polices.
- If the first policy in the authentication list is *local* and the device denies the login credentials
 of the user, then it attempts to log the user into the device management using the other
 polices in the order specified.
- If the first policy in the authentication list is *radius* or *Ldap* and the device rejects a login, then the login is immediately rejected without attempting to log in the user using another policy. If there is no response from the RADIUS or LDAP server, then the device attempts to authenticate the user with the next policy.

- If the first policy in the authentication list is *reject*, then the devices immediately rejects the user login without attempting another policy.
- Verify that the authentication list defaultV24AuthList contains at least one policy different from *reject*.
- ▶ ias

The device authenticates the end devices logging in using 802.1X with the integrated authentication server (IAS). The integrated authentication server manages the login data in a separate database. See the *Network Security* > 802.1X > IAS dialog.

You can only assign this value to the authentication list defaultDot1x8021AuthList.

🕨 Ldap

The device authenticates the users with authentication data and access role saved in a central location. You specify the Active Directory server that the device uses in the *Device Security* > LDAP > *Configuration* dialog.

Dedicated applications

Displays the dedicated applications. When users access the device with the relevant application, the device uses the specified policies for the authentication.

To allocate another application to the list or remove the allocation, click the 🖨 button. The device lets you assign each application to exactly one list.

Active

Activates/deactivates the list.

Possible values:

- marked (default setting) The list is activated. The device uses the policies in this list when users access the device with the relevant application.
- unmarked The list is deactivated.

3.3 LDAP

[Device Security > LDAP]

The Lightweight Directory Access Protocol (LDAP) lets you authenticate and authorize the users at a central point in the network. A widely used directory service accessible through LDAP is Active Directory[®].

The device forwards the login data of the user to the authentication server using the Lightweight Directory Access Protocol (LDAP). The authentication server decides if the login data is valid and transfers the authorizations of the user to the device.

Upon successful login, the device caches the login data. This speeds up the login process when users log into the device management again. In this case, no complex LDAP search operation is necessary.

The menu contains the following dialogs:

LDAP Configuration

LDAP Role Mapping

3.3.1 LDAP Configuration

[Device Security > LDAP > Configuration]

This dialog lets you specify up to 4 authentication servers. An authentication server authenticates and authorizes the users when the device forwards the login data to the server.

The device sends the login data to the first authentication server. When no response comes from this server, the device contacts the next server in the table.

Operation

Operation

Enables/disables the LDAP client.

If in the *Device Security > Authentication List* dialog you specify the value ldap in one of the columns *Policy 1* to *Policy 5*, then the device uses the *LDAP* client. Prior to this, specify in the *Device Security >* LDAP *> Role Mapping* dialog at least one mapping for this access role *administrator*. This provides you access to the device as administrator after logging into the device management through LDAP.

Possible values:

▶ On

The LDAP client is enabled.

Off (default setting)
 The *LDAP* client is disabled.

Configuration

Buttons



Removes the cached login data of the successfully logged in users.

Client cache timeout [min]

Specifies for how many minutes after successfully logging into the device management the login data of a user remain valid. When a user logs in again within this time, no complex LDAP search operation is necessary. The login process is much faster.

Possible values:

1..1440 (default setting: 10)

Bind user

Specifies the user ID in the form of the "Distinguished Name" (DN) with which the device logs into the LDAP server.

If the LDAP server requires a user ID in the form of the "Distinguished Name" (DN) for the login, then this information is necessary. In Active Directory environments, this information is unnecessary.

The device attempts to authenticate on the LDAP server with the user ID to find the "Distinguished Name" (DN) for the users logging into the device management. The device conducts the search according to the settings in the *Base DN* and *User name attribute* fields.

Possible values:

Alphanumeric ASCII character string with 0..64 characters

Bind user password

Specifies the password which the device uses together with the user ID specified in the *Bind user* field when logging into the LDAP server.

Possible values:

Alphanumeric ASCII character string with 0..64 characters

Base DN

Specifies the starting point for the search in the directory tree in the form of the "Distinguished Name" (DN).

Possible values:

Alphanumeric ASCII character string with 0..255 characters

User name attribute

Specifies the LDAP attribute which contains a biunique user name. Afterwards, the user uses the user name contained in this attribute to log into the device management.

Often the LDAP attributes userPrincipalName, mail, sAMAccountName and uid contain a unique user name.

The device adds the character string specified in the *Default domain* field to the user name under the following condition:

- The user name contained in the attribute does not contain the @ character.
- In the *Default domain* field, a domain name is specified.

Possible values:

Alphanumeric ASCII character string with 0..64 characters (default setting: userPrincipalName) Default domain

Specifies the character string which the device adds to the user name of the users logging in if the user name does not contain the @ character.

Possible values:

▶ Alphanumeric ASCII character string with 0..64 characters

Certificates/CRLs

To establish a secure connection, the device requires to obtain a valid digital certificate to verify the identity of the server. The prerequisite is that you have transferred the public certificate of the server onto the device. Ask the server administrator for a digital certificate in X.509 format. For security reasons, Hirschmann recommends using only digital certificates signed by a Certification Authority (CA).

A Certificate Revocation List (CRL) contains a list of digital certificates revoked by the Certification Authority (CA) before their scheduled expiration date. When establishing a secure connection to the server, the device stops setting up the connection if the CRL includes the public certificate of the server. The device logs the event in the System Log. For security reasons, Hirschmann recommends using only CRLs signed by a Certification Authority (CA).

Buttons

Clear all Certificates/CRLs

Deletes the digital certificates and CRLs transferred onto the device from the non-volatile memory (NVM).

URL

Specifies the path and file name of the digital certificate or CRL.

The device accepts digital certificates and CRLs with the following properties:

- X.509 format
- . PEM file name extension
 - Base64-coded and enclosed by the lines
 -----BEGIN CERTIFICATE----...
 or
 -----BEGIN CRL----...
 ...
 -----END CRL-----

The device gives you the following options for transferring the file onto the device:

Import from the PC

When the file is located on your PC or on a network drive, drag and drop it onto the 1 area. As an alternative, click in the area to select the file.

 Import from an FTP server
 This option is not recommended if you transmit data over untrusted networks.
 When the file is on an FTP server, specify the URL for the file in the following form: ftp://<user>:<password>@<IP address>[:port]/<path>/<file name>

Import from a TFTP server

This option is not recommended if you transmit data over untrusted networks. When the file is on a TFTP server, specify the URL for the file in the following form: tftp://<IP address>/<path>/<file name>

- Import from an SCP or SFTP server
 - When the file is on an SCP or SFTP server, specify the URL for the file in the following form: scp:// or sftp://<IP address/<path>/<file name>
 - Click the *Start* button to open the *Credentials* window. In this window, you enter the *User name* and *Password* to log into the server.

scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name> Remember to set up the SCP or SFTP server as an SSH known host before the device accesses the server for the first time. See the *Device Security* > SSH Known Hosts dialog.

Start

Transfers the file specified in the URL field onto the device.

In this dialog, you can transfer a maximum of 16 digital certificates and additionally a maximum of 16 CRLs onto the device.

For the changes to take effect after transferring a digital certificate or a CRL into the device, disable and re-enable the *LDAP* function. See the *Operation* frame.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Adds a table row.



Removes the selected table row.

Index

Displays the index number to which the table row relates. The device automatically assigns the value when you add a table row.

Description

Specifies the description.

You have the option to describe here the authentication server or note additional information.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Address

Specifies the IP address or the DNS name of the server.

If in the *Connection security* column a value other than *none* is specified and the digital certificate contains only DNS names of the server, then specify a DNS name.

Possible values:

- Valid IPv4 address (default setting: 0.0.0.0)
- Valid IPv6 address
- DNS name in the format <domain>.<tld> or <host>.<domain>.<tld> The prerequisite is that you also enable the *Client* function in the *Advanced* > *DNS* > *Client* > *Global* dialog.

To establish an encrypted connection using a digital certificate, verify that the Common Name or Subject Alternative Name information in the digital certificate that you have transferred onto the device matches the value you specify here. Otherwise, the device will not be able to verify the identity of the server.

_ldap._tcp.<domain>.<tld> Using this DNS name, the device queries the LDAP server list (SRV Resource Record) from the DNS server.

Destination TCP port

Specifies the TCP Port on which the server expects the requests.

If you have specified the value <u>ldap.tcp.domain.tld</u> in the *Address* column, then the device ignores this value.

Possible values:

```
    0..65535 (2<sup>16</sup>-1) (default setting: 389)
Exception: Port 2222 is reserved for internal functions.
```

Frequently used TCP-Ports:

- LDAP: 389
- LDAP over SSL: 636
- Active Directory Global Catalogue: 3268
- Active Directory Global Catalogue SSL: 3269

Connection security

Specifies the protocol which encrypts the communication between the device and the authentication server.

Possible values:

- none
 - No encryption.

The device establishes an LDAP connection to the server and transmits the communication including the passwords in clear text.

 ssl Encryption with SSL.
 The device establishes a TLS connection to the server and tunnels the LDAP communication over it.

startTLS (default setting)

Encryption with startTLS extension.

The device establishes an LDAP connection to the server and encrypts the communication.

The prerequisite for encrypted communication is that the device uses the correct time. If the digital certificate contains only the DNS names, then you specify the DNS name of the server in the *Address* column. Enable the *Client* function in the *Advanced* > *DNS* > *Client* > *Global* dialog.

If the digital certificate contains the IP address of the server in the *Subject Alternative Name* field, then the device is able to verify the identity of the server without the DNS setting.

Server status

Displays the connection status and the authentication with the authentication server.

Possible values:

🕨 ok

The server is reachable.

If in the *Connection security* column a value other than *none* is specified, then the device has verified the digital certificate of the server.

unreachable Server is unreachable.

▶ other

The device has not established a connection to the server yet.

Active

Activates/deactivates the use of the server.

Possible values:

marked

The device uses the server.

unmarked (default setting) The device does not use the server.

3.3.2 LDAP Role Mapping

[Device Security > LDAP > Role Mapping]

This dialog lets you set up to 64 mappings to assign an access role to users.

In the table you specify if the device assigns an access role to the user based on an attribute with a specific value or based on the group membership.

- The device searches for the attribute and the attribute value within the user object.
- By evaluating the "Distinguished Name" (DN) contained in the member attributes, the device checks group the membership.

When a user logs into the device management, the device searches for the following information on the LDAP server:

- In the related user project, the device searches for attributes specified in the mappings.
- In the group objects of the groups specified in the mappings, the device searches for the member attributes.

On this basis, the device checks any mapping.

- Does the user object contain the required attribute? or
- Is the user member of the group?

If the device does not find a match, then the user does not get access to the device.

If the device finds more than one mapping that applies to a user, then the setting in the *Matching policy* field decides. The user either obtains the access role with the more extensive authorizations or the 1st access role in the table that applies.

Configuration

Matching policy

Specifies which access role the device applies if more than one mapping applies to a user.

Possible values:

highest (default setting)

The device applies the access role with more extensive authorizations.

▶ first

The device applies the rule which has the lower value in the *Index* column to the user.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the *Create* window to add a table row.

In the *Index* field, you specify the index number.
 Possible values:
 1..64





Removes the selected table row.

Index

Displays the index number to which the table row relates. You specify the index number when you add a table row.

Role

Specifies the access role that regulates the access of the user to the individual functions of the device.

Possible values:

unauthorized

The user is blocked, and the device rejects the user login. Assign this value to temporarily lock the user account. If an error is detected when another role is being assigned, then the device assigns this access role to the user account.

guest (default setting) The user is authorized to monitor the device.

auditor

The user is authorized to monitor the device and to save the log file in the *Diagnostics* > *Report* > Audit Trail dialog.

operator

The user is authorized to monitor the device and to change the settings – with the exception of security settings for device access.

administrator

The user is authorized to monitor the device and to change the settings.

Туре

Specifies if a group or an attribute with an attribute value is specified in the *Parameter* column.

Possible values:

- attribute (default setting) The Parameter column contains an attribute with an attribute value.
- ▶ group

The Parameter column contains the "Distinguished Name" (DN) of a group.

Parameter

Specifies a group or an attribute with an attribute value, depending on the setting in the *Type* column.

Possible values:

- Alphanumeric ASCII character string with 0..255 characters
- The device differentiates between upper and lower case.
 - If in the *Type* column the value *attribute* is specified, then you specify the attribute in the form of Attribute_name=Attribute_value.
 Example: 1=Germany
 - If in the *Type* column the value *group* is specified, then you specify the "Distinguished Name" (DN) of a group.

Example: CN=admin-users,OU=Groups,DC=example,DC=com

Active

Activates/deactivates the role mapping.

Possible values:

- marked (default setting) The role mapping is active.
- unmarked

The role mapping is inactive.

3.4 Management Access

[Device Security > Management Access]

The menu contains the following dialogs:

- Server
- ► IP Access Restriction
- ▶ Web
- Command Line Interface
- SNMPv1/v2 Community

3.4.1 Server

[Device Security > Management Access > Server]

This dialog lets you set up the server services which enable users or applications to access the management of the device.

The dialog contains the following tabs:

- [Information]
- ► [SNMP]
- [Telnet]
- ▶ [SSH]
- ▶ [HTTP]
- ▶ [HTTPS]

[Information]

This tab displays as an overview which server services are enabled.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

SNMPv1

Displays if the server service is active or inactive, which authorizes access to the device using SNMP version 1. See the *SNMP* tab.

Possible values:

marked

Server service is active.

unmarked Server service is inactive.

SNMPv2

Displays if the server service is active or inactive, which authorizes access to the device using SNMP version 2. See the *SNMP* tab.

Possible values:

marked

Server service is active.

unmarked

Server service is inactive.

SNMPv3

Displays if the server service is active or inactive, which authorizes access to the device using SNMP version 3. See the *SNMP* tab.

Possible values:

marked

Server service is active.

unmarked Server service is inactive.

Telnet server

Displays if the server service is active or inactive, which authorizes access to the device using Telnet. See the *Telnet* tab.

Possible values:

marked

Server service is active.

unmarked

Server service is inactive.

SSH server

Displays if the server service is active or inactive, which authorizes access to the device using Secure Shell (SSH). See the SSH tab.

Possible values:

- marked
 - Server service is active.
- unmarked Server service is inactive.

HTTP server

Displays if the server service is active or inactive, which authorizes access to the device using the Graphical User Interface through HTTP. See the *HTTP* tab.

Possible values:

- marked
 - Server service is active.
- unmarked

Server service is inactive.

HTTPS server

Displays if the server service is active or inactive, which authorizes access to the device using the Graphical User Interface through HTTPS. See the *HTTPS* tab.

Possible values:

- marked
 - Server service is active.
- unmarked Server service is inactive.

[SNMP]

This tab lets you specify settings for the SNMP agent of the device and to enable/disable access to the device with different SNMP versions.

The SNMP agent enables access to the device management with SNMP-based applications.

Configuration

SNMPv1

Activates/deactivates the access to the device with SNMP version 1.

Possible values:

marked

SNMP version 1 access is active.

- You specify the community names in the Device Security > Management Access > SNMPv1/v2 Community dialog.
- You activate/deactivate the write access for the *read and write* authorization in the *Device* Security > Management Access > SNMPv1/v2 Community dialog.
- unmarked (default setting) SNMP version 1 access is inactive.

SNMPv2

Activates/deactivates the access to the device with SNMP version 2.

Possible values:

marked

SNMP version 2 access is active.

- You specify the community names in the Device Security > Management Access > SNMPv1/v2 Community dialog.
- You activate/deactivate the write access for the *read and write* authorization in the *Device* Security > Management Access > SNMPv1/v2 Community dialog.
- unmarked (default setting) SNMP version 2 access is inactive.

SNMPv3

Activates/deactivates the access to the device with SNMP version 3.

Possible values:

- marked (default setting) Access is activated.
- unmarked Access is deactivated.

Network management systems like Industrial HiVision use this protocol to communicate with the device.

UDP port

Specifies the number of the UDP port on which the SNMP agent receives requests from clients.

Possible values:

1..65535 (2¹⁶-1) (default setting: 161) Exception: Port 2222 is reserved for internal functions.

To enable the SNMP agent to use the new port after a change, you proceed as follows:

- \Box Click the \checkmark button.
- □ Select in the *Basic Settings > Load/Save* dialog the active configuration profile.
- \Box Click the **\Box** button to save the current settings.
- Restart the device.

SNMPover802

Activates/deactivates the access to the device through SNMP over IEEE 802.

Possible values:

- marked
 - Access is activated.
- unmarked (default setting) Access is deactivated.

[Telnet]

This tab lets you enable/disable the Telnet server in the device and specify its settings.

The Telnet server enables access to the device management remotely through the Command Line Interface. Telnet connections are unencrypted.

Operation

Telnet server

Enables/disables the Telnet server.

Possible values:

- ▶ *On* (default setting)
 - The Telnet server is enabled.

The access to the device management is possible through the Command Line Interface using an unencrypted Telnet connection.

▶ 0ff

The Telnet server is disabled.

Note: If the *SSH* server is disabled and you also disable the *Telnet* server, then the access to the Command Line Interface is only possible through the serial interface of the device.

Configuration

TCP port

Specifies the number of the TCP port on which the device receives Telnet requests from clients.

Possible values:

1..65535 (2¹⁶-1) (default setting: 23) Exception: Port 2222 is reserved for internal functions.

The server restarts automatically after the port is changed. Existing connections remain in place.

Connections

Displays how many Telnet connections are currently established to the device.

Connections (max.)

Specifies the maximum number of Telnet connections to the device that can be set up simultaneously.

Possible values:

1..5 (default setting: 5)

Session timeout [min]

Specifies the timeout in minutes. After the device has been inactive for this time, it ends the session for the user logged into the device management.

A change in the value takes effect the next time a user logs into the device management.

Possible values:

• 0

Deactivates the function. The connection remains established in the case of inactivity.

▶ 1..160 (default setting: 5)

[SSH]

This tab lets you enable/disable the SSH server in the device and specify its settings required for SSH. The server works with SSH version 2.

The SSH server enables access to the device management remotely through the Command Line Interface. SSH connections are encrypted.

The SSH server identifies itself to the clients using its public RSA key. When first setting up the connection, the client program displays the user the fingerprint of this key. The fingerprint contains a Base64-coded character sequence that is easy to check. When you make this character sequence available to the users through a reliable channel, they have the option to compare both fingerprints. If the character sequences match, then the client is connected to the correct server.

The device lets you generate the private and public keys (host keys) required for RSA directly in the device. As an alternative, transfer your own host key in PEM format onto the device.

As an alternative, the device lets you load the RSA key (host key) from an external memory during the system startup. You activate this function in the *Basic Settings* > *External Memory* dialog, *SSH key auto upload* column.

Operation

SSH server

Enables/disables the SSH server.

Possible values:

- On (default setting)
 - The SSH server is enabled.

The access to the device management is possible through the Command Line Interface using an encrypted SSH connection.

You can start the server only if there is an RSA signature in the device.

- ▶ Off
 - The SSH server is disabled.

When you disable the SSH server, the existing connections remain established. However, the device helps prevent new connections from being set up.

Note: If the *Telnet* server is disabled and you also disable the *SSH* server, then the access to the Command Line Interface is only possible through the serial interface of the device.

Configuration

TCP port

Specifies the number of the TCP port on which the device receives SSH requests from clients.

Possible values:

1..65535 (2¹⁶-1) (default setting: 22) Exception: Port 2222 is reserved for internal functions.

The server restarts automatically after the port is changed. Existing connections remain in place.

Sessions

Displays how many SSH connections are currently established to the device.

Sessions (max.)

Specifies the maximum number of SSH connections to the device that can be set up simultaneously.

Possible values:

1..5 (default setting: 5)

Session timeout [min]

Specifies the timeout in minutes. After the user logged into the device management has been inactive for this time, the device ends the connection.

A change in the value takes effect the next time a user logs into the device management.

Possible values:

▶ 0

Deactivates the function. The connection remains established in the case of inactivity.

1..160 (default setting: 5)

Signature

RSA present

Displays if an RSA host key is present in the device.

Possible values:

marked

A key is present.

unmarked No key is present.

Create

Generates a host key in the device. The prerequisite is that the SSH server is disabled.

Length of the key generated:

2048 bit (RSA)

To get the SSH server to use the generated host key, restart the SSH server.

As an alternative, transfer your own host key in PEM format onto the device. See the Key import frame.

Delete

Removes the host key from the device. The prerequisite is that the SSH server is disabled.

Oper status

Displays if the device currently generates a host key.

It is possible that another user triggered this action.

Possible values:

- 🕨 rsa
 - The device currently generates an RSA host key.
- none
 - The device does not generate a host key.

Fingerprint

The fingerprint is an easy to verify string that uniquely identifies the host key of the SSH server.

After importing a new host key, the device continues to display the existing fingerprint until you restart the server.

Fingerprint type

Specifies which fingerprint the RSA fingerprint field displays.

Possible values:

- ▶ md5
 - The RSA fingerprint field displays the fingerprint as hexadecimal MD5 hash.
- sha256 (default setting)

The RSA fingerprint field displays the fingerprint as Base64-coded SHA256 hash.

RSA fingerprint

Displays the fingerprint of the public host key of the SSH server.

When you change the settings in the *Fingerprint type* field, click afterwards the \checkmark button and then

the ${f C}$ button to update the display.

Key import

URL

Specifies the path and file name of your own RSA host key.

The device accepts the RSA key if it has the following key length:

2048 bit (RSA)

The device gives you the following options for transferring the file onto the device:

Import from the PC

When the file is located on your PC or on a network drive, drag and drop it onto the 1 area. As an alternative, click in the area to select the file.

 Import from an FTP server
 This option is not recommended if you transmit data over untrusted networks.
 When the file is on an FTP server, specify the URL for the file in the following form: ftp://<user>:<password>@<IP address>[:port]/<file name>

Import from a TFTP server

This option is not recommended if you transmit data over untrusted networks. When the file is on a TFTP server, specify the URL for the file in the following form: tftp://<IP address>/<path>/<file name>

- Import from an SCP or SFTP server
- When the file is on an SCP or SFTP server, specify the URL for the file in the following form: scp:// or sftp://<IP address/<path>/<file name>
 - Click the *Start* button to open the *Credentials* window. In this window, you enter the *User name* and *Password* to log into the server.

scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name> Remember to set up the SCP or SFTP server as an SSH known host before the device accesses the server for the first time. See the *Device Security* > SSH Known Hosts dialog.

Start

Transfers the file specified in the URL field onto the device.

For the changes to take effect after transferring a digital certificate onto the device, disable and reenable the *SSH server* function. See the *Operation* frame.

[HTTP]

This tab lets you enable/disable the Hypertext Transfer Protocol (HTTP) for the web server and specify the settings required for HTTP.

The web server provides the Graphical User Interface through an unencrypted HTTP connection. For security reasons, disable the Hypertext Transfer Protocol (HTTP) and use the Hypertext Transfer Protocol Secure (HTTPS) instead.

The device supports up to 10 simultaneous connections using HTTP or HTTPS.

Note: If you change the settings in this tab and click the \checkmark button, then the device ends the session and disconnects every opened connection. To continue working with the Graphical User Interface, log in again.

Operation

HTTP server

Enables/disables the *HTTP* function for the web server.

Possible values:

- On (default setting)
 - The *HTTP* function is enabled.

The access to the device management is possible through an unencrypted *HTTP* connection. When the *HTTPS* function is also enabled, the device automatically redirects the request for a *HTTP* connection to an encrypted *HTTPS* connection.

► Off

The HTTP function is disabled.

When the *HTTPS* function is enabled, the access to the device management is possible through an encrypted *HTTPS* connection.

Note: If the *HTTP* and *HTTPS* functions are disabled, then you can enable the *HTTP* function using the Command Line Interface command http server to get to the Graphical User Interface.

Configuration

TCP port

Specifies the number of the TCP port on which the web server receives HTTP requests from clients.

Possible values:

1..65535 (2¹⁶-1) (default setting: 80) Exception: Port 2222 is reserved for internal functions.

[HTTPS]

This tab lets you enable/disable the Hypertext Transfer Protocol Secure(HTTPS) for the web server and specify the settings required for HTTPS.

The web server provides the Graphical User Interface through an encrypted HTTP connection.

A digital certificate is required for the encryption of the HTTP connection. The device lets you generate this digital certificate yourself or to transfer an existing digital certificate onto the device.

The device supports up to 10 simultaneous connections using HTTP or HTTPS.

Note: If you change the settings in this tab and click the \checkmark button, then the device ends the session and disconnects every opened connection. To continue working with the Graphical User Interface, log in again.

Operation

HTTPS server

Enables/disables the HTTPS function for the web server.

Possible values:

- *On* (default setting)
 - The HTTPS function is enabled.

The access to the device management is possible through an encrypted *HTTPS* connection. When there is no digital certificate present, the device generates a digital certificate before it enables the *HTTPS* function.

► Off

The HTTPS function is disabled.

When the *HTTP* function is enabled, the access to the device management is possible through an unencrypted *HTTP* connection.

Note: If the *HTTP* and *HTTPS* functions are disabled, then you can enable the *HTTPS* function using the Command Line Interface command https server to get to the Graphical User Interface.

Configuration

TCP port

Specifies the number of the TCP port on which the web server receives HTTPS requests from clients.

Possible values:

1..65535 (2¹⁶-1) (default setting: 443) Exception: Port 2222 is reserved for internal functions.

Certificate

If the device uses a digital certificate not signed by a Certification Authority (CA) known to the web browser, then the web browser may display a warning message before loading the Graphical User Interface.

To address the warning, you have the following possibilities:

- Transfer a digital certificate onto the device whose Certification Authority (CA) is known to your web browser. This may additionally require you to make the Certification Authority (CA) known to your web browser or operating system.
- As a workaround, you can also add an exception rule for the existing device certificate in your web browser.

Present

Displays if a digital certificate is present in the device.

Possible values:

- marked
 - A digital certificate is present.
- unmarked
 - The digital certificate has been removed.

Create

Generates a digital certificate in the device.

Until restarting the web server uses the previous certificate.

To get the web server to use the newly generated digital certificate, restart the web server. Restarting the web server is possible only through the Command Line Interface.

As an alternative, transfer your own digital certificate onto the device. See the *Certificate import* frame.

Delete

Deletes the digital certificate.

Until restarting the web server uses the previous certificate.

Oper status

Displays if the device currently generates or deletes a digital certificate.

It is possible that another user has triggered the action.

Possible values:

▶ none

The device does currently not generate or delete a digital certificate.

▶ delete

The device currently deletes a digital certificate.

generate

The device currently generates a digital certificate.

Fingerprint

The fingerprint is an easily verified hexadecimal number sequence that uniquely identifies the digital certificate of the HTTPS server.

After importing a new digital certificate, the device displays the current fingerprint until you restart the server.

Fingerprint type

Specifies which fingerprint the *Fingerprint* field displays.

Possible values:

🕨 sha1

- The *Fingerprint* field displays the SHA1 fingerprint of the digital certificate.
- sha256 (default setting) The *Fingerprint* field displays the SHA256 fingerprint of the digital certificate.

Fingerprint

Hexadecimal character sequence of the digital certificate used by the server.

When you change the settings in the *Fingerprint type* field, click afterwards the \checkmark button and then

the ${f C}$ button to update the display.

Certificate import

URL

Specifies the path and file name of the digital certificate.

The device accepts digital certificates with the following properties:

- X.509 format
- . PEM file name extension

Base64-coded and enclosed by the lines

```
    -----BEGIN PRIVATE KEY-----
    ...
    Or
    -----BEGIN CERTIFICATE-----
    ...
    -----END CERTIFICATE-----
```

RSA key with 2048 bit length

The device gives you the following options for transferring the file onto the device:

Import from the PC

When the file is located on your PC or on a network drive, drag and drop it onto the 1 area. As an alternative, click in the area to select the file.

 Import from an FTP server
 This option is not recommended if you transmit data over untrusted networks.
 When the file is on an FTP server, specify the URL for the file in the following form: ftp://<user>:<password>@<IP address>[:port]/<path>/<file name>

Import from a TFTP server

This option is not recommended if you transmit data over untrusted networks. When the file is on a TFTP server, specify the URL for the file in the following form: tftp://<IP address>/<path>/<file name>

- Import from an SCP or SFTP server
 - When the file is on an SCP or SFTP server, specify the URL for the file in the following form: - scp://orsftp://<IP address>[:port]/<path>/<file name>
 - Click the *Start* button to open the *Credentials* window. In this window, you enter the *User name* and *Password* to log into the server.
 - scp:// or sftp://<user>:<password>@<IP address>[:port]/<path>/<file name>
 Remember to set up the SCP or SFTP server as an SSH known host before the device
 accesses the server for the first time. See the Device Security > SSH Known Hosts dialog.

Start

Transfers the file specified in the URL field onto the device.

For the changes to take effect after transferring a digital certificate onto the device, disable and reenable the *HTTPS server* function. See the *Operation* frame.

3.4.2 IP Access Restriction

[Device Security > Management Access > IP Access Restriction]

This dialog lets you restrict access to the device management from a specific IP address range for selected applications.

- If the function is disabled, then access to the device management is unrestricted. Everyone can
 access the device management from any IP address using any application.
- If the function is enabled, then access is restricted. Everyone can access the device management only under the following conditions:
 - At least one rule is active.
 - and
 - You access the device with a permitted application from a permitted IP address range specified in the rule.

Operation

Operation

Enables/disables the IP Access Restriction function.

Possible values:

▶ On

The *IP Access Restriction* function is enabled. The access to the device management is restricted.

Note: Before you enable the function, verify that the table contains at least one active rule that grants you access to the device management. Otherwise, access to the device management is only

possible using the Command Line Interface through the serial connection.

Off (default setting) The IP Access Restriction function is disabled.

Table

You have the option of defining up to 16 table rows and activating them separately.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

HAD Add

Adds a table row.



Removes the selected table row.

Displays the index number to which the table row relates. The device automatically assigns the

When you delete a table row, this leaves a gap in the numbering. When you add a table row, the

value when you add a table row.

device fills the first gap. Possible values: ▶ 1..16 Address Specifies the IP address of the network from which you allow the access to the device management. You specify the network range in the *Netmask* column. Possible values: Valid IPv4 address (default setting: 0.0.0.0) Netmask Specifies the range of the network specified in the Address column. Possible values: Valid netmask (default setting: 0.0.0.0) Example: To restrict access from a single IP address, specify the value as 255.255.255.255. HTTP Activates/deactivates the HTTP access. Possible values: marked (default setting) HTTP access is active. Access is possible from the adjacent IP address range. unmarked HTTP access is inactive. HTTPS Activates/deactivates the HTTPS access. Possible values: marked (default setting) HTTPS access is active. Access is possible from the adjacent IP address range. unmarked HTTPS access is inactive. SNMP Activates/deactivates the SNMP access. Possible values: marked (default setting) SNMP access is active. Access is possible from the adjacent IP address range. unmarked SNMP access is inactive.

Telnet

Activates/deactivates the Telnet access.

Possible values:

- marked (default setting)
- Telnet access is active. Access is possible from the adjacent IP address range.
- unmarked Telnet access is inactive.

SSH

Activates/deactivates the SSH access.

Possible values:

- marked (default setting) SSH access is active. Access is possible from the adjacent IP address range.
- unmarked SSH access is inactive.

IEC61850-MMS

Activates/deactivates the access to the MMS server.

Possible values:

- marked (default setting) IEC61850-MMS access is active. Access is possible from the adjacent IP address range.
- unmarked IEC61850-MMS access is inactive.

Modbus TCP

Activates/deactivates the access to the Modbus TCP server.

Possible values:

- marked (default setting) Modbus TCP access is active. Access is possible from the adjacent IP address range.
- unmarked Modbus TCP access is inactive.

EtherNet/IP

Activates/deactivates the access to the EtherNet/IP server.

Possible values:

- marked (default setting) Ethernet/IP access is active. Access is possible from the adjacent IP address range.
- unmarked

Ethernet/IP access is inactive.

PROFINET

Activates/deactivates the access to the PROFINET server.

Possible values:

- marked (default setting)
 - PROFINET access is active. Access is possible from the adjacent IP address range.
- unmarked PROFINET access is inactive.

Active

Activates/deactivates the table row.

Possible values:

marked (default setting)

The table row is active. The device restricts the access to the device management from the specified IP address range for the selected applications.

unmarked

The table row is inactive. The device does not restrict access to the device management from the specified IP address range for the selected applications.

3.4.3 Web

[Device Security > Management Access > Web]

In this dialog, you specify settings for the Graphical User Interface.

Configuration

Web interface session timeout [min]

Specifies the timeout in minutes. After the device has been inactive for this time, it ends the session for the user logged into the device management.

Possible values:

▶ 0..160 (default setting: 5)

The value Ø deactivates the function, and the user remains logged in when inactive.

3.4.4 Command Line Interface

[Device Security > Management Access > CLI]

In this dialog, you specify settings for the Command Line Interface. For further information about the Command Line Interface, see the "Command Line Interface" reference manual.

The dialog contains the following tabs:

▶ [Global]

[Login banner]

[Global]

This tab lets you change the prompt in the Command Line Interface and specify the automatic closing of sessions through the serial interface when they have been inactive.

The device has the following serial interfaces.

V.24 interface

Configuration

Login prompt

Specifies the character string that the device displays in the Command Line Interface at the start of every command line.

Possible values:

- Alphanumeric ASCII character string with 0..128 characters (0x20..0x7E) including space characters
 - Wildcards
 - %d date
 - %i IP address
 - %m MAC address
 - %p product name
 - %t time
 - Default setting: (RSPE)

Changes to this setting are immediately effective in the active Command Line Interface session.

Serial interface timeout [min]

Specifies the time in minutes after which the device automatically closes the session of an inactive user logged into the device management with the Command Line Interface through the serial interface.

Possible values:

▶ 0..160 (default setting: 5)

The value 0 deactivates the function, and the user remains logged into the device management when inactive.

A change in the value takes effect the next time a user logs into the device management.

For the *Telnet* server and the *SSH* server, you specify the timeout in the *Device Security* > *Management* Access > Server dialog.

[Login banner]

In this tab you replace the start screen of the Command Line Interface with your own text.

In the default setting, the start screen displays information about the device, such as the software version and the device settings. With the function in this tab, you deactivate this information and replace it with an individually specified text.

To display your own text in the Command Line Interface and in the Graphical User Interface before the login, you use the *Device Security > Pre-login Banner* dialog.

Operation

Operation

Enables/disables the Login banner function.

Possible values:

▶ On

The Login banner function is enabled.

The device displays the text information specified in the *Banner text* field to the users that log into the device management through the Command Line Interface.

Off (default setting)

The Login banner function is disabled.

The start screen displays information about the device. The text information in the *Banner text* field is kept.

Banner text

Banner text

Specifies the character string that the device displays in the Command Line Interface at the start of every session.

Possible values:

Alphanumeric ASCII character string with 0..1024 characters (0x20..0x7E) including space characters

<Tab>

<Line break>

3.4.5 SNMPv1/v2 Community

[Device Security > Management Access > SNMPv1/v2 Community]

In this dialog, you specify the community name for SNMPv1/v2 applications and activate/deactivate the write access for the *read and write* authorization.

Applications send requests using SNMPv1/v2 with a community name in the SNMP data packet header. Depending on the community name (see *Community* column) and the write access setting (see the checkbox in the *SNMP V1/V2 readOnly* column), the application gets *read-only* authorization or *read and write* authorization.

You activate the access to the device using SNMPv1/v2 in the *Device Security > Management* Access > Server dialog.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Community

Displays the authorization for SNMPv1/v2 applications to the device.

Possible values:

▶ Write

For requests with the community name entered, the application receives *read and write* authorization.

If the SNMP V1/V2 readOnly checkbox is marked, then the application receives read-only authorization.

Read

For requests with the community name entered, the application receives *read-only* authorization.

Name

Specifies the community name for the adjacent authorization.

Possible values:

- Alphanumeric ASCII character string with 0..64 characters The device accepts the following characters:
 - <space>
 - 0..9
 - a..z
 - A..Z
 - !"#\$%&'()*+,-./:;<=>?@[\]^_`{|}~

private (default setting for read and write authorization)
public (default setting for read-only authorization)

Configuration

SNMP V1/V2 readOnly

Activates/deactivates the write access for the Write community.

Possible values:

marked

The write access for the Write community is inactive. For requests with the community name entered, the application receives *read-only* authorization.

unmarked (default setting)

The write access for the Write community is active.

For requests with the community name entered, the application receives *read and write* authorization.

3.5 Pre-login Banner

[Device Security > Pre-login Banner]

This dialog lets you display a greeting or information text to users before they log into the device management.

The users see this text in the login dialog of the Graphical User Interface and of the Command Line Interface. Users logging into the device management with SSH see the text - regardless of the client used - before or during the login.

To display the text only in the Command Line Interface, use the settings in the *Device Security* > Management Access > *CLI* dialog.

Operation

Operation

Enables/disables the Pre-login Banner function.

Using the *Pre-login Banner* function, the device displays a greeting or information text in the login dialog of the Graphical User Interface and of the Command Line Interface.

Possible values:

▶ On

The Pre-login Banner function is enabled.

The device displays the text specified in the Banner text field in the login dialog.

Off (default setting) The *Pre-login Banner* function is disabled.
 The device does not display a text in the login dialog. When you enter a text in the *Banner text* field, the device saves this text.

Banner text

Banner text

Specifies information text that the device displays in the login dialog of the Graphical User Interface and of the Command Line Interface.

Possible values:

Alphanumeric ASCII character string with 0..512 characters (0x20..0x7E) including space characters

<Tab>

<Line break>

3.6 SSH Known Hosts

[Device Security > SSH Known Hosts]

The device only permits SSH-based connections from or to remote servers that are known to the device. In the state on delivery, no remote server is set up as a known host on the device.

In this dialog, you make the remote servers known by their public key fingerprints. You can set up a maximum of 50 public key fingerprints. The device verifies the identity of the remote server by comparing the public key fingerprint stored on the device with the fingerprint calculated from the public key which the server actually sent. If the calculated public key fingerprint does not match the stored public key fingerprint, the device terminates the connection.

If a remote server has several keys set up, for different encryption algorithms, add each of the public key fingerprints as a separate item.

Note: Verify that the public key fingerprints you store on the device is from a trustworthy source, the SSH server administrator, for example.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

In the *Index* field, you specify the index number.

Possible values:

1..50

- The device lets you specify up to 50 known hosts.
- In the Address field, you specify the address of the server. If the server can be accessed using both an IP address and a DNS name, then add a separate table row for each address type. Possible values:
 - Valid IPv4 address
 - Valid IPv6 address
 - DNS hostname

- ▶ In the *Key fingerprint* field, you specify the public key fingerprint of the server.
 - You can find out the public key fingerprint of the server, for example, as follows:
 - from the administrator of a known SSH server
 - from the error message following an unsuccessful software update in the Software dialog due to the mismatch between the public key fingerprint stored in the device and the fingerprint calculated from the public key which the server actually sent
 - Possible values:
 - Base64-coded SHA256 hash sequence with a length of 43 or 44 characters
- In the Key type field, you specify the algorithm that was used for generating the public key of the server. You can find out the Key type value simultaneously and through the same method you used to obtain the public key fingerprint.

If you accidentally select a different algorithm, then the device cannot identify the public key using the public key fingerprint.

Possible values:

- dsa
- rsa
- ecdsa
- ed25519



Removes the selected table row.

Index

Displays the index number to which the table row relates. You specify the index number when you add a table row.

Address

Displays the address of the server.

Possible values:

- Valid IPv4 address
- Valid IPv6 address
- DNS hostname

Key fingerprint

Specifies the public key fingerprint of the server.

Possible values:

Base64-coded SHA256 hash sequence with a length of 43 or 44 characters To modify the public key fingerprint, first unmark the checkbox in the *Active* column.

Key type

Displays the algorithm that was used for generating the public key of the server.

Possible values:

- 🕨 dsa
- 🕨 rsa
- 🕨 ecdsa
- ed25519

Active

Activates/deactivates the table row.

Possible values:

- marked (default setting)
 - The table row is active.

The device considers the server set up in this table row to be known. When you transfer a file from an external server onto the device or vice versa, the device verifies the identity of the external server based on this public key fingerprint.

unmarked

The table row is inactive.

The device considers the server set up in this table row to be unknown. When you transfer a file from an external server onto the device or vice versa, the device terminates the connection to this server.

4 Network Security

The menu contains the following dialogs:

- Network Security Overview
- Port Security
- ▶ 802.1X
- ► RADIUS
- DoS
- DHCP Snooping
- Dynamic ARP Inspection
- ► ACL

4.1 Network Security Overview

[Network Security > Overview]

This dialog displays an overview over the network security rules used in the device.

Overview

The top level displays:

- The ports to which a network security rule is assigned
- The VLANs to which a network security rule is assigned

The subordinate levels display:

 The set-up ACL rules See the Network Security > ACL dialog.

Buttons

Q

Displays a text field to search for a keyword. When you enter a character or string, the overview displays only items related to this keyword.

42

Collapses the levels. The overview then displays only the first level of the items.

23

Expands the levels. The overview then displays every level of the items.

+

Expands the current item and displays the items of the next lower level.

Collapses the item and hides the items of the underlying levels.

4.2 **Port Security**

[Network Security > Port Security]

The device lets you forward only data packets from desired senders on a port. When the *Port Security* function is enabled, the device checks the VLAN ID and MAC address of the sender before it forwards a data packet. The device discards data packets from not desired senders and logs this event.

In this dialog, a *Wizard* window helps you associate the ports with the address of one or more desired senders. In the device, these addresses are known as *static entries*. To view the specified

static addresses, select the relevant port and click the \sum_{x}^{∞} button.

To simplify the setup process, the device lets you record the address of the desired senders automatically. The device "learns" the addresses by evaluating the received data packets. In the device, these addresses are known as *dynamic entries*. When a user-defined upper limit has been reached (*Dynamic limit*), the device stops the "learning" on the relevant port. The device forwards only the data packets of the senders already registered on the port. When you adapt the upper limit to the number of expected senders, you thus make *MAC Flooding* attacks more difficult.

Note: With the automatic recording of the *dynamic entries*, the device constantly discards the first data packet from unknown senders. Using this first data packet, the device checks if the upper limit has been reached. The device records the addresses until the upper limit is reached. Afterwards, the device forwards data packets that it receives on the relevant port from this sender.

Operation

Operation

Enables/disables the Port Security function in the device.

Possible values:

▶ On

The *Port Security* function is enabled.

The device checks the VLAN ID and the source MAC address before it forwards a data packet. The device forwards a received data packet only if the VLAN and the source MAC address of the data packet are desired on the relevant port. For this setting to take effect, you also activate the *Port Security* function on the relevant ports.

Off (default setting) The *Port Security* function is disabled.

The device forwards every received data packet without checking the source address.

Configuration

Auto-disable

Activates/deactivates the Auto-Disable function for Port Security in the device.

Possible values:

marked

The Auto-Disable function for Port Security is active.

Also mark the checkbox in the Auto-disable column for the relevant ports.

The device disables the port and optionally sends an SNMP trap when one of the following events occurs:

- The device registers at least one address of a sender that is not desired on the port.
- The device registers more addresses than specified in the *Dynamic limit* column.

unmarked (default setting) The Auto-Disable function for Port Security is inactive.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the *Wizard* window that helps you associate the ports with the address of one or more desired senders. See "[Wizard: Port security]" on page 168.

Port

Displays the port number.

Active

Activates/deactivates the Port Security function on the port.

Possible values:

marked

The device checks every data packet received on the port and forwards it only if the source address of the data packet is desired. Also enable the *Port Security* function in the *Operation* frame.

unmarked (default setting)

The device forwards every data packet received on the port without checking the source address.

Note: When you operate the device as an active participant within an *MRP* ring or *HIPER Ring*, we recommend that you unmark the checkbox for the ring ports.

Note: When you operate the device as an active participant of a *Ring/Network Coupling* or *RCP*, we recommend that you unmark the checkbox for the relevant coupling ports.

Auto-disable

Activates/deactivates the Auto-Disable function for Port Security on the port.

Possible values:

marked (default setting)

The Auto-Disable function is active on the port.

The device disables the port and optionally sends an SNMP trap when one of the following events occurs:

- The device registers at least one address of a sender that is not desired on the port.
- The device registers more addresses than specified in the *Dynamic limit* column.

The *Link status* LED for the port flashes 3 × per period. This restriction makes *MAC Spoofing* attacks more difficult.

The prerequisite is that in the Configuration frame the Auto-disable checkbox is marked.

- The *Diagnostics > Ports > Auto-Disable* dialog displays which ports are currently disabled due to the parameters being exceeded.
- After a waiting period, the Auto-Disable function enables the port again automatically. For this you go to the Diagnostics > Ports > Auto-Disable dialog and specify a waiting period for the relevant port in the Reset timer [s] column.

unmarked

The Auto-Disable function is inactive on the port.

Send trap

Activates/deactivates the sending of SNMP traps when the device discards a data packet from an undesired sender on the port.

Possible values:

- marked
 - The sending of SNMP traps is active. The prerequisite is that in the *Diagnostics > Status Configuration > Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

If the device discards data packets from a sender that is not desired on the port, then the device sends an SNMP trap.

unmarked (default setting) The sending of SNMP traps is inactive.

Trap interval [s]

Specifies the delay time in seconds that the device waits after sending an SNMP trap before sending the next SNMP trap.

Possible values:

▶ 0..3600 (default setting: 0)

The value 0 deactivates the delay time.

Dynamic limit

Specifies the upper limit for the number of automatically registered addresses (*dynamic entries*). When the upper limit is reached, the device stops "learning" on this port.

Adjust the value to the number of expected senders.

If the port registers more addresses than specified here, then the *Auto-Disable* function disables the port. The prerequisite is that you mark the checkbox in the *Auto-disable* column and the *Auto-disable* checkbox in the *Configuration* frame.

Possible values:

▶ 0

No automatic registering of addresses on this port.

1..600 (default setting: 600)

Static limit

Specifies the upper limit for the number of addresses associated with the port using the *Wizard* window (*static entries*).

Possible values:

▶ 0

No association possible between the port and a desired sender. Only specify this value if you specify a value > 0 in the *Dynamic limit* column.

1..64 (default setting: 64)

Dynamic entries

Displays the number of addresses that the device has automatically registered.

Static MAC entries

Displays the number of MAC addresses associated with the port.

Last violating VLAN ID/MAC

Displays the VLAN ID and MAC address of an undesired sender whose data packets the device last discarded on this port.

Sent traps

Displays the number of discarded data packets on this port that caused the device to send an SNMP trap.

[Wizard: Port security]

The Wizard window helps you associate the ports with the address of one or more desired senders.

The *Wizard* window guides you through the following steps:

- Select port
- MAC addresses

Note: The device saves the addresses associated with the port until you deactivate the *Port Security* function on the relevant port or disable the *Port Security* function in the device.

After closing the *Wizard* window, click the \checkmark button to save your settings.

Select port

Port

Specifies the port that you associate with the address of desired senders in the next step.

MAC addresses

Static entries (x/y)

Displays the number of addresses associated with the port using the *Wizard* window and the upper limit for *static entries*. The lower part of the *Wizard* window displays the entries in detail, if any.



Removes the entries in the lower part of the *Wizard* window. The device removes the respective association between a port and the desired senders.

VLAN ID

Specifies the VLAN ID of the desired sender.

Possible values:

1..4042

MAC address

Specifies the MAC address of the desired sender.

Possible values:

Valid Unicast MAC address Specify the value with a colon separator, for example 00:11:22:33:44:55.

Note: You can assign a MAC address to only one port.

Add

Adds a *static entry* based on the values specified in the *VLAN ID* and *MAC address* fields. As a result, you find a new entry in the lower part of the *Wizard* window.

Entries in the lower part of the window

The lower part of the *Wizard* window displays the VLAN ID and MAC address of desired senders on this port. In the following list you find a description of the icons specific to these entries.

Static entry: When you click the icon, the device removes the *static entry* and the respective association between the port and the desired senders.

\bigstar

Dynamic entry: When you click the icon, the icon changes to \mathbf{X} . The device converts the *dynamic entry* to a *static entry* when you close the *Wizard* window. To undo this change, click the icon again before you close the *Wizard* window.

4.3 802.1X

[Network Security > 802.1X]

With the port-based access control according to IEEE 802.1X, the device monitors the access to the network from connected end devices. The device (authenticator) lets an end device (supplicant) have access to the network if it logs in with valid login data. The authenticator and the end devices communicate using the EAPoL (Extensible Authentication Protocol over LANs) authentication protocol.

The device supports the following methods to authenticate end devices:

- radius
 - A RADIUS server in the network authenticates the end devices.
- ias

The Integrated Authentication Server (IAS) implemented in the device authenticates the end devices. Compared to RADIUS, the IAS provides only basic functions.

The menu contains the following dialogs:

- 802.1X Global
- 802.1X Port Configuration
- 802.1X Port Clients
- ► 802.1X EAPOL Port Statistics
- 802.1X Port Authentication History
- 802.1X Integrated Authentication Server (IAS)

4.3.1 802.1X Global

[Network Security > 802.1X > Global]

This dialog lets you specify basic settings for the port-based access control.

Operation

Operation

Enables/disables the 802.1X function.

Possible values:

▶ On

The *802.1X* function is enabled. The device checks the access to the network from connected end devices. The port-based access control is enabled.

off (default setting) The 802.1X function is disabled. The port-based access control is disabled.

Configuration

VLAN assignment

Activates/deactivates the assigning of the relevant port to a VLAN. This function lets you provide selected services to the connected end device in this VLAN.

Possible values:

marked

The assigning is active.

If the end device successfully authenticates itself, then the device assigns to the relevant port the VLAN ID transferred by the RADIUS authentication server.

unmarked (default setting)

The assigning is inactive. The relevant port is assigned to the VLAN specified in the *Network Security* > 802.1X > Port *Configuration* dialog, *Assigned VLAN ID* column.

Dynamic VLAN creation

Activates/deactivates the automatic creation of the VLAN assigned by the RADIUS authentication server if the VLAN does not exist.

Possible values:

marked

The automatic VLAN creation is active. The device sets up the VLAN if it does not exist.

unmarked (default setting)

The automatic VLAN creation is inactive.

If the assigned VLAN does not exist, then the port remains assigned to the original VLAN.

Monitor mode

Activates/deactivates the monitor mode.

Possible values:

marked

The monitor mode is active.

The device monitors the authentication and helps with diagnosing detected errors. If an end device has not logged in successfully, then the device gives the end device access to the network.

unmarked (default setting) The monitor mode is inactive.

MAC authentication bypass format options

Group size

Specifies the size of the MAC address groups. The device splits the MAC address for authentication into groups. The size of the groups is specified in half bytes, each of which is represented as one character.

Possible values:

```
1
The device splits the MAC address into 12 groups of one character.
Example: A-A-B-B-C-C-D-D-E-E-F-F
```

2

The device splits the MAC address into 6 groups of 2 characters. Example: AA-BB-CC-DD-EE-FF

▶ 4

The device splits the MAC address into 3 groups of 4 characters. Example: AABB-CCDD-EEFF

12 (default setting) The device formats the MAC address as one group of 12 characters. Example: AABBCCDDEEFF

Group separator

Specifies the character which separates the groups.

Possible values:

```
    - (default setting)
dash
    :
colon
    .
dot
```

Upper or lower case

Specifies if the device formats the authentication data in lowercase or uppercase letters.

Possible values:

Lower-case

upper-case (default setting)

Password

Specifies the optional password for the clients which use the authentication bypass.

Possible values:

- Alphanumeric ASCII character string with 0..64 characters After entering the field displays ***** (asterisk) instead of the password.
- <empty>

The device uses the user name of the client also as the password.

Information

Monitor mode clients

Displays to how many end devices the device gave network access even though they did not log in successfully.

The prerequisite is that in the *Configuration* frame the *Monitor mode* function is active.

Non monitor mode clients

Displays the number of end devices to which the device gave network access after successful login.

Policy 1

Displays the method that the device currently uses to authenticate the end devices using the protocol 802.1X.

You specify the method used in the Device Security > Authentication List dialog.

- □ To authenticate the end devices through a RADIUS server, you assign the radius policy to the 8021x list.
- □ To authenticate the end devices through the Integrated Authentication Server (IAS) you assign the ias policy to the 8021x list.

4.3.2 802.1X Port Configuration

[Network Security > 802.1X > Port Configuration]

This dialog lets you specify the access settings for every port.

When multiple end devices are connected to a port, the device lets you authenticate these individually (multi-client authentication). In this case, the device lets logged in end devices have access to the network. In contrast, the device blocks access for unauthenticated end devices, or for end devices whose authentication has elapsed.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Port control

Specifies how the device grants access to the network (Port control mode).

Possible values:

forceUnauthorized

The device blocks the access to the network. You use this setting if an end device is connected to the port that does not receive access to the network.

auto

The device grants access to the network if the end device logged in successfully. You use this setting if an end device is connected to the port that logs in at the authenticator.

Note: If other end devices are connected through the same port, then they get access to the network without additional authentication.

► *forceAuthorized* (default setting)

When end devices do not support IEEE 802.1X, the device grants access to the network. You use this setting if an end device is connected to the port that receives access to the network without logging in.

multiClient

The device grants access to the network if the end device logs in successfully. If the end device does not send any EAPOL data packets, then the device grants or denies access to the network individually depending on the MAC address of the end device. See the MAC authorized bypass column.

You use this setting if multiple end devices are connected to the port or if the MAC authorized bypass function is required.

Authentication state

Displays the current status of the authentication on the port (Controlled Port Status).

Possible values:

authorized

The end device is logged in successfully.

unauthorized The end device is not logged in.

Assigned VLAN ID

Displays the VLAN that the authenticator assigned to the port. This value applies only on ports in which the *Port control* column contains the value *auto*.

Possible values:

▶ 0..4042 (default setting: 0)

You find the VLAN that the authenticator assigned to the ports in the *Network Security* > 802.1X > Port *Clients* dialog.

For the ports in which the *Port control* column contains the value *multiClient*, the device assigns the VLAN tag based on the MAC address of the end device when receiving data packets without a VLAN tag.

Reason

Displays the reason for the assignment of the VLAN. This value applies only on ports in which the *Port control* column contains the value *auto*.

Possible values:

- notAssigned (default setting)
- radius
- questVLan
- unauthenticatedVLan

You find the VLAN that the authenticator assigned to the ports for a supplicant in the *Network Security* > 802.1X > Port Clients dialog.

Guest VLAN ID

Specifies the VLAN that the authenticator assigns to the port if the end device does not log in during the time period specified in the *Guest VLAN period* column. This value applies only on ports in which the *Port control* column contains the value *auto* or *multiclient*.

This function lets you grant end devices, without IEEE 802.1X support, access to selected services in the network.

Possible values:

0 (default setting)

The authenticator does not assign a Guest VLAN to the port.

1...4042

Note: The *MAC authorized bypass* function and the *Guest VLAN ID* function cannot be in use simultaneously.

Unauthenticated VLAN ID

Specifies the VLAN that the authenticator assigns to the port if the end device does not log in successfully. This value applies only on ports in which the *Port control* column contains the value *auto*.

This function lets you grant end devices without valid login data access to selected services in the network.

Possible values:

▶ 0...4042 (default setting: 0)

The effect of the value 0 is that the authenticator does not assign a Unauthenticated VLAN to the port.

Note: Assign to the port a VLAN set up statically in the device.

MAC authorized bypass

Activates/deactivates the MAC-based authentication.

This function lets you authenticate end devices without IEEE 802.1X support on the basis of their MAC address.

Possible values:

marked

The MAC-based authentication is active.

The device sends the MAC address of the end device to the RADIUS authentication server. The device assigns the end device to the respective VLAN based on its MAC address, as if the end device had authenticated directly using the *802.1X* protocol.

unmarked (default setting) The MAC-based authentication is inactive.

Periodic reauthentication

Activates/deactivates periodic reauthentication requests.

Possible values:

marked

The periodic reauthentication requests are active.

The device periodically requests the end device to log in again. You specify this time period in the *Reauthentication period* [s] column.

If the authenticator assigned a Voice VLAN, Unauthenticated VLAN or Guest VLAN to the end device, then this setting becomes ineffective.

unmarked (default setting)
 The periodic reauthentication requests are inactive.
 The device keeps the end device logged in.

Reauthentication period [s]

Specifies the period in seconds after which the authenticator periodically requests the end device to log in again.

Possible values: ▶ 1..65535 (2¹⁶-1) (default setting: 3600)

Users (max.)

Specifies the upper limit for the number of end devices that the device authenticates on this port at the same time. This upper limit applies only to ports in which the *Port control* column contains the value multiClient.

Possible values:

1..16 (default setting: 16)

Quiet period [s]

Specifies the time period in seconds in which the authenticator does not accept any more logins from the end device after an unsuccessful login attempt (*Quiet period* [s]).

Possible values:

0..65535 (2¹⁶-1) (default setting: 60)

Transmit period [s]

Specifies the period in seconds after which the authenticator requests the end device to log in again. After this waiting period, the device sends an EAP request/identity data packet to the end device.

Possible values:
1..65535 (2¹⁶-1) (default setting: 30)

Supplicant timeout [s]

Specifies the period in seconds for which the authenticator waits for the login of the end device.

Possible values:
1..65535 (2¹⁶-1) (default setting: 30)

Server timeout [s]

Specifies the period in seconds for which the authenticator waits for the response from the authentication server (RADIUS or IAS).

Possible values:

1..65535 (2¹⁶-1) (default setting: 30)

Requests (max.)

Specifies how many times the authenticator requests the end device to log in until the time specified in the *Supplicant timeout* [s] column has elapsed. The device sends an EAP request/identity data packet to the end device as often as specified here.

Possible values:

▶ 0..10 (default setting: 2)

Guest VLAN period

Displays the period in seconds for which the authenticator waits for EAPOL data packets after the end device is connected. If this period elapses, then the authenticator grants the end device access to the network and assigns the port to the Guest VLAN specified in the *Guest VLAN ID* column.

The value in this column is the triple of the value specified in the Transmit period [s] column.

Status

Displays the current status of the Authenticator (Authenticator PAE state).

Possible values:

- initialize
- disconnected
- connecting
- authenticating
- authenticated
- aborting
- held
- ▶ forceAuth
- ▶ forceUnauth

Backend authentication state

Displays the current status of the connection to the authentication server (Backend Authentication state).

Possible values:

- request
- response
- success
- ▶ fail
- timeout
- ▶ idle
- initialize

Initialize port

Activates/deactivates the port initialization to activate the access control on the port or reset it to its initial state. Use this function only on ports in which the *Port control* column contains the value *auto* or *multiClient*.

Possible values:

- marked
 The port initialization is active.
 When the initialization is complete, the device changes the value to unmarked again.
- unmarked (default setting) The port initialization is inactive. The device keeps the current port status.

Reauthenticate

Activates/deactivates the one-time reauthentication request.

Use this function only on ports in which the *Port control* column contains the value *auto* or *multiClient*.

The device also lets you periodically request the end device to log in again. See the *Periodic reauthentication* column.

Possible values:

marked

The one-time reauthentication request is active.

The device requests the end device to log in again. Afterwards, the device changes the value to unmarked again.

unmarked (default setting)

The one-time reauthentication request is inactive. The device keeps the end device logged in.

4.3.3 802.1X Port Clients

[Network Security > 802.1X > Port Clients]

This dialog displays information on the connected end devices.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

User name

Displays the user name with which the end device logged in.

MAC address

Displays the MAC address of the end device.

Filter ID

Displays the name of the filter list that the RADIUS authentication server assigned to the end device after successful authentication.

The authentication server transfers the filter ID attributes in the Access Accept data packet.

Assigned VLAN ID

Displays the VLAN that the authenticator assigned to the port after the successful authentication of the end device.

If for the port in the *Network Security* > 802.1X > Port Configuration dialog, Port control column the value *multiClient* is specified, then the device assigns the VLAN tag based on the MAC address of the end device when receiving data packets without a VLAN tag.

VLAN assignment reason

Displays the reason for the assignment of the VLAN.

Possible values:

- default
- radius
- unauthenticatedVLan
- guestVLan
- monitorVLan
- invalid

The field only displays a valid value as long as the client is authenticated.

Session timeout

Displays the remaining time in seconds until the login of the end device expires. This value applies only if for the port in the *Network Security* > 802.1X > Port Configuration dialog, Port control column the value *auto* or *multiClient* is specified.

The authentication server assigns the timeout period to the device through RADIUS. The value 0 means that the authentication server has not assigned a timeout.

Termination action

Displays the action performed by the device when the login has elapsed.

Possible values:

- default
- reauthenticate

4.3.4 802.1X EAPOL Port Statistics

[Network Security > 802.1X > Statistics]

This dialog displays which EAPOL data packets the end device has sent and received for the authentication of the end devices.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Removes the selected table row.

Port

Displays the port number.

Received

Displays the total number of EAPOL data packets that the device received on the port.

Transmitted

Displays the total number of EAPOL data packets that the device sent on the port.

Start

	Displays the number of EAPOL start data packets that the device received on the port.
Logoff	Displays the number of EAPOL logoff data packets that the device received on the port.
Response/ID	Displays the number of EAP response/identity data packets that the device received on the port.

Response

Displays the number of valid EAP response data packets that the device received on the port (without EAP response/identity data packets).

Request/ID

Displays the number of EAP request/identity data packets that the device received on the port.

Request

Displays the number of valid EAP request data packets that the device received on the port (without EAP request/identity data packets).

Invalid

Displays the number of EAPOL data packets with an unknown frame type that the device received on the port.

Received error

Displays the number of EAPOL data packets with an invalid packet body length field that the device received on the port.

Packet version

Displays the protocol version number of the EAPOL data packet that the device last received on the port.

Source of last received packet

Displays the sender MAC address of the EAPOL data packet that the device last received on the port.

The value 00:00:00:00:00:00 means that the port has not received any EAPOL data packets yet.

4.3.5 802.1X Port Authentication History

[Network Security > 802.1X > Port Authentication History]

The device registers the authentication process of the end devices that are connected to its ports. This dialog displays the information recorded during the authentication.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Removes the selected table row.

Port

Time

Displays the time at which the authenticator authenticated the end device.

Present for

Displays the time that has elapsed since the device generated this log entry.

MAC address

Displays the MAC address of the end device.

VLAN ID

Displays the ID of the VLAN that was assigned to the end device before the login.

Status

Displays the status of the authentication on the port.

Possible values:

success

The authentication was successful.

failure The authentication did not succeed.

Access

Displays if the device grants the end device access to the network.

Possible values:

▶ granted

The device grants the end device access to the network.

denied

The device denies the end device access to the network.

Assigned VLAN ID

Displays the ID of the VLAN that the authenticator assigned to the port.

VLAN type

Displays the type of the VLAN that the authenticator assigned to the port.

Possible values:

- default
- radius
- unauthenticatedVLan
- guestVLan
- monitorVLan
- notAssigned

Reason

Displays the reason for assigning the VLAN and the VLAN type.

4.3.6 802.1X Integrated Authentication Server (IAS)

[Network Security > 802.1X > IAS]

The Integrated Authentication Server (IAS) lets you authenticate end devices using the protocol 802.1X. Compared to RADIUS, the IAS has a very limited range of functions. The authentication is based only on the user name and the password.

In this dialog, you manage the login data of the end devices. The device lets you set up to 100 sets of login data.

To authenticate the end devices through the Integrated Authentication Server you assign in the *Device Security > Authentication List* dialog the is policy to the 8021x list.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

• In the User name field, you specify the name of the user account on the end device.



Removes the selected table row.

User name

Displays the name of the user account on the end device.

To add a user account, click the $\overset{\blacksquare}{+}$ button.

Password

Specifies the password with which the user authenticates.

Possible values:

Alphanumeric ASCII character string with 0..64 characters

The device differentiates between upper and lower case.

Active

Activates/deactivates the login data.

Possible values:

marked

The login data is active. An end device has the option of logging in with this login data using the protocol 802.1X.

unmarked (default setting) The login data is inactive.

4.4 RADIUS

[Network Security > RADIUS]

With its factory settings, the device authenticates users based on the local user management. However, as the size of a network increases, it becomes more difficult to keep the login data of the users consistent across the devices.

RADIUS (Remote Authentication Dial-In User Service) lets you authenticate and authorize the users at a central point in the network. A RADIUS server performs the following tasks here:

Authentication

The authentication server authenticates the users when the RADIUS client at the access point forwards the login data of the users to the server.

Authorization

The authentication server authorizes logged in users for selected services by assigning various parameters for the relevant end device to the RADIUS client at the access point.

Accounting

The accounting server records the traffic data that has occurred during the port authentication according to IEEE 802.1X. This lets you subsequently determine which services the users have used, and to what extent.

If you assign the radius policy to an application in the *Device Security > Authentication List* dialog, then the device operates in the role of the RADIUS client. The device forwards the login data of the users to the primary authentication server. The authentication server decides if the login data is valid and transfers the authorizations of the users to the device.

The device assigns the Service Type transferred in the response of a RADIUS server as follows to an access role existing in the device:

- Administrative-User: administrator
- Login-User: operator
- NAS-Prompt-User: guest

The device also lets you authenticate end devices with IEEE 802.1X through an authentication server. To do this, you assign the radius policy to the 8021x list in the *Device Security* > *Authentication List* dialog.

The menu contains the following dialogs:

- RADIUS Global
- RADIUS Authentication Server
- RADIUS Accounting Server
- RADIUS Authentication Statistics
- RADIUS Accounting Statistics

4.4.1 RADIUS Global

[Network Security > RADIUS > Global]

This dialog lets you specify basic settings for RADIUS.

RADIUS configuration

Buttons



Deletes the statistics in the *Network Security* > *RADIUS* > *Authentication Statistics* dialog and in the *Network Security* > *RADIUS* > *Accounting Statistics* dialog.

Retransmits (max.)

Specifies how many times the device retransmits an unanswered request to the authentication server before the device sends the request to an alternative authentication server.

Possible values:

1..15 (default setting: 4)

Timeout [s]

Specifies how many seconds the device waits for a response after a request to an authentication server before it retransmits the request.

Possible values:

1..30 (default setting: 5)

Accounting

Activates/deactivates the accounting.

Possible values:

marked

Accounting is active. The device sends the traffic data to an accounting server specified in the *Network Security* > RADIUS > *Accounting Server* dialog.

unmarked (default setting) Accounting is inactive.

NAS IP address (attribute 4)

Specifies the IP address that the device transfers to the authentication server as attribute 4. Specify the IP address of the device or another available address.

Note: The device only includes the attribute 4 if the packet was triggered by the *802.1X* authentication request of an end device (supplicant).

Possible values:

Valid IPv4 address (default setting: 0.0.0.0)

In many cases, there is a firewall between the device and the authentication server. In the Network Address Translation (NAT) in the firewall changes the original IP address, and the authentication server receives the translated IP address of the device.

The device transfers the IP address in this field unchanged across the Network Address Translation (NAT).

4.4.2 RADIUS Authentication Server

[Network Security > RADIUS > Authentication Server]

This dialog lets you specify up to 8 authentication servers. An authentication server authenticates and authorizes the users when the device forwards the login data to the server.

The device sends the login data to the specified primary authentication server. When the server does not respond, the device contacts the specified authentication server that is highest in the table. When no response comes from this server either, the device contacts the next server in the table.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the *Create* window to add a table row.

- In the *Index* field, you specify the index number.
- In the Address field, you specify the IP address of the server.



Removes the selected table row.

Index

Displays the index number to which the table row relates. You specify the index number when you add a table row.

Name

Displays the name of the server. To change the value, click the relevant field.

Possible values:

 Alphanumeric ASCII character string with 1..32 characters (default setting: Default-RADIUS-Server)
 You can specify the same name for several servers. When several servers have the same name, the setting in the *Primary server* column applies. Address

Specifies the IP address of the server.

Possible values:

Valid IPv4 address

Destination UDP port

Specifies the number of the UDP port on which the server receives requests.

Possible values:

 0..65535 (2¹⁶-1) (default setting: 1812) Exception: Port 2222 is reserved for internal functions.

Secret

Displays ****** (asterisks) when you specify a password with which the device logs into the server. To change the password, click the relevant field.

Possible values:

Alphanumeric ASCII character string with 1..64 characters

You get the password from the administrator of the authentication server.

Primary server

Specifies the authentication server as primary or secondary.

Possible values:

marked

The server is specified as the primary authentication server. The device sends the login data for authenticating the users to this authentication server.

This setting applies only if more than one server in the table has the same value in the *Name* column.

unmarked (default setting)

The server is the secondary authentication server. When the device does not receive a response from the primary authentication server, the device sends the login data to the secondary authentication server.

Active

Activates/deactivates the connection to the server.

The device uses the server, if you specify in the *Device Security* > *Authentication List* dialog the value radius in one of the columns *Policy 1* to *Policy 5*.

Possible values:

marked (default setting)

The connection is active. The device sends the login data for authenticating the users to this server if the preconditions named above are fulfilled.

unmarked

The connection is inactive. The device does not send any login data to this server.

4.4.3 RADIUS Accounting Server

[Network Security > RADIUS > Accounting Server]

This dialog lets you specify up to 8 accounting servers. An accounting server records the traffic data that has occurred during the port authentication according to IEEE 802.1X. The prerequisite is that in the *Network Security* > *RADIUS* > *Global* dialog the *Accounting* function is active.

The device sends the traffic data to the first accounting server that can be reached. When the accounting server does not respond, the device contacts the next server in the table.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

- In the *Index* field, you specify the index number.
- In the Address field, you specify the IP address of the server.



Removes the selected table row.

Index

Displays the index number to which the table row relates. You specify the index number when you add a table row.

Possible values:

▶ 1..8

Name

Displays the name of the server.

To change the value, click the relevant field.

Possible values:

Alphanumeric ASCII character string with 1..32 characters (default setting: Default-RADIUS-Server) Address

Specifies the IP address of the server.

Possible values:

Valid IPv4 address

Destination UDP port

Specifies the number of the UDP port on which the server receives requests.

Possible values:

 0..65535 (2¹⁶-1) (default setting: 1813) Exception: Port 2222 is reserved for internal functions.

Secret

Displays ****** (asterisks) when you specify a password with which the device logs into the server. To change the password, click the relevant field.

Possible values:

Alphanumeric ASCII character string with 1..16 characters

You get the password from the administrator of the authentication server.

Active

Activates/deactivates the connection to the server.

Possible values:

- marked (default setting) The connection is active. The device sends traffic data to this server if the preconditions named above are fulfilled.
- unmarked

The connection is inactive. The device does not send any traffic data to this server.

4.4.4 RADIUS Authentication Statistics

[Network Security > RADIUS > Authentication Statistics]

This dialog displays information about the communication between the device and the authentication server. The table displays the information for each server in a separate table row.

To delete the statistic, click in the *Network Security* > *RADIUS* > *Global* dialog the button.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Name

Displays the name of the server.

IP address

Displays the IP address of the server.

Round trip time

Displays the time interval in hundredths of a second between the last response received from the server (Access Reply/Access Challenge) and the corresponding data packet sent (Access Request).

Access requests

Displays the number of access data packets that the device sent to the server. This value does not take repetitions into account.

Retransmitted access requests

Displays the number of access data packets that the device retransmitted to the server.

Access accepts

Displays the number of access accept data packets that the device received from the server.

Access rejects

Displays the number of access reject data packets that the device received from the server.

Access challenges

Displays the number of access challenge data packets that the device received from the server.

Malformed access responses

Displays the number of malformed access response data packets that the device received from the server (including data packets with an invalid length).

Bad authenticators

Displays the number of access response data packets with an invalid authenticator that the device received from the server.

Pending requests

Displays the number of access request data packets that the device sent to the server to which it has not yet received a response from the server.

Timeouts

Displays how many times no response to the server was received before the specified waiting time elapsed.

Unknown types

Displays the number data packets with an unknown data type that the device received from the server on the authentication port.

Packets dropped

Displays the number of data packets that the device received from the server on the authentication port and then discarded them.

4.4.5 RADIUS Accounting Statistics

[Network Security > RADIUS > Accounting Statistics]

This dialog displays information about the communication between the device and the accounting server. The table displays the information for each server in a separate table row.

To delete the statistic, click in the *Network Security* > *RADIUS* > *Global* dialog the button.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Name

Displays the name of the server.

IP address

Displays the IP address of the server.

Round trip time

Displays the time interval in hundredths of a second between the last response received from the server (Accounting Response) and the corresponding data packet sent (Accounting Request).

Accounting requests

Displays the number of accounting request data packets that the device sent to the server. This value does not take repetitions into account.

Retransmitted accounting requests

Displays the number of accounting request data packets that the device retransmitted to the server.

Received packets

Displays the number of accounting response data packets that the device received from the server.

Malformed packets

Displays the number of malformed accounting response data packets that the device received from the server (including data packets with an invalid length).

Bad authenticators

Displays the number of accounting response data packets with an invalid authenticator that the device received from the server.

Pending requests

Displays the number of accounting request data packets that the device sent to the server to which it has not yet received a response from the server.

Timeouts

Displays how many times no response to the server was received before the specified waiting time elapsed.

Unknown types

Displays the number data packets with an unknown data type that the device received from the server on the accounting port.

Packets dropped

Displays the number of data packets that the device received from the server on the accounting port and then discarded them.

4.5 DoS

[Network Security > DoS]

Denial of Service (DoS) is a cyberattack that aims to make certain services or devices unusable. In this dialog, you can set up several filters to help protect the device itself and other devices in the network from DoS attacks.

The menu contains the following dialogs: DoS Global

4.5.1 DoS Global

[Network Security > DoS > Global]

In this dialog, you specify the DoS settings for the TCP/UDP, IP and ICMP protocols.

Note: We recommend activating the filters to increase the level of security of the device.

TCP/UDP

A scanner uses port scans to prepare network attacks. The scanner uses different techniques to determine running devices and open ports. This frame lets you activate filters for specific scanning techniques.

The device supports the detection of the following scan types:

- Null scans
- Xmas scans
- SYN/FIN scans
- TCP Offset attacks
- TCP SYN attacks
- L4 Port attacks
- Minimal Header scans

Null Scan filter

Activates/deactivates the Null Scan filter.

The device detects and discards incoming TCP packets with the following properties:

- No TCP flags are set.
- The TCP sequence number is 0.

Possible values:

- marked
 - The filter is active.
- unmarked (default setting) The filter is inactive.

Xmas filter

Activates/deactivates the Xmas filter.

The device detects and discards incoming TCP packets with the following properties:

- The TCP flags FIN, URG and PSH are simultaneously set.
- The TCP sequence number is 0.

Possible values:

- marked The filter is active.
- unmarked (default setting) The filter is inactive.

SYN/FIN filter

Activates/deactivates the SYN/FIN filter.

The device detects incoming data packets with the TCP flags SYN and FIN set simultaneously and discards them.

Possible values:

- marked The filter is active.
- unmarked (default setting) The filter is inactive.

TCP Offset protection

Activates/deactivates the TCP Offset protection.

The TCP Offset protection detects incoming TCP data packets whose fragment offset field of the IP header is equal to 1 and discards them.

The TCP Offset protection accepts UDP and ICMP packets whose fragment offset field of the IP header is equal to 1.

Possible values:

marked

The protection is active.

unmarked (default setting) The protection is inactive.

TCP SYN protection

Activates/deactivates the TCP SYN protection.

The TCP SYN protection detects incoming data packets with the TCP flag SYN set and a L4 source port <1024 and discards them.

Possible values:

- marked
 - The protection is active.
- unmarked (default setting) The protection is inactive.

L4 Port protection

Activates/deactivates the L4 Port protection.

The L4 Port protection detects incoming TCP and UDP data packets whose source port number and destination port number are identical and discards them.

Possible values:

marked

The protection is active.

unmarked (default setting) The protection is inactive.

Min. Header Size filter

Activates/deactivates the Minimal Header filter.

The Minimal Header filter detects incoming data packets whose IP payload length in the IP header minus the outer IP header size is smaller than the minimum TCP header size. If this is the first fragment that the device detects, then the device discards the data packet.

Possible values:

marked

The filter is active.

unmarked (default setting) The filter is inactive.

Min. TCP header size

Displays the minimum size of a valid TCP header.

IP

Land Attack filter

Activates/deactivates the *Land Attack* filter. With the *Land Attack* method, the attacking station sends data packets whose source and destination addresses are identical to the IP address of the recipient.

Possible values:

```
marked
```

The filter is active. The device discards data packets whose source and destination addresses are identical.

unmarked (default setting) The filter is inactive.

ICMP

This dialog provides you with filter options for the following ICMP parameters:

- Fragmented data packets
- ICMP packets from a specific size upwards
- Broadcast pings

Fragmented packets filter

Activates/deactivates the filter for fragmented ICMP packets.

The filter detects fragmented ICMP packets and discards them.

Possible values:

marked The filter is active.

unmarked (default setting) The filter is inactive. Packet size filter

Activates/deactivates the filter for incoming ICMP packets.

The filter detects ICMP packets whose payload size exceeds the size specified in the *Allowed* payload size [byte] field and discards them.

Possible values:

marked

The filter is active.

unmarked (default setting) The filter is inactive.

Allowed payload size [byte]

Specifies the maximum allowed payload size of ICMP packets in bytes.

Mark the *Packet size filter* checkbox if you want the device to discard incoming data packets whose payload size exceeds the maximum allowed size for ICMP packets.

Possible values:

0..1472 (default setting: 512)

Drop broadcast ping

Activates/deactivates the filter for Broadcast Pings. Broadcast Pings are a known evidence for Smurf Attacks.

Possible values:

- marked The filter is active. The device detects Broadcast Pings and drops them.
- unmarked (default setting) The filter is inactive.

4.6 DHCP Snooping

[Network Security > DHCP Snooping]

DHCP Snooping is a function that supports the network security. DHCP Snooping monitors DHCP packets between DHCP clients and the DHCP server and acts like a firewall between the untrusted hosts and the trusted DHCP servers.

In this dialog, you set up and monitor the following device behavior:

- Validate DHCP packets from untrusted sources and filter out invalid packets.
- Limit the amount of DHCP data packets from trusted and untrusted sources.
- Set up and update the DHCP Snooping binding database. This database contains the MAC address, IP address, VLAN and port of DHCP clients at untrusted ports.
- Validate follow-up requests from untrusted hosts on the basis of the DHCP Snooping binding database.

You can activate DHCP Snooping globally and for a specific VLAN. You specify the security status (trusted or untrusted) on individual ports. Verify that the DHCP service can be reached through trusted ports. For DHCP Snooping you typically set up the user/client ports as untrusted and the uplink ports as trusted.

The menu contains the following dialogs:

- DHCP Snooping Global
- DHCP Snooping Configuration
- DHCP Snooping Statistics
- DHCP Snooping Bindings

4.6.1 DHCP Snooping Global

[Network Security > DHCP Snooping > Global]

This dialog lets you set up the global DHCP Snooping parameters for your device:

- Activate/deactivate DHCP Snooping globally.
- Activate/deactivate Auto-Disable globally.
- Enable/disable the checking of the source MAC address.
- Specify the name, storage location and storing interval for the binding database.

Operation

Operation

Enables/disables the DHCP Snooping function globally.

Possible values:

► On

Off (default setting)

Configuration

Verify MAC

Activates/deactivates the source MAC address verification in the Ethernet packet.

Possible values:

marked

The source MAC address verification is active.

The device compares the source MAC address with the MAC address of the client in the received DHCP packet.

unmarked (default setting) The source MAC address verification is inactive.

Auto-disable

Activates/deactivates the Auto-Disable function for DHCP Snooping.

Possible values:

marked

The *Auto-Disable* function for *DHCP Snooping* is active. Also mark the checkbox in the *Auto-disable* column on the *Port* tab in the *Network Security > DHCP Snooping > Configuration* dialog for the relevant ports.

unmarked (default setting) The Auto-Disable function for DHCP Snooping is inactive.

Binding database

Remote file name

Specifies the name of the file in which the device saves the DHCP Snooping binding database.

Note: The device saves only dynamic bindings in the persistent binding database. The device saves static bindings in the configuration profile.

Remote IP address

Specifies the remote IP address under which the device saves the persistent DHCP Snooping binding database. With the value 0.0.0 the device saves the binding database locally.

Possible values:

- Valid IPv4 address
- ▶ 0.0.0.0 (default setting)

The device saves the DHCP Snooping binding database locally.

Store interval [s]

Specifies the time delay in seconds after which the device saves the DHCP Snooping binding database when the device identifies a change in the database.

Possible values:

15..86400 (1 d) (default setting: 300)

4.6.2 DHCP Snooping Configuration

[Network Security > DHCP Snooping > Configuration]

This dialog lets you set up DHCP Snooping for individual ports and for individual VLANs.

The dialog contains the following tabs:

- [Port]
- ▶ [VLAN ID]

[Port]

In this tab you set up the DHCP Snooping function for individual ports.

- Set up a port as trusted/untrusted.
- Activate/deactivate the logging of invalid packets for individual ports.
- Limit the amount of DHCP packets.
- Deactivate a port automatically if the amount of DHCP data packets exceeds the threshold value.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Trust

Activates/deactivates the security status (trusted, untrusted) of the port.

Possible values:

marked

The port is set up as trusted. DHCP Snooping forwards permissible client packets through trusted ports.

Typically, you have connected the trusted port to a DHCP server.

unmarked (default setting) The port is set up as untrusted. On untrusted ports, the device compares the receiver port with the client port in the binding database.

Log

Activates/deactivates the logging of invalid packets that the device determines on this port.

Possible values:

- marked
 - The logging of invalid packets is active.
- unmarked (default setting) The logging of invalid packets is inactive.

Rate limit

Specifies the maximum number of DHCP packets per burst interval on the port. If the number of incoming DHCP packets is currently exceeding the specified limit in a burst interval, then the device discards the additional incoming DHCP packets.

Possible values:

-1 (default setting)

Deactivates the limitation of the number of DHCP packets per burst interval on this port.

0..150packets per interval Limits the maximum number of DHCP packets per burst interval on this port.

You specify the burst interval in the Burst interval column.

If you activate the auto-disable function, then the device also disables the port. You find the auto-disable function in the *Auto-disable* column.

Burst interval

Specifies the length of the burst interval in seconds on this port. The burst interval is relevant for the rate limiting function.

You specify the maximum number of DHCP packets per burst interval in the Rate limit column.

Possible values:

1..15 (default setting: 1)

Auto-disable

Activates/deactivates the *Auto-Disable* function for the parameters that the *DHCP Snooping* function is monitoring on the port.

Possible values:

marked (default setting)

The Auto-Disable function is active on the port.

The prerequisite is that in the *Network Security > DHCP Snooping > Global* dialog, in the *Configuration* frame the *Auto-disable* checkbox is marked.

- If the port receives more DHCP packets than specified in the *Rate limit* field in the time specified in the *Burst interval* column, then the device disables the port. The *Link status* LED for the port flashes 3× per period.
- The *Diagnostics > Ports > Auto-Disable* dialog displays which ports are currently disabled due to the parameters being exceeded.
- After a waiting period, the Auto-Disable function enables the port again automatically. For this you go to the Diagnostics > Ports > Auto-Disable dialog and specify a waiting period for the relevant port in the Reset timer [s] column.

unmarked

The *Auto-Disable* function on the port is inactive.

[VLAN ID]

In this tab you set up the DHCP Snooping function for individual VLANs.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

VLAN ID

Displays the VLAN ID to which the table row relates.

Active

Activates/deactivates the DHCP Snooping function in this VLAN.

The *DHCP Snooping* function forwards valid DHCP client messages to the trusted ports in VLANs without the *Routing* function.

Possible values:

- marked
 - The DHCP Snooping function is active in this VLAN.
- unmarked (default setting)

The DHCP Snooping function is inactive in this VLAN.

The device forwards DHCP packets according to the switching settings without monitoring the packets. The binding database remains unchanged.

Note: To enable DHCP Snooping for a port, enable the *DHCP Snooping* function globally in the *Network Security > DHCP Snooping > Global* dialog. Verify that you assigned the port to a VLAN in which DHCP Snooping is enabled.

4.6.3 DHCP Snooping Statistics

[Network Security > DHCP Snooping > Statistics]

With DHCP Snooping, the device logs detected errors and generates statistics. In this dialog, you monitor the DHCP Snooping statistics for each port.

The device logs the following:

- · Errors detected when validating the MAC address of the DHCP client
- DHCP client messages with a detected incorrect port
- DHCP server messages to untrusted ports

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Resets the values in the table.

Port

Displays the port number.

MAC verify failures

Displays the number of discrepancies between the MAC address of the DHCP client in the 'chaddr' field of the DHCP data packet and the source address in the Ethernet packet.

Invalid client messages

Displays the number of incoming DHCP client messages received on the port for which the device expects the client on another port according to the DHCP Snooping binding database.

Invalid server messages

Displays the number of DHCP server messages the device received on the untrusted port.

4.6.4 DHCP Snooping Bindings

[Network Security > DHCP Snooping > Bindings]

DHCP Snooping uses DHCP messages to set up and update the binding database.

- Static bindings
 The device lets you enter up to 1024 static DHCP Snooping bindings in the database.
- Dynamic bindings
 The dynamic binding database contains data for clients only on untrusted ports.

This menu lets you specify the settings for static and dynamic bindings.

- Set up new static bindings and set them to active/inactive.
- Display, activate/deactivate or delete static bindings that have been set up.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

In the *MAC address* field, you specify the MAC address which you bind to an IP address and a VLAN ID.

Possible values:

Valid Unicast MAC address Specify the value with a colon separator, for example 00:11:22:33:44:55.



Removes the selected table row.

The prerequisite is that in the Active column the checkbox is unmarked.

Also, the device removes the dynamic bindings of this port set up with the IP Source Guard function.

MAC address

Displays the MAC address that you bind to an IP address and a VLAN ID.

IP address

Specifies the IP address for the static DHCP Snooping binding.

Possible values:

Valid Unicast IPv4 address smaller than 224.x.x.x and outside the range 127.0.0.0/8 (default setting: 0.0.0.0)

VLAN ID

Specifies the VLAN ID to which the table row relates.

Possible values: VLAN IDs of the set-up VLANs>

Port

Specifies the port for the static DHCP Snooping binding.

Possible values:

Available ports

Remaining binding time

Displays the remaining time for the dynamic DHCP Snooping binding.

Active

Activates/deactivates the specified static DHCP Snooping binding.

Possible values:

marked

The static DHCP Snooping binding is active. The prerequisite is that in the *Time > Basic Settings* dialog the date and time are set correctly in the device. Otherwise, the bindings may get lost after rebooting the device.

unmarked (default setting) The static DHCP Snooping binding is inactive.

4.7 Dynamic ARP Inspection

[Network Security > Dynamic ARP Inspection]

Dynamic ARP Inspection is a function that supports the network security. This function analyzes ARP packets, logs them, and discards invalid and hostile ARP packets.

The *Dynamic ARP Inspection* function helps prevent a range of man-in-the-middle attacks. With this kind of attack, a hostile station listens in on the data stream from other subscribers by encroaching on the ARP cache of its unsuspecting neighbors. The hostile station sends ARP requests and ARP responses and enters the IP address of another subscriber for its own MAC address in the IP-to-MAC address relationship (binding).

Using the following measures, the *Dynamic ARP Inspection* function helps ensure that the device only forwards valid ARP requests and ARP responses.

- Listening in on ARP requests and ARP responses on untrusted ports.
- Verifying that the determined packets have a valid IP to MAC address relationship (binding) before the device updates the local ARP cache and before the device forwards the packets to the related destination address.
- Discarding invalid ARP packets.

The device lets you specify up to 100 active ARP ACLs (access lists). You can activate up to 20 rules for each ARP ACL.

The menu contains the following dialogs:

- Dynamic ARP Inspection Global
- Dynamic ARP Inspection Configuration
- Dynamic ARP Inspection ARP Rules
- Dynamic ARP Inspection Statistics

4.7.1 Dynamic ARP Inspection Global

[Network Security > Dynamic ARP Inspection > Global]

Configuration

Verify source MAC

Activates/deactivates the source MAC address verification. The device executes the check in both ARP requests and ARP responses.

Possible values:

- marked
 - The source MAC address verification is active.
 - The device checks the source MAC address of the received ARP packets.
 - The device transmits ARP packets with a valid source MAC address to the related destination address and updates the local ARP cache.
 - The device discards ARP packets with an invalid source MAC address.
- unmarked (default setting)
 - The source MAC address verification is inactive.

Verify destination MAC

Activates/deactivates the destination MAC address verification. The device executes the check in ARP responses.

Possible values:

- marked
 - The destination MAC address verification is active.
 - The device checks the destination MAC address of the incoming ARP packets.
 - The device transmits ARP packets with a valid destination MAC address to the related destination address and updates the local ARP cache.
 - The device discards ARP packets with an invalid destination MAC address.
- unmarked (default setting)

The checking of the destination MAC address of the incoming ARP packets is inactive.

Verify IP address

Activates/deactivates the IP address verification.

In ARP requests, the device checks the source IP address. In ARP responses, the device checks the destination and source IP address.

The device designates the following IP addresses as invalid:

- 0.0.0.0
- Broadcast addresses 255.255.255.255
- Multicast addresses 224.0.0.0/4 (Class D)
- Class E addresses 240.0.0/4 (reserved for subsequent purposes)
- Loopback addresses in the range 127.0.0.0/8.

Possible values:

- marked
 - The IP address verification is active.

The device checks the IP address of the incoming ARP packets. The device transmits ARP packets with a valid IP address to the related destination address and updates the local ARP cache. The device discards ARP packets with an invalid IP address.

unmarked (default setting) The IP address verification is inactive.

Auto-disable

Activates/deactivates the Auto-Disable function for Dynamic ARP Inspection.

Possible values:

- marked
 - The *Auto-Disable* function for *Dynamic ARP Inspection* is active. Also mark the checkbox in the *Port* column on the *Auto-disable* tab in the *Network Security* > Dynamic ARP Inspection > *Configuration* dialog for the relevant ports.
- unmarked (default setting) The Auto-Disable function for Dynamic ARP Inspection is inactive.

4.7.2 Dynamic ARP Inspection Configuration

[Network Security > Dynamic ARP Inspection > Configuration]

The dialog contains the following tabs:

[Port]

► [VLAN ID]

[Port]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Trust

Activates/deactivates the monitoring of ARP packets on untrusted ports.

Possible values:

- marked Monitoring is active.
 The device monitors ARP packets on untrusted ports.
 The device immediately forwards ARP packets on trusted ports.
- unmarked (default setting) Monitoring is inactive.

Rate limit

Specifies the maximum number of ARP packets per interval on this port. If the rate of incoming ARP packets is currently exceeding the specified limit in a burst interval, then the device discards the additional incoming ARP packets. You specify the burst interval in the *Burst interval* column.

Optionally, the device also deactivates the port if you activate the auto-disable function. You enable/disable the *Auto-Disable* function in the *Auto-disable* column.

Possible values:

- -1 (default setting)
 Deactivates the limitation of the number of ARP packets per burst interval on this port.
- 0..300packets per interval Limits the maximum number of ARP packets per burst interval on this port.

Burst interval

Specifies the length of the burst interval in seconds on this port. The burst interval is relevant for the rate limiting function.

You specify the maximum number of ARP packets per burst interval in the *Rate limit* column.

Possible values:

1..15 (default setting: 1)

Auto-disable

Activates/deactivates the *Auto-Disable* function for the parameters that the *Dynamic ARP Inspection* function is monitoring on the port.

Possible values:

marked (default setting)

The Auto-Disable function is active on the port. The prerequisite is that in the Network Security > Dynamic ARP Inspection > Global dialog, in the Configuration frame the Auto-disable checkbox is marked.

- If the port receives more ARP packets than specified in the *Rate limit* field in the time specified in the *Burst interval* column, then the device disables the port. The *Link status* LED for the port flashes 3× per period.
- The *Diagnostics* > *Ports* > *Auto-Disable* dialog displays which ports are currently disabled due to the parameters being exceeded.
- After a waiting period, the Auto-Disable function enables the port again automatically. For this you go to the Diagnostics > Ports > Auto-Disable dialog and specify a waiting period for the relevant port in the Reset timer [s] column.

unmarked

The Auto-Disable function on the port is inactive.

[VLAN ID]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

VLAN ID

```
Displays the VLAN ID to which the table row relates.
```

Log

Activates/deactivates the logging of invalid ARP packets that the device determines in this VLAN. If the device detects an error when checking the IP, source MAC or destination MAC address, or when checking the IP-to-MAC address relationship (binding), then the device identifies an ARP packet as invalid.

Possible values:

- marked The logging of invalid packets is active. The device registers invalid ARP packets.
- unmarked (default setting) The logging of invalid packets is inactive.

Binding check

Activates/deactivates the checking of incoming ARP packets that the device receives on untrusted ports and on VLANs for which the *Dynamic ARP Inspection* function is active. For these ARP packets the device checks the ARP ACL and the DHCP Snooping relationship (bindings).

Possible values:

- marked (default setting) The binding check of ARP packets is active.
- unmarked
 - The binding check of ARP packets is inactive.

Strict ACL check

Activates/deactivates the strict checking of incoming ARP packets based on the ARP ACL rules specified.

Possible values:

- marked
 - The strict checking is active.

The device checks the incoming ARP packets based on the ARP ACL rule specified in the ACL column.

- unmarked (default setting)
 - The strict checking is inactive.

The device checks the incoming ARP packets based on the ARP ACL rule specified in the ACL column and subsequently on the entries in the DHCP Snooping database.

ACL

Specifies the ARP ACL that the device uses.

Possible values:

<rule name>

You add and edit the rules in the Network Security > Dynamic ARP Inspection > ARP Rules dialog.

Active

Activates/deactivates the Dynamic ARP Inspection function in this VLAN.

Possible values:

marked

The Dynamic ARP Inspection function is active in this VLAN.

unmarked (default setting) The Dynamic ARP Inspection function is inactive in this VLAN.

4.7.3 Dynamic ARP Inspection ARP Rules

[Network Security > Dynamic ARP Inspection > ARP Rules]

This dialog lets you specify rules for checking and filtering ARP packets.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

- From the *Name* drop-down list, you select the name of the ARP rule or specify a new name.
 When you add a new name, click the + icon.
- In the Source IP address field, you specify the source IP address of the ARP rule.
- In the Source MAC address field, you specify the source MAC address of the ARP rule.



Removes the selected table row.

Name

Displays the name of the ARP rule.

Source IP address

Specifies the source address of the IP data packets to which the device applies the rule.

Possible values:

Valid IPv4 address

The device applies the rule to IP data packets with the specified source address.

Source MAC address

Specifies the source address of the MAC data packets to which the device applies the rule.

Possible values:

Valid MAC address

The device applies the rule to MAC data packets with the specified source address.

Active

Activates/deactivates the ARP rule.

Possible values:

- marked (default setting)
 - The rule is active.
- unmarked The rule is inactive.

4.7.4 Dynamic ARP Inspection Statistics

[Network Security > Dynamic ARP Inspection > Statistics]

This window displays the number of discarded and forwarded ARP packets in an overview.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Resets the values in the table.

VLAN ID

Displays the VLAN ID to which the table row relates.

Packets forwarded

Displays the number of ARP packets that the device forwards after checking them using the *Dynamic ARP Inspection* function.

Packets dropped

Displays the number of ARP packets that the device discards after checking them using the *Dynamic ARP Inspection* function.

DHCP drops

Displays the number of ARP packets that the device discards after checking the DHCP Snooping relationship (binding).

DHCP permits

Displays the number of ARP packets that the device forwards after checking the DHCP Snooping relationship (binding).

ACL drops

Displays the number of ARP packets that the device discards after checking them using the ARP ACL rules.

ACL permits

Displays the number of ARP packets that the device forwards after checking them using the ARP ACL rules.

Bad source MAC

Displays the number of ARP packets that the device discards after the *Dynamic ARP Inspection* function detected an error in the source MAC address.

Bad destination MAC

Displays the number of ARP packets that the device discards after the *Dynamic ARP Inspection* function detected an error in the destination MAC address.

Invalid IP address

Displays the number of ARP packets that the device discards after the *Dynamic ARP Inspection* function detected an error in the IP address.

4.8 ACL

[Network Security > ACL]

In this menu, you specify the settings for the Access Control Lists (ACL). Access Control Lists contain rules which the device applies successively to the data stream on its ports or VLANs.

If a data packet matches the criteria of one or more rules, then the device applies the action specified in the first applicable rule to the data stream. The device ignores the rules that follow the first applicable rule. Possible actions include:

- *permit*: The device forwards the data packet to a port or to a VLAN.
- When necessary, the device forwards a copy of the data packets to a further port.
- *deny*: The device drops the data packet.

In the default setting, the device forwards every data packet. As soon as you assign an Access Control List to a port or VLAN, then this behavior changes. The device enters at the end of an Access Control List an implicit *Deny-All* rule. Consequently, the device discards data packets that do not match the criteria of any rules. If you want a different behavior, then add a *Permit-All* rule at the end of your Access Control Lists.

Proceed as follows to set up Access Control Lists and rules:

- □ Make a time profile if necessary. See the *Network Security* > *ACL* > *Time Profile* dialog. The device applies Access Control Lists with a time profile at specified times instead of permanently.
- □ Make a rule and specify the rule settings. See the *Network Security* > *ACL* > *IPv4 Rule* dialog, or the *Network Security* > *ACL* > *MAC Rule* dialog.
- Assign the Access Control List to the ports and VLANs of the device. See the Network Security > ACL > Assignment dialog.

The menu contains the following dialogs:

- ACL IPv4 Rule
- ACL MAC Rule
- ACL Assignment
- ACL Time Profile

4.8.1 ACL IPv4 Rule

[Network Security > ACL > IPv4 Rule]

In this dialog, you specify the rules that the device applies to the IP data packets.

An Access Control List (group) contains one or more rules. The device applies the rules of an Access Control List successively, beginning with the rule with the numerically lowest value in the *Index* column.

The device lets you filter according to the following criteria:

- · Source or destination IP address of a data packet
- Type of the transmitting protocol
- Source or destination port of a data packet
- Classification according to DSCP
- Classification according to ToS

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

· From the Group name drop-down list, you select the Access Control List name to which the rule

belongs or specify a new name. When you add a new name, click the + icon.

In the *Index* field, you specify the number of the rule within the Access Control List. If the Access
Control List contains multiple rules, then the device processes the rule with the lowest index
value first.



Removes the selected table row.

Group name

Displays the name of the Access Control List. The Access Control List contains the rules.

Index

Displays the number of the rule within the Access Control List. You specify the index number when you add a table row.

If the Access Control List contains multiple rules, then the device processes the rule with the numerically lowest value first.

Match every packet

Specifies to which IP data packets the device applies the rule.

Possible values:

- marked (default setting)
 - The device applies the rule to every IP data packet.
- unmarked

The device applies the rule to IP data packets depending on the value in the following fields:

- Source IP address, Destination IP address, Protocol
- DSCP, TOS priority, TOS mask
- ICMP type, ICMP code
- IGMP type
- Established
- Packet fragmented
- TCP flag

Source IP address

Specifies the source address of the IP data packets to which the device applies the rule.

Possible values:

- ?.?.?? (default setting) The device applies the rule to IP data packets with any source address.
 Valid IPv4 address
- The device applies the rule to IP data packets with the specified source address. You use the ? character as a wild card.

Example 192.?.?.32: The device applies the rule to IP data packets whose source address begins with 192. and ends with .32.

Valid IPv4 address/bit mask

The device applies the rule to IP data packets with the specified source address. The inverse bit mask lets you specify the address range with bit-level accuracy.

Example 192.168.1.0/0.0.0.127: The device applies the rule to IP data packets with a source address in the range from 192.168.1.0 to127.

Destination IP address

Specifies the destination address of the IP data packets to which the device applies the rule.

Possible values:

?.?.? (default setting)

The device applies the rule to IP data packets with any destination address.

Valid IPv4 address

The device applies the rule to data packets with the specified destination address.

You use the ? character as a wild card.

Example 192.?.?.32: The device applies the rule to IP data packets whose source address begins with 192. and ends with .32.

Valid IPv4 address/bit mask

The device applies the rule to data packets with the specified destination address. The inverse bit mask lets you specify the address range with bit-level accuracy.

Example 192.168.1.0/0.0.0.127: The device applies the rule to IP data packets with a destination address in the range from 192.168.1.0 to127.

Protocol

Specifies the IP protocol or Layer 4 protocol type of the data packets to which the device applies the rule. The device applies the rule only to data packets that contain the specified value in the *Protocol* field.

Possible values:

any (default setting)

The device applies the rule to every IP data packet without evaluating the protocol type.

▶ icmp

Internet Control Message Protocol (RFC 792)

▶ igmp

Internet Group Management Protocol

 ip-in-ip IP in IP tunneling (RFC 2003)

▶ tcp

Transmission Control Protocol (RFC 793)

▶ udp

User Datagram Protocol (RFC 768)

▶ ip

Internet Protocol

Source TCP/UDP port

Specifies the source port of the IP data packets to which the device applies the rule. The prerequisite is that in the *Protocol* column the value TCP or UDP is specified.

Possible values:

```
any (default setting)
```

The device applies the rule to every IP data packet without evaluating the source port.

▶ 1..65535 (2¹⁶-1)

The device applies the rule only to IP data packets containing the specified source port. To specify a port range, you can use one of the following operators:

- <

_ ``

- Range below the specified port number
- Range above the specified port number
- !=

Entire port range except the specified port

Destination TCP/UDP port

Specifies the destination port of the IP data packets to which the device applies the rule. The prerequisite is that in the *Protocol* column the value TCP or UDP is specified.

Possible values:

any (default setting)

The device applies the rule to every IP data packet without evaluating the destination port.

1..65535 (2¹⁶-1)

The device applies the rule only to IP data packets containing the specified destination port. To specify a port range, you can use one of the following operators:

- <

Range below the specified port number

Range above the specified port number
 !=

Entire port range except the specified port

DSCP

Specifies the Differentiated Service Code Point (DSCP value) in the header of the IP data packets to which the device applies the rule.

Possible values:

- (default setting)

- The device applies the rule to every IP data packet without evaluating the DSCP value.
- ▶ 0..63
 - The device applies the rule only to IP data packets containing the specified DSCP value.

TOS priority

Specifies the *IP Precedence (ToS)* value in the header of the IP data packets to which the device applies the rule.

Possible values:

- any (default setting)
 - The device applies the rule to every IP data packet without evaluating the *ToS* value.
- ▶ 0..7
 - The device applies the rule only to IP data packets containing the specified *ToS* value.

TOS mask

Specifies the bit mask for the *ToS* value in the header of the IP data packets to which the device applies the rule. The prerequisite is that in the *TOS priority* column a *ToS* value is specified.

Possible values:

- any (default setting)
 - The device applies the rule to IP data packets and evaluates the ToS value completely.
- ▶ 1..1f

The device applies the rule to IP data packets and evaluates the bits of the *ToS* value specified in the bit mask.

ICMP type

Specifies the ICMP type in the TCP header of the IP data packets to which the device applies the rule.

Possible values:

-1 (default setting)

ICMP type matching is inactive.

0..255

The device applies the rule to every IP data packet and evaluates the specified ICMP type.

ICMP code

Specifies the ICMP code in the TCP header of the IP data packets to which the device applies the rule. The prerequisite is that in the *ICMP type* field an ICMP value is specified.

Possible values:

-1 (default setting)

ICMP code matching is inactive.

▶ 0..255

The device applies the rule to every IP data packet and evaluates the specified ICMP code.

IGMP type

Specifies the IGMP type in the TCP header of the IP data packets to which the device applies the rule.

Possible values:

Ø (default setting)

IGMP type matching is inactive.

▶ 1..255

The device applies the rule to every IP data packet and evaluates the specified IGMP type.

Established

Activates/deactivates applying the ACL rule to TCP data packets which have either the RST bit, or the ACK bit set in the TCP header.

Possible values:

marked

The device applies the rule to every IP data packet in which the RST bit, or the ACK bit is set in the TCP header.

unmarked (default setting) Matching is inactive.

Packet fragmented

Activates/deactivates applying the ACL rule to the packet fragments.

To filter the complete data packet including its fragments, add 2 ACL rules.

- Create an ACL rule for the initial data packet to filter on both at the protocol level and at the TCP/ UDP ports.
- Create a second ACL rule for the fragments to filter only at the protocol level.

Possible values:

marked

The device applies the ACL rule to the fragments. Use this setting in the second ACL rule for the fragments.

unmarked (default setting) The device does not apply the ACL rule to the fragments.

TCP flag

Specifies the TCP flag and mask value.

The device lets you enter multiple values, by separating the values with a comma.

Specify the flags as either + or -.

Possible values:

(default setting)
 TCP flag matching is inactive.

- -

When you use this value in combination with the following flags, the device evaluates packets in which the flag is not set.

+

When you use this value in combination with the following flags, the device evaluates packets in which the flag is set.

▶ fin

Indicates that the sending device has finished its transmission.

► syn

Indicates that the Synchronize sequence numbers are significant. Only the first packet sent from each end device has this flag set.

rst

Indicates a reset of the TCP connection.

🕨 psh

Indicates the push function, in which a device asks to push the buffered data to the receiving application.

ack

Indicates that the Acknowledgment field is significant. Every packet, after the initial syn packet sent by the client, has this flag set.

urg

Indicates that the Urgent pointer field is significant.

Action

Specifies how the device processes received IP data packets when the device applies the rule.

Possible values:

permit (default setting)

The device forwards the IP data packets.

deny

The device drops the IP data packets.

Redirection port

Specifies the port to which the device forwards the IP data packets. The prerequisite is that in the *Action* column the value *permit* is specified. The device does not provide the option of mirroring IP data packets across VLAN boundaries.

Possible values:

- (default setting)

The *Redirection port* function is inactive.

Port number> The device forwards the IP data packets to the specified port.

Mirror port

Specifies the port to which the device forwards a copy of the IP data packets. The prerequisite is that in the *Action* column the value *permit* is specified. The device does not provide the option of mirroring IP data packets across VLAN boundaries.

Possible values:

- (default setting)
 The *Mirror port* function is inactive.
- <Port number>
 - The device forwards a copy of the IP data packets to the specified port.

Assigned queue ID

Specifies the priority queue to which the device assigns the IP data packets.

Possible values:

- (default setting)

▶ 0..7

Log

Activates/deactivates the logging in the log file. See the *Diagnostics > Report > System Log* dialog.

Possible values:

- marked
 - Logging is active.

The prerequisite is that in the *Network Security* > *ACL* > *Assignment* dialog the Access Control List is assigned to a VLAN or port.

The device registers in the log file, in an interval of 30 s, how many times it applied the deny rule to IP data packets.

unmarked (default setting) Logging is inactive.

The device lets you activate this function for up to 128 deny rules.

Time profile

Specifies if the device applies the rule permanently or time-controlled.

Possible values:

<empty> (default setting)

The device applies the rule permanently.

```
▶ [Time Profile]
```

The device applies the rule only at the times specified in the time profile. You edit the time profile in the *Network Security > ACL > Time Profile* dialog.

Rate limit

Specifies the limit for the data transfer rate for the port specified in the *Redirection port* column. The limit applies to the summary of the data sent and received.

This function limits the data stream on the port or in the VLAN:

Possible values:

 0 (default setting) No limitation of the data transfer rate.

1..4294967295 (2³²-1)

If the data transfer rate on the port exceeds the value specified, then the device discards superfluous IP data packets. The prerequisite is that in the *Burst size* column a value >0 is specified. You specify the measurement unit of the limit in the *Unit* column.

Unit

Specifies the measurement unit for the data transfer rate specified in the Rate limit column.

Possible values:

▶ kbps

kBytes per second

Burst size

Specifies the limit in KByte for the data volume during temporary bursts.

Possible values:

Image: 0 (default setting)

No limitation of the data volume.

1..128

If during temporary bursts on the port the data volume exceeds the value specified, then the device discards superfluous MAC data packets. The prerequisite is that in the *Rate limit* column a value >0 is specified.

Recommendation:

- If the bandwidth is known:
 Burst size = bandwidth × allowed duration of a burst / 8
- If the bandwidth is unknown:
 Burst size = 10 × MTU (Maximum Transmission Unit) of the port

4.8.2 ACL MAC Rule

[Network Security > ACL > MAC Rule]

In this dialog, you specify the rules that the device applies to the MAC data packets.

An Access Control List (group) contains one or more rules. The device applies the rules of an Access Control List successively, beginning with the rule with the numerically lowest value in the *Index* column.

The device lets you filter according to the following criteria:

- Source or destination MAC address of a data packet
- Type of the transmitting protocol
- Membership of a specific VLAN
- Service class of a data packet

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Opens the Create window to add a table row.

- · From the Group name drop-down list, you select the Access Control List name to which the rule
 - belongs or specify a new name. When you add a new name, click the + icon.
- In the *Index* field, you specify the number of the rule within the Access Control List. If the Access
 Control List contains multiple rules, then the device processes the rule with the lowest index
 value first.

x Remove

Removes the selected table row.

Group name

Displays the name of the Access Control List. The Access Control List contains the rules.

Index

Displays the number of the rule within the Access Control List. You specify the index number when you add a table row.

If the Access Control List contains multiple rules, then the device processes the rule with the numerically lowest value first.

Match every packet

Specifies to which MAC data packets the device applies the rule.

Possible values:

- marked (default setting)
 - The device applies the rule to every MAC data packet.
- unmarked
 - The device applies the rule to MAC data packets depending on the value in the following fields:
 - Source MAC address
 - Destination MAC address
 - Ethertype
 - Ethertype custom value
 - VLAN ID
 - COS

Source MAC address

Specifies the source address of the MAC data packets to which the device applies the rule.

Possible values:

- ??:??:??:??:??:?? (default setting)
 The device applies the rule to MAC data packets with any set
 - The device applies the rule to MAC data packets with any source address.
- Valid MAC address

The device applies the rule to MAC data packets with the specified source address. You use the ? character as a wild card.

Valid MAC address/bit mask

The device applies the rule to MAC data packets with the specified source address. The bit mask lets you specify the address range with bit-level accuracy.

Example 00:11:22:33:44:54/FF:FF:FF:FF:FC: The device applies the rule to MAC data packets with a source address in the range from 00:11:22:33:44:54 to ...:57.

Destination MAC address

Specifies the destination address of the MAC data packets to which the device applies the rule.

Possible values:

??:??:??:??:?? (default setting)

The device applies the rule to MAC data packets with any destination address.

Valid MAC address

The device applies the rule to MAC data packets with the specified destination address. You use the ? character as a wild card.

Example 00:11:??:??:??: The device applies the rule to MAC data packets whose destination address begins with 00:11.

Valid MAC address/bit mask The device applies the rule to MAC data packets with the specified source address. The bit mask lets you specify the address range with bit-level accuracy. Example 00:11:22:33:44:54/FF:FF:FF:FF:FF:FC: The device applies the rule to MAC data packets with a destination address in the range from 00:11:22:33:44:54 to ...:57.

Ethertype

Specifies the *Ethertype* keyword of the MAC data packets to which the device applies the rule.

Possible values:

custom (default setting)

The device applies the value specified in the *Ethertype custom value* column.

- appletalk
- 🕨 arp
- 🕨 ibmsna
- ipv4
- ▶ ipv6
- ▶ ipxold
- mplsmcast
- mplsucast
- netbios
- novell
- ▶ rarp
- pppoe

Ethertype custom value

Specifies the *Ethertype* value of the MAC data packets to which the device applies the rule. The prerequisite is that in the *Ethertype* column the value *custom* is specified.

Possible values:

Ø (default setting)

The device applies the rule to every MAC data packet without evaluating the *Ethertype* value.

▶ 600..ffff

The device applies the rule only to MAC data packets that contain the *Ethertype* value specified here.

VLAN ID

Specifies the VLAN ID of the MAC data packets to which the device applies the rule.

Possible values:

Image: 0 (default setting)

The device applies the rule to every MAC data packet without evaluating the VLAN ID.

▶ 1..4042

COS

Specifies the Class of Service (COS) value of the MAC data packets to which the device applies the rule.

Possible values:

▶ 0..7

any (default setting)

The device applies the rule to every MAC data packet without evaluating the Class of Service value.

Note: For data packets without a VLAN tag, the device uses the *Port priority* instead of the COS value.

Action

Specifies how the device processes received MAC data packets when the device applies the rule.

Possible values:

- permit (default setting)
 - The device forwards the MAC data packets.

deny

The device discards the MAC data packets.

Redirection port

Specifies the port to which the device forwards the MAC data packets. The prerequisite is that in the *Action* column the value *permit* is specified. The device does not provide the option of mirroring IP data packets across VLAN boundaries.

Possible values:

- (default setting)
 - The *Redirection port* function is inactive.
- <Port number>

The device forwards the MAC data packets to the specified port.

Mirror port

Specifies the port to which the device forwards a copy of the MAC data packets. The prerequisite is that in the *Action* column the value *permit* is specified. The device does not provide the option of mirroring IP data packets across VLAN boundaries.

Possible values:

 - (default setting) The *Mirror port* function is disabled.

<Port number>

The device forwards a copy of the MAC data packets to the specified port.

Assigned queue ID

Specifies the ID of the priority queue to which the device forwards the MAC data packets.

Possible values:

- (default setting)

▶ 0..7

Activates/deactivates the logging in the log file. See the Diagnostics > Report > System Log dialog.

Possible values:

marked

Logging is active.

The prerequisite is that in the *Network Security > ACL > Assignment* dialog the Access Control List is assigned to a VLAN or port.

The device registers in the log file, in an interval of 30 s, how many times it applied the deny rule to MAC data packets.

unmarked (default setting) Logging is inactive.

The device lets you activate this function for up to 128 deny rules.

Time profile

Specifies if the device applies the rule permanently or time-controlled.

Possible values:

- <empty> (default setting) The device applies the rule permanently.
- [Time Profile] The device applies the rule only at the times specified in the time profile. You edit the time profile in the Network Security > ACL > Time Profile dialog.

Rate limit

Specifies the limit for the data transfer rate for the port specified in the *Redirection port* column. The limit applies to the summary of the data sent and received.

This function limits the data stream on the port or in the VLAN:

Possible values:

- 0 (default setting) No limitation of the data transfer rate.
- 1..4294967295 (2³²-1)

If the data transfer rate on the port exceeds the value specified, then the device discards superfluous MAC data packets. The prerequisite is that in the *Burst size* column a value >0 is specified. You specify the measurement unit of the limit in the *Unit* column.

Unit

Specifies the measurement unit for the data transfer rate specified in the Rate limit column.

Possible values:

🕨 kbps

kBytes per second

Burst size

Specifies the limit in KByte for the data volume during temporary bursts.

Possible values:

- ♦ (default setting)
 - No limitation of the data volume.
- 1..128

If during temporary bursts on the port the data volume exceeds the value specified, then the device discards superfluous MAC data packets. The prerequisite is that in the *Rate limit* column a value >0 is specified.

Recommendation:

- If the bandwidth is known:
 Burst size = bandwidth × allowed duration of a burst / 8
- If the bandwidth is unknown:
 Burst size = 10 × MTU (Maximum Transmission Unit) of the port

4.8.3 ACL Assignment

[Network Security > ACL > Assignment]

This dialog lets you assign one or more Access Control Lists to the ports and VLANs of the device. By assigning a priority you specify the processing sequence, provided you assign one or more Access Control Lists to a port or VLAN.

The device applies rules successively, namely in the sequence specified by the rule index. You specify the priority of a group in the *Priority* column. The lower the number, the higher the priority. In this process, the device applies the rules with a high priority before the rules with a low priority.

The assignment of Access Control Lists to ports and VLANs results in the following different types of ACLs:

- Port-based IPv4 ACLs
- Port-based MAC ACLs
- VLAN-based IPv4 ACLs
- VLAN-based MAC ACLs

The device lets you apply the Access Control Lists to data packets received (inbound).

Note: Before you enable the function, verify that at least one active table row in the table lets you access. Otherwise, the connection to the device terminates if you change the settings. To access the device management is possible only using the CLI through the serial interface of the device.

Note: You cannot apply IP ACL rules and DiffServ rules together in the same direction on a port.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to assign a rule to a port or a VLAN.

- From the *Port/VLAN* drop-down list, you select the port or the VLAN to which the device applies the rule.
- In the *Priority* field, you specify the sequence in which the device applies the rules to the data stream.
- From the *Direction* drop-down list, you select if the device applies the rule to received or sent data packets.
- From the Group name drop-down list, you select the rule that the device assigns to the port or VLAN.



Removes the selected table row.

Group name

Displays the name of the Access Control List. The Access Control List contains the rules.

_	
Туре	Displays if the Access Control List contains MAC rules or IPv4 rules.
	Possible values:
	mac The Access Control List contains MAC rules.
	 <i>ip</i> The Access Control List contains IPv4 rules.
	You edit Access Control Lists with IPv4 rules in the <i>Network Security > ACL > IPv4 Rule</i> dialog. You edit Access Control Lists with MAC rules in the <i>Network Security > ACL > MAC Rule</i> dialog.
Port	
	Displays the port to which the Access Control List is assigned. The field remains empty when the Access Control List is assigned to a VLAN.
VLAN ID	
	Displays the VLAN to which the Access Control List is assigned. The field remains empty when the Access Control List is assigned to a port.
Direction	
	Displays that the device applies the Access Control List to received data packets. The device can apply the Access Control Lists only to received data packets.
Priority	
	Displays the priority of the Access Control List.
	Using the priority, you specify the sequence in which the device applies the Access Control Lists to the data stream. The device applies the rules in ascending order which starts with priority 1. If an Access Control List is assigned to a port and to a VLAN with the same priority, then the device applies the rules the rules to the port first.
	Possible values: ▶ 14294967295 (2 ³² -1)
Active	
Autive	Displays if the Access Control List on the port or in the VLAN is active.
	Possible values:
	marked (default setting) The Access Control List is active.
	unmarked

The Access Control List is inactive.

4.8.4 ACL Time Profile

[Network Security > ACL > Time Profile]

This dialog lets you set up time profiles. If you assign a time profile to an ACL rule, then the device applies the rule at the times specified in the time profile. If no time profile is assigned, the device applies the rule permanently.

The device lets you set up to 100 time profiles. The device applies the ACL rules during the time specified within the time period.

Each time profile can contain:

- One Absolute time period and up to 9 Periodic time periods
- or
- Up to 10 Periodic time periods

The implied *Deny-All* rule of the ACLs is permanently valid independently of the time control.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Note: If you reconfigure a time period, then first specify the end time and then the start time. Otherwise, the dialog displays an error message.

Buttons



Opens the Create window to add a time period.

• From the *Profile name* drop-down list, you select the name of the time profile to which the time

period belongs or specify a new name. When you add a new name, click the + icon.

- In the *Type* field, you specify the type of time period.
 - With the *Periodic* radio button, you specify a time period during which the device activates the recurring rule.
 - With the *Absolute* radio button, you specify a time period during which the device activates the rule one time. Within every time profile, exactly one such time period is allowed.



Removes the selected table row.

Profile name

Displays the name of the time profile. The time profile contains the time periods.

Operational status

Displays whether the status of the time profile is currently active/inactive.

Index

Displays the number of the time period within the time profile. The device automatically assigns the value when you add a table row.

Туре

Displays the time profile type.

Possible values:

- Absolute
 - The device applies the rule once. For more information, refer to columns Start date to End time.
- Periodic

The device applies the rule recurrently. For more information, refer to columns *Start days* to *End time*.

Absolute

Start date

Specifies the date at which the device starts to apply the one-time rule.

Possible values:

```
<Day of the week, date>
(depending on the language and region settings of your computer)
```

Start time

Specifies the time at which the device starts to apply the one-time rule.

Possible values:

hh:mm AM/PM Hour:Minute

End date

Specifies the date at which the device terminates the one-time rule.

Possible values:

```
<Day of the week, date>
(depending on the language and region settings of your computer)
```

The device also allows you to specify time periods that span several days.

Example:

- Start date: Sat
- Start time: 12:00 PM

- End date: Sun
- End time: 11:00 AM

End time

Specifies the time at which the device terminates the one-time rule.

Possible values:

hh:mm AM/PM Hour:Minute

Periodic

Start days

Specifies the days of the week on which the device periodically starts to apply the rule.

The device allows you to specify multiple values in the *Start days* column, for example a list of the weekdays *Mon*, *Tue*, *Wed*, *Thu*, *Fri*. In this case, verify that the *Start days* and *End days* fields contain identical values. The device then applies the rule every weekday at the times specified in the *Start time* and *End time* fields.

Possible values:

- 🕨 Sun
- Mon
- ► Tue
- ► Wed
- Thu
- **F**ri
- Sat

Start time

Specifies the time at which the device periodically starts to apply the rule.

Possible values:

hh:mm AM/PM Hour:Minute

End days

Specifies the days of the week on which the device periodically terminates the rule.

The device allows you to specify multiple values in the *End days* column, for example a list of the weekdays *Mon*,*Tue*,*Wed*,*Thu*,*Fri*. In this case, verify that the *Start days* and *End days* fields contain identical values. The device then applies the rule every weekday at the times specified in the *Start time* and *End time* fields.

The device also allows you to specify time periods that span several days. In this case, verify that the *Start days* and *End days* fields each contain a single value.

Example: Start days: Sat, Start time: 12:00 PM, End days: Sun, End time: 11:00 AM

Possible values:

- SunMon
- ► Tue
- ► Wed
- Thu
- 🕨 Fri
- Sat

End time

Specifies the time at which the device periodically terminates the rule.

Possible values:

hh:mm AM/PM Hour:Minute

5 Switching

The menu contains the following dialogs:

- Switching Global
- Rate Limiter
- Filter for MAC Addresses
- ► IGMP Snooping
- MRP-IEEE
- ► GARP
- QoS/Priority
- VLAN
- L2-Redundancy

5.1 Switching Global

[Switching > Global]

This dialog lets you specify the following settings:

- Change the Aging time of the MAC address table (forwarding database) entries
- Enable the flow control in the device
- Activate the VLAN-unaware mode function

If a large number of data packets are received in the priority queue of a port at the same time, then this can cause the port memory to overflow. This happens, for example, when the device receives data on a Gigabit port and forwards it to a port with a lower bandwidth. The device discards superfluous data packets.

The flow control mechanism defined in IEEE 802.3 helps ensure that no data packets are lost due to a buffer overflow on a port. Shortly before the buffer memory of a port is completely full, the device signals to the connected devices that it is not accepting any more data packets from them.

- In full-duplex mode, the device sends a pause data packet.
- In half-duplex mode, the device simulates a collision.

The connected devices then stop sending data packets for the duration of the signaling. On an uplink port, this can possibly cause undesired sending interruptions in the higher-level network segment ("wandering backpressure"). The flow control mechanism thus lowers the network to the bandwidth that the slowest device in the network can process.

According to IEEE 802.1Q, the device forwards data packets with a VLAN tag in a VLAN \geq 1. However, a few applications on connected end devices send or receive data packets with a VLAN ID=0. Data packets with a VLAN ID=0 are called *Priority Tagged Frames*. When the device receives one of these data packets, before forwarding it, the device overwrites the original value in the data packet with the VLAN ID of the receiving port.

If you activate the *VLAN-unaware mode* function, then this deactivates the VLAN settings in the device. The device then transparently forwards the data packets and evaluates the priority information contained only in the data packet.

Configuration

MAC address

Displays the MAC address of the device.

Aging time [s]

Specifies the aging time in seconds.

Possible values:

10..500000 (default setting: 30)

The device monitors the age of the learned unicast MAC addresses. The device deletes address entries that exceed a particular age (aging time) from its MAC address table (forwarding database).

You find the MAC address table (forwarding database) in the *Switching > Filter for MAC Addresses* dialog.

Flow control

Activates/deactivates the flow control in the device.

Possible values:

marked

The flow control is active in the device.

Additionally activate the flow control on the required ports. See the *Basic Settings > Port* dialog, *Configuration* tab, checkbox in the *Flow control* column.

unmarked (default setting) The flow control is inactive in the device.

If you are using a redundancy function, then you deactivate the flow control on the participating ports. If the flow control and the redundancy function are active at the same time, it is possible that the redundancy function operates differently than intended.

VLAN-unaware mode

Activates/deactivates the mode in which the device ignores the VLAN ID and forwards the data packets unchanged. The device continues to evaluate the priority information in the data packets.

On the connected end devices, only some applications require receiving data packets with a VLAN ID=0. If applications in the network require this, then activate the function.

Possible values:

marked

The device operates in the VLAN-unaware mode according to IEEE 802.1Q:

- The device ignores the VLAN settings in the device and the VLAN ID in the data packets.
 The device forwards the data packets based on their destination MAC address.
- The device evaluates the priority information contained in the VLAN tag of the data packets.
- The device ignores the VLAN settings specified in the Switching > VLAN > Configuration and Switching > VLAN > Port dialogs.

Note: You specify the VLAN ID 1 for every function in the device which uses VLAN settings. Among other things, this applies to static filters, MRP and IGMP Snooping.

unmarked (default setting)

The device operates in the VLAN-aware mode according to IEEE 802.1Q:

- The device evaluates the VLAN tags in the data packets.
- The device forwards the data packets based on their destination MAC address or destination IP address in the corresponding VLAN.
- The device evaluates the priority information contained in the data packet.
- When the device receives a data packet with a VLAN ID=0 it assigns the VLAN ID of the port to the data packet. See the *Switching* > *VLAN* > *Port* dialog.

5.2 Rate Limiter

[Switching > Rate Limiter]

The device lets you limit the amount of data packets on the ports to help provide stable operation even with a large data volume. If the amount of data packets on a port exceed the threshold value, then the device discards the excess data packets on this port.

The rate limiter function operates only on Layer 2, and is used to limit the effects of storms of data packets that flood the device (typically Broadcasts).

The rate limiter function ignores protocol information on higher layers, such as IP or TCP.

The dialog contains the following tabs:

[Ingress][Egress]

[Ingress]

In this tab you enable the *Rate Limiter* function. The threshold value specifies the maximum amount of data packets the port receives. If the amount of data packets on a port exceed the specified threshold value, then the device discards the excess data packets on this port.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Unit

Specifies the unit for the threshold value:

Possible values:

percent (default setting)

Specifies the threshold value as a percentage of the data rate of the port.

▶ pps

Specifies the threshold value in data packets per second.

Broadcast mode

Activates/deactivates the rate limiter function for received broadcast data packets.

Possible values:

marked

unmarked (default setting)

If the threshold value is exceeded, then the device discards the excess broadcast data packets on this port.

Broadcast threshold

Specifies the threshold value for received broadcasts on this port.

Possible values:

- 0..14880000 (default setting: 0)
 - The value 0 deactivates the rate limiter function on this port.
 - □ If you select the value *percent* in the *Unit* column, then enter a percentage value from 1 to 100.
 - □ If you select the value *pps* in the *Unit* column, then enter an absolute value for the data rate.

Multicast mode

Activates/deactivates the rate limiter function for received multicast data packets.

Possible values:

- marked
- unmarked (default setting)

If the threshold value is exceeded, then the device discards the excess multicast data packets on this port.

Multicast threshold

Specifies the threshold value for received multicasts on this port.

Possible values:

- 0..14880000 (default setting: 0)
 - The value Ø deactivates the rate limiter function on this port.
 - □ If you select the value *percent* in the *Unit* column, then enter a percentage value from 0 to 100.
 - □ If you select the value *pps* in the *Unit* column, then enter an absolute value for the data rate.

Unknown unicast mode

Activates/deactivates the rate limiter function for received unicast data packets with an unknown destination address.

Possible values:

marked

unmarked (default setting)

If the threshold value is exceeded, then the device discards the excess unicast data packets on this port.

Unicast threshold

Specifies the threshold value for received unicasts with an unknown destination address on this port.

Possible values:

0..14880000 (default setting: 0)

The value 0 deactivates the rate limiter function on this port.

- □ If you select the value *percent* in the *Unit* column, then enter a percentage value from 0 to 100.
- □ If you select the value *pps* in the *Unit* column, then enter an absolute value for the data rate.

[Egress]

In this tab you specify the egress transmission rate on the port.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Bandwidth [%]

Specifies the egress transmission rate.

Possible values:

- Image: 0 (default setting)
 - The bandwidth limitation is disabled.

▶ 1..100

The bandwidth limitation is enabled. This value specifies the percentage of overall link speed for the port in 1% increments.

5.3 Filter for MAC Addresses

[Switching > Filter for MAC Addresses]

This dialog lets you display and edit address filters for the MAC address table (forwarding database). Address filters specify the way the data packets are forwarded in the device based on the destination MAC address.

Each table row represents one filter. The device automatically sets up the filters. The device lets you set up additional filters manually.

The device forwards the data packets as follows:

- When the table contains the destination address of a data packet, the device forwards the data packet from the receiving port to the port specified in the table row.
- When there is no table row for the destination address, the device forwards the data packet from the receiving port to every other port.

Table

To delete the learned MAC addresses from the MAC address table (forwarding database), click in the *Basic Settings > Restart* dialog the *Clear FDB* button.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

- In the MAC address field, you specify the destination MAC address.
- In the VLAN ID field, you specify the VLAN ID.
- In the list field, you select the ports.
 - □ If the destination MAC address is a unicast address, select exactly one port.
 - □ If the destination MAC address is a multicast or broadcast address, select one or more ports.
 - □ Do not select a port to add a *Discard* filter. The device discards data packets with the destination MAC address specified in the table row.



Removes the selected table row.



Removes the MAC addresses from the forwarding table that have the value *Learned* in the *Status* column.

Address

Displays the destination MAC address to which the table row relates.

VLAN ID

Displays the ID of the VLAN to which the table row relates.

The device learns the MAC addresses for every VLAN separately (independent VLAN learning).

Status

Displays how the device has set up the address filter.

Possible values:

▶ Learned

Address filter set up automatically by the device based on received data packets.

Mgmt

MAC address of the device. The address filter is protected against changes.

▶ Other

Static address added by the following function:

- 802.1X
- Port Security
- Permanent

Address filter set up manually. The address filter stays set up permanently.

► GMRP

Multicast address filter automatically set up by GMRP.

► IGMP

Address filter automatically set up by IGMP Snooping.

MRP-MMRP

Multicast address filter automatically set up by MMRP.

<Port number>

Displays how the corresponding port transmits data packets which it directs to the adjacent destination address.

Possible values:

▶ -

The port does not transmit any data packets to the destination address.

learned

The port transmits data packets to the destination address. The device has automatically set up the filter based on received data packets.

▶ IGMP learned

The port transmits data packets to the destination address. The device has automatically set up the filter based on IGMP.

unicast static

The port transmits data packets to the destination address. A user has set up the filter.

multicast static

The port transmits data packets to the destination address. A user has set up the filter.

5.4 IGMP Snooping

[Switching > IGMP Snooping]

The Internet Group Management Protocol (IGMP) is a protocol for dynamically managing Multicast groups. The protocol describes the distribution of Multicast data packets between routers and end devices on Layer 3.

The device lets you use the IGMP Snooping function to also use the IGMP mechanisms on Layer 2:
Without IGMP Snooping, the device forwards the Multicast data packets to every port.

 With the activated IGMP Snooping function, the device forwards the Multicast data packets only on ports to which Multicast receivers are connected. This reduces the network load. The device evaluates the IGMP data packets transmitted on Layer 3 and uses the information on Layer 2.

Activate the IGMP Snooping function not until the following conditions are fulfilled:

- There is a Multicast router in the network that generates IGMP queries (periodic queries).
- The devices participating in IGMP Snooping forward the IGMP queries.

The device links the IGMP reports with the entries in its MAC address table (forwarding database). When a multicast receiver joins a multicast group, the device adds a table row for this port in the *Switching > Filter for MAC Addresses* dialog. When the multicast receiver leaves the multicast group, the device removes the table row.

The menu contains the following dialogs:

- IGMP Snooping Global
- ► IGMP Snooping Configuration
- IGMP Snooping Enhancements
- ► IGMP Snooping Querier
- IGMP Snooping Multicasts

5.4.1 IGMP Snooping Global

[Switching > IGMP Snooping > Global]

This dialog lets you enable the *IGMP Snooping* function in the device and set the function up for each port and each VLAN.

Operation

Operation

Enables/disables the IGMP Snooping function in the device.

Possible values:

🕨 On

The *IGMP Snooping* function is enabled in the device according to RFC 4541 (*Considerations for Internet Group Management Protocol (IGMP) and Multicast Listener Discovery (MLD) Snooping Switches*).

Off (default setting)

The *IGMP Snooping* function is disabled in the device.

The device transmits received query, report, and leave data packets without evaluating them. Received data packets with a Multicast destination address are transmitted to every port by the device.

Information

Buttons



Removes the IGMP Snooping entries and resets the counter in the Information frame to 0.

Processed multicast controls

Displays the number of Multicast control data packets processed.

This statistic encompasses the following packet types:

- IGMP Reports
- IGMP Queries version V1
- IGMP Queries version V2
- IGMP Queries version V3
- IGMP Queries with an incorrect version
- PIM or DVMRP packets

The device uses the Multicast control data packets to set up the MAC address table (forwarding database) for transmitting the Multicast data packets.

Possible values:

▶ 0..2147483647 (2³¹-1)

You use the *Clear IGMP snooping data* button in the *Basic Settings > Restart* dialog or the command clear igmp-snooping using the Command Line Interface to reset the IGMP Snooping entries, including the counter for the processed multicast control data packets.

5.4.2 IGMP Snooping Configuration

[Switching > IGMP Snooping > Configuration]

This dialog lets you enable the *IGMP Snooping* function in the device and set the function up for each port and each VLAN.

The dialog contains the following tabs:

[VLAN ID][Port]

[VLAN ID]

In this tab you set up the IGMP Snooping function for every VLAN.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

VLAN ID

Displays the ID of the VLAN to which the table row relates.

Active

Activates/deactivates the IGMP Snooping function for this VLAN.

The prerequisite is that the IGMP Snooping function is globally enabled.

Possible values:

marked

IGMP Snooping is activated for this VLAN. The VLAN has joined the Multicast data stream.

unmarked (default setting) IGMP Snooping is deactivated for this VLAN. The VLAN has left the Multicast data stream.

Group membership interval

Specifies the time in seconds for which a VLAN from a dynamic Multicast group remains entered in the MAC address table (forwarding database) when the device does not receive any more report data packets from the VLAN.

Specify a value larger than the value in the Max. response time column.

Possible values:

2..3600 (default setting: 260)

Max. response time

Specifies the time in seconds in which the members of a Multicast group respond to a query data packet. For their response, the members specify a random time within the response time. You thus help prevent the multicast group members from responding to the query at the same time.

Specify a value smaller than the value in the Group membership interval column.

Possible values:

1..25 (default setting: 10)

Fast leave admin mode

Activates/deactivates the Fast Leave function for this VLAN.

Possible values:

marked

When the Fast Leave function is active and the device receives an IGMP Leave message from a multicast group, the device immediately removes the entry from its MAC address table (forwarding database).

unmarked (default setting)

When the Fast Leave function is inactive, the device first sends MAC-based queries to the members of the multicast group and removes an entry when a VLAN does not send any more report messages.

MRP expiration time

Multicast Router Present Expiration Time. Specifies the time in seconds for which the device waits for a query on this port that belongs to a VLAN. When the port does not receive a query data packet, the device removes the port from the list of ports with connected multicast routers.

You have the option of configuring this parameter only if the port belongs to an existing VLAN.

Possible values:

▶ 0

unlimited timeout - no expiration time

1..3600 (default setting: 260)

[Port]

In this tab you set up the IGMP Snooping function for every port.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Active

Activates/deactivates the IGMP Snooping function on the port.

The prerequisite is that the IGMP Snooping function is globally enabled.

Possible values:

- marked (default setting) IGMP Snooping is active on this port. The device includes the port in the multicast data stream.
- unmarked IGMP Snooping is inactive on this port. The port left the multicast data stream.

Group membership interval

Specifies the time in seconds for which a port, from a dynamic multicast group, remains entered in the MAC address table (forwarding database) when the device does not receive any more report data packets from the port.

Possible values:

2..3600 (default setting: 260)

Specify the value larger than the value in the Max. response time column.

Max. response time

Specifies the time in seconds in which the members of a Multicast group respond to a query data packet. For their response, the members specify a random time within the response time. You thus help prevent the multicast group members from responding to the query at the same time.

Possible values:

1..25 (default setting: 10)

Specify a value lower than the value in the Group membership interval column.

MRP expiration time

Specifies the Multicast Router Present Expiration Time. The MRP expiration time is the time in seconds for which the device waits for a query packet on this port. When the port does not receive a query data packet, the device removes the port from the list of ports with connected multicast routers.

Possible values:

• 0

unlimited timeout - no expiration time

1...3600 (default setting: 260)

Fast leave admin mode

Activates/deactivates the Fast Leave function on the port.

Possible values:

marked

When the Fast Leave function is active and the device receives an IGMP Leave message from a multicast group, the device immediately removes the entry from its MAC address table (forwarding database).

unmarked (default setting)

When the Fast Leave function is inactive, the device first sends MAC-based queries to the members of the multicast group and removes an entry when a port does not send any more report messages.

Static query port

Activates/deactivates the Static query port mode.

Possible values:

marked

The *Static query port* mode is active. The port is a static query port in the set-up VLANs. If you use the *RCP* function and the device operates as slave, then do not activate the *Static query port* mode for the ports on the secondary ring/network.

unmarked (default setting) The Static query port mode is inactive. The port is not a static query port. The device transmits IGMP report messages to the port only if it receives IGMP queries.

VLAN IDs

Displays the ID of the VLANs to which the table row relates.

5.4.3 IGMP Snooping Enhancements

[Switching > IGMP Snooping > Snooping Enhancements]

This dialog lets you select a port for a VLAN and to set up the port.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the *Wizard* window that helps you select and set up the ports. See "[Wizard: IGMP snooping enhancements]" on page 257.

VLAN ID

Displays the ID of the VLAN to which the table row relates.

<Port number>

Displays for every VLAN set up in the device if the relevant port is a query port. Additionally, the field displays if the device transmits every Multicast stream in the VLAN to this port.

Possible values:

> -

The port is not a query port in this VLAN.

L = Learned

The device detected the port as a query port because the port received IGMP queries in this VLAN. The port is not a statically set up query port.

A = Automatic

The device detected the port as a query port. The prerequisite is that you set up the port as *Learn* by *LLDP*.

S = Static (manual setting)

A user specified the port as a static query port. The device transmits IGMP reports only to ports on which it previously received IGMP queries – and to statically set-up query ports.

- To assign this value, perform the following steps:
- Open the *Wizard* window.
- □ On the *Configuration* page, mark the *Static* checkbox.

- P = Learn by LLDP (manual setting)
 - A user specified the port as Learn by LLDP.

With the Link Layer Discovery Protocol (LLDP), the device detects Hirschmann devices connected directly to the port. The device denotes the detected query ports with A. To assign this value, perform the following steps:

- Open the *Wizard* window.
- On the *Configuration* page, mark the *Learn by LLDP* checkbox.
- F = Forward All (manual setting)

A user specified the port so that the device forwards every received Multicast stream in the VLAN to this port. Use this setting for diagnostic purposes, for example.

- To assign this value, perform the following steps:
- Open the *Wizard* window.
- □ On the *Configuration* page, mark the *Forward all* checkbox.

Display categories

Enhances the clarity of the display. The table emphasizes the cells which contain the specified value. This helps to analyze and sort the table according to your needs.

Possible values:

Learned (L)

The table displays cells which contain the value L and possibly further values. Cells which contain other values than L only, the table displays with the "-" symbol.

Static (S)

The table displays cells which contain the value S and possibly further values. Cells which contain other values than S only, the table displays with the "-" symbol.

Automatic (A)

The table displays cells which contain the value A and possibly further values. Cells which contain other values than A only, the table displays with the "-" symbol.

► Learned by LLDP (P)

The table displays cells which contain the value P and possibly further values. Cells which contain other values than P only, the table displays with the "-" symbol.

► Forward all (F)

The table displays cells which contain the value F and possibly further values. Cells which contain other values than F only, the table displays with the "-" symbol.

[Wizard: IGMP snooping enhancements]

The *Wizard* window helps you select and set up the ports.

The *Wizard* window guides you through the following steps:

- Selection VLAN/Port
- Configuration

After closing the *Wizard* window, click the ✓ button to save your settings.

Selection VLAN/Port

VLAN ID

Select the VLAN ID.

Port

Select the ports.

Configuration

/LAN ID	
	Displays the selected VLAN ID.

Port

Displays the number of the selected ports.

Static

Specifies the port as a static query port in the set-up VLANs. The device transmits IGMP report messages to the ports at which it receives IGMP queries. This lets you also transmit IGMP report messages to other selected ports or connected Hirschmann devices (Automatic).

Learn by LLDP

Specifies the port as *Learn by LLDP*. Lets the device detect directly connected Hirschmann devices using LLDP and learn the related ports as a query port.

Forward all

Specifies the port as *Forward all*. With the *Forward all* setting, the device sends on this port every data packet with a Multicast address in the destination address field.

5.4.4 IGMP Snooping Querier

[Switching > IGMP Snooping > Querier]

The device forwards a Multicast stream only to those ports to which a Multicast receiver is connected.

To detect which ports Multicast receivers are connected to, the device sends query data packets on the ports at a given interval. When a Multicast receiver is connected, it joins the Multicast stream by responding to the device with a report data packet.

This dialog lets you set up the Snooping Querier settings globally and for the set-up VLANs.

Operation

Operation

Enables/disables the IGMP Querier function globally in the device.

Possible values:

► On

Off (default setting)

Configuration

In this frame you specify the IGMP Snooping Querier settings for the General Query data packets.

Protocol versior

Specifies the IGMP version of the General Query data packets.

Possible values:

```
1
IGMP v1
2 (default setting)
IGMP v2
3
IGMP v3
```

Query interval [s]

Specifies the time in seconds after which the device itself generates *General Query* data packets when it has received query data packets from the Multicast router.

Possible values:

1..1800 (default setting: 60)

Expiry interval [s]

Specifies the time in seconds after which an active querier switches from the passive state back to the active state if it has not received any query packets for longer than specified here.

Possible values:

▶ 60..300 (default setting: 125)

Table

In the table you specify the Snooping Querier settings for the set-up VLANs.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

VLAN ID

Displays the ID of the VLAN to which the table row relates.

Active

Activates/deactivates the IGMP Snooping Querier function for this VLAN.

Possible values:

marked

The IGMP Snooping Querier function is active for this VLAN.

unmarked (default setting) The IGMP Snooping Querier function is inactive for this VLAN.

Current state

Displays if the Snooping Querier is active for this VLAN.

Possible values:

- marked
 - The Snooping Querier is active for this VLAN.
- unmarked

The Snooping Querier is inactive for this VLAN.

IP address

Specifies the IP address that the device adds as the source address in generated *General Query* data packets. You use the address of the multicast router.

Possible values:

Valid IPv4 address (default setting: 0.0.0.0)

Protocol version

Displays the Internet Group Management Protocol (IGMP) version of the *General Query* data packets.

Possible values:

1 IGMP v1
2 (default setting) IGMP v2
3 IGMP v3

Max. response time

Displays the time in seconds in which the members of a Multicast group respond to a query data packet. For their response, the members specify a random time within the response time. This helps prevent every Multicast group member to respond to the query at the same time.

Last querier address

Displays the IP address of the Multicast router from which the last received IGMP query was sent out..

Last querier version

Displays the IGMP version that the Multicast router used when sending out the last IGMP query received in this VLAN.

5.4.5 IGMP Snooping Multicasts

[Switching > IGMP Snooping > Multicasts]

The device lets you specify how it forwards data packets with unknown Multicast addresses: Either the device discards these data packets, floods them to every port, or forwards them only to the ports that previously received query packets.

The device also forwards the data packets with known Multicast addresses to the query ports.

Configuration

Unknown multicasts

Specifies how the device forwards data packets with unknown Multicast addresses.

Possible values:

Discard

The device discards data packets with an unknown MAC Multicast address.

- Send to all ports (default setting)
- The device forwards data packets with an unknown MAC Multicast address to every port.
- Send to query ports The device forwards data packets with an unknown MAC Multicast address to the query ports.

Table

In the table you specify the settings for known Multicasts for the set-up VLANs.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

VLAN ID

Displays the ID of the VLAN to which the table row relates.

Known multicasts

Specifies how the device forwards data packets with known Multicast addresses.

Possible values:

send to query and registered ports

The device forwards data packets with a known MAC/IP Multicast address to the query ports and to the registered ports.

send to registered ports (default setting) The device forwards data packets with a known MAC/IP Multicast address to registered ports.

5.5 MRP-IEEE

[Switching > MRP-IEEE]

The IEEE 802.1ak amendment to the IEEE 802.1Q standard introduced the Multiple Registration Protocol (MRP) to replace the Generic Attribute Registration Protocol (GARP). The IEEE standards association also modified and replaced the GARP applications, GARP Multicast Registration Protocol (GMRP) and GARP VLAN Registration Protocol (GVRP). The Multiple MAC Registration Protocol (MMRP) and the Multiple VLAN Registration Protocol (MVRP) replace these protocols.

MRP-IEEE helps confine traffic to the required areas of the LAN. To confine traffic, the MRP-IEEE applications distribute attribute values to participating MRP-IEEE devices across a LAN registering and de-registering multicast group membership and VLAN identifiers.

Registering group participants lets you reserve resources for specific data packets transversing a LAN. Defining resource requirements regulates the level of traffic, allowing the devices to determine the required resources and provides for dynamic maintenance of the allocated resources.

The menu contains the following dialogs:

- MRP-IEEE Configuration
- MRP-IEEE Multiple MAC Registration Protocol
- MRP-IEEE Multiple VLAN Registration Protocol

5.5.1 MRP-IEEE Configuration

[Switching > MRP-IEEE > Configuration]

This dialog lets you set the various MRP timers. By maintaining a relationship between the various timer values, the protocol operates efficiently and with less likelihood of unnecessary attribute withdraws and re-registrations. The default timer values effectively maintain these relationships.

When you reconfigure the timers, maintain the following relationships:

- To allow for re-registration after a Leave or LeaveAll event, even if there is a lost message, specify the LeaveTime to: ≥ (2x JoinTime) + 60.
- To minimize the volume of rejoining data packets generated following a LeaveAll event, specify the value for the LeaveAll timer larger than the LeaveTime value.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Join time [1/100s]

Specifies the Join timer which controls the interval between transmit opportunities applied to the Applicant state machine.

Possible values:

10..100 (default setting: 20)

Leave time [1/100s]

Specifies the Leave timer which controls the period that the Registrar state machine waits in the leave (LV) state before transiting to the empty (MT) state.

Possible values:

20..600 (default setting: 60)

Leave all time [1/100s]

Specifies the LeaveAll timer which controls the frequency with which the LeaveAll state machine generates LeaveAll PDUs.

Possible values:

200..6000 (default setting: 1000)

5.5.2 MRP-IEEE Multiple MAC Registration Protocol

[Switching > MRP-IEEE > MMRP]

The Multiple MAC Registration Protocol (MMRP) lets end devices and MAC switches register and de-register group membership and individual MAC address information with switches located in the same LAN. The switches within the LAN disseminate the information through switches that support extended filtering services. Using the MAC address information, MMRP lets you confine multicast traffic to the required areas of a Layer 2 network.

For an example of how MMRP works, consider a security camera mounted on a mast overlooking a building. The camera sends multicast packets onto a LAN. You have 2 end devices installed for surveillance in separate locations. You register the MAC addresses of the camera and the 2 end devices in the same multicast group. You then specify the MMRP settings on the ports to send the multicast group packets to the 2 end devices.

The dialog contains the following tabs:

- ▶ [Configuration]
- [Service requirement]
- ▶ [Statistics]

[Configuration]

In this tab you select active MMRP port participants and set the device to transmit periodic events. The dialog also lets you enable VLAN registered MAC address broadcasting.

A periodic state machine exists for each port and transmits periodic events regularly to the applicant state machines associated with active ports. Periodic events contain information indicating the status of the devices associated with the active port.

Operation

Operation

Enables/disables the global *MMRP* function in the device. The device participates in MMRP message exchanges.

Possible values:

▶ On

The device is a normal participant in MMRP message exchanges.

Off (default setting)
 The device ignores MMRP messages.

Configuration

Periodic state machine

Enables/disables the global periodic state machine in the device.

Possible values:

▶ On

With MMRP *Operation* enabled globally, the device transmits MMRP messages in one-second intervals, on MMRP participating ports.

Off (default setting)
 Disables the periodic state machine in the device.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Active

Activates/deactivates the port MMRP participation.

Possible values:

- marked (default setting) With MMRP enabled globally and on this port, the device sends and receives MMRP messages on this port.
- unmarked Disables the port MMRP participation.

Restricted group registration

Activates/deactivates the restriction of dynamic MAC address registration using MMRP on the port.

Possible values:

marked

If enabled and a static filter entry for the MAC address exists on the VLAN concerned, then the device registers the MAC address attributes dynamically.

unmarked (default setting)

Activates/deactivates the restriction of dynamic MAC address registration using MMRP on the port.

[Service requirement]

This tab contains forwarding parameters for each active VLAN, specifying the ports on which multicast forwarding applies. The device lets you statically setup VLAN ports as *Forward all* or Forbidden. You set the Forbidden MMRP service requirement statically only through the Graphical User Interface or Command Line Interface.

A port is setup only as ForwardAll or Forbidden.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

VLAN ID

Displays the ID of the VLAN.

<Port number>

Specifies the service requirement handling for the port.

Possible values:

FA

Specifies the ForwardAll traffic setting on the port. The device forwards the data packets destined to MMRP registered multicast MAC addresses on the VLAN. The device forwards the data packets to ports which MMRP has dynamically setup or ports which the administrator has statically setup as ForwardAll ports.

► F

Specifies the Forbidden traffic setting on the port. The device blocks dynamic MMRP ForwardAll service requirements. With ForwardAll requests blocked on this port in this VLAN, the device blocks the data packets destined to MMRP registered multicast MAC addresses on this port. Furthermore, the device blocks MMRP service request for changing this value on this port.

- (default setting)
 Disables the forwarding functions on this port.
- Learned

Displays values setup by MMRP service requests.

[Statistics]

Devices on a LAN exchange Multiple MAC Registration Protocol Data Units (MMRPDUs) to maintain statuses of devices on an active MMRP port. This tab lets you monitor the MMRP data packets statistics for each port.

Information

Buttons



Resets the port statistics counters and the values in the Last received MAC address column.

Transmitted MMRP PDU

Displays the number of MMRPDUs transmitted in the device.

Received MMRP PDU

Displays the number of MMRPDUs received in the device.

Received bad header PDU

Displays the number of MMRPDUs received with a bad header in the device.

Received bad format PDU

Displays the number of MMRPDUs with a bad data field that were not transmitted in the device.

Transmission failed

Displays the number of MMRPDUs not transmitted in the device.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Transmitted MMRP PDU

Displays the number of MMRPDUs transmitted on the port.

Received MMRP PDU

Displays the number of MMRPDUs received on the port.

Received bad header PDU

Displays the number of MMRPDUs with a bad header that were received on the port.

Received bad format PDU

Displays the number of MMRPDUs with a bad data field that were not transmitted on the port.

Transmission failed

Displays the number of MMRPDUs not transmitted on the port.

Last received MAC address

Displays the MAC address from which the port last received MMRPDUs.

5.5.3 MRP-IEEE Multiple VLAN Registration Protocol

[Switching > MRP-IEEE > MVRP]

The Multiple VLAN Registration Protocol (MVRP) provides a mechanism that lets you distribute VLAN information and configure VLANs dynamically. For example, when you configure a VLAN on an active MVRP port, the device distributes the VLAN information to other MVRP enabled devices. Using the information received, an MVRP enabled device dynamically generates the VLAN trunks on other MVRP enabled devices as needed.

The dialog contains the following tabs:

[Configuration]

▶ [Statistics]

[Configuration]

In this tab you select active MVRP port participants and set the device to transmit periodic events.

A periodic state machine exists for each port and transmits periodic events regularly to the applicant state machines associated with active ports. Periodic events contain information indicating the status of the VLANs associated with the active port. Using the periodic events, MVRP enabled switches dynamically maintain the VLANs.

Operation

Operation

Enables/disables the global Applicant Administrative Control which specifies if the Applicant state machine participates in MMRP message exchanges.

Possible values:

🕨 On

Normal Participant. The Applicant state machine participates in MMRP message exchanges.

Off (default setting)

Non-Participant. The Applicant state machine ignores MMRP messages.

Configuration

Periodic state machine

Enables/disables the periodic state machine in the device.

Possible values:

▶ On

The periodic state machine is enabled. With MVRP *Operation* enabled globally, the device transmits MVRP periodic events every 1 s, on MVRP participating ports.

off (default setting)
 The periodic state machine is disabled.
 Disables the periodic state machine in the device.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Active

Activates/deactivates the port MVRP participation.

Possible values:

marked (default setting) With MVRP enabled globally and on this port, the device distributes VLAN membership information to MVRP-aware devices connected to this port.

unmarked Disables the port MVRP participation.

Restricted VLAN registration

Activates/deactivates the Restricted VLAN registration function on this port.

Possible values:

marked

If enabled and a static VLAN registration entry exists, then the device lets you add a dynamic VLAN for this entry.

unmarked (default setting) Disables the *Restricted VLAN registration* function on this port.

[Statistics]

Devices on a LAN exchange Multiple VLAN Registration Protocol Data Units (MVRPDUs) to maintain statuses of VLANs on active ports. This tab lets you monitor the MVRP data packets.

Information

Buttons



Resets the port statistics counters and the values in the Last received MAC address column.

Transmitted MVRP PDU

Displays the number of MVRPDUs transmitted in the device.

Received MVRP PDU

Displays the number of MVRPDUs received in the device.

Received bad header PDU

Displays the number of MVRPDUs received with a bad header in the device.

Received bad format PDU

Displays the number of MVRPDUs with a bad data field that the device blocked.

Transmission failed

Displays the number of detected failures while adding a message into the MVRP queue.

Message queue failures

Displays the number of MVRPDUs that the device blocked.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Transmitted MVRP PDU

Displays the number of MVRPDUs transmitted on the port.

Received MVRP PDU

Displays the number of MVRPDUs received on the port.

Received bad header PDU

Displays the number of MVRPDUs with a bad header that the device received on the port.

Received bad format PDU

Displays the number of MVRPDUs with a bad data field that the device blocked on the port.

Transmission failed

Displays the number of MVRPDUs that the device blocked on the port.

Registrations failed

Displays the number of unsuccessful registration attempts on the port.

Last received MAC address

Displays the MAC address from which the port last received MVRPDUs.

5.6 GARP

[Switching > GARP]

The Generic Attribute Registration Protocol (GARP) is defined by the IEEE standards association to provide a generic framework so switches can register and deregister attribute values, such as VLAN identifiers and multicast group membership.

When an attribute for a participant is registered or deregistered according to GARP, the participant is modified according to specific rules. The participants are a set of reachable end stations and network devices. The defined set of participants at any given time, along with their attributes, is the reachability tree for the subset of the network topology. The device forwards the data frames only to the registered end stations. The station registration helps prevent attempts to send data to the end stations that are unreachable.

Note: Before you enable the *GMRP* function, verify that the *MMRP* function is disabled.

The menu contains the following dialogs:

GMRPGVRP

5.6.1 **GMRP**

[Switching > GARP > GMRP]

The GARP Multicast Registration Protocol (GMRP) is a Generic Attribute Registration Protocol (GARP) that provides a mechanism allowing network devices and end stations to dynamically register group membership. The devices register group membership information with the devices attached to the same LAN segment. GARP also lets the devices distribute the information across the network devices that support extended filtering services.

GMRP and GARP are industry-standard protocols defined by the IEEE 802.1D.

Operation

Operation

Enables/disables the global *GMRP* function in the device. The device participates in GMRP message exchanges.

Possible values:

► On

GMRP is enabled.

Off (default setting) The device ignores GMRP messages.

Multicasts

Unknown multicasts

Enables/disables the unknown multicast data to be either flooded or discarded.

Possible values:

discard

The device discards unknown multicast data.

fLood (default setting) The device forwards unknown multicast data to every port.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

GMRP active

Activates/deactivates the port GMRP participation.

The prerequisite is that the *GMRP* function is globally enabled.

Possible values:

marked (default setting) The port *GMRP* participation is active.

unmarked

The port GMRP participation is inactive.

Service requirement

Specifies the ports on which multicast forwarding applies.

Possible values:

- Forward all unregistered groups (default setting) The device forwards data destined to GMRP-registered multicast MAC addresses on the VLAN. The device forwards data to the unregistered groups.
- Forward all groups

The device forwards data destined to every group, registered or unregistered.

5.6.2 GVRP

[Switching > GARP > GVRP]

The GARP VLAN Registration Protocol or Generic VLAN Registration Protocol (GVRP) is a protocol that facilitates control of Virtual Local Area Networks (VLANs) within a larger network. GVRP is a Layer 2 network protocol, used to automatically set up devices in a VLAN network.

GVRP is a GARP application that provides IEEE 802.1Q-compliant VLAN pruning, and setting up dynamic VLAN on 802.1Q trunk ports. With GVRP, the device exchanges VLAN configuration information with other GVRP devices. Thus, the device reduces the unnecessary broadcast and unknown unicast traffic. Exchanging VLAN configuration information also lets you dynamically add and manage VLANs connected through the 802.1Q trunk ports.

Operation

Operation

Enables/disables the *GVRP* function globally in the device. The device participates in *GVRP* message exchanges. If the function is disabled, then the device ignores *GVRP* messages.

Possible values:

🕨 On

The GVRP function is enabled.

Off (default setting)
 The *GVRP* function is disabled.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

GVRP active

Activates/deactivates the port GVRP participation.

The prerequisite is that the GVRP function is globally enabled.

Possible values:

- marked (default setting) The port *GVRP* participation is active.
 unmarked
 - The port *GVRP* participation is inactive.

5.7 QoS/Priority

[Switching > QoS/Priority]

Communication networks transmit a number of applications at the same time that have different requirements as regards availability, bandwidth and latency periods.

QoS (Quality of Service) is a procedure defined in IEEE 802.1D. It is used to distribute resources in the network. You therefore have the possibility of providing minimum bandwidth for necessary applications. The prerequisite is that the end devices and the devices in the network support prioritized data transmission. Data packets with high priority are given preference when transmitted by devices in the network. You transfer data packets with lower priority when there are no data packets with a higher priority to be transmitted.

The device provides the following setting options:

- You specify how the device evaluates QoS/prioritization information for inbound data packets.
- For outbound packets, you specify which QoS/prioritization information the device writes in the data packet (for example priority for management packets, *Port priority*).

Note: If you use the functions in this menu, then disable the flow control. The flow control is inactive if in the *Switching* > *Global* dialog, *Configuration* frame the *Flow control* checkbox is unmarked.

The menu contains the following dialogs:

- QoS/Priority Global
- QoS/Priority Port Configuration
- ▶ 802.1D/p Mapping
- ► IP DSCP Mapping
- Queue Management
- DiffServ

5.7.1 QoS/Priority Global

[Switching > QoS/Priority > Global]

The device lets you maintain access to the device management, even in situations with heavy utilization. In this dialog, you specify the required QoS/priority settings.

Configuration

VLAN priority for management packets

Specifies the VLAN priority for sending management data packets. Depending on the VLAN priority, the device assigns the data packet to a specific *traffic class* and thus to a specific priority queue of the port.

Possible values:

0..7 (default setting: 0)

In the *Switching* > *QoS/Priority* > *802.1D/p Mapping* dialog, you assign a *traffic class* to every VLAN priority.

IP DSCP value for management packets

Specifies the IP DSCP value for sending management data packets. Depending on the IP DSCP value, the device assigns the data packet to a specific *traffic class* and thus to a specific priority queue of the port.

Possible values:

▶ 0 (be/cs0)..63 (default setting: 0 (be/cs0))

Some values in the list also have a DSCP keyword, for example 0 (*be/cs0*), 10 (*af11*) and 46 (*ef*). These values are compatible with the *IP Precedence* model.

In the *Switching* > *QoS/Priority* > *IP DSCP Mapping* dialog you assign a *traffic class* to every IP DSCP value.

Queues per port

Displays the number of priority queues per port.

The device has 8 priority queues per port. You assign every priority queue to a specific *traffic class* (*traffic class* according to IEEE 802.1D).

5.7.2 **QoS/Priority Port Configuration**

[Switching > QoS/Priority > Port Configuration]

In this dialog, you specify for every port how the device processes received data packets based on their QoS/priority information.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Port priority

Specifies what VLAN priority information the device writes into a data packet if the data packet contains no priority information. After this, the device forwards the data packet depending on the value specified in the *Trust mode* column.

Possible values:

0..7 (default setting: 0)

Trust mode

Specifies how the device handles a received data packet if the data packet contains QoS/priority information.

Possible values:

untrusted

The device forwards the data packet according to the priority specified in the *Port priority* column. The device ignores the priority information contained in the data packet. In the *Switching* > *QoS/Priority* > *802.1D/p Mapping* dialog, you assign a *traffic class* to every VLAN priority.

trustDot1p (default setting)

The device forwards the data packet according to the priority information in the VLAN tag. In the *Switching* > *QoS/Priority* > *802.1D/p Mapping* dialog, you assign a *traffic class* to every VLAN priority.

trustIpDscp

- If the data packet is an IP packet, then:

The device forwards the data packet according to the IP DSCP value contained in the data packet.

In the *Switching* > QoS/Priority > IP DSCP Mapping dialog you assign a *traffic class* to every IP DSCP value.

If the data packet is not an IP packet, then:

The device forwards the data packet according to the priority specified in the *Port priority* column.

In the *Switching* > *QoS/Priority* > *802.1D/p Mapping* dialog, you assign a *traffic class* to every VLAN priority.

Untrusted traffic class

Displays the *traffic class* assigned to the VLAN priority information specified in the *Port priority* column. In the *Switching* > *QoS/Priority* > *802.1D/p Mapping* dialog, you assign a *traffic class* to every VLAN priority.

Possible values:

▶ 0..7

5.7.3 802.1D/p Mapping

[Switching > QoS/Priority > 802.1D/p Mapping]

The device forwards data packets with a VLAN tag according to the contained QoS/priority information with a higher or lower priority.

In this dialog, you assign a *traffic class* to every VLAN priority. You assign the *traffic classes* to the priority queues of the ports.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

VLAN priority

Displays the VLAN priority.

Traffic class

Specifies the traffic class assigned to the VLAN priority.

Possible values:

▶ 0..7

- Ø assigned to the priority queue with the lowest priority.
- 7 assigned to the priority queue with the highest priority.

Note: Among other things redundancy mechanisms use the highest *traffic class*. Therefore, select another *traffic class* for application data.

Default assignment of the VLAN priority to traffic classes

VLAN Priority	Traffic class	Content description according to IEEE 802.1D
0	2	Best Effort Normal data without prioritizing
1	0	Background Non-time-sensitive data and background services
2	1	Standard Normal data
3	3	Excellent Effort Crucial data
4	4	Controlled Load Time-sensitive data with a high priority
5	5	Video Video transmission with delays and jitter <100 ms
6	6	Voice Voice transmission with delays and jitter <10 ms
7	7	Network Control Data for network management and redundancy mechanisms

5.7.4 IP DSCP Mapping

[Switching > QoS/Priority > IP DSCP Mapping]

The device forwards IP data packets according to the DSCP value contained in the data packet with a higher or lower priority.

In this dialog, you assign a *traffic class* to every DSCP value. You assign the *traffic classes* to the priority queues of the ports.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

DSCP value

Displays the DSCP value.

Traffic class

Specifies the *traffic class* which is assigned to the DSCP value.

Possible values:

- ▶ 0..7
 - Ø assigned to the priority queue with the lowest priority.
 - 7 assigned to the priority queue with the highest priority.

Default assignment of the DSCP values to traffic classes

DSCP Value	DSCP Name	Traffic class
0	Best Effort /CS0	2
1-7		2
8	CS1	0
9,11,13,15		0
10,12,14	AF11,AF12,AF13	0
16	CS2	1
17,19,21,23		1
18,20,22	AF21,AF22,AF23	1
24	CS3	3
25,27,29,31		3
26,28,30	AF31,AF32,AF33	3
32	CS4	4
33,35,37,39		4
34,36,38	AF41,AF42,AF43	4
40	CS5	5
41,42,43,44,45,47		5
46	EF	5

DSCP Value	DSCP Name	Traffic class
48	CS6	6
49-55		6
56	CS7	7
57-63		7

5.7.5 Queue Management

[Switching > QoS/Priority > Queue Management]

This dialog lets you enable and disable the *Strict priority* function for the *traffic classes*. When you disable the *Strict priority* function, the device processes the priority queues of the ports with *Weighted Fair Queuing*.

You also have the option of assigning a minimum bandwidths to every *traffic classes* which the device uses to process the priority queues with *Weighted Fair Queuing*.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Traffic class

Displays the traffic class.

Strict priority

Activates/deactivates the processing of the port priority queue with Strict priority for this traffic class.

Possible values:

marked (default setting)

The processing of the port priority queue with *Strict priority* is active.

- The port forwards only data packets that are in the priority queue with the highest priority.
 When this priority queue is empty, the port forwards data packets that are in the priority queue with the next lower priority.
- The port forwards data packets with a lower *traffic class* after the priority queues with a higher priority are empty. In unfavorable situations, the port does not send these data packets.
- When you select this setting for a *traffic class*, the device also enables the function for *traffic classes* with a higher priority.
- Use this setting for applications such as VoIP or video that require the least possible delay.

unmarked

The processing of the port priority queue with *Strict priority* is inactive. The device uses *Weighted Fair Queuing/*"Weighted Round Robin" (WRR) to process the port priority queue.

- The device assigns a minimum bandwidth to each *traffic class*.
- Even under a high network load the port transmits data packets with a low *traffic class*.
- When you select this setting for a *traffic class*, the device also disables the function for *traffic classes* with a lower priority.

Min. bandwidth [%]

Specifies the minimum bandwidth for this *traffic class* when the device is processing the priority queues of the ports with *Weighted Fair Queuing*.

Possible values:

▶ 0..100 (default setting: 0 = the device does not reserve any bandwidth for this *traffic class*)

The value specified in percent refers to the available bandwidth on the port. When you disable the *Strict priority* function for every *traffic class*, the maximum bandwidth is available on the port for the *Weighted Fair Queuing*.

The maximum total of the assigned bandwidths is 100 %.

Max. bandwidth [%]

Specifies the shaping rate at which a traffic class transmits packets (Queue Shaping).

Possible values:

Ø (default setting)

The device does not reserve any bandwidth for this traffic class.

▶ 1..100

The device reserves the specified bandwidth for this *traffic class*. The specified value in percent refers to the maximum available bandwidth on this port.

For example, using Queue Shaping lets you limit the rate of a strict high-priority queue. Limiting a strict high-priority queue lets the device also process low-priority queues. To use queue shaping, you set the maximum bandwidth for a particular queue.

5.7.6 DiffServ

[Switching > QoS/Priority > DiffServ]

Differentiated Services (DiffServ) filter data packets to prioritize or limit the data stream.

- In a class, you specify the filter criteria.
- In a policy, you link the class with actions.

The device applies the actions of the policy to those data packets that meet the filter criteria of the assigned class.

To set up DiffServ, perform the following steps:

- □ Create a class with the filter criteria.
- Create a policy.
- □ Assign a class with the filter criteria to the policy.
- □ Specify the actions of the policy.
- □ Assign the policy to a port.
- □ Activate the DiffServ function.

The device lets you use the following per class and per instance configurations:

- 13 rules per class
- 28 instances per policy
- 3 attributes per instance

The menu contains the following dialogs:

- DiffServ Overview
- DiffServ Global
- DiffServ Class
- DiffServ Policy
- DiffServ Assignment

5.7.6.1 DiffServ Overview

[Switching > QoS/Priority > DiffServ > Overview]

This dialog displays the DiffServ settings used in the device.

Overview

The top level displays:

- The ports for which someone has set up a DiffServ policy.
- The direction of the data packets which the DiffServ policy affects.

The subordinate levels display:

- The Policy name string and the Policy index number.
- The Policy instance number.
- The Class name string and the Protocol name.
- The settings specified in the DiffServ class.

Buttons

Q

Displays a text field to search for a keyword. When you enter a character or string, the overview displays only items related to this keyword.

46

Collapses the levels. The overview then displays only the first level of the items.

:3

Expands the levels. The overview then displays every level of the items.

+

Expands the current item and displays the items of the next lower level.

_

Collapses the item and hides the items of the underlying levels.

5.7.6.2 DiffServ Global

[Switching > QoS/Priority > DiffServ > Global]

In this dialog, you enable the DiffServ function.

Operation

Operation

Enables/disables the *DiffServ* function.

Possible values:

▶ On

The *DiffServ* function is enabled.

The device processes data packets according to the DiffServ rules.

Off (default setting) The *DiffServ* function is disabled.

5.7.6.3 DiffServ Class

[Switching > QoS/Priority > DiffServ > Class]

In this dialog, you specify the data packets to which the device executes the actions specified in the *Switching* > *QoS/Priority* > *DiffServ* > *Policy* dialog. This assignment is called a class.

Only one class can be assigned to a policy. This means each class can contain multiple filter criteria.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Opens the Create window to add a table row. See "[Create window]" on page 290.



Removes the selected table row.

Class name

Specifies the name of the DiffServ class. The device lets you change the class name directly in the table.

Possible values:Alphanumeric ASCII character string with 1..31 characters

Criteria

Displays the specified criteria for this rule.

[Create window]

Class name

Specifies the name of the DiffServ class.

Possible values:

Alphanumeric ASCII character string with 1..31 characters

Туре

Specifies the type of Class Rule for matching; this determines the individual match conditions for the present class rule.

Depending on which value you select, the following visible parameters change.

To match every packet regardless of content, select the value every.

Possible values:

- cos (default setting)
- dstip
- dstl4port
- ▶ dstmac
- every
- ▶ ipdscp
- ipprecedence
- ▶ iptos
- ▶ protocol
- refclass
- ▶ srcip
- srcl4port
- ▶ srcmac
- Cos2
- ▶ etype
- vLanid
- vLanid2

Type = cos

COS

Specifies the Class of Service value as the match value for the class.

Possible values:

▶ 0..7 (default setting: 0)

Type = dstip

Destination IP address

Specifies the destination IP address as the match value for the class.

Possible values:

Valid IP address

Destination IP address mask

Specifies the mask for the destination IP address.

Possible values:

Valid netmask

Type = dstl4port

Destination port

Specifies the destination Layer 4 port as the match value for the class.

Possible values:

Valid TCP or UDP port number

Type = dstmac

Destination MAC address

Specifies the destination MAC address as the match value for the class.

Possible values:

Valid MAC address

Destination MAC address mask

Specifies the mask for the destination MAC address.

Possible values:

Valid netmask

Type = ipdscp

DSCP

Specifies the DSCP (Differentiated Services Code Point) value as the match value for the class.

Possible values:

0..63 (default setting: 0(be/cs0))

Type = ipprecedence

TOS priority

Specifies the *IP Precedence* value as the match value for the class. The bits are the high-order 3 bits of the *Service Type* octet in the IPv4 header.

Possible values:

0..7 (default setting: 0)

Type = iptos

TOS mask

Specifies the IP TOS bits and mask as the match value for the class. The TOS bits are the 8 bits of the *Service Type* octet in the IPv4 header.

Possible values:

▶ 0x00..0xFF

Type = protocol

Protocol number

Specifies the value of the Protocol field in the IPv4 header as the match value for the class.

Possible values:

0..255

Some common values are listed here:

- 1 ICMP
- 2
- IGMP
- 4

IPv4 (IPv4 in IPv4 encapsulation)

- 6
- TCP
- UDP
- 41
- IPv6 (IPv6 in IPv4 encapsulation)
- 255

A rule with this value matches every protocol in the list.

The IANA defined the "Assigned Internet Protocol Numbers" that you enter here.

To find a list of the assigned numbers use the following link: www.iana.org/assignments/protocolnumbers/protocol-numbers.xhtml. Type = refclass

Ref class

Specifies the parent class as a corresponding reference class. This reference class uses the set of match rules specified in a parent class as the match value.

Possible values:

Name of the DiffServ Class>

Conditions:

- If the reference class refers only to the parent class, then the parent class to which you bind this rule and the reference class produce the same results.
- Any attempt to delete the parent class while still referenced to by another class fails.
- If the reference class uses the parent class as the match value, then any subsequent change to the parent class rules changes the reference class rules only.
- You add subsequent rules to the parent class compatible with the rules existing in the reference class.

Type = srcip

Source IP address

Specifies the source IP address as the match value for the class.

Possible values:

Valid IP address

Source IP address mask

Specifies the mask for the source IP address.

Possible values:

Valid netmask

Type = srcl4port

Source port

Specifies the source Layer 4 port as the match value for the class.

Possible values:Valid TCP or UDP port number

Type = srcmac

Source MAC address

Specifies the source MAC address as the match value for the class.

Possible values:

Valid MAC address and mask

Source MAC address mask

Specifies the mask for the source MAC address.

Possible values:

Valid netmask

Type = cos2

COS 2

Specifies a secondary Class of Service value as the match value for the class.

Possible values:

0..7 (default setting: 0)

Type = etype

Etype

Specifies the *Ethertype* value as the match value for the class.

```
Possible values:
```

```
custom (default setting)
You specify the Ethertype in the Etype value field.
appletalk
arp
ibmsna
ipv4
ipv6
ipx
mplsmcast
mplsucast
netbios
novell
pppoe
rarp
```

Etype value

Specifies the user-defined Ethertype value.

The prerequisite is that in the *Etype* field the value *custom* is specified.

Possible values:

▶ 0x0600..0xFFFF

Type = vlanid

VLAN ID

Specifies the VLAN ID as the match value for the class.

Possible values:

▶ 1..4042

Type = vlanid2

VLAN2 ID

Specifies the secondary VLAN ID as the match value for the class.

Possible values:

▶ 1..4042

5.7.6.4 DiffServ Policy

[Switching > QoS/Priority > DiffServ > Policy]

In this dialog, you specify which actions the device performs on data packets which fulfill the filter criteria specified in the *Switching* > *QoS/Priority* > *DiffServ* > *Class* dialog. This assignment is called a policy.

Only one policy can be assigned to a port. Each policy can contain multiple actions.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row. See "[Create window]" on page 297.



Removes the selected table row.



Opens the *Modify attribute* window to specify the action that the device performs on the data packets. The prerequisite is that the table row that contains a value in the *Attribute* column is selected.

Policy name

Displays the name of the policy.

To change the value, click the relevant field.

Possible values:

Alphanumeric ASCII character string with 1..31 characters

Direction

Displays that the device applies the policy to received data packets.

Class name

Displays the name of the class that is assigned to the policy.

The filter criteria are specified in the class.

Attribute

Displays the action that the device performs on the data packets.

- □ To change an existing action, select the affected table row and click the 🖍 button.
- \Box To add further actions to a policy, click the $\overset{\blacksquare}{+}$ button.

[Create window]

In this dialog, you add a policy or add further actions to an existing policy.

Policy name

Specifies the name of the policy.

- $\hfill\square$ To add a policy, enter a new name.
- □ To add more actions to an existing policy, select a name in the list.

Possible values:

Alphanumeric ASCII character string with 1..31 characters

Direction

Displays that the device applies the policy to received data packets.

Class name

Assigns the class to the policy.

The filter criteria are specified in the class.

Туре

Specifies the policy type.

Depending on which value you select, the following visible parameters change.

Possible values:

- markCosVal (default setting)
- markIpDscpVal
- markIpPrecedenceVal
- policeSimple
- policeTworate
- assignQueue
- 🕨 drop
- redirect
- ▶ mirror
- markCosAsSecCos

Type = markCosVal

Overwrites the priority field in the VLAN tag of the Ethernet packets:

- In the VLAN tag, the device overwrites the priority value in the COS parameter.
- With QinQ-tagged (IEEE 802.1ad) Ethernet packets, the device writes the value to the outer tag (*Service tag* or *S tag*).
- With data packets without VLAN tags, the device adds a priority tag.

Can be combined with Type = redirect and mirror.

COS

Specifies the priority value that the device writes to the priority field of the VLAN tag of the Ethernet packets.

Possible values:

▶ 0..7

Type = markIpDscpVal

Overwrites the DS field of the IP packets.

The device writes the value specified in the *DSCP* parameter to the DS field. Subsequent devices in the network to which the device forwards the IP packets, prioritize the IP packets according to this setting. For making the device prioritize the IP packets, also enqueue the IP packets with Type = assignQueue into the desired queue.

Can be combined with Type = assignQueue, redirect, and mirror.

DSCP

Specifies the value that the device writes to the DS field of the IP packets.

Possible values:

▶ 0..63

Type = markIpPrecedenceVal

Overwrites the TOS field of the IP packets.

The device writes the value specified in the TOS priority parameter to the TOS field.

Can be combined with Type = assignQueue, redirect, and mirror.

TOS priority

Specifies the value that the device writes to the TOS field of the IP packets.

Possible values:

▶ 0..7

Type = policeSimple

Limits the classified data stream to the values specified in the *Simple C rate* and *Simple C burst* fields: • If the transfer rate and burst size of the data stream are below the specified values, then the device applies the action specified in the Conform action field.

 If the transfer rate and burst size of the data stream are above the specified values, then the device applies the action specified in the *Non conform action* field.

Can be combined with Type = assignQueue, redirect, and mirror.

Simple C rate

Specifies the committed rate in kbit/s.

Upper limit

Possible values: ▶ 1..4294967295 (2³²-1)

Simple C burst

Specifies the committed burst size in kBytes.

Possible values:

▶ 0..128

Conform action, Non conform action

In the *Conform action* field, you specify the action that the device applies to the compliant data stream. Compliant means that the data stream is under the limits specified in the parameters *Simple C rate* and *Simple C burst*.

In the *Non conform action* field, you specify the action that the device applies to the non-compliant data stream. Non-compliant means that the data stream is over the limits specified in the parameters *Simple C rate* and *Simple C burst*.

Possible values:

▶ drop

Discards the data packets.

markDscp

Overwrites the DS field of the IP packets. The device writes the value specified in the adjacent field [0..63] to the DS field.

▶ markPrec

Overwrites the TOS field of the IP packets.

The device writes the value specified in the adjacent field [0..7] to the TOS field.

send

Sends the data packets.

- markCos
 - Overwrites the priority field in the VLAN tag of the Ethernet packets:
 - in the VLAN tag, the device overwrites the priority value in the COS parameter.
 - With QinQ-tagged (IEEE 802.1ad) Ethernet packets, the device writes the value to the outer tag (Service tag or S tag).
 - With Ethernet packets without VLAN tags, the device adds a priority tag.

markCos2

With QinQ-tagged Ethernet packets, overwrites the priority field in the inner tag (*Customer tag* or *C tag*) with the value specified in the adjacent field [0..7].

markCosAsSecCos

Overwrites the priority field in the outer tag (*Service tag* or *S tag*) with the priority value of the inner tag (*C tag*).

Color conform class

Specifies the class of the received data stream that the devices designates as conform (green).

Possible values:

blind

The device operates in the *Color-Blind* mode. The devices designates the complete data stream received as conform (green).

Name of the DiffServ Class>

The devices designates only this class of the received data stream as conform (green). Those classes are selectable for which in the *Switching* > *QoS/Priority* > *DiffServ* > *Class* dialog, *Criteria* column a rule of the type *cos*, *ipdscp*, *ipprec*, *cos2* is specified.

Verify that the filter criteria of the class selected from the *Class name* drop-down list above and of the class selected from this drop-down list, is neither identical nor exclude each other. Exclusion criteria are:

- The filter criteria have the same rule type, for example *cos* and *cos*. Use classes with a different rule type, for example *cos* and *ipdscp*.
- One of the classes references with the rule type *refclass* another class that conflicts with the used classes.

Type = policeTworate

Limits the classified data stream to the values specified in the *Two rate C rate*, *Two rate C burst*, *Two rate P rate*, and *Two rate P burst* fields.

- If the transfer rate and burst size are below Two rate C rate and Two rate C burst, then the device
 applies the Conform action action to the data stream.
- If the transfer rate and burst size are between Two rate C rate and Two rate P rate as well as Two
 rate C burst and Two rate P burst, then the device applies the Exceed action action to the data
 stream.
- If the transfer rate and burst size are above *Two rate P rate* and *Two rate P burst*, then the device applies the *Non conform action* action to the data stream.

Can be combined with Type = assignQueue, redirect, and mirror.

Two rate C rate

Specifies the committed rate in kbit/s.

Possible values:

1..4294967295 (2³²-1)

Two rate C burst

Specifies the committed burst size in kBytes.

Possible values:

▶ 0..128

Two rate P rate

Specifies the peak rate (max. allowable transfer rate of the data stream) in kbit/s.

Possible values: ▶ 1..4294967295 (2³²-1)

Two rate P burst

Specifies the peak burst size (max. allowable burst size) in kBytes.

Possible values:

▶ 1..128

Conform action Conform value Exceed action Exceed value Non conform action Non conform value

In the *Conform action* field, you specify the action that the device applies to the compliant data stream. Compliant means that transfer rate and burst size are below *Two rate C rate* and *Two rate C burst*.

In the *Exceed action* field, you specify the action that the device applies to the data stream. The prerequisite is that the transfer rate and burst size are between *Two rate C rate* and *Two rate P rate*

as well as Two rate C burst and Two rate P burst.

In the *Non conform action* field, you specify the action that the device applies to the non-compliant data stream. Non-compliant means that the transfer rate and burst size are above *Two rate P rate* and *Two rate P burst*.

Possible values:

▶ drop

Discards the data packets.

markDscp

Overwrites the DS field of the IP packets.

The device writes the value specified in the adjacent field [0..63] to the DS field.

▶ markPrec

Overwrites the TOS field of the IP packets.

The device writes the value specified in the adjacent field [0..7] to the TOS field.

send

Sends the data packets.

markCos

Overwrites the priority field in the VLAN tag of the Ethernet packets:

- in the VLAN tag, the device overwrites the priority value in the COS parameter.
- With QinQ-tagged (IEEE 802.1ad) Ethernet packets, the device writes the value to the outer tag (Service tag or S tag).
- With Ethernet packets without VLAN tags, the device adds a priority tag.
- markCos2

With QinQ-tagged Ethernet packets, overwrites the priority field in the inner tag (*Customer tag* or *C tag*) with the value specified in the adjacent field [0..7].

markCosAsSecCos

Overwrites the priority field in the outer tag (S tag) with the priority value of the inner tag (C tag).

Color conform class

Specifies the class of the received data stream that the devices designates as conform (green).

Possible values:

🕨 0 - blind

The device operates in the *Color-Blind* mode. The devices designates the complete data stream received as conform (green).

Name of the DiffServ Class>

The devices designates only this class of the received data stream as conform (green). Those classes are selectable for which in the *Switching* > *QoS/Priority* > *DiffServ* > *Class* dialog, *Criteria* column a rule of the type *cos*, *ipdscp*, *ipprec*, *cos2* is specified.

Verify that the filter criteria of the class selected from the *Class name* drop-down list above and of the class selected from this drop-down list, is neither identical nor exclude each other. Exclusion criteria are:

- The filter criteria have the same rule type, for example *cos* and *cos*. Use classes with a different rule type, for example *cos* and *ipdscp*.
- One of the classes references with the rule type *refcLass* another class that conflicts with the used classes.

Type = assignQueue

Changes the priority queue into which the device adds the data packets.

The device enqueues the data packets into the priority queue with the ID specified in the Queue ID parameter.

Can be combined with Type = drop, markCosVaL, and markCosAsSecCos.

Queue ID

Specifies the ID of the priority queue into which the device adds the data packets. See the *Traffic class* field in the *Switching* > *QoS/Priority* > *802.1D/p Mapping* dialog.

Possible values:

▶ 0..7

Type = drop

Discards the data packets.

Can be combined with *Type = mirror*, if *mirror* is set up first.

Type = redirect

The device forwards the received data stream to the port specified in the *Redirection interface* field.

Can be combined with Type = markCosVal, markIpDscpVal, markIpPrecedenceVal, policeSimple, policeTworate, assignQueue, and markCosAsSecCos.

Redirection interface

Specifies the destination port.

Possible values:

<Port number>

Number of the destination port. The device forwards the data packets to this port.

Note: The destination port needs sufficient bandwidth to absorb the data stream. If the copied data stream exceeds the bandwidth of the destination port, then the device discards superfluous data packets on the destination port.

Type = mirror

The device copies the received data stream and also transfers it to the port specified in the *Mirror interface* field.

Can be combined with Type = markCosVal, markIpDscpVal, markIpPrecedenceVal, policeSimple, policeTworate, assignQueue, and markCosAsSecCos.

Mirror interface

Specifies the destination port.

Possible values:

<Port number> Number of the destination port. The device copies the data packets to this port.

Note: The destination port needs sufficient bandwidth to absorb the data stream. If the copied data stream exceeds the bandwidth of the destination port, then the device discards superfluous data packets on the destination port.

Type = markCosAsSecCos

Overrides the priority field in the outer VLAN tag of the Ethernet packets with the priority value of the inner VLAN tag.

Can be combined with Type = assignQueue, redirect, and mirror.

5.7.6.5 DiffServ Assignment

[Switching > QoS/Priority > DiffServ > Assignment]

In this dialog, you assign the policy to a port.

Note: You cannot apply IP ACL rules and DiffServ rules together in the same direction on a port.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row. See "[Create window]" on page 306.

x Remove

Removes the selected table row.

Port

Displays the port number.

Direction

```
Displays the interface direction to which you assigned the policy.
```

Policy name

```
Displays the name of the policy assigned to the interface.
```

Status

```
Displays the port status.
```

Active

Activates/deactivates the DiffServ parameters associated with this table row.

Possible values:

marked

The device forwards the data packets according to the specified DiffServ settings.

unmarked

The device forwards the data packets without regarding the specified DiffServ settings.

[Create window]

Port

Specifies the port to which the table row relates.

Possible values:

Available ports

Direction

Specifies the direction in which the device applies the policy.

Possible values:

In (default setting)

🕨 Out

Policy

Specifies the policy assigned to the port.

Possible values:

Available policies

5.8 VLAN

[Switching > VLAN]

With VLAN (Virtual Local Area Network) you distribute the data packets in the physical network to logical subnets. This provides you with the following advantages:

- High flexibility
 - With VLAN you distribute the data packets to logical networks in the existing infrastructure.
 Without VLAN, it would be necessary to have additional devices and complicated cabling.
 - With VLAN you specify network segments independently of the location of the individual end devices.
- Improved throughput
 - In VLANs data packets can be transferred by priority.
 - When the priority is high, the device transfers the data of a VLAN preferentially, for example for time-sensitive applications such as VoIP phone calls.
 - When the data packets and Broadcasts are distributed in small network segments instead of in the entire network, the network load is considerably reduced.
- Increased security

The distribution of the data packets among individual logical networks makes unwanted accessing more difficult and strengthens the system against attacks such as MAC Flooding or MAC Spoofing.

The device supports packet-based "tagged" VLANs according to IEEE 802.1Q. The VLAN tagging in the data packet indicates the VLAN to which the data packet belongs.

The device forwards the tagged data packets of a VLAN only on ports that are assigned to the same VLAN. This reduces the network load.

The device learns the MAC addresses for every VLAN separately (independent VLAN learning).

The device prioritizes the received data stream in the following sequence:

- Voice VLAN
- MAC-based VLAN
- IP subnet-based VLAN
- Protocol-based VLAN
- Port-based VLAN

The menu contains the following dialogs:

- VLAN Global
- VLAN Configuration
- VLAN Port
- VLAN Voice
- MAC Based VLAN
- Subnet-based VLAN
- Protocol Based VLAN

5.8.1 VLAN Global

[Switching > VLAN > Global]

This dialog lets you view general VLAN parameters for the device.

Configuration

Buttons



Resets the VLAN settings of the device to the default setting.

Note that you lose your connection to the device if you have changed the VLAN for the device management in the *Basic Settings > Network > Global* dialog.

Max. VLAN ID

Highest ID assignable to a VLAN.

See the Switching > VLAN > Configuration dialog.

VLANs (max.)

Displays the maximum number of VLANs possible.

See the *Switching* > *VLAN* > *Configuration* dialog.

VLANs

Number of VLANs currently set up in the device.

See the *Switching* > *VLAN* > *Configuration* dialog.

The VLAN 1 is permanently set up in the device.

Double VLAN tag ethertype

Displays the value of the outer VLAN tag that a Core port adds to the data packet to be forwarded.

Possible values:

0x8100 (802.10) Normal VLAN tag

5.8.2 VLAN Configuration

[Switching > VLAN > Configuration]

In this dialog, you manage the VLANs. To set up a VLAN, add a further table row. There you specify for each port if it transmits data packets of the respective VLAN and if the data packets contain a VLAN tag.

You distinguish between the following VLANs:

- The user sets up static VLANs.
- The device sets up dynamic VLANs automatically and removes them if the prerequisites cease to apply.
 - For the following functions the device sets up dynamic VLANs:
 - MRP: If you assign to the ring ports a non-existing VLAN, then the device sets up this VLAN.
 - *MVRP*: The device sets up a VLAN based on the messages of neighboring devices.

Note: The settings are effective only if the *VLAN-unaware mode* function is inactive. See the *Switching* > *Global* dialog.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

Hadd

Opens the Create window to add a table row.

In the VLAN ID field, you specify the VLAN ID.

🕱 Remove

Removes the selected table row.

VLAN ID

ID of the VLAN.

The device supports up to 256 VLANs simultaneously set up.

Possible values:

1..4042

Status

Displays how the VLAN is set up.

Possible values:

other

VLAN 1

or

VLAN set up using the 802.1X function. See the Network Security > 802.1X dialog.

permanent

VLAN set up by the user.

or

VLAN set up using the *MRP* function. See the *Switching* > *L2-Redundancy* > *MRP* dialog. If you save the settings in the non-volatile memory, then the VLANs with this setting remain set up after a restart.

dynamicMvrp

VLAN set up using the *MVRP* function. See the *Switching* > *MRP-IEEE* > *MVRP* dialog. VLANs with this setting are write-protected. The device removes a VLAN from the table as soon as the last port leaves the VLAN.

Name

Specifies the name of the VLAN.

Possible values:

Alphanumeric ASCII character string with 1..32 characters

RSPAN VLAN

Specifies the VLAN as the RSPAN VLAN.

Possible values:

marked

The device uses the VLAN exclusively to send the RSPAN data packets in the direction of the *Destination port* of the *Destination switch*. See the *Diagnostics > Ports > RSPAN* dialog. Do not use the VLAN for any other purposes.

The device disables source MAC address learning in the VLAN.

unmarked (default setting) The device does not use the VLAN to send RSPAN data packets.

<Port number>

Specifies if the respective port transmits data packets of the VLAN and if the data packets contain a VLAN tag.

Possible values:

- (default setting)

The port is not a member of the VLAN and does not transmit data packets of the VLAN.

T = Tagged

The port is a member of the VLAN and transmits the data packets with a VLAN tag. You use this setting for uplink ports, for example.

 LT = Tagged Learned The port is a member of the VLAN and transmits the data packets with a VLAN tag. The device has automatically set up the entry based on the *GVRP* or *MVRP* function.
 F = Forbidden

- The port is not a member of the VLAN and does not transmit data packets of this VLAN. Additionally, the device helps prevent the port from becoming a VLAN member through the *MVRP* function.
- U = Untagged (default setting for VLAN 1) The port is a member of the VLAN and transmits the data packets without a VLAN tag. Use this setting if the connected device does not evaluate any VLAN tags, for example on end ports.
- LU = Untagged Learned

The port is a member of the VLAN and transmits the data packets without a VLAN tag. The device has automatically set up the entry based on the *GVRP* or *MVRP* function.

Note: Verify that the port on which the network management station is connected is a member of the VLAN in which the device transmits the management data. In the default setting, the device transmits the management data on VLAN 1. Otherwise, the connection to the device terminates when you transfer the changes to the device. The access to the device management is possible only using the Command Line Interface through the serial interface.

5.8.3 VLAN Port

[Switching > VLAN > Port]

In this dialog, you specify how the device handles received data packets that have no VLAN tag, or whose VLAN tag differs from the VLAN ID of the port.

This dialog lets you assign a VLAN to the ports and thus specify the port VLAN ID.

Additionally, you also specify for each port how the device forwards data packets if the *VLAN-unaware mode* function is inactive and one of the following situations occurs:

- The port receives data packets without a VLAN tagging.
- The port receives data packets with VLAN priority information (VLAN ID 0, priority tagged).
- The VLAN ID in the tag of the data packet differs from the VLAN ID of the port.

Note: The settings are effective only if the *VLAN-unaware mode* function is inactive. See the *Switching* > *Global* dialog.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Port-VLAN ID

Specifies the VLAN ID which the device assigns to data packets received without a VLAN tag.

Prerequisites:

In the Acceptable packet types column, the value admitAll is specified.

Possible values:

1..4042 (default setting: 1) A VLAN you set up.

If you use the *MRP* function and you did not assign a VLAN to the ring ports, then you specify the value 1 here for the ring ports. Otherwise, the device assigns the value to the ring ports automatically.

Acceptable packet types

Specifies if the port transmits or discards received data packets without a VLAN tag.

Possible values:

- admitAll (default setting) The port accepts data packets both with and without a VLAN tag.
- ► admitOnLyVLanTagged The port accepts only data packets tagged with a VLAN ID \ge 1.

Ingress filtering

Activates/deactivates the ingress filtering.

Possible values:

marked

The ingress filtering is active.

The device compares the VLAN ID in the data packet with the VLANs of which the port is a member. See the *Switching* > *VLAN* > *Configuration* dialog. If the VLAN ID in the data packet matches one of these VLANs, then the device forwards the data packet. Otherwise, the device discards the data packet.

- unmarked (default setting)
 - The ingress filtering is inactive.

The device forwards received data packets without comparing the VLAN ID. Thus, the device also forwards data packets in VLANs in which the port is not a member.

Double VLAN tag mode

Activates/deactivates the Double VLAN Tag mode on the port.

Possible values:

marked

The *Double VLAN Tag mode* is active on the port.

The port operates as a *Core* port. The device adds an outer VLAN tag to the data packet to be forwarded on the port. The *Ethertype* value of this VLAN tag you specify in the *Switching* > VLAN > *Global* dialog.

unmarked (default setting)

The Double VLAN Tag mode is inactive on the port.

- If the checkbox is unmarked for each other port, then the port operates as a normal port.
- If the checkbox is marked for any other port, then the port operates as an Access port. The device assigns the Port-VLAN ID value of the port to each received data packet. The port forwards the originally received data packet with or without a VLAN tag.

The port VLAN ID is the tunnel VLAN ID. You add the port as a member to the appropriate VLAN. The port transmits the data packets without a VLAN tag.

5.8.4 VLAN Voice

[Switching > VLAN > Voice]

Use the Voice VLAN feature to separate voice and data packets on a port, by VLAN and/or priority. A primary benefit of Voice VLAN is safeguarding the quality of voice data when the port has a high load.

The device detects VoIP phones using the Link Layer Discovery Protocol - Media Endpoint Discovery (LLDP-MED). The device then adds the appropriate port to the member set of the setup Voice VLAN. The member set is either tagged or untagged. Tagging depends on the Voice VLAN interface mode (*vLan*, *dot1p-priority*, *none*, *untagged*).

Another benefit of the Voice VLAN feature is that the VoIP phone obtains VLAN ID or priority information from the device using LLDP-MED. As a result, the VoIP phone sends voice data packets with VLAN tag, priority tag or untagged. This depends on the specified Voice VLAN Interface mode. You activate Voice VLAN on the port which is connecting to the VoIP phone.

Operation

Operation

Enables/disables the Voice function of the device globally.

Possible values:

l On

Off (default setting)

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Voice VLAN mode

Specifies if the port transmits or discards received data packets without voice VLAN tagging or with voice VLAN priority information.

Possible values:

disabled (default setting) Deactivates the Voice function for this table row.

none

Lets the IP telephone use its own configuration for sending untagged voice data packets.

- vlan/dot1p-priority The port filters data packets of the voice VLAN using the vlan and dot1p priority tags.
- untagged The port filters data packets without a voice VLAN tag.

vLan

The port filters data packets of the voice VLAN using the vlan tag.

dot1p-priority

The port filters data packets of the voice VLAN using the dot1p priority tags. If you select this value, then additionally specify a proper value in the *Priority* column.

Data priority mode

Specifies the trust mode for the data packets on the particular port.

The device uses this mode for data packets on the voice VLAN, when it detects a VoIP telephone and a PC using the same cable for transmitting data.

Possible values:

marked (default setting)

If voice data packets are present on the interface, then the data packets have the normal priority.

unmarked

If voice data packets are present and the value dot1p-priority is specified in the Voice VLAN mode column, then the data packets have the priority 0. If the interface only transmits data, then the data has the normal priority.

Status

Displays the status of the Voice VLAN on the port.

Possible values:

- marked
 - The Voice VLAN is enabled.
- unmarked The Voice VLAN is disabled.

VLAN ID

Specifies the VLAN ID to which the table row relates. To forward data packets to this VLAN using this filter, select in the *Voice VLAN mode* column the value *vLan*.

Possible values:

1..4042 (default setting: 0)

Priority

Specifies the Voice VLAN Priority of the port.

Prerequisites:

In the Voice VLAN mode column, the value dot1p-priority is specified.

Possible values:

0..7

none

Deactivates the Voice VLAN Priority of the port.

DSCP

Specifies the IP DSCP value.

Possible values:

0 (be/cs0)..63 (default setting: 0 (be/cs0))

Some values in the list also have a DSCP keyword, for example 0 (*be/cs0*), 10 (*af11*) and 46 (*ef*). These values are compatible with the *IP Precedence* model.

In the *Switching* > QoS/Priority > IP DSCP Mapping dialog you assign a *traffic class* to every IP DSCP value.

Bypass authentication

Activates the Voice VLAN Authentication mode.

If you deactivate the function and set the value in the *Voice VLAN mode* column to *dot1p-priority*, then voice devices require an authentication.

Possible values:

marked (default setting)

If you activated the function in the *Network Security* > 802.1X > Global dialog, then set the *Port control* parameter for this port to the *multiClient* value before activating this function. You find the *Port control* parameter in the *Network Security* > 802.1X > Global dialog.

unmarked

5.8.5 MAC Based VLAN

[Switching > VLAN > MAC Based VLAN]

In a MAC-based VLAN, the device forwards the data packets based on the source MAC address associated with a VLAN. User-defined filters determine if a packet belongs to a particular VLAN.

MAC-based VLANs specify the filtering criteria only for untagged or priority-tagged packets. Assign a port to a MAC-based VLAN to transmit packets with a specific source MAC address in that VLAN. The device then forwards untagged packets received with the specified MAC address to the assigned MAC-based VLAN. Other untagged packets are subject to normal VLAN classification rules.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

- In the MAC address field, you specify the MAC address.
- In the VLAN ID field, you specify the VLAN ID.



Removes the selected table row.

MAC address

Displays the MAC address to which the table row relates.

The device supports up to 256 simultaneous MAC-based VLAN assignments.

Possible values:

Valid MAC address

VLAN ID

Displays the ID of the VLAN to which the table row relates.

Possible values:

1..4042 (set up VLAN IDs)

5.8.6 Subnet-based VLAN

[Switching > VLAN > Subnet-based VLAN]

In IP subnet-based VLANs, the device forwards the data packets based on the source IP address and subnet mask associated with the VLAN. User-defined filters determine if a packet belongs to a particular VLAN.

IP subnet-based VLANs specify the filtering criteria only for untagged packets or priority tagged packets. Assign a port to an IP subnet-based VLAN to transmit packets with a specific source IP address in that VLAN. The device then forwards untagged packets received with the specified IP address to the assigned IP subnet-based VLAN.

To set up an IP subnet-based VLAN, specify an IP address, a subnet mask, and the corresponding VLAN identifier. When multiple entries apply, the device uses the entry with the longest prefix first.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Opens the Create window to add a table row.

- In the *IP address* field, you specify the IP address.
- In the *Netmask* field, you specify the netmask.
- In the VLAN ID field, you specify the VLAN ID.



Removes the selected table row.

IP address

Displays the IP address to which you assign the subnet-based VLAN.

The device supports up to 128 VLANs set up simultaneously to subnet-based VLANs.

Possible values:

Valid IP address

Netmask

Displays the netmask to which you assign the subnet-based VLAN.

Possible values: ▶ Valid IP netmask

VLAN ID

Displays the VLAN ID.

Possible values: 1..4042

5.8.7 Protocol Based VLAN

[Switching > VLAN > Protocol Based VLAN]

In a protocol-based VLAN, specified ports bridge data packets based on the L3 protocol (Ethertype) associated with the VLAN. User-defined packet filters determine if a packet belongs to a particular VLAN.

Protocol-based VLANs specify the filtering criteria only for untagged packets. Assign a port to a protocol-based VLAN for a specific protocol. The device then forwards untagged packets received with the specified protocol to the protocol-based VLAN. The device assigns other untagged packets with the port VLAN ID.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Adds a table row.



Removes the selected table row.

Group ID

Displays the group identifier of the protocol-based VLAN entry.

The device supports up to 128 protocol-based VLAN associations simultaneously.

	Possible values: ▶ 1128
Name	
	Specifies the group name of the protocol-based VLAN entry.
	Possible values: ▶ Alphanumeric ASCII character string with 116 characters
VLAN ID	
	Specifies the VLAN.
	Possible values: ▶ 14042 (default setting: 0)
Port	
	Specifies the ports that are assigned to the group.
	Possible values:
	<pre> <port number=""> (default setting: -) From the drop-down list, select the ports. </port></pre>
Ethertype	
21	Specifies the Ethertype value assigned to the VLAN.
	The Ethertype is a two-octet field in an Ethernet packet to indicate which protocol the payload contains.
	Possible values:
	 0x06000xFFFF Ethertype as a hexadecimal number sequence When you enter a decimal value, the device converts the value into a hexadecimal number
	sequence when you click the 🗸 button.
	 ip Ethertype keyword for IPv4 (equivalent to 0x0800)
	▶ arp
	Ethertype keyword for ARP (equivalent to 0x0806) ipx
	Ethertype keyword for IPX (equivalent to 0x8137)

5.9 L2-Redundancy

[Switching > L2-Redundancy]

The menu contains the following dialogs:

MRP

► HIPER Ring

- DLR (depends on hardware)
- PRP (depends on hardware)
 HSR (depends on hardware)
- Spanning Tree
- Link AggregationLink Backup
- ► FuseNet

5.9.1 MRP

[Switching > L2-Redundancy > MRP]

The Media Redundancy Protocol (MRP) is a protocol that lets you set up high-availability, ringshaped network structures. An MRP Ring with Hirschmann devices is made up of up to 100 devices that support the Media Redundancy Protocol (MRP) according to IEC 62439.

If a section is not operating, then the ring structure of an MRP Ring changes back into a line structure. You can specify the maximum recovery time.

The Ring Manager device closes the ends of a backbone in a line structure to a redundant ring.

Note: Spanning Tree and Ring Redundancy have an effect on each other. Deactivate the Spanning Tree function for the ports connected to the MRP Ring. See the Switching > L2-Redundancy > Spanning Tree > Port dialog.

When you work with oversized Ethernet packets (the value in the *MTU* column for the port is >1518, see the *Basic Settings* > *Port* dialog), the switching time of the MRP Ring reconfiguration depends on the following parameters:

- Bandwidth of the ring line
- Size of the Ethernet packets
- Number of devices in the ring

Set the recovery time sufficiently large to help avoid delays in the MRP packages due to latencies in the devices. You can find the formula for calculating the switching time in IEC 62439-2, section 9.5.

Operation

Buttons

Delete ring configuration

Disables the redundancy function and resets the settings in the dialog to the default setting.

Operation

Enables/disables the MRP function.

After you set up the parameters for the MRP Ring, enable the function here.

Possible values:

▶ On

The MRP function is enabled.

After you set up the devices in the MRP Ring, the redundancy is active.

0ff (default setting)
 The *MRP* function is disabled.

Ring port 1/Ring port 2

Port

Specifies the number of the port that is operating as a ring port.

Possible values:

> <Port number>
Number of the ring port

Note: If the device uses the software supporting Fast MRP, then you cannot select a *Link Aggregation* port as a ring port.

Operation

Displays the operating status of the ring port.

Possible values:

- forwarding The port is enabled, connection exists.
- blocked The port is blocked, connection exists.
- disabled The port is disabled.
- not-connected
 No connection exists.

Fixed backup

Activates/deactivates the Backup port function for the Ring port 2.

Note: The switch over to the Primary port can exceed the maximum ring recovery time.

Possible values:

marked

The *Ring port 2* backup function is active. When the ring is closed, the *Ring Manager* device reverts back to the primary ring port.

unmarked (default setting) The Ring port 2 backup function is inactive. When the ring is closed, the Ring Manager device continues to send data on the secondary ring port.

Configuration

Ring manager

Enables/disables the Ring manager function.

If there is one device at each end of the line, then you activate this function.

Possible values:

- ▶ On
 - The *Ring manager* function is enabled.
 - The device operates in the *Ring Manager* mode.

To help avoid unexpected behavior, do not enable the function on a device on which the *RCP* function is enabled.

Off (default setting)
 The *Ring manager* function is disabled.
 The device operates exclusively in the *Ring Client* mode.

Advanced mode

Activates/deactivates the Advanced mode for fast recovery times.

Possible values:

- marked (default setting)
 Advanced mode active.
 MRP-capable Hirschmann devices support this mode.
- unmarked

Advanced mode inactive. Select this setting if another device in the ring does not support this mode.

Ring recovery

Specifies the maximum recovery time in milliseconds for reconfiguration of the ring. This setting is effective only if the device operates in the *Ring Manager* mode.

Possible values:

- ▶ 500ms
- 200ms (default setting)
- 30ms (depends on hardware)
- 10ms (depends on hardware)

Shorter switching times make greater demands on the response time of every individual device in the ring. Use values lower than *500ms* if the other devices in the ring also support this shorter recovery time.

Note: The switching times *30ms* and *10ms* are available for devices with an FPGA (hardware for extended functions). The product code indicates if your device supports Fast MRP. To use the functions, load the device software supporting Fast MRP.

Set the switching time to 10ms only if you use up to 20 devices in the ring that support this switching time. If you use more than 20 of these devices, then set the switching time to at least 30ms.

When you are working with oversized Ethernet packets, the number of devices in the ring is limited. Note that the switching time depends on several parameters. See the description above.

VLAN ID

Specifies the VLAN ID which you assign to the ring ports.

Possible values:

- 0 (default setting)
 No VLAN assigned
 - No VLAN assigned.

Assign in the *Switching* > *VLAN* > *Configuration* dialog to the ring ports for VLAN 1 the value U.

1..4042

VLAN assigned.

If you assign to the ring ports a non-existing VLAN, then the device sets up this VLAN. In the *Switching* > VLAN > *Configuration* dialog, the device adds a table row for the VLAN and assigns the value T to the ring ports.

Information

Information

Displays messages for the redundancy configuration and the possible causes of detected errors.

When the device operates in the *Ring Client* or *Ring Manager* mode, the following messages are possible:

- Redundancy available The redundancy is set up. When a component of the ring becomes inoperable, the redundant line takes over its function.
- Configuration error: Error on ringport Link. An error is detected in the cabling of the ring ports.

When the device operates in the *Ring Manager* mode, the following messages are possible:

- Configuration error: Packets from another ring manager received. Another device exists in the ring that operates in the Ring Manager mode. Enable the Ring manager function only on one device in the ring.
- Configuration error: Ring link is connected to wrong port. A line in the ring is connected with a different port instead of with a ring port. The device only receives test data packets on one ring port.

5.9.2 HIPER Ring

[Switching > L2-Redundancy > HIPER Ring]

The concept of HIPER Ring redundancy enables the construction of high-availability, ring-shaped networks. The device operates exclusively in the *Ring Client* mode. This function lets you extend an existing HIPER Ring or to replace a device already participating as a *Ring Client* in a HIPER Ring.

A HIPER Ring contains a *Ring Manager (RM)* device which controls the ring. The *Ring Manager* device sends watchdog packets into the ring on both the primary and secondary ports. When the *Ring Manager* device receives the watchdog packets on both ports, the *Primary port* remains in the forwarding state and the secondary port remains in the discarding state.

The device operates exclusively in the *Ring Client* mode. This means that the device detects watchdog packets on its ring ports and sends a *Link Down* or *Link Up* packet to the *Ring Manager* device when the link status changes.

The device only supports Fast Ethernet and Gigabit Ethernet ports as ring ports. Furthermore, the device only supports HIPER Ring in VLAN 1.

Note: Spanning Tree and Ring Redundancy have an effect on each other. Deactivate the Spanning Tree function for the ports connected to the HIPER Ring. See the Switching > L2-Redundancy > Spanning Tree > Port dialog.

Note: Set up the devices of the HIPER Ring individually. Before you connect the redundant link, complete the setup of every device of the HIPER Ring. You thus help avoid loops during the configuration phase.

Operation

Operation

Enables/disables the HIPER Ring client.

Possible values:

▶ On

The HIPER Ring client is enabled.

Off (default setting) The *HIPER Ring* client is disabled.

Ring port 1/Ring port 2

Port

Specifies the port number of the primary/secondary ring port.

Possible values:

(default setting)
 No primary/secondary ring port selected.

<Port number>
 Number of the ring port

State

Displays the state of the primary/secondary ring port.

Possible values:

not-available The HIPER Ring client is disabled. or

No primary or secondary ring port selected.

active

The ring port is enabled and logically up.

inactive

No link available on the ring port.

As soon as the link on a ring port is interrupted, the device sends a *Link Down* packet to the *Ring Manager* device on the other ring port.

Information

Mode

Displays that the device operates in the Ring Client mode.

5.9.3 DLR (depends on hardware)

[Switching > L2-Redundancy > DLR]

The Device Level Ring (DLR) protocol provides high network availability in a ring topology. The primary purpose of the DLR protocol is implementation in EtherNet/IP end-devices that have 2 Ethernet ports and embedded Layer 2 switch technology. The DLR protocol provides network fault detection and reconfiguration to support demanding control applications.

The DLR network uses a ring supervisor to monitor the network. The ring supervisor controls data on the ring by sending data only on the primary ring port until a break in the ring occurs. When a break in the ring occurs, the ring supervisor unblocks the secondary port, allowing the data to reach the ring participants located on the other side of the break.

To maintain control of the network, the active ring supervisor sends *Beacon* packets through both ports. The device lets you specify the interval between consecutive *Beacon* packets. The *Beacon* packets help detect an interruption in the ring, send *Ring State* messages to the participants, and also contain the following information:

- the precedence of the active ring supervisor
- the MAC address of the active ring supervisor
- the *Beacon* timeout
- the DLR VLAN ID

In the supervisor mode, the device also sends *Announce* packets, once every second, through the unblocked port only. The *Announce* packets also contain *Ring State* messages.

In the non-supervisor mode, the device functions as a *Beacon* based participant. Upon receiving a Ring Fault State message from the active ring supervisor, the *Beacon* based participant flushes its unicast MAC address table (forwarding database), and conducts a Neighbor Check. The Neighbor Check helps isolate an interruption between adjacent participants.

DLR uses a VLAN to distribute information contained in the *Beacon* packet, to other ring participants as priority tagged. The default setting for the DLR VLAN is 0. You can specify the VLAN ID only in this dialog. You use VLAN ID 0 with the *VLAN-unaware mode*.

Verify that the functions which directly affect the *DLR* function have the following settings:

EtherNet/IP	Advanced > Industrial Protocols > EtherNet/IP dialog • Operation = On • Write access = marked
Spanning Tree	Switching > L2-Redundancy > Spanning Tree > Global dialog • Operation = 0ff
VLAN	Switching > Global dialog • VLAN-unaware mode = marked
IGMP Snooping	Switching > IGMP Snooping > Global dialog • Operation = On Switching > IGMP Snooping > Configuration dialog, Port tab • Active = marked Switching > IGMP Snooping > Snooping Enhancements dialog • DLR ring ports = SF (Static and Forward all) Switching > IGMP Snooping > Querier dialog • Operation = On

Note: *DLR* is available for devices with an FPGA (hardware for extended functions). The product code indicates if your device supports *DLR*. To use the functions, load the device software supporting *DLR*.

The menu contains the following dialogs:

- DLR Configuration (depends on hardware)
- ▶ DLR Statistics (depends on hardware)

5.9.3.1 DLR Configuration (depends on hardware)

[Switching > L2-Redundancy > DLR > Configuration]

In this dialog, you specify the role of the device in the ring. When you specify the device as a ring supervisor, the device sends *Beacon* packets containing its precedence for active ring supervisor candidacy. As an active ring supervisor, the device monitors the ring for interruption and sends configuration information to the ring participants.

Operation

Operation

Enables/disables the *DLR* function globally.

Possible values:

- On (default setting)
- The *DLR* function is enabled.

▶ 0ff

The *DLR* function is disabled.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

Service action

Opens the Service action dialog to specify the DLR services that the device uses to help locate and clear detected faults.

Possible values:

- verifyFaultLocation (default setting) The supervisor verifies the fault location by retransmitting the Locate_Fault packet to ring participants.
- cLearRapidFaults Clears the Rapid Fault condition where the ring supervisor detected a cycle of rapid ring faults.
- restartSignOn Restarts the Sign On process and refreshes the participants list.

Ring index

Displays the index number to which the table row relates.

Name

Specifies the name of the DLR ring.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Ring port 1

Specifies the first of 2 ring ports used to connect the device to the DLR ring.

Possible values:

<Port number> (default setting: 1/1) From the drop-down list, select the port.

Ring port 1 status

Displays the status of Ring port 1.

Possible values:

- disabled
 - The port is disabled.

To enable the port, open the *Basic Settings > Port* dialog, *Configuration* tab. In the *Port on* column, mark the appropriate checkbox.

blocked

The port is the secondary port, sending and receiving only Beacon packets.

▶ forwarding

The port is the *Primary port*, sending and receiving data, *Beacon* packets, and *Announce* packets.

notConnected The port is physically unconnected.

Ring port 2

Specifies the second of 2 ring ports used to connect the device to the DLR ring.

Possible values:

<Port number> (default setting: 1/2) From the drop-down list, select the port.

Ring port 2 status

Displays the status of Ring port 2.

Possible values:

- disabled
 - The port is disabled.

To enable the port, open the *Basic Settings > Port* dialog, *Configuration* tab. In the *Port on* column, mark the appropriate checkbox.

blocked

The port is the secondary port, sending and receiving only Beacon packets.

forwarding

The port is the *Primary port*, sending and receiving data, *Beacon* packets, and *Announce* packets.

notConnected

The port is physically unconnected.

Supervisor active

Activates/deactivates the supervisor function.

Possible values:

marked

The device is set up as a ring supervisor. The device monitors the ring for interruptions. If an interruption in the ring occurs, then the device unblocks the secondary port and forwards data on the secondary port.

unmarked (default setting) The device is a *Beacon* based ring participant.

Status

Displays the status of the device in the DLR ring.

Possible values:

backup

Another device in the same ring is the active supervisor.

- supervisor This device is the active supervisor.
- node

The device functions as a *Beacon* based ring participant.

▶ nonDLr

The device has detected that the network topology is something other than a ring using the DLR protocol.

unsupported

The configuration in the table row is invalid.

Supervisor precedence

Specifies the precedence value of the device for the ring supervisor selection. The device sends the value in the *Beacon* packets to other devices participating in the ring. When another ring supervisor is present on the same ring, the device with the higher value is selected active ring supervisor. When both values are the same, the device with the higher MAC address becomes active supervisor.

Possible values:

▶ 0..255 (default setting: 0)

A numerically higher value indicates a higher precedence.

Beacon interval [µs]

Specifies the interval, in microseconds, at which the supervisor sends *Beacon* packets. The ring supervisor transmits a *Beacon* packet through both of its Ethernet ports once per *Beacon* interval. When the ring is intact, the device receives the *Beacon* packet on the opposite ports, and leaves the blocked port in the blocking mode.

Possible values:

 400..100000 (10⁵) (default setting: 400) Lower interval times increase the recovery time. When the ring contains only DLR participants, use the following formula to calculate: Minimum value = 13 * Number of ring participants

Beacon timeout [µs]

Specifies the amount of time, in microseconds, the device listens for *Beacon* packets. After the device times out the reception of a *Beacon* packet, it takes the appropriate action depending on its role as an active supervisor or ring participant.

Possible values:

```
1600..500000 (5 × 10<sup>5</sup>) (default setting: 10000)
Set this value to at least 4 times the value specified in the Beacon interval [µs] column.
When the ring contains only DLR participants, use the following formula to calculate:
Maximum value = (Number of ring participants * (1 - 0.1) * 25) + (Number of ring
participants * 0.1 * 137)
```

VLAN ID

Specifies the VLAN ID used to send the DLR protocol messages to the other devices on the ring.

The active supervisor informs the ring participants which VLAN ID to use in the *Beacon* packets. You set up the VLAN in the *Switching* > *VLAN* > *Configuration* dialog.

The prerequisite for setting the VLAN ID 0 is that in the *Switching* > *Global* dialog the *VLAN-unaware mode* checkbox is marked.

Possible values:

▶ 0..4042 (default setting: 1)

Active

Activates/deactivates the DLR configuration.

Possible values:

marked

The DLR configuration is active.

unmarked (default setting) The DLR configuration is inactive.

5.9.3.2 DLR Statistics (depends on hardware)

[Switching > L2-Redundancy > DLR > Statistics]

This dialog displays the status of the ring, the type of topology, number of participants, and other information to help you to analyze the network.

This dialog also displays a list of participating ring participants. The active ring supervisor gathers the information contained in the participants list using the Sign_On packet. If the participants list is too large, then the DLR Object returns, Reply Data Too Large (code 0x11).

The dialog contains the following tabs:
[Status]
[Participants]

[Status]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Ring index

Displays the index number to which the table row relates.

Capability

Displays the capabilities of the device.

Possible values:

announce

The device is an announce-based ring participant.

- beacon The device is capable of sending *Beacon* packets.
- supervisor

The device is capable of being a supervisor.

- gateway
 The device is capable of being a gateway.
- flushTable The device is capable of flushing the unicast MAC address table (forwarding database).

Status

Displays the status of the device in the DLR ring.

Possible values:

🕨 backup

Another device in the same ring is the active supervisor.

supervisor This device is the active supervisor.

node

The device functions as a *Beacon* based ring participant.

🕨 nonDlr

The device has detected that the network topology is something other than a ring using the DLR protocol.

unsupported

The table row parameters are invalid.

Network topology

Displays the current network topology mode.

Possible values:

▶ Linear

The network is linear.

▶ ring

The network is a DLR ring.

Network status

Displays the current network status.

Possible values:

normal

After the device receives *Beacon* packets on both ports, the supervisor transitions to the *NORMAL_STATE*, flushes the unicast MAC address table (forwarding database), and sets a port to blocking. The device sends *Beacon* packets with the *Ring State* value specified as *RING_NORMAL_STATE*. The ring supervisor also sends an *Announce* packet out of the unblocked port, with the *Ring State* value specified as *RING_NORMAL_STATE*.

ringFault

The reasons for which the device displays the value are as follows:

- During the system startup, an enabled ring supervisor starts in the FAULT_STATE with both ports sending and receiving packets.
- The device received a *Beacon* packet from another supervisor with a higher precedence.

Upon receipt of a *Beacon* packet with the Ring State set to *RING_FAULT_STATE*.
 When the device is in the *FAULT_STATE*, the ring supervisor continues to send *Beacon* packets to detect ring restoration.

Loop

The device has detected a loop in the network.

partial

The device detected a partial network fault where the *Beacon* packets are lost only in one direction. If the active ring supervisor detects a partial fault, then it blocks data packets on one port and sets a status value in the DLR Object. The condition requires user intervention.

rapidFault

The device detected a rapid fault, detecting 5 faults in a 30 second period. Rapid faults can lead to an instable network. If the active ring supervisor detects a rapid fault, then it blocks data packets on one port and sets a status value in the DLR Object. The condition requires user intervention. To reset the device open the *Switching* > L2-*Redundancy* > *DLR* > *Configuration* dialog and set the value *cLearRapidFaults* in the *Service* column.

Last status change

Displays the time, in seconds, since the network status last changed.

Participants

Displays the number of devices in the ring protocol participants list.

Supervisor IP address

Displays the IPv4 address assigned to the active supervisor.

Supervisor MAC address

Displays the MAC address of the active ring supervisor.

Supervisor precedence

Displays the precedence value of the active ring supervisor.

Faults

Displays the number of times that the device has detected a ring fault, since starting as either the active or the backup supervisor.

Port 1 IP address

Displays the IPv4 address assigned to Ring port 1.

Port 1 MAC address

Displays the MAC address of last active ring participant on Ring port 1.

Port 2 IP address

Displays the IPv4 address assigned to Ring port 2.

Port 2 MAC address

Displays the MAC address of last active ring participant on Ring port 2.

[Participants]

Only the active ring supervisor displays the ring participants.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Index

Displays the index number to which the table row relates.

IP address

Displays the IP address of the participating ring participant.

MAC address

Displays the MAC address of the participating ring participant.

5.9.4 PRP (depends on hardware)

[Switching > L2-Redundancy > PRP]

The Parallel Redundancy Protocol (PRP) is defined in the international standard IEC 62439-3. PRP uses 2 independent LANs with any ring, star, bus and mesh topologies, providing a high availability of network connections.

To connect the device to the PRP network, use either100 Mbit/s FDX or 1000 Mbit/s FDX on both of the specially marked ports, *Port A* and *Port B*.

The maximum allowed size of Ethernet packets on these ports is restricted to 1534 bytes. See the *MTU* column in the *Basic Settings > Port* dialog.

The main advantage of PRP is that the destination node receives packets from the source as long as one LAN is available. The absence of the second LAN due to repairs or maintenance has no impact on the packet transmission.

The network device which connects the end devices to the network implements the Parallel Redundancy Protocol (PRP). The Ethernet switches in both LANs are standard switches that are oblivious to PRP. A Double Attached Node implementing PRP (DANP) is a network device with PRP functionality and has one connection into each independent LAN. A Single Attached Node (SAN) is a standard Ethernet device with a single LAN interface directly connected to one of the redundant LANs. For this reason, a SAN is unable to use the redundant LAN.

A Redundancy Box (RedBox) is a network device which implements the PRP functionality for standard ethernet devices. A standard ethernet device when connected to a PRP network through a RedBox is a virtual DANP (VDAN).

Note: *PRP* is available for devices with an FPGA (hardware for extended functions). The product code indicates if your device supports *PRP*. To use the functions, load the device software supporting *PRP*.

Note: If the inter-frame gap is shorter than the latency between the 2 LANs, then a frame-ordering mismatch can occur. Frame-ordering mismatch is a phenomenon of the Parallel Redundancy Protocol (PRP). The only solution to help avoid a frame-ordering mismatch is to verify that the interframe gap is greater than the latency between the LANs.

The menu contains the following dialogs:

- PRP Configuration (depends on hardware)
- PRP DAN/VDAN Table (depends on hardware)
- PRP Proxy Node Table (depends on hardware)
- PRP Statistics (depends on hardware)

5.9.4.1 PRP Configuration (depends on hardware)

[Switching > L2-Redundancy > PRP > Configuration]

In this dialog, you enable/disable the *PRP* function, and set up PRP supervision packet reception and transmission.

The *MRP* and *Spanning Tree* functions cannot operate on the same ports as the *PRP* function. Disable the *MRP* function or choose different ports. Deactivate the *Spanning Tree* function on the PRP ports.

Note: When PRP is active, it uses the interfaces 1/1 and 1/2. As seen in the *Switching* > *VLAN*, *Switching* > *Rate Limiter* and *Switching* > *Filter for MAC Addresses* dialogs, the *PRP* function replaces the interfaces 1/1 and 1/2 with the interface prp/1. Set up the VLAN membership, the rate limiting, and the MAC filtering for the interface prp/1.

Operation

Operation

Enables/disables the PRP function.

Possible values:

▶ On

The *PRP* function is globally enabled. When this function is active, the device processes the data stream according to the set up.

Off (default setting) The *PRP* function is globally disabled.
 To help avoid network loops, disable the *PRP* function on *Port A* or *Port B* before disabling the *PRP* function globally.

Note: When you use SFPs for PRP ports and the device only supports 100 Mbit/s, verify that the SFPs support 100 Mbit/s.

Port A / Port B

Physical port

Displays the number of the physical port which the device uses as the PRP Port A or Port B.

Port A admin state Port B admin state

Enables/disables the *PRP* function on the port.

Possible values:

On (default setting)

The *PRP* function on the port is enabled.

► Off

The PRP function on the port is disabled.

Supervision packet receiver

Evaluate supervision packets

Activates/deactivates the analysis of the supervision packets.

Possible values:

- marked (default setting) The analysis of the supervision packets is activated. The device receives Supervision Packets and analyzes them.
- unmarked

The analysis of the supervision packets is deactivated. The device receives supervision packets without analyzing them.

Supervision packet sender

Active

Enables/disables the transmission of supervision packets.

Possible values:

On (default setting) The transmission of supervision packets is enabled. The RedBox transmits its own supervision packets.

► Off

The transmission of supervision packets is disabled.

Send VDAN packets

Activates/deactivates the transmission of VDAN supervision packets.

The prerequisite is that the Supervision packet sender function is active.

Possible values:

marked (default setting)

The transmission of VDAN supervision packets is active. The RedBox transmits both its own supervision packets and the supervision packets for the VDANs listed in the *Proxy Node Table*.

unmarked

The transmission of VDAN supervision packets is inactive.

Configuration

MTU

Specifies the maximum allowed size of Ethernet packets on the interface in bytes. This setting lets you increase the max. allowed size of Ethernet packets that this interface receives or transmits.

Possible values:

- ▶ 1518..1530 (default setting: 1518) (depends on hardware)
 - With the setting 1518, the port transmits the Ethernet packets up to the following size:
 - 1518 bytes without VLAN tag
 - (1514 bytes + 4 bytes CRC)
 - 1522 bytes with VLAN tag
 - (1518 bytes + 4 bytes CRC)

Speed

Specifies the speed of the PRP interface. The prerequisite is that both PRP member ports operate with the specified speed.

Possible values:

- 100Mbps (default setting)
- ▶ 1Gbps

5.9.4.2 PRP DAN/VDAN Table (depends on hardware)

[Switching > L2-Redundancy > PRP > DAN/VDAN Table]

This dialog lets you analyze the LANs. This is helpful for example, when the *Last seen A* counter of one port continually increases while the *Last seen B* counter remains the same (and the other way round). This condition indicates the interruption of a LAN connection.

DAN/VDAN means Double Attached Node / Virtual Double Attached Node.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

_		
	00	0
	85	

Resets the entire table.

Index

Displays the index number to which the table row relates.

MAC address

Displays the MAC address of the node.

Last seen A

Displays the time between received first packets for this node on LAN A. When the counter reaches the value of 497 days, it overflows and restarts from 0.

Last seen B

Displays the time between received first packets for this node on LAN B. When the counter reaches the value of 497 days, it overflows and restarts from 0.

Remote node type

Displays the type of node.

Possible values:

- redboxp Management
- vdanp Client

5.9.4.3 PRP Proxy Node Table (depends on hardware)

[Switching > L2-Redundancy > PRP > Proxy Node Table]

This dialog informs you of the connected devices for which this device provides PRP redundancy.

Note: The Redbox supports up to 128 hosts. If this number is exceeded with Redbox, then the device drops the packets.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Resets the entire table.

Index

Displays the index number to which the table row relates.

MAC address

Displays the MAC address of the connected devices for which this device implements PRP redundancy.

5.9.4.4 PRP Statistics (depends on hardware)

[Switching > L2-Redundancy > PRP > Statistics]

This dialog lists receive events for various MIB Managed Objects. Each entry represents link degradation for the MIB Managed Objects listed in the description column. The table lists how many times the event occurred for each path through the device. The Port A entries for example, specify the path between the transceiver, through the Link Redundancy Entity (LRE) to the UDP and TCP layers.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

Rocot
17636

Resets the entire table.

Description

	Displays the MIB Managed Objects description to which the Port A, Port B, and Interlink entries refer.
Port A	Displays the number of MIB Managed Objects events on <i>Port A</i> . The device examines the data packets as these pass from receive transceiver A to the LRE.
Port B	Displays the number of MIB Managed Objects events on <i>Port B</i> . The device examines the data packets as these pass from receive transceiver B to the LRE.
Interlink	Displays the number of MIB Managed Objects events on the interlink. The counters are active for the MIB Managed Objects that pertain to the interlink. The other counters remain empty. A sample is made of the data packets as they pass from the LRE to the switch.
CPU port	Displays the number of MIB Managed Objects events on the CPU Port. There is one MIB Managed Object that pertains to the CPU Port. The other counters remain empty. A sample is made of the data packets as these pass from receive transceiver to the CPU.

5.9.5 HSR (depends on hardware)

[Switching > L2-Redundancy > HSR]

An HSR-based ring offers zero recovery time (HSR = High-availability Seamless Redundancy). HSR is suited for applications that demand high availability and short reaction times. For example, protection applications for electrical station automation and controllers for synchronized drives which require constant connection.

HSR Redundancy Boxes (RedBox) use 2 Ethernet ports operating in parallel to connect to a ring. An HSR RedBox operating in this configuration is a Doubly Attached Node implementing the HSR protocol (DANH). A standard ethernet device connected to the HSR ring through an HSR RedBox is a Virtual DANH (VDANH).

The transmitting HSR node or HSR RedBox sends twin packets, one in each direction, on the ring. For identification, the HSR node injects the twin packets with an HSR tag. The HSR tag consists of a port identifier, the length of the payload and a sequence number. In a normal operating ring, the destination HSR node or RedBox receives both packets within a certain time skew. An HSR node forwards the first packet to arrive to the upper layers and discards the second packet when it arrives. A RedBox on the other hand forwards the first packet to the VDANHs and discards the second packet when it arrives.

The device performs a specific role in the network. Set up a device as an HSR RedBox if the device connects standard ethernet devices to an HSR ring. Set up a device as an HSR node if the device connects a PRP LAN to an HSR ring.

A single HSR ring accommodates up to 7 PRP LANs. Set up the device to identify and tag the data packets addressed for the connected PRP LAN.

The number of HSR nodes in the ring should not exceed 50. If the HSR interface speed is *1Gbps*, then the number should not exceed 300.

It is useful to limit the amount of data packets injected into the HSR ring. If there are any third-party devices with a higher latency in the ring, then you reduce the number of ring participants. Verify that the sum of bandwidths applied to the HSR nodes is less than 84 %.

Note: *HSR* is available for devices with an FPGA (hardware for extended functions). The product code indicates if your device supports *HSR*. To use the functions, load the device software supporting *HSR*.

The menu contains the following dialogs:

- ► HSR Configuration (depends on hardware)
- ► HSR DAN/VDAN Table (depends on hardware)
- ► HSR Proxy Node Table (depends on hardware)
- ► HSR Statistics (depends on hardware)

5.9.5.1 HSR Configuration (depends on hardware)

[Switching > L2-Redundancy > HSR > Configuration]

In this dialog, you enable the *HSR* function, set up HSR supervision packets, and specify the function that the device executes in the HSR ring.

The *MRP* and *Spanning Tree* functions cannot operate on the same ports as the *HSR* function. Disable the *MRP* function or choose different ports. Deactivate the *Spanning Tree* function on the HSR ports.

Note: When HSR is active, it uses the interfaces 1/1 and 1/2. As seen in the *Switching* > *Rate Limiter* and *Switching* > *Filter for MAC Addresses* dialogs, the *HSR* function replaces the interfaces 1/1 and 1/2 with the interface hsr/1. Set up the VLAN membership and the rate limiting for the interface hsr/1.

Operation

Operation

Enables/disables the HSR function globally.

Possible values:

🕨 On

When this function is active, the device processes the data stream according to the set-up.

Off (default setting)

Note: When you use SFPs for HSR ports and the device only supports 100 Mbit/s, verify that the SFPs support 100 Mbit/s.

Port A / Port B

Physical port

Displays the number of the physical port which the device uses as the HSR Port A or Port B.

Port A admin state Port B admin state

Enables/disables the HSR function on the port.

Possible values:

On (default setting)

The HSR function on the port is enabled.

▶ 0ff

The HSR function on the port is disabled.

Supervision packet receiver

Evaluate supervision packets

Activates/deactivates the supervision packet analysis.

Possible values:

- marked (default setting) Supervision packet analysis is active. The device receives supervision data packets and analyzes them.
- unmarked

Supervision packet analysis is inactive. The device receives supervision data packets without analyzing them.

Supervision packet sender

Active

Enables/disables the transmission of supervision packets.

Possible values:

On (default setting) The transmission of supervision packets is enabled. The RedBox transmits its own supervision packets.

► Off

The transmission of supervision packets is disabled.

Send VDAN packets

Activates/deactivates the transmission of VDAN supervision packets.

The prerequisite is that you enable the transmission of supervision packets. See the Active field.

Possible values:

marked (default setting)

The transmission of VDAN supervision packets is active. The RedBox transmits both its own supervision packets and the supervision packets for the VDANs listed in the *Proxy Node Table*.

unmarked

The transmission of VDAN supervision packets is inactive.

Configuration

MTU

Specifies the maximum allowed size of Ethernet packets on the interface in bytes.

Possible values:

- ▶ 1518..1530 (default setting: 1518) (depends on hardware)
 - With the setting 1518, the port transmits the Ethernet packets up to the following size:
 - 1518 bytes without VLAN tag
 - (1514 bytes + 4 bytes CRC)
 - 1522 bytes with VLAN tag (1518 bytes + 4 bytes CRC)

This setting lets you increase the max. allowed size of Ethernet packets that this interface receives or transmits.

Note: If you increase the value, then it can be necessary to increase the MTU size of other ports by the same amount. See the *MTU* column in the *Basic Settings > Port* dialog, *Configuration* tab.

Speed

Specifies the speed of the HSR interface. The prerequisite is that both HSR member ports operate with the specified speed.

Possible values:

100Mbps (default setting)
 1Gbps

HSR parameter (depends on hardware)

HSR mode

Specifies the forwarding capacity of the device for unicast data packets.

Possible values:

modeh (default setting)

If the host operates as a proxy for a destination device, then it removes unicast data packets from the ring and forwards them to the destination address.

▶ modeu

If the host operates as a proxy for a destination device, then it forwards unicast data packets around the ring and forwards them to the destination address. If the packets return to the source node, then the device discards the unicast data packets.

Switching node type

Specifies the function that the device executes in the HSR ring.

Possible values:

hsrredboxsan (default setting) You use this setting if you connect SANs to the device within a HSR ring.

hsrredboxprpa

You use this setting to connect the corresponding device with PRP LAN A. Furthermore, set the *Redbox identity* parameter for the corresponding network connection.

hsrredboxprpb

You use this setting to connect the corresponding device with PRP LAN B. Furthermore, set the *Redbox identity* parameter for the corresponding network connection.

Note: If you specify the value *hsrredboxprpa* or *hsrredboxprpb*, then increase the MTU size on the interface. See the *Configuration* frame, *MTU* field.

Also increase the MTU size of the ports connected with LAN A and LAN B in the PRP networks by the same amount. See the *MTU* column in the *Basic Settings > Port* dialog, *Configuration* tab.

Redbox identity

Specifies the tags for the PRP LAN data packets.

The parameter identifies and tags the data packets for the PRP LAN that you connect to this device. The device identifies the data packets for up to 7 PRP LANs that you connect to the HSR ring.

The prerequisite is that in the *Switching node type* field the value *hsrredboxprpa* or *hsrredboxprpb* is specified.

Possible values:

id1a (default setting)

Use this value to handle the HSR data packets for LAN A in PRP network 1.

🕨 id1b

Use this value to handle the HSR data packets for LAN B in PRP network 1.

▶ id2a

Use this value to handle the HSR data packets for LAN A in PRP network 2.

▶ id2b

Use this value to handle the HSR data packets for LAN B in PRP network 2.

- ► ...
- ▶ id7a

Use this value to handle the HSR data packets for LAN A in PRP network 7.

▶ id7b

Use this value to handle the HSR data packets for LAN B in PRP network 7.

5.9.5.2 HSR DAN/VDAN Table (depends on hardware)

[Switching > L2-Redundancy > HSR > DAN/VDAN Table]

This dialog lets you analyze the LANs. This is helpful for example, when the *Last seen A* counter of one port continually increases while the *Last seen B* counter remains the same (and the other way round). This condition indicates the interruption of a LAN connection.

DAN/VDAN means Double Attached Node / Virtual Double Attached Node.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

Door	
Rest	

Resets the entire table.

Index

Displays the index number to which the table row relates.

MAC address

Displays the MAC address of the node.

Last seen A

Displays the time between received first packets for this node on LAN A. When the counter reaches the value of 497 days, it overflows and restarts from 0.

Last seen B

Displays the time between received first packets for this node on LAN B. When the counter reaches the value of 497 days, it overflows and restarts from 0.

Remote node type

Displays the type of node.

Possible values:

- redboxh Management
- vdanh Client

5.9.5.3 HSR Proxy Node Table (depends on hardware)

[Switching > L2-Redundancy > HSR > Proxy Node Table]

This dialog informs you of the connected devices for which this device provides HSR redundancy.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Resets the entire table.

Index

Displays the index number to which the table row relates.

Possible values: 1..128

MAC address

Displays the MAC addresses of the connected devices for which this device implements HSR redundancy.

5.9.5.4 HSR Statistics (depends on hardware)

[Switching > L2-Redundancy > HSR > Statistics]

This dialog lists receive events for various MIB Managed Objects. Each entry represents link degradation for the MIB Managed Objects listed in the description column. The table lists how many times the event occurred for each path through the device. The Port A entries for example, specify the path between the transceiver, through the Link Redundancy Entity (LRE) to the UDP and TCP layers.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

R		
	03	

Resets the entire table.

Description

	Displays the MIB Managed Objects description to which the Port A, Port B, and Interlink entries refer.
Port A	Displays the number of MIB Managed Objects events on <i>Port A</i> . The device examines the data packets as these pass from receive transceiver A to the LRE.
Port B	Displays the number of MIB Managed Objects events on <i>Port B</i> . The device examines the data packets as these pass from receive transceiver B to the LRE.
Interlink	Displays the number of MIB Managed Objects events on the interlink. The counters are active for the MIB Managed Objects that pertain to the interlink. The other counters remain empty. A sample is made of the data packets as they pass from the LRE to the switch.
CPU port	Displays the number of MIB Managed Objects events on the CPU Port. There is one MIB Managed Object that pertains to the CPU Port. The other counters remain empty. A sample is made of the data packets as these pass from receive transceiver to the CPU.

5.9.6 Spanning Tree

[Switching > L2-Redundancy > Spanning Tree]

The Spanning Tree Protocol (STP) is a protocol that deactivates redundant paths of a network to help avoid loops. If a network component becomes inoperable on the path, then the device calculates the new topology and reactivates these paths.

The Rapid Spanning Tree Protocol (RSTP) enables fast switching to a newly calculated topology without interrupting existing connections. RSTP gets average reconfiguration times of less than a second. When you use RSTP in a ring with 10 to 20 devices, you can get reconfiguration times in the order of milliseconds.

The device supports the Multiple Spanning Tree Protocol (MSTP) standardized in IEEE 802.1, which is a further development of the Spanning Tree Protocol (STP).

Note: When you connect the device to the network through twisted-pair SFPs instead of through usual twisted-pair ports, the reconfiguration of the network takes slightly longer.

The menu contains the following dialogs:

- Spanning Tree Global
- Spanning Tree MSTP
- Spanning Tree Port

5.9.6.1 Spanning Tree Global

[Switching > L2-Redundancy > Spanning Tree > Global]

In this dialog, you enable/disable the Spanning Tree function and specify the bridge settings.

Operation

Operation

Enables/disables the Spanning Tree function in the device.

Possible values:

- On (default setting)
- ► Off

The device behaves transparently. The device floods received Spanning Tree data packets like multicast data packets to the ports.

Variant

Variant

Specifies the protocol used for the Spanning Tree function:

Possible values:

rstp (default setting) The protocol RSTP is active.
 With RSTP (IEEE 802.1Q-2005), the Spanning Tree function operates for the underlying physical layer.

▶ mstp

The protocol MSTP is active.

To help avoid longer recovery times, specify the maximum value 40 in the Tx holds field.

Traps

Send trap

Activates/deactivates the sending of SNMP traps for the following events:

- Another bridge takes over the *Root bridge* role.
- The topology changes. A port changes its *Port state* from *forwarding* into *discarding* or from *discarding* into *forwarding*.

Possible values:

marked (default setting) The sending of SNMP traps is active.

unmarked

The sending of SNMP traps is inactive.

Ring only mode

Active

Activates/deactivates the *Ring only mode* function, in which the device does not verify the age of the BPDUs.

Possible values:

marked

The *Ring only mode* function is active. Use this setting for applications for RSTP rings with diameters greater than 40.

unmarked (default setting) The Ring only mode function is inactive.

First port

Specifies the port number of the first interface.

Possible values:

<Port number> (default setting: -)

Second port

Specifies the port number of the second interface.

Possible values:

Port number> (default setting: -)

Bridge configuration

Bridge ID

Displays the Bridge Identifier of the device.

The device with the numerically lowest *Bridge Identifier* value takes over the role of the *Root bridge* in the network.

Possible values:

<Bridge priority> / <MAC address> Value in the Priority field / MAC address of the device

Priority

Specifies the Bridge priority of the device.

Possible values:

0..61440 in steps of 4096 (default setting: 32768 (2¹⁵))

To make this device the *Root bridge*, assign the numerically lowest value for the priority in the network to the device.

Hello time [s]

Specifies the time in seconds between the sending of two configuration messages (Hello data packets).

Possible values:

1..2 (default setting: 2)

If the device takes over the role of the *Root bridge*, then the other devices in the network use the value specified here.

Otherwise, the device uses the value that the *Root bridge* specifies. See the *Root information* frame.

Due to the interaction with the *Tx holds* parameter, we recommend that you do not change the default setting.

Forward delay [s]

Specifies the delay time for the status change in seconds.

Possible values:

▶ 4..30 (default setting: 15)

If the device takes over the role of the *Root bridge*, then the other devices in the network use the value specified here.

Otherwise, the device uses the value that the Root bridge specifies. See the Root information frame.

In the Rapid Spanning Tree Protocol (RSTP), the bridges negotiate a status change without a specified delay.

The *Spanning Tree* function uses the parameter to delay the status change between the statuses *disabled*, *discarding*, *learning*, *forwarding*.

The parameters *Forward delay* [s] and *Max age* have the following relationship:

Forward delay $[s] \ge (Max age/2) + 1$

If you enter values in the fields that contradict this relationship, then the device replaces these values with the last valid values or with the default value.

Max age

Specifies the maximum permitted branch length, namely the number of devices to the Root bridge.

Possible values:

▶ 6..40 (default setting: 20)

If the device takes over the role of the *Root bridge*, then the other devices in the network use the value specified here.

Otherwise, the device uses the value that the Root bridge specifies. See the Root information frame.

The Spanning Tree function uses the parameter to specify the validity of STP-BPDUs in seconds.

Tx holds

Limits the maximum transmission rate for sending BPDUs.

Possible values:

1..40 (default setting: 10)

To help avoid longer recovery times when using the MSTP protocol, set the maximum value to 40.

When the device sends a BPDU, the device increments a counter on this port.

When the counter reaches the value specified here, the port stops sending BPDUs. On the one hand, this reduces the load generated by RSTP, and on the other when the device does not receive BPDUs, a communication interruption can be caused.

The device decrements the counter by 1 every second. In the following second, the device sends a maximum of 1 new BPDU.

BPDU guard

Activates/deactivates the BPDU guard function in the device.

With this function, the device helps protect the network from incorrect configurations, attacks with STP-BPDUs, and unwanted topology changes.

Possible values:

marked

The BPDU guard is active.

- The device applies the function to manually specified *Edge ports*. For these ports, in the Switching > L2-Redundancy > Spanning Tree > Port dialog, CIST tab the checkbox in the Admin edge port column is marked.
- If an *Edge port* receives an STP-BPDU, then the device disables the port. For this port, in the *Basic Settings > Port* dialog, *Configuration* tab the checkbox in the *Port on* column is unmarked.
- unmarked (default setting) The BPDU guard is inactive.

To reset the status of the port to the value *forwarding*, you proceed as follows:

□ If the port is still receiving BPDUs:

□ In the *Switching* > *L2-Redundancy* > *Spanning Tree* > *Port* dialog, *CIST* tab unmark the checkbox in the *Admin edge port* column.

or

- □ In the *Switching* > *L*2-*Redundancy* > *Spanning Tree* > *Global* dialog, unmark the *BPDU guard* checkbox.
- □ To re-enable the port again you use the *Auto-Disable* function. As an alternative, proceed as follows:
 - □ Open the *Basic Settings > Port* dialog, *Configuration* tab.
 - □ Mark the checkbox in the *Port on* column.

BPDU filter (all admin edge ports)

Activates/deactivates the STP-BPDU filter on every manually specified *Edge port*. For these ports, in the *Switching* > *L2-Redundancy* > *Spanning Tree* > *Port* dialog, *CIST* tab the checkbox in the *Admin edge port* column is marked.

Possible values:

marked

The BPDU filter is active on every *Edge port*.

- The function does not use these ports in *Spanning Tree* operations.
- The device does not send STP-BPDUs on these ports.
- The device drops any STP-BPDUs received on these ports.
- unmarked (default setting)
 - The global BPDU filter is inactive.

You have the option to explicitly activate the BPDU filter for single ports. See the *Port BPDU filter* column in the *Switching > L2-Redundancy > Spanning Tree > Port* dialog.

Auto-disable

Activates/deactivates the *Auto-Disable* function for the parameters that *BPDU guard* is monitoring on the port.

Possible values:

- marked
 - The Auto-Disable function for the BPDU guard is active.
 - When the port receives an STP-BPDU, the device disables an *Edge port*. The Link status LED for the port flashes 3× per period.
 - The *Diagnostics > Ports > Auto-Disable* dialog displays which ports are currently disabled due to the parameters being exceeded.
 - After a waiting period, the Auto-Disable function enables the port again automatically. For this you go to the Diagnostics > Ports > Auto-Disable dialog and specify a waiting period for the relevant port in the Reset timer [s] column.

unmarked (default setting)

The *Auto-Disable* function for the *BPDU guard* is inactive.

Root information

Root ID

Displays the Bridge Identifier of the current Root bridge.

Priority

Displays the Bridge priority of the current Root bridge.

Possible values:0..61440 in steps of 4096

Hello time [s]

Displays the time in seconds that the *Root bridge* specifies between the sending of two configuration messages (Hello data packets).

Possible values:

The device uses this specified value. See the Bridge configuration frame.

Forward delay [s]

Displays the delay time in seconds set up by the Root bridge for status changes.

Possible values:

▶ 4..30

The device uses this specified value. See the Bridge configuration frame.

In the Rapid Spanning Tree Protocol (RSTP), the bridges negotiate a status change without a specified delay.

The *Spanning Tree* function uses the parameter to delay the status change between the statuses *disabled*, *discarding*, *learning*, *forwarding*.

Max age

Specifies the maximum permitted branch length that the *Root bridge* sets up, namely the number of devices to the *Root bridge*.

Possible values:

6..40 (default setting: 20)

The Spanning Tree function uses the parameter to specify the validity of STP-BPDUs in seconds.

Topology information

Bridge is root

Displays if the device currently has the role of the Root bridge.

Possible values:

marked

The device currently has the role of the Root bridge.

unmarked

Another device currently has the role of the Root bridge.

Root port

Displays the number of the port from which the current path leads to the Root bridge.

If the device takes over the role of the Root bridge, then the field displays the value no Port.

Root path cost

Displays the path cost for the path that leads from the *Root port* of the device to the *Root bridge* of the layer 2 network.

Possible values:

▶ 0

The device takes over the role of the Root bridge.

1..20000000 (2× 10⁸)

Topology changes

Displays how many times the device has put a port into the *forwarding* status using the *Spanning Tree* function since the *Spanning Tree* instance was started.

Time since topology change

Displays the time since the last topology change.

Possible values:

<days, hours:minutes:seconds>

5.9.6.2 Spanning Tree MSTP

[Switching > L2-Redundancy > Spanning Tree > MSTP]

In this dialog, you manage the settings of the global and local MST instances.

In contrast to the local MST instances, the global MST instance is set up permanently in the device. The global MST instance contains the VLANs that are not explicitly allocated to a local MST instance.

The device supports up to 16 local MST instances. To add a local MST instance, click the + button.

While STP has a single Spanning Tree spanning the network, MSTP lets you set up one Spanning Tree per VLAN or group of VLANs. Thus it is possible to specify several smaller Spanning Trees covering one network.

How to help avoid longer convergence times:

- □ Only use devices in the network that support RSTP or MSTP.
- Adjust the following parameters to the topology and number of bridges:
 - Maximum allowed number of devices to the Root bridge
 Switching > L2-Redundancy > Spanning Tree > Global dialog, Max age field
 - Maximum allowed number of bridges within the MST region in a branch to the *Root bridge* Switching > L2-Redundancy > Spanning Tree > MSTP dialog, Global CIST parameter frame, Hops (max.) field

For bridges in an MST region, specify identical values for the following parameters:

- Name of the MST region
- Revision level of the MST region
- Allocation of the VLANs to the MST instances
 - Include ports connecting the bridges of an MST region as members in the VLANs set up on the bridges. The ports are to transmit the data packets with a VLAN tag. You thus help avoid potential connection interruptions within the MST region when the topology is changed.
 - Include ports connecting an MST region with other MST regions or with the CST region (boundary ports) as members in the VLANs set up in both regions. The ports are to transmit the data packets with a VLAN tag. You thus help avoid potential connection interruptions when topology changes affecting the boundary ports are made.

MST region identifier

Name

Specifies the name of the MST region to which the device belongs.

Possible values:

Alphanumeric ASCII character string with 1..32 characters

Revision level

Specifies the version number of the MST region to which the device belongs.

Possible values: • 0..65535 (2¹⁶-1) (default setting: 1)

Checksum

Displays the MD5 checksum of the MST configuration.

Global CIST parameter

Hops (max.)

Specifies the maximum number of bridges within the MST region in a branch to the Root bridge.

Possible values:

6..40 (default setting: 20)

Attached VLANs

Displays the IDs of the VLANs that are assigned only to the global MST instance and to no other local MST instance.

Possible values:

 ID of the statically configured VLANs (default setting: 1)

Bridge ID

Displays the Bridge Identifier of the device.

Possible values:

- <Bridge priority> / <MAC address>
 - The value is made up as follows:
 - Value in the Priority field. See the Switching > L2-Redundancy > Spanning Tree > Global dialog, Bridge configuration frame.
 - MAC address of the device.

Root ID

Displays the *Bridge Identifier* of the current *CIST Root bridge* of the whole Layer 2 network.

Possible values:

<Bridge priority> / <MAC address>

The device with the numerically lowest *Bridge Identifier* value takes over the role of the *CIST Root bridge* in the network. The following devices are able to take over the role of the *Root bridge*:

- Bridges not belonging to any MST region
- Bridges belonging to the global instance of an MST region

In the whole Layer 2 network, the bridges use the time settings of the CIST Root bridge, for example *Hello time* [s].

Regional root ID

Displays the *Bridge Identifier* of the current *Root bridge* that belongs to the global instance of the MST region to which this device belongs.

Possible values:

<Bridge priority> / <MAC address>

The values in the *Regional root ID* and *Root ID* fields are identical when the regional *Root bridge* has the numerically lowest *Bridge Identifier* value in the whole Layer 2 network.

Root port

Displays the port of the device from which the path leads to the current *CIST Root bridge* of the whole Layer 2 network.

Possible values:

no Port

The device currently has the role of the Root bridge.

<Port number>

The path to the current CIST Root bridge of the whole Layer 2 network leads over this port.

Root path cost

Displays the path cost for the path that leads from the regional *Root bridge* of the MST region to the current *CIST Root bridge* of the whole Layer 2 network.

Possible values:

• 0

The regional Root bridge simultaneously has the role of the CIST Root bridge.

```
1..20000000 (2× 10<sup>8</sup>)
```

For the devices within an MST region, the Root path cost values are identical.

If you do not use the *MSTP* function, then the *Root path cost* values are identical to the root path costs of STP or RSTP. In this case, every device considers itself as an own region.

Internal root path cost

Displays the internal path cost for the path that leads from the *Root port* of the device to the current regional *Root bridge* of the MST region.

Possible values:

• 0

The local bridge simultaneously has the role of the current regional Root bridge.

▶ 1..20000000 (2× 10⁸)

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Adds a table row.

The device supports up to local 16 instances.



Removes the selected table row.



Opens the *Configure VLANs* window to allocate VLANs to the local MST instance which is selected in the table.

MSTI

Displays the instance number of the local MST instance.

Attached VLANs

Displays the IDs of the VLANs that are allocated to this local MST instance.

Priority

Specifies the Bridge priority of the local MST instance.

Possible values:

0..61440 in steps of 4096 (default setting: 32768 (2¹⁵))

Assign the numerically lowest value for the priority in this local MST instance to the device to make this device the *Root bridge*.

Bridge ID

Displays the Bridge Identifier.

The device with the numerically lowest *Bridge Identifier* value takes over the role of the regional MSTI *Root bridge* in the instance.

Possible values:

Sum of the value in the Priority and MST/ fields / MAC address of the device.

Time since topology change

Displays the time that has elapsed since the last topology change within this instance.

Topology changes

Displays how many times the device has put a port into the *forwarding* status using the *Spanning Tree* function since the *Spanning Tree* instance was started.

Topology change

Displays if the device has detected a topology change within the instance.

Possible values:

marked

The device has detected a topology change.

unmarked The device has not detected a topology change.

Root ID

Displays the Bridge Identifier of the current Root bridge in this instance.

Possible values:

<Bridge ID> / <MAC address>

Root path cost

Displays the path cost for the path that leads from the *Root port* of the device to the *Root bridge* of the instance.

Possible values:

• 0

The bridge is simultaneously the Root bridge of the instance.

▶ 1..20000000 (2× 10⁸)

Root port

Displays the port of the device from which the current path leads to the Root bridge of the instance.

Possible values:

no Port

The device currently has the role of the Root bridge.

<Port number> The path to the current *Root bridge* of the instance leads over this port.

5.9.6.3 Spanning Tree Port

[Switching > L2-Redundancy > Spanning Tree > Port]

In this dialog, you activate the Spanning Tree function on the ports, specify *Edge ports*, and specify the settings for various protection functions.

The dialog contains the following tabs:

[CIST]
 [Guards]
 [MSTI < MSTI>]

[CIST]

In this tab you have the option to activate the Spanning Tree function on the ports individually, specify the settings for *Edge ports*, and view the current values. The abbreviation CIST stands for *Common and Internal Spanning Tree*.

Note: Deactivate the *Spanning Tree* function on the ports that are participating in other Layer 2 redundancy protocols. Otherwise, it is possible that the redundancy protocols operate differently than intended. This can cause loops.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

STP active

Activates/deactivates the Spanning Tree function on the port.

Possible values:

- marked (default setting) The Spanning Tree function is active on the port.
- unmarked

The *Spanning Tree* function is inactive on the port. If the *Spanning Tree* function is enabled in the device and inactive on the port, then the port does not send STP-BPDUs and drops any STP-BPDUs received.

Port state

Displays the transmission status of the port.

Possible values:

discarding

The port is blocked and forwards only STP-BPDUs.

Learning The port is blocked, but it learns the MAC addresses of received data packets. forwarding The port forwards data packets.

disabled

The port is inactive. See the *Basic Settings > Port* dialog, *Configuration* tab.

🕨 manualFwd

The *Spanning Tree* function is disabled on the port. The port forwards STP-BPDUs.

notParticipate

The port is not participating in STP.

Port role

Displays the current role of the port in the CIST.

Possible values:

▶ root

Port with the cheapest path to the *Root bridge*.

alternate

Port with the alternative path to the Root bridge (currently blocking).

designated

Port for the side of the tree averted from the Root bridge (currently blocking).

backup

Port receives STP-BPDUs from its own device.

▶ master

Port with the cheapest path to the CIST. The port is the CIST Root port of the regional CIST Root bridge. The port is unique in an MST region.

disabled The port is inactive. See the Basic Settings > Port dialog, Configuration tab.

Port path cost

Specifies the path costs of the port.

Possible values:

0..200000000 (2× 10⁸) (default setting: 0)

When the value is 0, the device automatically calculates the path costs depending on the data rate of the port.

Port priority

Specifies the priority of the port.

Possible values:

0..240 in steps of 16 (default setting: 128)

This value represents the first 4 bits of the port ID.

Received bridge ID

Displays the Bridge Identifier of the device from which this port last received an STP-BPDU.

Possible values:

- ► For ports with the *designated* role, the device displays the information for the STP-BPDU last received by the port. This helps to diagnose the detected STP problems in the network.
- ► For the *alternate*, *backup*, *master*, and *root* port roles, in the stationary condition (static topology) this information is identical to the information of the *designated* port role.
- ▶ If a port has no connection or if it did not receive any STP-BDPUs yet, then the device displays the values that the port can send with the *designated* role.

Received port ID

Displays the port ID of the device from which this port last received an STP-BPDU.

Possible values:

- ► For ports with the *designated* role, the device displays the information for the STP-BPDU last received by the port. This helps to diagnose the detected STP problems in the network.
- ► For the *alternate*, *backup*, *master*, and *root* port roles, in the stationary condition (static topology) this information is identical to the information of the *designated* port role.
- If a port has no connection or if it did not receive any STP-BDPUs yet, then the device displays the values that the port can send with the *designated* role.

Received path cost

Displays the path cost that the higher-level bridge has from its *Root port* in the local MST instance to the *Root bridge*.

Possible values:

- ► For ports with the *designated* role, the device displays the information for the STP-BPDU last received by the port. This helps to diagnose the detected STP problems in the network.
- For the *alternate*, *backup*, *master*, and *root* port roles, in the stationary condition (static topology) this information is identical to the information of the *designated* port role.
- If a port has no connection or if it did not receive any STP-BDPUs yet, then the device displays the values that the port can send with the *designated* role.

Admin edge port

Activates/deactivates the *Admin edge port* mode. If the port is connected to an end device, then use the *Admin edge port* mode. This setting lets the *Edge port* change faster to the *forwarding* state after linkup and thus a faster accessibility of the end device.

Possible values:

marked

The Admin edge port mode is active.

The port is connected to an end device.

- After the connection is set up, the port changes to the *forwarding* state without changing to the *Learning* state beforehand.
- If the port receives an STP-BPDU and the BPDU guard function is active, then the device deactivates the port. See the Switching > L2-Redundancy > Spanning Tree > Global dialog.
- unmarked (default setting)
 - The Admin edge port mode is inactive.

The port is connected to another STP bridge.

After the connection is set up, the port changes to the *Learning* status before changing to the *forwarding* state, if applicable.

Auto edge port

Activates/deactivates the automatic detection of whether you connect an end device to the port. The prerequisite is that the checkbox in the *Admin edge port* column is unmarked.

Possible values:

- marked (default setting)
 - The automatic detection is active.

After the installation of the connection and after $1.5 \times Hello time [s]$, the device sets the port to the *forwarding* status (default setting $1.5 \times 2 s$) if the port did not receive any STP-BPDUs during this time.

unmarked

The automatic detection is inactive. After the installation of the connection, and after *Max age* the device sets the port to the *forwarding* status. (default setting: 20 s)

Oper edge port

Displays if an end device or an STP bridge is connected to the port.

Possible values:

- marked
 - An end device is connected to the port. The port does not receive any STP-BPDUs.
- unmarked

An STP bridge is connected to the port. The port receives STP-BPDUs.

Oper PointToPoint

Displays if the port is connected to an STP device through a direct full-duplex link.

Possible values:

marked

The port is connected directly to an STP device through a full-duplex link. The direct, decentralized communication between 2 bridges provides short reconfiguration times.

unmarked

The port is connected in another way, for example through a half-duplex link or through a hub.

Port BPDU filter

Activates/deactivates the filtering of STP-BPDUs on the port explicitly.

The prerequisite is that the port is a manually specified *Edge port*. For these ports, the checkbox in the *Admin edge port* column is marked.

Possible values:

marked

The BPDU filter is active on the port.

The function excludes the port from Spanning Tree operations.

- The device does not send STP-BPDUs on the port.
- The device drops any STP-BPDUs received on the port.
- unmarked (default setting)
 - The BPDU filter is inactive on the port.

You have the option to globally activate the BPDU filter for every *Edge port*. See the *Switching* > L2-Redundancy > *Spanning Tree* > *Global* dialog, *Bridge configuration* frame.

If the BPDU filter (all admin edge ports) checkbox is marked, then the BPDU filter is still active on the port.

BPDU filter status

Displays if the BPDU filter is active on the port.

Possible values:

marked

The BPDU filter is active on the port as a result of the following settings:

- The checkbox in the Port BPDU filter column is marked.
- and/or
- The checkbox in the BPDU filter (all admin edge ports) column is marked. See the Switching > L2-Redundancy > Spanning Tree > Global dialog, Bridge configuration frame.
- unmarked

The BPDU filter is inactive on the port.

BPDU flood

Activates/deactivates the *BPDU flood* mode on the port even if the *Spanning Tree* function is inactive on the port. The device floods STP-BPDUs received on the port to the ports for which the *Spanning Tree* function is inactive and the *BPDU flood* mode is active too.

Possible values:

- marked
 - The BPDU flood mode is active.
- unmarked (default setting) The BPDU flood mode is inactive.

[Guards]

This tab lets you specify the settings for various protection functions on the ports.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Root guard

Activates/deactivates the monitoring of STP-BPDUs on the port. The prerequisite is that the *Loop* guard function is inactive.

With this setting the device helps you protect the network from incorrect configurations or attacks with STP-BPDUs that try to change the topology. This setting is relevant only for ports with the STP role *designated*.

Possible values:

- marked
 - The monitoring of STP-BPDUs is active.
 - If the port receives an STP-BPDU with better path information to the *Root bridge*, then the device discards the STP-BPDU and sets the status of the port to the value *discarding* instead of *root*.
 - If there are no STP-BPDUs with better path information to the *Root bridge*, then the device resets the status of the port after 2 × *Hello time* [s].
- unmarked (default setting) The monitoring of STP-BPDUs is inactive.

TCN guard

Activates/deactivates the monitoring of *Topology Change* notifications on the port. With this setting the device helps you protect the network from attacks with STP-BPDUs that try to change the topology.

Possible values:

- marked
 - The monitoring of Topology Change notifications is active.
 - The port ignores the *Topology Change* flag in received STP-BPDUs.
 - If the received BPDU contains other information that causes a topology change, then the device processes the BPDU even if the *TCN guard* function is active.
 Example: The device receives better path information for the *Root bridge*.
- unmarked (default setting)

The monitoring of *Topology Change* notifications is inactive. If the device receives STP-BPDUs with a *Topology Change* flag, then the device deletes the

MAC address table (forwarding database) of the port and forwards the *Topology Change* notifications.

Loop guard

Activates/deactivates the monitoring of loops on the port. The prerequisite is that the *Root guard* function is inactive.

With this setting the device helps prevent loops if the port does not receive any more STP-BPDUs. Use this setting only for ports with the STP role *alternate*, *backup* or *root*.

Possible values:

marked

The monitoring of loops is active. This helps prevent loops for example, if you disable the Spanning Tree function on the remote device or if the connection is interrupted only in the receiving direction.

- If the port does not receive any STP-BPDUs for a while, then the device sets the status of the port to the value *discarding* and marks the checkbox in the *Loop state* column.
- If the port receives STP-BPDUs again, then the device sets the status of the port to a value according to *Port role* and unmarks the checkbox in the *Loop state* column.
- unmarked (default setting)

The monitoring of loops is inactive.

If the port does not receive any STP-BPDUs for a while, then the device sets the status of the port to the value *forwarding*.

Loop state

Displays if the loop state of the port is inconsistent.

Possible values:

- marked
 - The loop state of the port is inconsistent:
 - The port is not receiving any STP-BPDUs and the Loop guard function is enabled.
 - The device sets the state of the port to the value *discarding*. The device thus helps prevent any potential loops.
- unmarked
 - The loop state of the port is consistent. The port receives STP-BPDUs.

Trans. into loop

Displays how many times the loop state of the port became inconsistent (marked checkbox in the *Loop state* column).

Trans. out of loop

Displays how many times the loop state of the port became consistent (unmarked checkbox in the *Loop state* column).

BPDU guard effect

Displays if the port received an STP-BPDU as an Edge port.

Prerequisite:

- The port is a manually specified *Edge port*. In the *Switching* > *L2-Redundancy* > *Spanning Tree* > Port dialog, the checkbox for this port in the *Admin edge port* column is marked.
- In the Switching > L2-Redundancy > Spanning Tree > Global dialog, the BPDU guard function is active.

Possible values:

marked

The port is an *Edge port* and received an STP-BPDU.

The device deactivates the port. For this port, in the *Basic Settings > Port* dialog, *Configuration* tab the checkbox in the *Port on* column is unmarked.

unmarked

The port is an *Edge port* and has not received any STP-BPDUs, or the port is not an *Edge port*.

To reset the status of the port to the value *forwarding*, you proceed as follows:

- □ If the port is still receiving BPDUs:
 - □ In the *CIST* tab, unmark the checkbox in the *Admin edge port* column. or
 - □ In the *Switching* > *L2-Redundancy* > *Spanning Tree* > *Global* dialog, unmark the *BPDU guard* checkbox.
- □ To activate the port, proceed as follows:
 - □ Open the *Basic Settings > Port* dialog, *Configuration* tab.
 - □ Mark the checkbox in the *Port on* column.

[MSTI <MSTI>]

This tab lets you specify the settings on the ports for path costs and priority in the local MST instance, and to view current values.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Port state

Displays the transmission status of the port.

Possible values:

- discarding The port is blocked and forwards only STP-BPDUs.
- Learning The port is blocked, but it learns the MAC addresses of received data packets.
- forwarding
 The port forwards data packets.
- disabled The port is inactive. See the Basic Settings > Port dialog, Configuration tab.
- manualFwd The Spanning Tree function is disabled on the port. The port forwards STP-BPDUs.
- notParticipate The port is not participating in STP.

Port role

Specifies the current role of the port in the local instance.

Possible values:

- ▶ root
 - Port with the cheapest path to the Root bridge.
- alternate

Port with the alternative path to the Root bridge (currently interrupted).

designated

Port for the side of the tree averted from the Root bridge.

backup

Port which receives STP-BPDUs from its own device.

master

Port with the cheapest path to the CIST. The port is the *CIST Root port* of the *CIST* Regional Root. The port is unique in an MST region.

disabled

The port is inactive. See the *Basic Settings > Port* dialog, *Configuration* tab.

Port path cost

Specifies the path costs of the port in the local instance.

Possible values:

```
0..200000000 (2× 10<sup>8</sup>) (default setting: 0)
```

When the value is 0, the device automatically calculates the path costs depending on the data rate of the port.

Port priority

Specifies the priority of the port in the local instance.

Possible values:

0..240 in steps of 16 (default setting: 128)

Received bridge ID

Displays the *Bridge Identifier* of the device from which this port last received an STP-BPDU in the local instance.

Received port ID

Displays the port ID of the device from which this port last received an STP-BPDU.

Possible values:

- ► For ports with the *designated* role, the device displays the information for the STP-BPDU last received by the port. This helps to diagnose the detected STP problems in the network.
- For the *alternate*, *backup*, *master*, and *root* port roles, in the stationary condition (static topology) this information is identical to the information of the *designated* port role.
- If a port has no connection or if it did not receive any STP-BDPUs yet, then the device displays the values that the port can send with the *designated* role.

Received path cost

Displays the path cost that the higher-level bridge has from its Root port to the Root bridge.

Possible values:

- ► For ports with the *designated* role, the device displays the information for the STP-BPDU last received by the port. This helps to diagnose the detected STP problems in the network.
- For the alternate, backup, master, and root port roles, in the stationary condition (static topology) this information is identical to the information of the designated port role.
- If a port has no connection or if it did not receive any STP-BDPUs yet, then the device displays the values that the port can send with the *designated* role.

5.9.7 Link Aggregation

[Switching > L2-Redundancy > Link Aggregation]

The *Link Aggregation* function lets you aggregate multiple parallel links. The prerequisite is that the links have the same speed and are full-duplex. The advantages compared to conventional connections using a single line are higher availability and a higher transmission bandwidth.

The criteria for distributing the load to the parallel links are based on the Hashing option function.

The Link Aggregation Control Protocol (LACP) makes it possible to monitor the packet-based continuous link status on the physical ports. LACP also helps ensure that the link partners meet the aggregation prerequisites.

If the remote side does not support the Link Aggregation Control Protocol (LACP), then you can use the *Static link aggregation* function. In this case, the device aggregates the links based on the link, link speed and duplex setting.

Configuration

Hashing option

Specifies which information the device uses to distribute the packets to the physical ports of the LAG interface. The device sends packets containing the same distribution-relevant information over the same physical port to keep the packet order.

This setting overwrites the value specified in the Hashing option column for the port.

Possible values:

- sourceMacVLan The device uses the Source MAC address, VLAN ID, EtherType fields of the packet, and the physical ingress port.
- destMacVLan

The device uses the Destination MAC address, VLAN ID, EtherType fields of the packet, and the physical ingress port.

- sourceDestMacVLan (default setting) The device uses the Source MAC address, Destination MAC address, VLAN ID, EtherType fields of the packet, and the physical ingress port.
- sourceIPsourcePort The device uses the Source IP address and Source TCP/UDP port fields of the packet.
- destIPdestPort

The device uses the Destination IP address and Destination TCP/UDP port fields of the packet.

sourceDestIPPort

The device uses the Source IP address, Destination IP address, Source TCP/UDP port, and Destination TCP/UDP port fields of the packet.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the *Create* window to add a table row for a LAG interface or to assign a physical port to a LAG interface.

- From the Trunk port drop-down list, you select the LAG interface number.
- From the *Port* drop-down list, you select the number of a physical port to assign to the LAG interface.

After you set up a LAG interface, the device adds the LAG interface to the table in the *Basic Settings > Port* dialog, *Statistics*tab.



Removes the selected table row.

Trunk port

Displays the LAG interface number.

Name

Specifies the name of the LAG interface.

Possible values:

Alphanumeric ASCII character string with 1..15 characters

Link/Status

Displays the current operating state of the LAG interface and the physical ports.

Possible values:

up (lag/... row)

The LAG interface is operational.

The prerequisites are:

- The Static link aggregation function is active on this LAG interface. or
- LACP is active on the physical ports assigned to the LAG interface, see the LACP active column.

and

The key specified for the LAG interface in the *LACP admin key* column matches the keys specified for the physical ports in the *LACP port actor admin key* column. and

The number of operational physical ports assigned to the LAG interface is greater than or equal to the value specified in the *Active ports (min.)* column.

🕨 up

The physical port is operational.

▶ down (lag/...row)

The LAG interface is inoperable.

down

The physical port is disabled. or No cable connected or no active link.

Active

Activates/deactivates the LAG interface.

Possible values:

- marked (default setting)
 - The LAG interface is active.

Consider that the following protocols do not work properly on the physical ports when you activate the LAG interface:

– PTP

unmarked The LAG interface is inactive.

-

STP active

Activates/deactivates the *Spanning Tree* function on this LAG interface. The prerequisite is that in the *Switching > L2-Redundancy > Spanning Tree > Global* dialog the *Spanning Tree* function is enabled.

You can also activate/deactivate the *Spanning Tree* function on the LAG interfaces in the *Switching* > L2-Redundancy > *Spanning Tree* > *Port* dialog.

Possible values:

- marked (default setting) The Spanning Tree function is active on this LAG interface.
- unmarked The Spanning Tree function is inactive on this LAG interface.

Static link aggregation

Activates/deactivates the *Static link aggregation* function on the LAG interface. The device aggregates the assigned physical ports to the LAG interface, even if the remote site does not support LACP.

Possible values:

marked

The *Static link aggregation* function is active on this LAG interface. The device aggregates an assigned physical port to the LAG interface as soon as the physical port gets a link. The device does not send LACPDUs and discards received LACPDUs.

unmarked (default setting)

The *Static link aggregation* function is inactive on this LAG interface. If the connection was successfully negotiated using LACP, then the device aggregates an assigned physical port to the LAG interface.

Hashing option

Specifies which information the device uses to distribute the packets to the individual physical ports of the LAG interface. This setting has priority over the value selected in the *Configuration* frame, *Hashing option* drop-down list.

For further information on the values, see the description of the *Hashing option* drop-down list in the *Configuration* frame.

MTU

Specifies the maximum allowed size of Ethernet packets on the LAG interface in bytes. Any present VLAN tag is not taken into account.

This setting lets you increase the size of the Ethernet packets for specific applications.

Possible values:

- 1518..12288 (default setting: 1518)
 - With the value 1518, the LAG interface transmits the Ethernet packets up to the following size:
 - 1518 bytes without VLAN tag (1514 bytes + 4 bytes CRC)
 - 1522 bytes with VLAN tag
 - (1518 bytes + 4 bytes CRC)

Track name

Displays the name of the tracking object made up of the values displayed in the *Type* and *Track ID* columns.

Active ports (min.)

Specifies the minimum number of physical ports to be active for the LAG interface to stay active. If the number of active physical ports is lower than the specified value, then the device deactivates the LAG interface.

If a redundancy function like *Spanning Tree* or *MRP* over LAG is active in the device, then you use this function to force the device to switch automatically to the redundant line.

Possible values:

1..4 (default setting: 1)
 Depending on the hardware, the upper value can be greater than 4, for example 8 or 32.

Туре

Displays if the LAG interface is based on the *Static link aggregation* function or on LACP.

Possible values:

▶ static

The LAG interface is based on the Static link aggregation function.

► dynamic

The LAG interface is based on LACP.

Send trap (Link up/down)

Activates/deactivates the sending of SNMP traps when the device detects a change in the link up/ down status for this interface.

Possible values:

- marked (default setting)
 - The sending of SNMP traps is active. The prerequisite is that in the *Diagnostics* > *Status Configuration* > *Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

When the device detects a link up/down status change, the device sends an SNMP trap.

unmarked

The sending of SNMP traps is inactive.

LACP admin key

Specifies the LAG interface key. The device uses this key to identify the ports that can be aggregated to the LAG interface.

Possible values:

```
▶ 0..65535 (2<sup>16</sup>-1)
```

You specify the corresponding value for the physical ports in the *LACP port actor admin key* column.

Port

Displays the physical port number assigned to the LAG interface.

Aggregation port status

Displays if the LAG interface aggregates the physical port.

Possible values:

- active
 - The LAG interface aggregates the physical port.
- inactive

The LAG interface does not aggregate the physical port.

LACP active

Activates/deactivates LACP on the physical port.

Possible values:

- marked (default setting) LACP is active on the physical port.
- unmarked LACP is inactive on the physical port.

LACP port actor admin key

Specifies the physical port key. The device uses this key to identify the ports that can be aggregated to the LAG interface.

Possible values:

▶ 0

The device ignores the key on this physical port when deciding to aggregate the port into the LAG interface.

1..65535 (2¹⁶-1)

If this value matches the value of the LAG interface specified in the *LACP admin key* column, then the device only aggregates this physical port to the LAG interface.

LACP actor admin state

Specifies the actor state values that the LAG interface transmits in the LACPDUs. This lets you control the LACPDU parameters.

The device lets you mix the values. From the drop-down list, select one or more items.

Possible values:

ACT

```
(LACP_Activity state)
```

When selected, the link transmits the LACPDUs cyclically, otherwise when requested.

- ► STO
 - (LACP Timeout state)

When selected, the link transmits the LACPDUs cyclically using the short timeout, otherwise using the long timeout.

AGG

(Aggregation state)

When selected, the device interprets the link as a candidate for aggregation, otherwise as an individual link.

For further information on the values, see IEEE 802.1AX-2014.

LACP actor oper state

Displays the actor state values that the LAG interface transmits in the LACPDUs.

Possible values:

```
► ACT
```

```
(LACP_Activity state)
```

When visible, the link transmits the LACPDUs cyclically, otherwise when requested.

```
► STO
```

```
(LACP_Timeout state)
```

When visible, the link transmits the LACPDUs cyclically using the short timeout, otherwise using the long timeout.

AGG

(Aggregation state)

When visible, the device interprets the link as a candidate for aggregation, otherwise as an individual link.

SYN

(Synchronization state)

When visible, the device interprets the link as IN_SYNC, otherwise as OUT_OF_SYNC.

 COL (Collecting state) When visible, collection of incoming frames is enabled on this link, otherwise disabled.
 DST (Distributing state) When visible, distribution of outgoing frames is enabled on this link, otherwise disabled.
 DFT (Defaulted state) When visible, the link uses defaulted operational information, administratively specified for the Partner. Otherwise the link uses the operational information received from a LACPDU.

EXP

```
(Expired state)
When visible, the link receiver is in the EXPIRED state.
```

LACP partner oper SysID

Displays the MAC address of the remote device connected to this physical port.

The LAG interface has received this information in a LACPDU from the partner.

LACP partner oper port

Displays the port number of the remote device connected to this physical port.

The LAG interface has received this information in a LACPDU from the partner.

LACP partner oper port state

Displays the partner state values that the LAG interface receives in the LACPDUs.

Possible values:

- ACT
- ► STO
- AGG
- SYN
- COL
- DST
- DFT
- ► EXP

For further information on the values, see the description of the *LACP actor oper state* column and IEEE 802.1AX-2014.

5.9.8 Link Backup

[Switching > L2-Redundancy > Link Backup]

With Link Backup, you set up pairs of redundant links. Each pair has a *Primary port* and a *Backup port*. The *Primary port* forwards the data packets until the device detects an error. If the device detects an error on the *Primary port*, then the Link Backup function transfers the data packets over to the *Backup port*.

The dialog also lets you set a fail back option. When you activate the *Fail back* function and the *Primary port* returns to normal operation, the device first blocks the data packets on the *Backup port* and then forwards the data packets to the *Primary port*. This process helps protect the device from causing loops in the network.

Operation

Operation

Enables/disables the Link Backup function globally in the device.

Possible values:

▶ On

Enables the Link Backup function.

Off (default setting) Disables the Link Backup function.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Adds a table row.



Removes the selected table row.

Primary port

Displays the *Primary port* of the interface pair. When you enable the Link Backup function, this port is responsible for forwarding the data packets.

Possible values:

Physical ports

Backup port

Displays the *Backup port* to which the device forwards the data packets if the device detects an error on the *Primary port*.

Possible values:

Physical ports except for the port you set as the Primary port.

Description

Specifies the Link Backup pair. Enter a name to identify the Backup pair.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Primary port status

Displays the status of the *Primary port* for this Link Backup pair.

Possible values:

forwarding

The link is up, no shutdown, and forwarding data packets.

blocking

The link is up, no shutdown, and blocking data packets.

🕨 down

The cable is unplugged, the port is powered off, the port link is interrupted, or a function in the device has disabled the port.

unknown

The Link Backup feature is globally disabled, or the port pair is inactive. Therefore, the device ignores the port pair settings.

Backup port status

Displays the status of the Backup port for this Link Backup pair.

Possible values:

forwarding

The link is up, no shutdown, and forwarding data packets.

blocking

The link is up, no shutdown, and blocking data packets.

🕨 down

The cable is unplugged, the port is powered off, the port link is interrupted, or a function in the device has disabled the port.

unknown

The Link Backup feature is globally disabled, or the port pair is inactive. Therefore, the device ignores the port pair settings.

Fail back

Activates/deactivates the automatic fail back.

Possible values:

- marked (default setting)
 - The automatic fail back is active.

After the delay timer expires, the *Backup port* changes to *blocking* and the *Primary port* changes to *forwarding*.

- unmarked
 - The automatic fail back is inactive.

The *Backup port* continues forwarding data packets even after the *Primary port* re-establishes a link or you manually change the admin status of the *Primary port* from shutdown to no shutdown.

Fail back delay [s]

Specifies the delay time in seconds that the device waits after the *Primary port* re-establishes a link. Furthermore, this timer also applies when you manually set the admin status of the *Primary port* from shutdown to no shutdown. After the delay timer expires, the *Backup port* changes to *blocking* and the *Primary port* changes to *forwarding*.

Possible values:

0..3600 (default setting: 30)

When set to 0, immediately after the *Primary port* re-establishes a link, the *Backup port* changes to *blocking* and the *Primary port* changes to *forwarding*. Furthermore, immediately after you manually set the admin status of from shutdown to no shutdown, the *Backup port* changes to *blocking* and the *Primary port* changes to *forwarding*.

Active

Activates/deactivates the Link Back up pair configuration.

Possible values:

marked

The Link Backup pair is active. The device senses the link and administration status and forwards the data packets according to the pair configuration.

unmarked (default setting) The Link Backup pair is inactive. The ports forward the data packets according to standard switching.

Create

Primary port

Specifies the *Primary port* of the backup interface pair. During normal operation this port is responsible for forwarding the data packets.

Possible values:

Physical ports

Backup port

Specifies the *Backup port* to which the device transfers the data packets to if the device detects an error on the *Primary port*.

Possible values:

Physical ports except for the port you set as the Primary port.

5.9.9 FuseNet

[Switching > L2-Redundancy > FuseNet]

The *FuseNet* protocols let you couple rings that are operating with one of the following redundancy protocols:

MRP

- Fast MRP (depends on hardware)
- HIPER Ring
- DLR (depends on hardware)
- RSTP

Note: If you use the *Ring/Network Coupling* function to couple networks, then verify that the networks only contain Hirschmann devices.

Use the following table to select the *FuseNet* coupling protocol to be used in the network:

Main Ring	Connected Network					
	MRP	Fast MRP ²⁾	HIPER Ring	DLR ²⁾	RSTP	
MRP	Sub Ring ¹⁾	Ring/Network Coupling	RCP Ring/Network Coupling	RCP Ring/Network Coupling	RCP Ring/Network Coupling	
Fast MRP ²⁾	Sub Ring ¹⁾	Ring/Network Coupling	RCP Ring/Network Coupling	Ring/Network Coupling	RCP Ring/Network Coupling	
HIPER Ring	Sub Ring	RCP Ring/Network Coupling	Ring/Network Coupling	RCP Ring/Network Coupling	RCP Ring/Network Coupling	
DLR ²⁾	Sub Ring RCP	-	RCP	-	RCP	
RSTP	RCP	RCP	RCP	RCP	_	

- no suitable coupling protocol
- 1) with the *MRP* function set-up on different VLANs
- 2) depending on the device settings

The menu contains the following dialogs:

- Sub Ring
- Ring/Network Coupling
- Redundant Coupling Protocol

5.9.9.1 Sub Ring

[Switching > L2-Redundancy > FuseNet > Sub Ring]

This dialog lets you set up the device to operate in the Sub Ring Manager mode.

The *Sub Ring* function lets you easily couple network segments to existing redundancy rings. The *Sub Ring Manager* device couples a Sub Ring to an existing ring (base ring).

You can integrate any devices that support MRP as participants in the Sub Ring. These devices do not require support for the *Sub Ring* function.

When setting up Sub Rings, remember the following rules:

- The device supports *Link Aggregation* in the Sub Ring
- No spanning tree on Sub Ring ports
- Same *MRP domain* on devices within a Sub Ring
- Different VLANs for base ring and Sub Ring

Specify the VLAN settings as follows:

- VLAN X for base ring
 - on the ring ports of the devices participating in the base ring
 - on the base ring ports of the Sub Ring Manager device
- VLAN Y for Sub Ring
 - on the ring ports of the devices participating in the Sub Ring
 - on the Sub Ring ports of the Sub Ring Manager device

Note: To help avoid loops, only close the redundant line when the settings are specified in every device participating in the ring.

Operation

Operation

Enables/disables the Sub Ring function.

Possible values:

- ▶ On
 - The Sub Ring function is enabled.
- *Off* (default setting) The *Sub Ring* function is disabled.

Information

Table entries (max.)

Displays the maximum number of Sub Rings supported by the device.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

- In the Sub Ring ID field, you specify the number that uniquely identifies the Sub Ring.
 Possible values:
 - ▶ 1..40000

You can replace the value prefilled by the device with any value in the range.

The device lets you set a maximum of 8 Sub Ring instances.



Removes the selected table row.

Sub Ring ID

Displays the number that uniquely identifies the Sub Ring.

Name

Specifies the optional name of the Sub Ring.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Active

Activates/deactivates the Sub Ring.

Activate the Sub Ring when the configuration of every device participating in the Sub Ring is complete. Close the Sub Ring only after activating the *Sub Ring* function.

Possible values:

- marked
 - The Sub Ring is active.
- unmarked (default setting) The Sub Ring is inactive.

Status

Displays the operational state of the Sub Ring configuration.

Possible values:

▶ noError

The device detects an acceptable Sub Ring configuration.

ringPortLinkError

- The ring port has no link.
- One of the Sub Ring lines is connected to one more port of the device. But the Sub Ring line
 is not connected to one of the ring ports of the device.

multipleSRM

The *Sub Ring Manager* device receives data packets from more than one *Sub Ring Manager* devices in the Sub Ring.

noPartnerManager

The Sub Ring Manager device receives its own data packets.

concurrentVLAN

The Media Redundancy Protocol (MRP) in the base ring uses the VLAN of the *Sub Ring Manager* domain.

concurrentPort

One more redundancy protocol uses the ring port of the Sub Ring Manager domain.

concurrentRedundancy

The Sub Ring Manager domain is inactive because of one more active redundancy protocol.

trunkMember

The ring port of the Sub Ring Manager domain is member of a Link Aggregation connection.

▶ sharedVLAN

The *Sub Ring Manager* domain is inactive because shared VLAN is active and the main ring also uses the Media Redundancy Protocol (MRP).

Redundancy

Displays if the redundancy is available.

When a component of the Sub Ring becomes inoperable, the redundant line takes over its function.

Possible values:

redGuaranteed

The redundancy is available.

redNotGuaranteed The redundancy is unavailable.

Port

Specifies the port that connects the device to the Sub Ring.

Possible values:

<Port number>

Administrative mode

Specifies the mode of the Sub Ring Manager device.

There are 2 *Sub-Ring Manager* devices that connect the Sub Ring to the base ring. As long as the Sub Ring is physically closed, one *Sub Ring Manager* device blocks its Sub Ring port.

Possible values:

manager (default setting)
 The Sub Ring port forwards data packets.
 When this value is set on both devices that couple the Sub Ring to the base ring, the device with the higher MAC address functions as the *redundantManager*.

redundantManager

The Sub Ring port is blocked while the Sub Ring is physically closed. If the Sub Ring is interrupted, then the Sub Ring port transmits the data packets. When this value is set on both devices that couple the Sub Ring to the base ring, the device with

the higher MAC address functions as the *redundantManager*.

singleManager

Use this value when the Sub Ring is coupled to the base ring through one single device. The prerequisite is that there are 2 instances of the Sub Ring in the table. Assign this value to both instances. The Sub Ring port of the instance with the higher port number is blocked while the Sub Ring is physically closed.

Operational mode

Displays the current mode of the Sub Ring Manager device.

Possible values:

▶ manager

The Sub Ring port forwards data packets.

redundantManager

The Sub Ring port is blocked while the Sub Ring is physically closed. If the Sub Ring is interrupted, then the Sub Ring port transmits the data packets.

singLeManager

The Sub Ring is coupled to the base ring through one single device. This device blocks its Sub Ring port with the higher port number while the Sub Ring is physically closed.

disabled

The Sub Ring is inactive.

Port status

Displays the connection status on the Sub Ring port.

Possible values:

forwarding

The port is passing frames according to the forwarding behavior of IEEE 802.1D.

disabled

The port is dropping every frame.

blocked

The port is dropping every frame with the exception of the following cases:

- The port passes frames used by the selected ring protocol specified to pass blocked ports.
- The port passes frames from other protocols specified to pass blocked ports.

not-connected

The port link is interrupted.

Sub Ring status

Displays the operational state of the Sub Ring in the Sub Ring Manager domain.

Possible values:

- undefined
- Undefined state
- open
 The Sub Ring is opened.
- closed
 - The Sub Ring is closed.

VLAN

Specifies the VLAN to which this Sub Ring is assigned. If no VLAN exists with the specified VLAN ID, then the device sets up the VLAN.

Possible values:

- Available set-up VLANs (default setting: 0)
 - If you do not want to use a separate VLAN for this Sub Ring, then you keep the value as Ø.

Partner MAC

Displays the MAC address of the Sub Ring Manager device at the other end of the Sub Ring.

MRP domain

Specifies the MRP domain of the *Sub Ring Manager* device. Assign the same MRP domain name to every member of a Sub Ring. If you only use Hirschmann devices, then you use the default value for the MRP domain; otherwise adjust this value if necessary. With multiple Sub Rings, the function lets you use the same MRP domain name for the Sub Rings.

Possible values:

Protocol

Specifies the protocol.

Possible values:

▶ iec-62439-mrp

5.9.9.2 Ring/Network Coupling

[Switching > L2-Redundancy > FuseNet > Ring/Network Coupling]

You use the *Ring/Network Coupling* function to redundantly couple an existing HIPER Ring, MRP Ring, or Fast HIPER Ring to another network or another ring. Verify that the coupling partners are Hirschmann devices.

Note: With two-switch coupling, verify that you have set up a HIPER Ring, MRP Ring, or Fast HIPER Ring before setting up the *Ring/Network Coupling* function.

In the *Switching* > *L2-Redundancy* > *FuseNet* > *Ring/Network Coupling* dialog, you can perform the following tasks:

- display an overview of the existing Ring/Network Coupling
- set up a Ring/Network Coupling instance
- enable/disable the Ring/Network Coupling instance
- delete the Ring/Network Coupling instance

When configuring the coupling ports, specify the following settings in the Basic Settings > Port dialog:

Port type	Bit rate	Port on	Autoneg	Manual configuration
ТХ	100 Mbit/s	marked	unmarked	100M FDX
ТХ	1 Gbit/s	marked	marked	_
Optical	100 Mbit/s	marked	unmarked	100M FDX
Optical	1 Gbit/s	marked	marked	_

Note: The operating modes of the port actually available depend on the device hardware and the media module used.

If you set up VLANs, then note the VLAN configuration of the coupling and partner coupling ports. Specify the following settings for the coupling and partner coupling ports:

- Switching > VLAN > Port dialog
 - Value in the *Port-VLAN ID* column = 1
 - Checkbox in the Ingress filtering column = unmarked
 - Switching > VLAN > Configuration dialog
 - VLAN membership = T

Independently of the VLAN settings, the device sends the ring coupling frames with VLAN ID 1 and priority 7. Verify that the device sends VLAN 1 frames tagged in the local ring and in the connected network. Tagging the VLAN frames maintains the priority of the ring coupling frames.

The *Ring/Network Coupling* function operates with test packets. The devices send their test packets with a VLAN tag, including VLAN ID 1 and the highest VLAN priority 7. If the unblocked port is a member in VLAN 1 and transmits the data packets without a VLAN tag, then the device also sends test packets.

Operation

Buttons



Disables the redundancy function and resets the parameters in the dialog to the default setting.

Operation

Enables/disables the Ring/Network Coupling function.

Possible values:

▶ On

- The Ring/Network Coupling function is enabled.
- Off (default setting) The Ring/Network Coupling function is disabled.

Information

Redundancy

Displays if the redundancy is available.

When a component of the ring becomes inoperable, the redundant line takes over its function.

Possible values:

redGuaranteed

The redundancy is available.

redNotGuaranteed The redundancy is unavailable.

Configuration failure

You have set up the function incorrectly, or there is no ring port connection.

Possible values:

▶ noError

slaveCouplingLinkError

The coupling line is not connected to the coupling port of the slave device. Instead, the coupling line is connected to another port of the slave device.

- slaveControlLinkError The control port of the slave device has no data link.
- masterControlLinkError

The control line is not connected to the control port of the master device. Instead, the control line is connected to another port of the master device.

twoSlaves

The control line connects two slave devices.

LocalPartnerLinkError

The partner coupling line is not connected to the partner coupling port of the slave device. Instead, the partner coupling line is connected to another port of the slave device in *one-switch coupling* mode.

LocalInvalidCouplingPort In one-switch coupling mode, the coupling line is not connected on the same device as the partner line. Instead, the coupling line is connected to another device.

couplingPortNotAvailable

The coupling port is not available because the module to which the port refers is not available or the port does not exist on this module.

controlPortNotAvailable

The control port is not available because the module to which the port refers is not available or the port does not exist on this module.

partnerPortNotAvaiLabLe The partner coupling port is not available because the module to which the port refers is not available or the port does not exist on this module.

Mode

Туре

Specifies the method used to couple the networks together.

Possible values:

- one-switch coupLing (default setting) Lets you specify the port settings in the Coupling port and Partner coupling port frames.
- two-switch coupling, master Lets you specify the port settings in the Coupling port frame.
- two-switch coupling with control line, master Lets you specify the port settings in the Coupling port and Control port frames.
- two-switch coupling, slave Lets you specify the port settings in the Coupling port frame.
- two-switch coupling with control line, slave Lets you specify the port settings in the Coupling port and Control port frames.

Coupling port

Port

Specifies the port to which you connect the redundant link.

Possible values:

_

No port selected.

<Port number> If you also have set up ring ports, then specify the coupling and ring ports on different ports.

To help prevent continuous loops, the device disables the coupling port in the following cases:

- disabling the function
- changing the configuration while the connections are operating on the ports

When the device has deactivated the coupling port, the *Port on* checkbox is unmarked in the *Basic Settings > Port* dialog, *Configuration* tab.

State

Displays the status of the selected port.

Possible values:

active The port is active.

standby The port is in stand-by mode.

- not-connected The port is not connected.
- not-applicable The port is incompatible with the set-up control mode.

Partner coupling port

Port

Specifies the port on which you connect the partner port. The field is visible when you select the *one-switch coupling* radio button in the *Mode* frame.

Possible values:

- (default setting) No port selected.
- <Port number>

If you also have set up ring ports, then specify the coupling and ring ports on different ports.

Interface index

Displays the index number of the port that the partner device uses for the connection. The field is visible when you select a two-switch coupling method in the *Mode* frame.

State

Displays the status of the selected port.

Possible values:

▶ active

The port is active.

▶ standby

The port is in stand-by mode.

- not-connected The port is not connected.
- not-applicable

The port is incompatible with the set-up control mode.

IP address

Displays the IP address of the partner device, when the devices are connected. The prerequisite is that you enable the partner device in the network. The field is visible when you select a two-switch coupling method in the *Mode* frame.

Control port

Port

Displays the port on which you connect the control line.

Possible values:

- (default setting) No port selected.

State

Displays the status of the selected port.

Possible values:

active

The port is active.

- standby The port is in stand-by mode.
- not-connected The port is not connected.
- not-applicable The port is incompatible with the set-up control mode.

Configuration

Redundancy mode

Specifies if the device responds to a detected failure in the remote ring or network.

Possible values:

redundant ring/network coupling

Either the main line or the redundant line is active. Both lines are not active simultaneously. If the device detects that the link is interrupted between the devices in the remote ring or network, then the standby device keeps the redundant port in the standby mode.

extended redundancy (default setting)

If the device detects a potential connection interruption between the devices in the remote ring or network, then the standby device forwards data on the redundant port. In this case, the main line and the redundant line are active simultaneously. This setting lets you maintain continuity in the remote network.

Note: During the reconfiguration period, package duplications can occur. Therefore, if your application is able to detect package duplications, then you can select this setting.

Coupling mode

Specifies the mode of coupling a specific type of network.

Possible values:

ring coupling (default setting)

The device couples redundant rings. The device lets you couple rings that use the following redundancy protocols:

- HIPER Ring
- Fast HIPER Ring
- MRP Ring
- network coupling

The device couples network segments. The function lets you couple mesh and bus networks together.

5.9.9.3 Redundant Coupling Protocol

[Switching > L2-Redundancy > FuseNet > RCP]

A ring topology provides short transition times with a minimal use of resources. However, to couple these rings redundantly to a higher-level network is more of a challenge.

When you want to use a standard protocol such as MRP for the ring redundancy and RSTP to couple the rings together, the *RCP* function helps provide options for you.

Do not use the following redundancy protocols on the ports of the *RCP* primary ring and the *RCP* secondary rings:

Sub Ring

Ring/Network Coupling

Operation

Operation

Enables/disables the RCP function.

Possible values:

- ▶ On
 - The *RCP* function is enabled.

To help avoid unexpected behavior, do not enable the function on a device on which the *Ring manager* function is enabled.

Off (default setting) The *RCP* function is disabled.

Primary ring/network / Secondary ring/network

If the device operates as slave (value in the *Role* field is *sLave*), then do not activate the *Static query port* mode for the ports on the secondary ring/network.

Inner port

Specifies the inner port number in the primary ring/secondary ring. The port is directly connected to the partner bridge.

Possible values:

- (default setting) No port selected.
- > <Port number>

Outer port

Specifies the outer port number in the primary ring/secondary ring.

Possible values:

- (default setting)
- No port selected.
- <Port number>

Primary Ring protocol/Secondary Ring protocol

Displays the protocol that is active on the redundant coupling port in the devices in the primary/ secondary ring.

If the *RCP* function is disabled, then the device displays the *NONE* value for both primary and secondary ring protocols. If you disable the active protocol on either primary or secondary ring, the device will display the *NONE* value for that respective ring protocol.

Coupler configuration

Role

Specifies the role of the local device.

Possible values:

- master The device operates as master.
- slave

The device operates as slave.

auto (default setting) The device automatically selects its role as *master* or *slave*.

Current role

Displays the current role of the local device. The value can be different from the set-up role:

- If you set up both partner bridges as *auto*, then the partner bridge that is currently coupling the instances takes the *master* role. The other partner bridge takes the *slave* role.
- If both partner bridges are set up as *master* or both as *sLave*, then the partner bridge with the smaller Basis MAC address takes the *master* role.
 The other partner bridge takes the *sLave* role.
- If the protocol is started and the partner bridge cannot be found for a bridge in the set-up role *master*, *slave* or *auto*, then the bridge sets its own role to *listening*.
- If the device detects a potential configuration problem, for example, the inner ring ports are connected crosswise, then the device sets its role to *error*.

Timeout [ms]

Specifies the maximum time, in milliseconds, during which the slave device waits for test packets from the master device on the outer ports before the slave device takes over the coupling. This only applies in the state in which both inner ports of the slave device have lost the connection to the master device.

Specify the timeout longer than the longest assumable interruption time for the redundancy protocol of the faster instance. Otherwise, loops can occur.

Possible values:

5..60000 in steps of 5 (default setting: 250) If you enter a value which is not a multiple of 5, then the device rounds up the value to the nearest multiple of 5.

Partner MAC address

Displays the basic MAC address of the partner device.

Partner IP address

Displays the IP address of the partner device.

Coupling state

Displays the coupling state of the local device.

Possible values:

forwarding

The coupling state of the port is forwarding.

blocking The coupling state of the port is blocking.

Redundancy state

Displays if the redundancy is available.

For a master-slave configuration, both bridges display this information.

Possible values:

redAvailable The redundancy is available.

redNotAvailable

The redundancy is unavailable.

6 Diagnostics

The menu contains the following dialogs:

- Status Configuration
- System
- Email Notification
- Syslog
- Ports
- ► LLDP
- Loop Protection
- ► SFlow
- Report

6.1 Status Configuration

[Diagnostics > Status Configuration]

The menu contains the following dialogs:

- Device Status
- Security Status
- Signal Contact
- MAC Notification
- Alarms (Traps)

6.1.1 Device Status

[Diagnostics > Status Configuration > Device Status]

The device status provides an overview of the overall condition of the device. Many process visualization systems record the device status for a device to present its condition in graphic form.

The device displays its current status as *error* or *ok* in the *Device status* frame. The device determines this status from the individual monitoring results.

The device displays detected faults in the *Status* tab and also in the *Basic Settings > System* dialog, *Device status* frame.

The dialog contains the following tabs:

▶ [Global]

▶ [Port]

▶ [Status]

[Global]

Device status

Device status

Displays the current status of the device. The device determines the status from the individual monitored parameters.

Possible values:

🕨 ok

▶ error

The device displays this value to indicate a detected error in one of the monitored parameters.

Traps

Send trap

Activates/deactivates the sending of SNMP traps when the device detects a change in a monitored function.

Possible values:

marked (default setting)
 The sending of SNMP traps is active. The prerequisite is that in the *Diagnostics > Status Configuration > Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

 If the device detects a change in the monitored functions, then the device sends an SNMP trap.

unmarked

The sending of SNMP traps is inactive.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Connection errors

Activates/deactivates the monitoring of the link status of the port/interface.

Possible values:

marked

Monitoring is active.

If the link interrupts on a monitored port/interface, then in the *Device status* frame, the value changes to *error*.

In the *Port* tab, you have the option of selecting the ports/interfaces to be monitored individually.

unmarked (default setting) Monitoring is inactive.

Temperature

Activates/deactivates the monitoring of the temperature in the device.

Possible values:

marked (default setting)

Monitoring is active.

If the temperature exceeds the specified upper threshold value or falls below the specified lower threshold value, then in the *Device status* frame, the value changes to *error*.

unmarked

Monitoring is inactive.

You specify the temperature threshold values in the *Basic Settings > System* dialog, *Upper temp. limit* [°C] field and *Lower temp. limit* [°C] field.

Ethernet module removal

Activates/deactivates the monitoring of the modules.

Possible values:

- marked
 - Monitoring is active.

If you remove a module from the device, then in the *Device status* frame, the value changes to *error*.

Further below, you have the option of selecting the modules to be monitored individually.

unmarked (default setting) Monitoring is inactive.

External memory removal

Activates/deactivates the monitoring of the active external memory.

Possible values:

marked

Monitoring is active. If you remove the active external memory from the device, then in the *Device status* frame, the value changes to *error*.

unmarked (default setting) Monitoring is inactive.

You specify the active external memory in the *Basic Settings > Load/Save* dialog, *External memory* frame.

External memory not in sync

Activates/deactivates the monitoring of the configuration profile in the device and in the external memory.

Possible values:

marked

Monitoring is active.

- In the *Device status* frame, the value changes to *error* in the following situations:
- The configuration profile only exists in the device.
- The configuration profile in the device differs from the configuration profile in the external memory.
- unmarked (default setting) Monitoring is inactive.

Ring redundancy

Activates/deactivates the monitoring of the ring redundancy.

Possible values:

- marked
 - Monitoring is active.
 - In the *Device status* frame, the value changes to *error* in the following situations:
 - The redundancy function becomes active (loss of redundancy reserve).
 - The device is a normal ring participant and detects an error in its settings.
- unmarked (default setting) Monitoring is inactive.

Power supply

Activates/deactivates the monitoring of the power supply unit.

Possible values:

- marked (default setting) Monitoring is active.
 If the device has a detected power supply fault, then in the *Device status* frame, the value changes to *error*.
- unmarked Monitoring is inactive.

Ethernet module

Activates/deactivates the monitoring of this module.

Possible values:

marked

Monitoring is active.

If you remove the module from the device, then in the *Device status* frame, the value changes to *error*.

unmarked (default setting) Monitoring is inactive.

This setting is effective when you mark the *Ethernet module removal* checkbox further up.

[Port]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Propagate connection error

Activates/deactivates the monitoring of the link on the port/interface.

Possible values:

- marked
 - Monitoring is active.

If the link on the selected port/interface is interrupted, then in the *Device status* frame, the value changes to *error*.

unmarked (default setting) Monitoring is inactive.

This setting takes effect when you mark the Connection errors checkbox in the Global tab.

[Status]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Timestamp

Displays the date and time of the event in the format, Month Day, Year hh:mm:ss AM/PM.

Cause

Displays the event which caused the SNMP trap.

6.1.2 Security Status

[Diagnostics > Status Configuration > Security Status]

This dialog gives you an overview of the status of the safety-relevant settings in the device.

The device displays its current status as *error* or *ok* in the *Security status* frame. The device determines this status from the individual monitoring results.

The device displays detected faults in the *Status* tab and also in the *Basic Settings > System* dialog, *Security status* frame.

The dialog contains the following tabs:

- [Global][Port]
- ▶ [Status]

[Global]

Security status

Security status

Displays the current status of the security-relevant settings in the device. The device determines the status from the individual monitored parameters.

Possible values:

- 🕨 ok
- error

The device displays this value to indicate a detected error in one of the monitored parameters.

Traps

Send trap

Activates/deactivates the sending of SNMP traps when the device detects a change in a monitored function.

Possible values:

marked

The sending of SNMP traps is active. The prerequisite is that in the *Diagnostics* > *Status Configuration* > *Alarms* (*Traps*) dialog the *Alarms* (*Traps*) function is enabled and at least one trap destination is specified.

If the device detects a change in the monitored functions, then the device sends an SNMP trap.

unmarked (default setting) The sending of SNMP traps is inactive.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Password default settings unchanged

Activates/deactivates the monitoring of the password for the locally set up user account admin.

Possible values:

- marked (default setting) Monitoring is active.
 If the password is set to the default setting for the admin user account, then in the Security status frame, the value changes to error.
- unmarked Monitoring is inactive.

You set the password in the Device Security > User Management dialog.

Min. password length shorter than 8

Activates/deactivates the monitoring of the Min. password length policy.

Possible values:

- marked (default setting)
- Monitoring is active.

If the value for the *Min. password length* policy is less than 8, then in the *Security status* frame, the value changes to *error*.

unmarked Monitoring is inactive.

You specify the *Min. password length* policy in the *Device Security* > *User Management* dialog in the *Configuration* frame.

Password policy settings deactivated

Activates/deactivates the monitoring of the Password policies settings.

Possible values:

- marked (default setting)
 - Monitoring is active.

If the value for at least one of the following policies is less than 1, then in the *Security status* frame, the value changes to *error*.

- Upper-case characters (min.)
- Lower-case characters (min.)
- Digits (min.)
- Special characters (min.)
- unmarked

Monitoring is inactive.

You specify the policy settings in the *Device Security* > *User Management* dialog in the *Password policy* frame.

User account password policy check deactivated

Activates/deactivates the monitoring of the *Policy check* function.

Possible values:

- marked Monitoring is active.
 If the *Policy check* function is inactive for at least one user account, then in the *Security status* frame, the value changes to *error*.
- unmarked (default setting) Monitoring is inactive.

You activate the *Policy check* function in the *Device Security > User Management* dialog.

Telnet server active

Activates/deactivates the monitoring of the Telnet server.

Possible values:

marked (default setting) Monitoring is active.

If you enable the Telnet server, then in the Security status frame, the value changes to error.

unmarked

Monitoring is inactive.

You enable/disable the Telnet server in the *Device Security* > *Management Access* > *Server* dialog, *Telnet* tab.

HTTP server active

Activates/deactivates the monitoring of the HTTP server.

Possible values:

- marked (default setting)
 Monitoring is active.
 If you enable the HTTP server, then in the Security status frame, the value changes to error.
- unmarked

Monitoring is inactive.

You enable/disable the HTTP server in the *Device Security* > *Management Access* > *Server* dialog, *HTTP* tab.

SNMP unencrypted

Activates/deactivates the monitoring of the SNMP server.

Possible values:

- marked (default setting)
 - Monitoring is active.

If at least one of the following conditions applies, then in the *Security status* frame, the value changes to *error*:

- The SNMPv1 function is enabled.
- The SNMPv2 function is enabled.
- The encryption for SNMPv3 is disabled.
 You enable the encryption in the *Device Security* > *User Management* dialog, in the *SNMP* encryption type column.
- unmarked

Monitoring is inactive.

You specify the settings for the SNMP agent in the *Device Security > Management Access > Server* dialog, *SNMP* tab.

Access to system monitor with serial interface possible

Activates/deactivates the monitoring of the system monitor.

When the system monitor is active, you have the possibility to change to the system monitor using a serial connection during the system startup.

Possible values:

- marked Monitoring is active.
 If you activate the system monitor, then in the Security status frame, the value changes to error.
- unmarked (default setting) Monitoring is inactive.

You activate/deactivate the system monitor in the *Diagnostics > System > Selftest* dialog.

Saving the configuration profile on the external memory possible

Activates/deactivates the monitoring of the configuration profile in the external memory.

Possible values:

marked

Monitoring is active.

If you activate the saving of the configuration profile in the external memory, then in the *Security status* frame, the value changes to *error*.

unmarked (default setting) Monitoring is inactive.

You activate/deactivate the saving of the configuration profile in the external memory in the *Basic Settings* > *External Memory* dialog.

Link interrupted on enabled device ports

Activates/deactivates the monitoring of the link on the active ports.

Possible values:

marked

Monitoring is active.

If the link interrupts on an active port, then in the Security status frame, the value changes to *error*. In the *Port* tab, you have the option of selecting the ports to be monitored individually.

unmarked (default setting) Monitoring is inactive.

Access with HiDiscovery possible

Activates/deactivates the monitoring of the HiDiscovery function.

Possible values:

- marked (default setting)
 - Monitoring is active.

If you enable the HiDiscovery function, then in the *Security status* frame, the value changes to *error*.

unmarked Monitoring is inactive.

You enable/disable the HiDiscovery function in the Basic Settings > Network > Global dialog.

Load unencrypted config from external memory

Activates/deactivates the monitoring of loading unencrypted configuration profiles from the external memory.

Possible values:

- marked (default setting)
 - Monitoring is active.

If the settings allow the device to load an unencrypted configuration profile from the external memory, then in the *Security status* frame, the value changes to *error*.

If the following preconditions are fulfilled, then the *Security status* frame in the *Basic Settings* > System dialog, displays an alarm.

- The configuration profile stored in the external memory is unencrypted. and
- The Config priority column in the Basic Settings > External Memory dialog has the value first or second.
- unmarked

Monitoring is inactive.

IEC61850-MMS active

Activates/deactivates the monitoring of the IEC61850-MMS function.

Possible values:

- marked (default setting)
 - Monitoring is active.

If you enable the *IEC61850-MMS* function, then in the *Security status* frame, the value changes to *error*.

unmarked Monitoring is inactive.

You enable/disable the *IEC61850-MMS* function in the *Advanced* > *Industrial Protocols* > *IEC61850-MMS* dialog, *Operation* frame.

Self-signed HTTPS certificate present

Activates/deactivates the monitoring of the digital certificate of the HTTPS server.

Possible values:

- marked (default setting) Monitoring is active.
 If the HTTPS server uses a self-generated digital certificate, then in the Security status frame, the value changes to error.
- unmarked Monitoring is inactive.

Modbus TCP active

Activates/deactivates the monitoring of the Modbus TCP function.

Possible values:

- marked (default setting) Monitoring is active.
 If you enable the *Modbus TCP* function, then in the *Security status* frame, the value changes to *error*.
- unmarked

Monitoring is inactive.

You enable/disable the *Modbus TCP* function in the *Advanced* > *Industrial Protocols* > *Modbus TCP* dialog, *Operation* frame.

EtherNet/IP active

Activates/deactivates the monitoring of the EtherNet/IP function.

Possible values:

- marked (default setting) Monitoring is active.
 If you enable the *EtherNet/IP* function, then in the *Security status* frame, the value changes to *error*.
- unmarked

Monitoring is inactive.

You enable/disable the *EtherNet/IP* function in the *Advanced* > *Industrial Protocols* > *EtherNet/IP* dialog, *Operation* frame.

PROFINET active

Activates/deactivates the monitoring of the *PROFINET* function.

Possible values:

- marked (default setting) Monitoring is active.
 If you enable the *PROFINET* function, then in the *Security status* frame, the value changes to *error*.
- unmarked Monitoring is inactive.

You enable/disable the *PROFINET* function in the *Advanced* > *Industrial Protocols* > *PROFINET* dialog, *Operation* frame.

[Port]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Link interrupted on enabled device ports

Activates/deactivates the monitoring of the link on the active ports.

Possible values:

- marked
 - Monitoring is active.

If the port is enabled (*Basic Settings > Port* dialog, *Configuration* tab, *Port on* checkbox is marked) and the link is down on the port, then in the *Security status* frame, the value changes to *error*.

unmarked (default setting) Monitoring is inactive.

This setting takes effect when you mark the *Link interrupted on enabled device ports* checkbox in the *Diagnostics > Status Configuration > Security Status* dialog, *Global* tab.

[Status]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Timestamp

Displays the date and time of the event in the format, Month Day, Year hh:mm:ss AM/PM.

Cause

Displays the event which caused the SNMP trap.

6.1.3 Signal Contact

[Diagnostics > Status Configuration > Signal Contact]

The signal contact is a potential-free relay contact. The device thus lets you perform remote diagnosis. The device uses the relay contact to signal the occurrence of events by opening the relay contact and interrupting the closed circuit.

Note: The device can contain several signal contacts. Each contact contains the same monitoring functions. Several contacts allow you to group various functions together providing flexibility in system monitoring.

The menu contains the following dialogs: Signal Contact 1 / Signal Contact 2

6.1.3.1 Signal Contact 1 / Signal Contact 2

[Diagnostics > Status Configuration > Signal Contact > Signal Contact 1]

In this dialog, you specify the trigger conditions for the signal contact.

The signal contact gives you the following options:

- Monitoring the correct operation of the device.
- Signaling the device status of the device.
- Signaling the security status of the device.
- Controlling external devices by manually setting the signal contacts.

The device displays detected faults in the *Status* tab and also in the *Basic Settings > System* dialog, *Signal contact status* frame.

The dialog contains the following tabs:

- ▶ [Global]
- ▶ [Port]
- ▶ [Status]

[Global]

Configuration

Mode

Specifies which events the signal contact indicates.

Possible values:

- Manual setting (default setting for Signal Contact 2, if present) You use this setting to manually open or close the signal contact, for example to turn on or off a remote device. See the Contact option list.
- Monitoring correct operation (default setting) Using this setting the signal contact indicates the status of the parameters specified in the table below.
- Device status

Using this setting the signal contact indicates the status of the parameters monitored in the *Diagnostics > Status Configuration > Device Status* dialog. In addition, you can read the status in the *Signal contact status* frame.

Security status

Using this setting the signal contact indicates the status of the parameters monitored in the *Diagnostics > Status Configuration > Security Status* dialog. In addition, you can read the status in the *Signal contact status* frame.

Device/Security status

Using this setting the signal contact indicates the status of the parameters monitored in the *Diagnostics* > *Status Configuration* > *Device Status* and the *Diagnostics* > *Status Configuration* > Security Status dialog. In addition, you can read the status in the *Signal contact status* frame.

Contact

Toggles the signal contact manually. The prerequisite is that from the *Mode* drop-down list the *Manual setting* item is selected.

Possible values:

open

The signal contact is opened.

close The signal contact is closed.

Signal contact status

Signal contact status

Displays the current status of the signal contact.

Possible values:

- Opened (error) The signal contact is opened. The circuit is interrupted.
- Closed (ok)
 - The signal contact is closed. The circuit is closed.

Trap configuration

Send trap

Activates/deactivates the sending of SNMP traps when the device detects a change in a monitored function.

Possible values:

marked

The sending of SNMP traps is active. The prerequisite is that in the *Diagnostics > Status Configuration > Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

If the device detects a change in the monitored functions, then the device sends an SNMP trap.

unmarked (default setting) The sending of SNMP traps is inactive.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Connection errors

Activates/deactivates the monitoring of the link status of the port/interface.

Possible values:

marked

Monitoring is active. If the link interrupts on a monitored port/interface, then the signal contact opens. In the *Port* tab, you have the option of selecting the ports/interfaces to be monitored individually.

unmarked (default setting) Monitoring is inactive.

Temperature

Activates/deactivates the monitoring of the temperature in the device.

Possible values:

marked (default setting)

Monitoring is active.

If the temperature exceeds the specified upper threshold value or falls below the specified lower threshold value, then the signal contact opens.

unmarked

Monitoring is inactive.

You specify the temperature threshold values in the *Basic Settings > System* dialog, *Upper temp. limit* [°C] field and *Lower temp. limit* [°C] field.

Ring redundancy

Activates/deactivates the monitoring of the ring redundancy.

Possible values:

- marked
 - Monitoring is active.
 - The signal contact opens in the following situations:
 - The redundancy function becomes active (loss of redundancy reserve).
 - The device is a normal ring participant and detects an error in its settings.
- unmarked (default setting) Monitoring is inactive.

Ethernet module removal

Activates/deactivates the monitoring of the modules.

Possible values:

- marked
 - Monitoring is active.

If you remove a module from the device, then the signal contact opens. Further below, you have the option of selecting the modules to be monitored individually.

unmarked (default setting) Monitoring is inactive. External memory removed

Activates/deactivates the monitoring of the active external memory.

You specify the active external memory in the *Basic Settings > Load/Save* dialog, *External memory* frame.

Possible values:

marked

Monitoring is active.

If you remove the active external memory from the device, then the signal contact opens.

unmarked (default setting) Monitoring is inactive.

External memory not in sync with NVM

Activates/deactivates the monitoring of the configuration profile in the device and in the external memory.

Possible values:

marked

Monitoring is active.

The signal contact opens in the following situations:

- The configuration profile only exists in the device.
- The configuration profile in the device differs from the configuration profile in the external memory.
- unmarked (default setting) Monitoring is inactive.

Ethernet loops

Activates/deactivates the monitoring of layer 2 Ethernet loops. You specify the settings for the *Loop Protection* function in the *Diagnostics > Loop Protection* dialog.

Possible values:

- marked Monitoring is active.
 If the device has detected an Ethernet loop, then the signal contact opens.
- unmarked (default setting) Monitoring is inactive.

Power supply

Activates/deactivates the monitoring of the power supply unit.

Possible values:

- marked (default setting) Monitoring is active.
 If the device has a detected power supply fault, then the signal contact opens.
- unmarked Monitoring is inactive.

Ethernet module

Activates/deactivates the monitoring of this module.

Possible values:

 marked Monitoring is active. If you remove this module from the device, then the signal contact opens.
 unmarked (default setting) Monitoring is inactive.

This setting is effective when you mark the *Ethernet module removal* checkbox further up.

[Port]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Propagate connection error

Activates/deactivates the monitoring of the link on the port/interface.

Possible values:

marked

Monitoring is active. If the link interrupts on the selected port/interface, then the signal contact opens.

unmarked (default setting) Monitoring is inactive.

This setting takes effect when you mark the Connection errors checkbox in the Global tab.

[Status]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Timestamp

Displays the date and time of the event in the format, Month Day, Year hh:mm:ss AM/PM.

Cause

Displays the event which caused the SNMP trap.

6.1.4 MAC Notification

[Diagnostics > Status Configuration > MAC Notification]

The device lets you track changes in the network using the MAC address of the devices in the network. The device saves the combination of port and MAC address in its MAC address table (forwarding database). If the device (un)learns the MAC address of a (dis)connected device, then the device sends an SNMP trap.

This function is intended for ports to which you connect end devices and thus the MAC address changes infrequently.

Operation

Operation

Enables/disables the MAC Notification function in the device.

Possible values:

🕨 On

The MAC Notification function is enabled.

Off (default setting) The *MAC Notification* function is disabled.

Configuration

Interval [s]

Specifies the send interval in seconds. If the device (un)learns the MAC address of a (dis)connected device, then the device sends an SNMP trap after this time.

Possible values:

▶ 0..2147483647 (2³¹-1) (default setting: 1)

Before sending an SNMP trap, the device registers up to 20 MAC addresses. If the device detects a high number of changes, then the device sends the SNMP trap before the send interval expires.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Active

Activates/deactivates the MAC Notification function on the port.

Possible values:

marked

The MAC Notification function is active on the port.

The device sends an SNMP trap in case of one of the following events:

- The device learns the MAC address of a newly connected device.

The device unlearns the MAC address of a disconnected device.

The prerequisite is that in the *Diagnostics* > *Status Configuration* > *Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

unmarked (default setting) The MAC Notification function is inactive on the port.

Last MAC address

Displays the MAC address of the device last connected on or disconnected from the port.

The device detects the MAC addresses of devices which are connected as follows:

- directly connected to the port
- connected to the port through other devices in the network

Last MAC status

Displays the status of the Last MAC address value on this port.

Possible values:

added

The device detected that another device was connected at the port.

removed

The device detected that the connected device was removed from the port.

▶ other

The device did not detect a status.

6.1.5 Alarms (Traps)

[Diagnostics > Status Configuration > Alarms (Traps)]

The device lets you send an SNMP trap in response to specific events.

You specify the events for which the device triggers an SNMP trap in the following dialogs:

- Diagnostics > Status Configuration > Device Status
- Diagnostics > Status Configuration > Security Status
- Diagnostics > Status Configuration > MAC Notification

The menu contains the following dialogs:

- Trap V3 User Management
- ► Trap Destinations

6.1.5.1 Trap V3 User Management

[Diagnostics > Status Configuration > Alarms (Traps) > Trap V3 User Management]

In this dialog, you specify the SNMPv3 trap users who can send SNMP traps to the trap destination(s). The device supports encrypted SNMPv3 traps and authentication for sending.

SNMPv3 trap users have permission to send SNMPv3 traps to the specified SNMPv3 trap hosts.

SNMPv3 trap users are intended for sending SNMPv3 traps to SNMPv3 trap hosts exclusively. SNMPv3 trap users are different from the user accounts set up in the device. Do not confuse them. See the *Device Security* > *User Management* dialog.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

Hadd

Opens the *Create* window to add a table row. The device adds an SNMPv3 trap user with the parameters you specify in this window.

• From the *User to be cloned* drop-down list, you select the user account, from which the device clones the authentication settings.

You need to select one of the user accounts set up in the device. You set up device user accounts in the *Device Security* > *User Management* dialog.

- In the *Trap User name* field, you specify the name for the SNMPv3 trap user. Possible values:
 - Alphanumeric ASCII character string with 1..32 characters
- From the *Trap User Auth Protocol* drop-down list, you select the protocol for sending SNMPv3 traps with authentication.
 Possible values:

none

- The device sends SNMPv3 traps unencrypted and without authentication.
- hmacmd5

The device sends SNMPv3 traps using the Message-Digest Algorithm 5 (HMACMD5) protocol.

Available if this protocol is already set for the user to be cloned.

hmacsha

The device sends SNMPv3 traps using the Secure Hash Algorithm (HMACSHA) protocol. Available if this protocol is already set for the user to be cloned.

 In the *Trap User Auth Password* field, you specify the password that the SNMPv3 trap user uses to authenticate before sending.

Possible values:

Alphanumeric ASCII character string with 8..64 characters

The prerequisite is that from the *Trap User Auth Protocol* drop-down list, an item other than *none* is selected.

 From the *Trap User Priv Protocol* drop-down list, you select the protocol that the device uses for this user to encrypt the SNMPv3 traps.
 Possible values:

none (default setting)
 No encryption.

des

Data Encryption Standard (DES).

Available if this protocol is already set for the user to be cloned.

- aesCfb128 Advanced Encryption Standard (AES). Available if this protocol is already set for the user to be cloned.
- In the *Trap User Priv Password* field, you specify the password that the SNMPv3 trap user uses to authenticate before sending.

Possible values:

▶ Alphanumeric ASCII character string with 8..64 characters

The prerequisite is that from the *Trap User Auth Protocol* drop-down list, an item other than *none* is selected.

When you click the *Ok* button, the device adds the table row for the SNMPv3 trap user. If you have selected an item other than *none* in the *Trap User Auth Protocol* or *Trap User Priv Protocol* drop-down list, the *Credentials* window opens first. Then, you enter the required password(s). Even if you enter an incorrect password, the device still adds the SNMPv3 trap user. However, when the device sends SNMPv3 traps, the trap destination cannot decrypt them.



Removes the selected table row.

SNMPv3 Notification User

Displays the name of the SNMPv3 trap user.

Authentication

Displays the protocol for sending SNMPv3 traps with authentication in the context of the SNMPv3 trap user.

Auth Password

Displays ***** (asterisks) instead of the authentication password of the SNMPv3 trap user.

To change the password, add another SNMPv3 trap user and then delete the existing one.

Privacy

Displays the protocol that the device uses for this user to encrypt the SNMPv3 traps.

Priv Password

Displays ***** (asterisks) instead of the password that the SNMPv3 trap user uses to authenticate before sending.

To change the password, add another SNMPv3 trap user and then delete the existing one.

User status

Displays the status of the SNMPv3 trap user.

Possible values:

- marked (default setting)
 - The SNMPv3 trap user is active.
- unmarked

The SNMPv3 trap user is inactive.

6.1.5.2 Trap Destinations

[Diagnostics > Status Configuration > Alarms (Traps) > Trap Destinations]

In this dialog, you specify the trap destinations to which the device sends SNMP traps.

For SNMPv3, the following conditions apply:

- The device sends SNMPv3 traps to the trap destination specified for the relevant SNMPv3 trap user.
- The device supports a maximum of 10 trap destinations for SNMPv3.

Operation

Operation

Enables/disables sending SNMP traps.

Possible values:

- On (default setting) Sending SNMP traps is enabled.
- ▶ Off
 - Sending SNMP traps is disabled.

SNMPv1/v2 trap community

Name

Specifies the community string that the device sends in each SNMPv1/v2 trap for authentication to the trap destination.

Possible values:

 Alphanumeric ASCII character string with 0..64 characters trap (default setting)

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row. Thus, you set up a trap destination on the device.

- In the *Name* field, you specify a name for the trap destination. Possible values:
 - ▶ Alphanumeric ASCII character string with 1..32 characters

 From the *Type* drop-down list, you select the SNMP version which the device uses to send SNMP traps to the trap destination.
 Possible values:

V1

- SNMP version 1
- For security reasons, we recommend not to use this setting.

V3

- SNMP version 3
- In the Address field, you specify the IP address and the port of the trap destination.
 Possible values:
 - <IPv4 address>:<port> If you do not specify a port, then the device automatically adds port 162 to the trap destination.
- From the SNMPv3 Trap user drop-down list, you select the SNMPv3 trap user in whose context the device sends SNMPv3 traps to the trap destination.
 - The prerequisite is that you select the V3 item from the *Type* drop-down list. You select one of the users that you have set up in the *Diagnostics* > *Status Configuration* > *Alarms* (*Traps*) > *Trap V3 User Management* dialog.
- From the Security level drop-down list, you select whether the device sends the SNMPv3 traps encrypted and whether authentication is required before sending.
 The prerequisite is that you select the V3 item from the *Type* drop-down list.
 Possible values:
 - noAuthNoPriv
 - The device sends SNMPv3 traps unencrypted without authentication.
 - For security reasons, we recommend not to use this setting.
 - authNoPriv
 The device sends SNMPv3 traps unencrypted.
 The user needs to authenticate before sending SNMPv3 traps.
 - ▶ authPriv
 - The device sends SNMPv3 traps encrypted.
 - The user needs to authenticate before sending SNMPv3 traps.



Removes the selected table row.

Name

Displays the name you specified for the SNMPv3 trap destination (trap host).

SNMP Protocol

Displays the SNMP version which the device uses to send SNMP traps to the trap destination.

Address

Specifies the IP address and the port of the trap destination (trap host).

Possible values:

<IPv4 address>:<port>

If you do not specify a port, then the device automatically adds port 162 to the trap destination.

SNMPv3 Trap user

Specifies the SNMPv3 trap user that the device uses to send SNMPv3 traps to the trap destination.

You select one of the SNMPv3 trap users that you have set up in the *Diagnostics* > *Status Configuration* > *Alarms* (*Traps*) > *Trap* V3 User Management dialog.

Security level

Specifies whether the device sends the SNMPv3 traps encrypted and whether authentication is required before sending.

Possible values:

- noAuthNoPriv The device sends SNMPv3 traps unencrypted without authentication. For security reasons, we recommend not to use this setting.
 authNoPriv The device sends SNMPv3 traps unencrypted.
- The device sends SNMPv3 traps unencrypted. The user needs to authenticate before sending SNMPv3 traps.
- authPriv

The device sends SNMPv3 traps encrypted. The user needs to authenticate before sending SNMPv3 traps.

Туре

Displays the notification type.

Active

Activates/deactivates the sending of SNMP traps to the trap destination.

Possible values:

- marked (default setting) The sending of SNMP traps to this trap destination is active.
- unmarked
 - The sending of SNMP traps to this trap destination is inactive.

6.2 System

[Diagnostics > System]

The menu contains the following dialogs:

- System Information
- Hardware State
- Configuration Check
- IP Address Conflict Detection
- ► ARP
- Selftest

6.2.1 System Information

[Diagnostics > System > System Information]

This dialog displays the current operating condition of individual components in the device. The displayed values are a snapshot; they represent the operating condition at the time the dialog was loaded to the page.

Buttons



Save system information

Saves the HTML page on your PC using the web browser dialog.

6.2.2 Hardware State

[Diagnostics > System > Hardware State]

This dialog provides information about the distribution and state of the flash memory of the device.

Information

Operating hours

Displays the total operating time of the device since it was delivered.

Possible values:
..d ..h ..m ..s Day(s) Hour(s) Minute(s) Second(s)

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Flash region

Displays the name of the parameter, for example for the relevant memory area.

Description

Displays a description for the parameter.

Flash sectors

Displays how many sectors are assigned to the memory area.

Sector erase operations

Displays how many times the device has overwritten the sectors of the memory area.

6.2.3 Configuration Check

[Diagnostics > System > Configuration Check]

The device lets you compare the settings in the device with the settings in its neighboring devices. For this purpose, the device uses the information that it received from its neighboring devices through topology recognition (LLDP).

The dialog lists the detected deviations, which affect the performance of the communication between the device and the recognized neighboring devices.

Note: A neighboring device without LLDP support, which forwards LLDP packets, can be the cause of equivocal messages in the dialog. This occurs if the neighboring device is a hub or a switch without management, which ignores IEEE 802.1D-2004. In this case, the dialog displays the devices recognized and connected to the neighboring device as connected to the device itself, even though they are connected to the neighboring device.

Configuration

Start configuration check...

Starts the check and updates the content of the table.

When the table remains empty, the configuration check was successful and the settings in the device are compatible with the settings in the detected neighboring devices.

Information



Displays the number of ERROR level deviations that the device detected during the configuration check.

Warning

Displays the number of WARNING level deviations that the device detected during the configuration check.

If you have set up more than 39 VLANs in the device, then the dialog continuously displays a warning. The reason is the limited number of possible VLAN data sets in LLDP packets with a maximum length. The device compares the first 39 VLANs automatically. If you have set up 40 or more VLANs in the device, then check the congruence of the further VLANs manually, if necessary.



Displays the number of INFORMATION level deviations that the device detected during the configuration check.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

:3

Displays detailed information about the detected deviations in the area below the table row. To hide the detailed information again, click the d_{r} button. If you click the icon in the table header, you display or hide the detailed information for each table row.

ID

Displays the rule ID of the deviations having occurred. The dialog combines several deviations with the same rule ID under one rule ID.

Level

Displays the level of deviation between the settings in this device and the settings in the detected neighboring devices.

The device differentiates between the following access statuses:

• INFORMATION

The performance of the communication between the two devices is not impaired.

WARNING

The performance of the communication between the two devices is possibly impaired.

ERROR

The communication between the two devices is impaired.

Message

Displays a summary of the detected deviations.

6.2.4 IP Address Conflict Detection

[Diagnostics > System > IP Address Conflict Detection]

Using the *IP Address Conflict Detection* function the device verifies that its IP address is unique in the network. For this purpose, the device analyzes received ARP packets.

In this dialog, you specify the procedure with which the device detects address conflicts and specify the required settings for this.

The device displays detected address conflicts in the table.

When the device detects an address conflict, the status LED of the device flashes red 4 times.

Operation

Operation

Enables/disables the IP Address Conflict Detection function.

Possible values:

 On (default setting) The *IP Address Conflict Detection* function is enabled. The device verifies that its IP address is unique in the network.
 Off

The IP Address Conflict Detection function is disabled.

Information

Conflict detected

Displays if an address conflict currently exists.

Possible values:

marked

The device detects an address conflict.

unmarked

The device does not detect an address conflict.

Configuration

Detection mode

Specifies the procedure with which the device detects address conflicts.

Possible values:

active and passive (default setting) The device uses active and passive address conflict detection.

active

Active address conflict detection. The device actively helps avoid communicating with an IP address that already exists in the network. The address conflict detection begins as soon as you connect the device to the network or change its IP parameters.

- The device sends 4 ARP probe data packets at the interval specified in the *Detection delay* [*ms*] field. If the device receives a response to these data packets, then there is an address conflict.
- If the device does not detect an address conflict, then it sends 2 gratuitous ARP data packets as an announcement. The device also sends these data packets when the address conflict detection is disabled.
- If the IP address already exists in the network, then the device changes back to the previously used IP parameters (if possible).
 If the device receives its IP parameters from a DHCP server, then it sends a DHCPDECLINE
- message back to the DHCP server.
 After the period specified in the *Release delay* [s] field, the device checks if the address conflict
- still exists. When the device detects 10 address conflicts one after the other, the device extends the waiting time to 60 s for the next check.
- When the device resolves the address conflict, the device management returns to the network again.
- ▶ passive

Passive address conflict detection. The device analyzes the data stream in the network. If another device in the network is using the same IP address, then the device initially "defends" its IP address. The device stops sending if the other device keeps sending with the same IP address.

- As a "defence" the device sends gratuitous ARP data packets. The device repeats this
 procedure for the number of times specified in the *Address protections* field.
- If the other device continues sending with the same IP address, then after the period specified in the *Release delay* [s] field, the device periodically checks if the address conflict still exists.
- When the device resolves the address conflict, the device management returns to the network again.

Send periodic ARP probes

Activates/deactivates the periodic address conflict detection.

Possible values:

- marked (default setting)
 - The periodic address conflict detection is active.
 - The device periodically sends an ARP probe data packet every 90 to 150 seconds and waits for the time specified in the *Detection delay [ms]* field for a response.
 - If the device detects an address conflict, then the device applies the passive detection mode function. If the Send trap function is active, then the device sends an SNMP trap.
- unmarked

The periodic address conflict detection is inactive.

Detection delay [ms]

Specifies the period in milliseconds for which the device waits for a response after sending a ARP data packets.

Possible values:

20..500 (default setting: 200)

Release delay [s]

Specifies the period in seconds after which the device checks again if the address conflict still exists.

Possible values:

▶ 3..3600 (default setting: 15)

Address protections

Specifies how many times the device sends gratuitous ARP data packets in the passive detection mode to "defend" its IP address.

Possible values:

0..100 (default setting: 1)

Protection interval [ms]

Specifies the period in milliseconds after which the device sends gratuitous ARP data packets again in the passive detection mode to "defend" its IP address.

Possible values:

20..10000 (default setting: 10000)

Send trap

Activates/deactivates the sending of SNMP traps when the device detects an address conflict.

Possible values:

marked (default setting) The sending of SNMP traps is active. The prerequisite is that in the *Diagnostics > Status Configuration > Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

If the device detects an address conflict, then the device sends an SNMP trap.

unmarked The sending of SNMP trans is inactive

The sending of SNMP traps is inactive.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Timestamp

Displays the time at which the device detected an address conflict.

Port

Displays the number of the port on which the device detected the address conflict.

IP address

Displays the IP address that is causing the address conflict.

MAC address

Displays the MAC address of the device with which the address conflict exists.

6.2.5 ARP

[Diagnostics > System > ARP]

This dialog displays the MAC and IP addresses of the neighboring devices connected to the device management.

The device can display both IPv4 and IPv6 addresses. For IPv6, the device obtains the addresses of the neighboring devices with the use of the Neighbor Discovery Protocol (NDP).

Table


For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

	C	1		2	r
J	~	~1	0	а	1

Removes the dynamically set up addresses from the ARP table.

Port



ARP table

IP address

Displays the IPv4 address or the IPv6 address of a neighboring device.

MAC address

```
Displays the MAC address of a neighboring device.
```

Last updated

Displays the time in seconds since the current settings of the entry were registered in the ARP table.

Туре

Displays the type of the entry.

Possible values:

static

Static entry. When the ARP table is deleted, the device keeps the static entry.

dynamic

Dynamic entry. When the *Aging time* [s] has been exceeded and the device does not receive any data from this device during this time, the device deletes the dynamic entry.

Local

IP and MAC address of the device management.

Active

Displays that the ARP table contains the IP/MAC address assignment as an active entry.

6.2.6 Selftest

[Diagnostics > System > Selftest]

This dialog lets you do the following:

- Activate/deactivate the RAM test when the device is being started.
- Activate/deactivate the option of changing to the system monitor during the system startup.
- Specify how the device behaves in the case of a detected error.

Configuration

If the device does not detect any readable configuration profile when restarting, then the following settings <u>block your access to the device permanently</u>.

- SysMon1 is available checkbox is unmarked.
- Load default config on error checkbox is unmarked.

This is the case, for example, if the password of the configuration profile that you are loading differs from the password set in the device. To have the device unlocked again, contact your sales partner.

RAM test

Activates/deactivates the RAM memory check during the system startup.

Possible values:

marked (default setting)

The RAM memory check is activated. During the system startup, the device checks the RAM memory.

unmarked The RAM memory check is deactivated. This shortens the start time for the device.

SysMon1 is available

Activates/deactivates the option of changing to the system monitor during the system startup.

Possible values:

marked (default setting)

The device lets you change to the system monitor during the system startup.

unmarked

The device starts without the option of changing to the system monitor.

Among other things, the system monitor lets you update the device software and to delete saved configuration profiles.

Load default config on error

Activates/deactivates the loading of the default settings if the device does not detect any readable configuration profile when restarting.

Possible values:

marked (default setting)

The device loads the default settings.

unmarked

The device interrupts the restart and stops. The access to the device management is possible only using the Command Line Interface through the serial interface.

To regain the access to the device through the network, open the system monitor and reset the settings. After the system startup, the device uses the default settings.

Table

In this table you specify how the device behaves in the case of a detected error.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Cause

Detected error causes to which the device reacts.

Possible values:

task

The device detects errors in the applications executed, for example if a task terminates or is not available.

resource

The device detects errors in the resources available, for example if the memory is becoming scarce.

software

The device detects software errors, for example error in the consistency check.

hardware

The device detects hardware errors, for example in the chip set.

Action

Specifies how the device behaves if the adjacent event occurs.

Possible values:

LogOnLy

The device registers the detected error in the log file. See the *Diagnostics > Report > System Log* dialog.

sendTrap

The device sends an SNMP trap. The prerequisite is that in the *Diagnostics* > *Status Configuration* > *Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

reboot (default setting) The device triggers a restart.

6.3 Email Notification

[Diagnostics > Email Notification]

The device lets you inform multiple recipients by email about events that have occurred.

The device sends the emails immediately or periodically depending on the event severity. Usually you specify events with a high severity to be sent immediately.

You can specify multiple recipients to which the device sends the emails either immediately or periodically.

The menu contains the following dialogs:

- Email Notification Global
- Email Notification Recipients
- Email Notification Mail Server

6.3.1 Email Notification Global

[Diagnostics > Email Notification > Global]

In this dialog, you specify the sender settings. Also, you specify for which event severities the device sends the emails immediately and for which periodically.

Operation

Operation

Enables/disables the sending of emails:

Possible values:

▶ On

The sending of emails is enabled.

Off (default setting) The sending of emails is disabled.

Information

Buttons

Clear email notification statistics

Resets the counters in the Information frame to 0.

Sent messages

Displays how many times the device has successfully sent an email to the mail server.

Undeliverable messages

Displays how many times the device has unsuccessfully tried to send an email to the mail server.

Time of the last messages sent

Displays the date and time at which the device has last sent an email to the mail server.

Certificates/CRLs

To establish a secure connection, the device requires to obtain a valid digital certificate to verify the identity of the server. The prerequisite is that you have transferred the public certificate of the server onto the device. Ask the server administrator for a digital certificate in X.509 format. For security reasons, Hirschmann recommends using only digital certificates signed by a Certification Authority (CA).

A Certificate Revocation List (CRL) contains a list of digital certificates revoked by the Certification Authority (CA) before their scheduled expiration date. When establishing a secure connection to the server, the device stops setting up the connection if the CRL includes the public certificate of the server. The device logs the event in the System Log. For security reasons, Hirschmann recommends using only CRLs signed by a Certification Authority (CA).

Buttons



Clear all Certificates/CRLs

Deletes the digital certificates and CRLs transferred onto the device from the non-volatile memory (NVM).

URL

Specifies the path and file name of the digital certificate or CRL.

The device accepts digital certificates and CRLs with the following properties:

- X.509 format
- .PEM file name extension
- Base64-coded and enclosed by the lines

```
-----BEGIN CERTIFICATE-----

...
-----END CERTIFICATE-----
Or
-----BEGIN CRL-----
...
-...
-----END CRL-----
```

The device gives you the following options for transferring the file onto the device:

Import from the PC

```
When the file is located on your PC or on a network drive, drag and drop it onto the <u>1</u> area.
As an alternative, click in the area to select the file.
```

```
    Import from an FTP server
    This option is not recommended if you transmit data over untrusted networks.
    When the file is on an FTP server, specify the URL for the file in the following form:
ftp://<user>:<password>@<IP address>[:port]/<path>/<file name>
```

Import from a TFTP server

This option is not recommended if you transmit data over untrusted networks. When the file is on a TFTP server, specify the URL for the file in the following form: tftp://<IP address/<path>/<file name>

- Import from an SCP or SFTP server
- When the file is on an SCP or SFTP server, specify the URL for the file in the following form:
 scp:// or sftp://<IP address>/<path>/<file name>
 - Click the *Start* button to open the *Credentials* window. In this window, you enter the *User name* and *Password* to log into the server.

scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name>
Remember to set up the SCP or SFTP server as an SSH known host before the device
accesses the server for the first time. See the Device Security > SSH Known Hosts dialog.

Start

Transfers the file specified in the URL field onto the device.

In this dialog, you can transfer a maximum of 20 digital certificates and additionally a maximum of 20 CRLs onto the device.

For the changes to take effect after transferring a digital certificate or a CRL into the device, disable and re-enable the *Email Notification* function. See the *Operation* frame.

Sender

Email address

Specifies the email address of the device.

The device sends the emails using this email address as the sender.

Possible values:

Alphanumeric ASCII character string with 0..255 characters (default setting: switch@hirschmann.com)

Notification urgent

Here you specify the settings for emails which the device sends immediately.

Severity

Specifies the minimum severity of events for which the device immediately sends an email. If an event of this severity occurs, or of a more urgent severity, then the device sends an email to the recipients.

Possible values:

- emergency
- alert (default setting)
- 🕨 critical
- error
- warning

notice
 informational
 debug

Subject

Specifies the subject of the email.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Notification non-urgent

Here you specify the settings for emails which the device sends periodically.

Severity

Specifies the minimum severity of events for which the device periodically sends an email. If an event of this severity occurs, or of a more urgent severity, then the device registers the event in the buffer. The device sends the buffer content periodically or when the buffer overflows.

If an event of a less urgent severity occurs, then the device does not register the event in the buffer.

Possible values:

- emergency
- alert
- 🕨 critical
- 🕨 error
- warning (default setting)
- notice
- informational
- debug

Subject

Specifies the subject of the email.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Sending interval [min]

Specifies the send interval in minutes.

If the device has registered at least one event, then the device sends an email with the log file after the time expires.

Possible values:

▶ 30..1440 (default setting: 30)

Send

Sends an email immediately with the buffer content and clears the buffer.

Meaning of the event severities

Severity	Meaning
emergency	Device not ready for operation
alert	Immediate user intervention required
critical	Critical status
error	Error status
warning	Warning
notice	Significant, normal status
informational	Information message
debug	Debug message

6.3.2 Email Notification Recipients

[Diagnostics > Email Notification > Recipients]

In this dialog, you specify the recipients to which the device sends the emails. The device lets you specify up to 10 recipients.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Adds a table row.



Removes the selected table row.

Index

Displays the index number to which the table row relates. The device automatically assigns the value when you add a table row.

Notification type

Specifies whether the device sends the emails to this recipient immediately or periodically.

Possible values:

- urgent (default setting) The device sends the emails to this recipient immediately.
- non-urgent

The device sends the emails to this recipient periodically.

Email address

Specifies the email address of the recipient.

Possible values:

Valid email address with up to 255 characters

Active

Activates/deactivates the informing of the recipient.

Possible values:

marked

The informing of the recipient is active.

unmarked (default setting) The informing of the recipient is inactive.

6.3.3 Email Notification Mail Server

[Diagnostics > Email Notification > Mail Server]

In this dialog, you specify the settings for the mail servers. The device supports encrypted and unencrypted connections to the mail server.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

He Add

Adds a table row.



Removes the selected table row.



Opens the Connection test window to send a test email.

If the mail server settings are correct, then the selected recipients receive a test email.

- From the *Recipient* drop-down list, you select to which recipients the device sends the test email. Possible values:
 - urgent

The device sends the test email to the recipients to which the device sends emails immediately.

- non-urgent The device sends the test email to the recipients to which the device sends emails periodically.
- In the Message text field, you specify the text of the test email.

Index

Displays the index number to which the table row relates. The device automatically assigns the value when you add a table row.

Description

Specifies the name of the server.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

IP address

Specifies the IP address or the DNS name of the server.

Possible values:

- Valid IPv4 address (default setting: 0.0.0.0)
- Valid IPv6 address
- DNS name in the format <domain>.<tld> or <host>.<domain>.<tld>

The prerequisite is that you also enable the *Client* function in the *Advanced* > *DNS* > *Client* > *Global* dialog.

To establish an encrypted connection using a digital certificate, verify that the Common Name or Subject Alternative Name information in the digital certificate that you have transferred onto the device matches the value you specify here. Otherwise, the device will not be able to verify the identity of the server.

Destination TCP port

Specifies the TCP port of the server.

Possible values:

1..65535 (2¹⁶-1) (default setting: 25) Exception: Port 2222 is reserved for internal functions.

Frequently used TCP-Ports:

- SMTP 25
- Message Submission 587

Encryption

Specifies the protocol which encrypts the connection between the device and the mail server.

Possible values:

none (default setting)

The device establishes an an unencrypted connection to the server.

🕨 tlsv1

The device establishes an encrypted connection to the server using the startTLS extension.

User name	
	Specifies the user name of the account which the device uses to authenticate on the mail server.
	Possible values: ▶ Alphanumeric ASCII character string with 0255 characters
Password	
	Specifies the password of the account which the device uses to authenticate on the mail server.
	Possible values: ▶ Alphanumeric ASCII character string with 0255 characters
Timeout [s]	
	Specifies the time in seconds after which the device sends an email again. The prerequisite is that the device was unsuccessful at sending the complete email due to a connection error.
	Possible values: ▶ 115 (default setting: 3)
Active	
	Activates/deactivates the use of the mail server.
	Possible values:
	marked The mail server is active. The device sends emails to this mail server.
	unmarked (default setting) The mail server is inactive.

The device does not send emails to this mail server.

6.4 Syslog

[Diagnostics > Syslog]

The device lets you report selected events, independent of the severity of the event, to different syslog servers.

In this dialog, you specify the settings for this function and manage up to 8 syslog servers.

Operation

Operation

Enables/disables the sending of events to the syslog servers.

Possible values:

▶ On

The sending of events is enabled. The device sends the events specified in the table to the specified syslog servers.

Off (default setting) The sending of events is disabled.

Certificates/CRLs

To establish a secure connection, the device requires to obtain a valid digital certificate to verify the identity of the server. The prerequisite is that you have transferred the public certificate of the server onto the device. Ask the server administrator for a digital certificate in X.509 format. For security reasons, Hirschmann recommends using only digital certificates signed by a Certification Authority (CA).

A Certificate Revocation List (CRL) contains a list of digital certificates revoked by the Certification Authority (CA) before their scheduled expiration date. When establishing a secure connection to the server, the device stops setting up the connection if the CRL includes the public certificate of the server. The device logs the event in the System Log. For security reasons, Hirschmann recommends using only CRLs signed by a Certification Authority (CA).

Buttons

Clear all Certificates/CRLs

Deletes the digital certificates and CRLs transferred onto the device from the non-volatile memory (*NVM*).

URL

Specifies the path and file name of the digital certificate or CRL.

The device accepts digital certificates and CRLs with the following properties:

- X.509 format
- . PEM file name extension
- Base64-coded and enclosed by the lines

```
-----BEGIN CERTIFICATE-----

...

Or

-----BEGIN CRL-----

...

-----END CRL-----
```

The device gives you the following options for transferring the file onto the device:

Import from the PC

When the file is located on your PC or on a network drive, drag and drop it onto the 1 area. As an alternative, click in the area to select the file.

- Import from an FTP server This option is not recommended if you transmit data over untrusted networks. When the file is on an FTP server, specify the URL for the file in the following form: ftp://<user>:<password>@<IP address>[:port]/<path>/<file name>
- Import from a TFTP server This option is not recommended if you transmit data over untrusted networks. When the file is on a TFTP server, specify the URL for the file in the following form: tftp://<IP address>/<path>/<file name>
- Import from an SCP or SFTP server
 When the file is on an SCP or SFTP server, specify the URL for the file in the following form:
 scp:// or sftp://<IP address>/<path>/<file name>
 - Click the *Start* button to open the *Credentials* window. In this window, you enter the *User name* and *Password* to log into the server.

scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name>

Remember to set up the SCP or SFTP server as an SSH known host before the device accesses the server for the first time. See the *Device Security* > *SSH Known Hosts* dialog.

Start

Transfers the file specified in the URL field onto the device.

In this dialog, you can transfer a maximum of 32 digital certificates and additionally a maximum of 32 CRLs onto the device.

For the changes to take effect after transferring a digital certificate or a CRL into the device, disable and re-enable the *Syslog* function. See the *Operation* frame.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Adds a table row.



Removes the selected table row.

Displays the index number to which the table row relates. The device automatically assigns the value when you add a table row.

When you delete a table row, this leaves a gap in the numbering. When you add a table row, the device fills the first gap.

Possible values:

1..8

IP address

Specifies the IP address of the syslog server.

Possible values:

- Valid IPv4 address (default setting: 0.0.0.0)
- Valid IPv6 address
- DNS name in the format <domain>.<tld> or <host>.<domain>.<tld>

The prerequisite is that you also enable the Client function in the Advanced > DNS > Client > Global dialog.

To establish an encrypted connection using a digital certificate, verify that the Common Name or Subject Alternative Name information in the digital certificate that you have transferred onto the device matches the value you specify here. Otherwise, the device will not be able to verify the identity of the server.

Destination UDP port

Specifies the TCP or UDP port on which the syslog server expects the log entries.

Possible values:

```
1..65535 (2<sup>16</sup>-1) (default setting: 514)
```

Transport type

Specifies the transport type the device uses to send the events to the syslog server.

Possible values:

udp (default setting)

The device sends the events over the UDP port specified in the Destination UDP port column. tls

The device sends the events over TLS on the TCP port specified in the Destination UDP port column.

Min. severity

Specifies the minimum severity of the events. The device sends a log entry for events with this severity and with more urgent severities to the syslog server.

Possible values:

- emergency
- alert
- critical
- error
- warning (default setting)

notice
 informational
 debug

Туре

Specifies the type of the log entry transmitted by the device.

Possible values:

systemLog (default setting)

▶ audittrail

Active

Activates/deactivates the transmission of events to the syslog server.

Possible values:

marked

The device sends events to the syslog server.

unmarked (default setting) The transmission of events to the syslog server is deactivated.

6.5 Ports

[Diagnostics > Ports]

The menu contains the following dialogs:

► SFP

- ► TP cable diagnosis
- Port Monitor
- Auto-Disable
- Port Mirroring
- RSPAN

6.5.1 SFP

[Diagnostics > Ports > SFP]

This dialog lets you look at the SFP transceivers currently connected to the device and their properties.

Table

The table displays valid values if the device is equipped with SFP transceivers.

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Module type

Type of the SFP transceiver, for example M-SFP-SX/LC.

Serial number

Displays the serial number of the SFP transceiver.

Connector type

Displays the connector type.

Supported

Displays if the device supports the SFP transceiver.

Temperature [°C]

Operating temperature of the SFP transceiver in °Celsius.

Tx power [mW]

Transmission power of the SFP transceiver in mW.

Rx power [mW]

Receiving power of the SFP transceiver in mW.

Tx power [dBm]

Transmission power of the SFP transceiver in dBm.

Rx power [dBm]

Receiving power of the SFP transceiver in dBm.

6.5.2 **TP** cable diagnosis

[Diagnostics > Ports > TP cable diagnosis]

This feature tests the cable attached to an interface for short or open circuit. The table displays the cable status and estimated length. The device also displays the individual cable pairs connected to the port. When the device detects a short circuit or a broken cable, it also displays the estimated distance to where it detected the problem.

To receive dependable results, use the *TP cable diagnosis* function for twisted-pair cables with a minimum length of 10 meters.

Note: This test temporarily interrupts the data stream on the port.

Information

Port

Displays the port number.

Start cable diagnosis...

Opens the Select port window.

From the *Port* drop-down list you select the port to be tested. Use for copper-based ports only.

To initiate the cable test on the selected port, click the Ok button.

Status

Status of the Virtual Cable Tester.

Possible values:

active

Cable testing is in progress.

To start the test, click the Start cable diagnosis... button. This action opens the Select port window.

success

The device successfully performed a test.

▶ failure

The device detected that the test was interrupted.

uninitialized

The device has not performed any test yet.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Cable pair

Displays the cable pair to which this table row relates. The device uses the first PHY index supported to display the values.

Result

Displays the results of the cable test.

Possible values:

- normal
 - The cable is functioning properly.
- open

There is a break in the cable causing an interruption.

short

Wires in the cable are touching together causing a short circuit.

unknown

The device displays this value for untested cable pairs.

The device displays different values than expected in the following cases:

- If no cable is connected to the port, then the device displays the value unknown instead of open.
- If the port is inactive, then the device displays the value short.

Min. length

Displays the minimum estimated length of the cable in meters.

If the cable length is unknown or in the *Information* frame the *Status* field displays the value *active*, failure or *uninitialized*, then the device displays the value 0.

Max. length

Displays the maximum estimated length of the cable in meters.

If the cable length is unknown or in the *Information* frame the *Status* field displays the value *active*, failure or *uninitialized*, then the device displays the value 0.

Distance [m]

Displays the estimated distance in meters from one end of the cable to the other or to an interruption in the cable.

If the cable length is unknown or in the *Information* frame the *Status* field displays the value *active*, failure or *uninitialized*, then the device displays the value 0.

6.5.3 **Port Monitor**

[Diagnostics > Ports > Port Monitor]

The *Port Monitor* function monitors the adherence to the specified parameters on the ports. If the *Port Monitor* function detects that the parameters are being exceeded, then the device performs an action.

To apply the *Port Monitor* function, perform the following steps:

- Global tab
 - □ Enable the *Port Monitor* function in the *Operation* frame.
- Activate for each port those parameters that you want the *Port Monitor* function to monitor.
- Link flap, CRC/Fragments and Overload detection tabs
- □ Specify the threshold values for the parameters for each port.
- Link speed/Duplex mode detection tab
 - Activate the allowed combinations of speed and duplex mode for each port.
- Global tab
 - □ Specify for each port an action that the device carries out if the *Port Monitor* function detects that the parameters have been exceeded.
- Auto-disable tab
 - □ Mark the *Auto-disable* checkbox for the monitored parameters if you have specified the *auto-disable* action at least once.

The dialog contains the following tabs:

- ▶ [Global]
- [Auto-disable]
- [Link flap]
- ▶ [CRC/Fragments]
- [Overload detection]
- [Link speed/Duplex mode detection]

[Global]

In this tab you enable the *Port Monitor* function and specify the parameters that the *Port Monitor* function is monitoring. Also specify the action that the device carries out if the *Port Monitor* function detects that the parameters have been exceeded.

Operation

Operation

Enables/disables the *Port Monitor* function globally.

Possible values:

▶ On

The Port Monitor function is enabled.

 Off (default setting) The Port Monitor function is disabled.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the *Which statistic should be deleted*? window. The window displays the ports that you can enable again and reset the related counters to 0. Click and select a table row to enable the corresponding port again.

This affects the counters in the following dialogs:

- Diagnostics > Ports > Port Monitor dialog
 - Link flap tab
 - CRC/Fragments tab
 - Overload detection tab
- Diagnostics > Ports > Auto-Disable dialog

Port

Displays the port number.

Link flap on

Activates/deactivates the monitoring of link flaps on the port.

Possible values:

marked

Monitoring is active.

- The Port Monitor function monitors link flaps on the port.
- If the device detects too many link flaps, then the device executes the action specified in the Action column.
- On the *Link flap* tab, specify the parameters to be monitored.
- unmarked (default setting) Monitoring is inactive.

CRC/Fragments on

Activates/deactivates the monitoring of CRC/fragment errors detected on the port.

Possible values:

marked

Monitoring is active.

- The *Port Monitor* function monitors CRC/fragment errors detected on the port.
- If the device detects too many CRC/fragment errors, then the device executes the action specified in the *Action* column.
- On the CRC/Fragments tab, specify the parameters to be monitored.
- unmarked (default setting) Monitoring is inactive.

Duplex mismatch detection active

Activates/deactivates the monitoring of duplex mismatches on the port.

Possible values:

marked

Monitoring is active.

- The *Port Monitor* function monitors duplex mismatches on the port.
- If the device detects a duplex mismatch, then the device executes the action specified in the Action column.
- unmarked (default setting) Monitoring is inactive.

Overload detection on

Activates/deactivates the overload detection on the port.

Possible values:

marked

Monitoring is active.

- The Port Monitor function monitors the data load on the port.
- If the device detects a data overload on the port, then the device executes the action specified in the *Action* column.
- On the Overload detection tab, specify the parameters to be monitored.
- unmarked (default setting) Monitoring is inactive.

Link speed/Duplex mode detection on

Activates/deactivates the monitoring of the link speed and duplex mode on the port.

Possible values:

- marked
 - Monitoring is active.
 - The Port Monitor function monitors the link speed and duplex mode on the port.
 - If the device detects an unpermitted combination of link speed and duplex mode, then the device executes the action specified in the *Action* column.
 - On the *Link speed/Duplex mode detection* tab, specify the parameters to be monitored.
- unmarked (default setting) Monitoring is inactive.

Active condition

Displays the monitored parameter that led to the action on the port.

Possible values:

- <
 - No monitored parameter.

The device does not carry out any action.

- Link flap Too many link changes during the observed period.
- CRC/Fragments Too many CRC/fragment errors detected during the observed period.
- Duplex mismatch Duplex mismatch detected.

- Overload detection
 Overload detected during the observed period.
- Link speed/Duplex mode detection Impermissible combination of speed and duplex mode detected.

Action

Specifies the action that the device carries out if the *Port Monitor* function detects that the parameters have been exceeded.

Possible values:

disable port

The device disables the port and sends an SNMP trap. The Link status LED for the port flashes 3× per period.

- To re-enable the port, select the table row of the port, click the button.
- If the parameters are no longer being exceeded, then the *Auto-Disable* function enables the relevant port again after the specified waiting period. The prerequisite is that on the *Auto-disable* tab the checkbox for the monitored parameter is marked.
- send trap
 - The device sends an SNMP trap.

The prerequisite is that in the *Diagnostics* > *Status Configuration* > *Alarms (Traps)* dialog the *Alarms (Traps)* function is enabled and at least one trap destination is specified.

auto-disable (default setting)

The device disables the port and sends an SNMP trap.

The Link status LED for the port flashes 3× per period.

The prerequisite is that on the *Auto-disable* tab the checkbox for the monitored parameter is marked.

- The *Diagnostics > Ports > Auto-Disable* dialog displays which ports are currently disabled due to the parameters being exceeded.
- After a waiting period, the Auto-Disable function enables the port again automatically. For this
 you go to the Diagnostics > Ports > Auto-Disable dialog and specify a waiting period for the
 relevant port in the Reset timer [s] column.

Port status

Displays the operating state of the port.

Possible values:

l up

The port is enabled.

🕨 down

The port is disabled.

notPresent
 Physical port unavailable.

[Auto-disable]

In this tab you activate the *Auto-Disable* function for the parameters monitored by the *Port Monitor* function.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Reason

Displays the parameters monitored by the *Port Monitor* function.

Mark the adjacent checkbox so that the *Port Monitor* function carries out the *auto-disable* action if it detects that the monitored parameters have been exceeded.

Auto-disable

Activates/deactivates the Auto-Disable function for the adjacent parameters.

Possible values:

marked

The *Auto-Disable* function for the adjacent parameters is active. If the adjacent parameters are exceeded and the value *auto-disable* is specified in the *Action* column, then the device carries out the *Auto-Disable* function.

unmarked (default setting) The Auto-Disable function for the adjacent parameters is inactive.

[Link flap]

In this tab you specify individually for every port the following settings:

- The number of link changes.
- The period during which the Port Monitor function monitors a parameter to detect discrepancies.

You also see how many link changes the Port Monitor function has detected up to now.

The *Port Monitor* function monitors those ports for which the checkbox in the *Link flap on* column is marked on the *Global* tab.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Sampling interval [s]

Specifies in seconds, the period during which the *Port Monitor* function monitors a parameter to detect discrepancies.

Possible values:

1..180 (default setting: 10)

Link flaps

Specifies the number of link changes.

If the *Port Monitor* function detects this number of link changes in the monitored period, then the device performs the specified action.

Possible values:

1..100 (default setting: 5)

Last sampling interval

Displays the number of errors that the device has detected during the period that has elapsed.

Total

Displays the total number of errors that the device has detected since the port was enabled.

[CRC/Fragments]

In this tab you specify individually for every port the following settings:

- The detected fragment error rate.
- The period during which the Port Monitor function monitors a parameter to detect discrepancies.

You also see the fragment error rate that the device has detected up to now.

The *Port Monitor* function monitors those ports for which the checkbox in the *CRC/Fragments on* column is marked on the *Global* tab.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Sampling interval [s]

Specifies in seconds, the period during which the *Port Monitor* function monitors a parameter to detect discrepancies.

Possible values:

▶ 5..180 (default setting: 10)

CRC/Fragments count [ppm]

Specifies the detected fragment error rate (in parts per million).

If the *Port Monitor* function detects this fragment error rate in the monitored period, then the device performs the specified action.

Possible values:

1..1000000 (10⁶) (default setting: 1000)

Last active interval [ppm]

Displays the fragment error rate that the device has detected during the period that has elapsed.

Total [ppm]

Displays the fragment error rate that the device has detected since the port was enabled.

[Overload detection]

In this tab you specify individually for every port the following settings:

- The load threshold values.
- The period during which the Port Monitor function monitors a parameter to detect discrepancies.

You also see the number of data packets that the device has detected up to now.

The *Port Monitor* function monitors those ports for which the checkbox in the *Overload detection on* column is marked on the *Global* tab.

The *Port Monitor* function does not monitor any ports that are members of a link aggregation group or PRP/HSR subscribers.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Туре

Specifies the type of data packets that the device takes into account when monitoring the load on the port.

Possible values:

🕨 all

The Port Monitor function monitors Broadcast, Multicast and Unicast packets.

bc (default setting)

The Port Monitor function monitors only Broadcast packets.

► bc-mc

The Port Monitor function monitors only Broadcast and Multicast packets.

Unit

Specifies the unit for the data rate.

Possible values:

pps (default setting) packets per second

kbps

kbit per second

The prerequisite is that in the *Type* column the value all is specified.

Lower threshold

Specifies the lower threshold value for the data rate.

The *Auto-Disable* function enables the port again only when the load on the port is lower than the value specified here.

Possible values:

0..10000000 (10⁷) (default setting: 0)

Upper threshold

Specifies the upper threshold value for the data rate.

If the *Port Monitor* function detects this load in the monitored period, then the device performs the specified action.

Possible values:

0..10000000 (10⁷) (default setting: 0))

Interval [s]

Specifies in seconds, the period that the *Port Monitor* function observes a parameter to detect that a parameter is being exceeded.

Possible values:

1..20 (default setting: 1)

Packets

Displays the number of Broadcast, Multicast and Unicast packets that the device has detected during the period that has elapsed.

Broadcast packets

Displays the number of Broadcast packets that the device has detected during the period that has elapsed.

Multicast packets

Displays the number of Multicast packets that the device has detected during the period that has elapsed.

kbit/s

Displays the data rate in Kbits per second that the device has detected during the period that has elapsed.

[Link speed/Duplex mode detection]

In this tab you activate the allowed combinations of speed and duplex mode for each port.

The *Port Monitor* function monitors those ports for which the checkbox in the *Link speed/Duplex mode detection on* column is marked on the *Global* tab.

The *Port Monitor* function monitors only enabled physical ports.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

10M HDX

Activates/deactivates the port monitor to accept a half-duplex and 10 Mbit/s data rate combination on the port.

Possible values:

marked

The port monitor takes into consideration the speed and duplex combination.

unmarked

If the port monitor detects the speed and duplex combination on the port, then the device executes the action specified in the *Global* tab.

10M FDX

Activates/deactivates the port monitor to accept a full-duplex and 10 Mbit/s data rate combination on the port.

Possible values:

marked

The port monitor takes into consideration the speed and duplex combination.

unmarked

If the port monitor detects the speed and duplex combination on the port, then the device executes the action specified in the *Global* tab.

100M HDX

Activates/deactivates the port monitor to accept a half-duplex and 100 Mbit/s data rate combination on the port.

Possible values:

marked

The port monitor takes into consideration the speed and duplex combination.

unmarked

If the port monitor detects the speed and duplex combination on the port, then the device executes the action specified in the *Global* tab.

100M FDX

Activates/deactivates the port monitor to accept a full-duplex and 100 Mbit/s data rate combination on the port.

Possible values:

marked

The port monitor takes into consideration the speed and duplex combination.

unmarked

If the port monitor detects the speed and duplex combination on the port, then the device executes the action specified in the *Global* tab.

1G FDX

Activates/deactivates the port monitor to accept a full-duplex and 1 Gbit/s data rate combination on the port.

Possible values:

marked

The port monitor takes into consideration the speed and duplex combination.

unmarked

If the port monitor detects the speed and duplex combination on the port, then the device executes the action specified in the *Global* tab.

6.5.4 Auto-Disable

[Diagnostics > Ports > Auto-Disable]

The *Auto-Disable* function lets you disable monitored ports automatically and enable them again as you desire.

For example, the *Port Monitor* function and selected functions in the *Network Security* menu use the *Auto-Disable* function to disable ports if monitored parameters are exceeded.

If the parameters are no longer being exceeded, then the *Auto-Disable* function enables the relevant port again after the specified waiting period.

The dialog contains the following tabs:

[Port][Status]

[Port]

This tab displays which ports are currently disabled due to the parameters being exceeded. If the parameters are no longer being exceeded and you specify a waiting period in the *Reset timer* [s] column, then the *Auto-Disable* function automatically enables the relevant port again.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the *Which statistic should be deleted?* window. The window displays the ports that you can enable again and reset the related counters to Ø. Click and select a table row to enable the corresponding port again.

This affects the counters in the following dialogs:

- Diagnostics > Ports > Auto-Disable dialog
- Diagnostics > Ports > Port Monitor dialog
 - Link flap tab
 - CRC/Fragments tab
 - Overload detection tab

Port

Displays the port number.

Reset timer [s]

Specifies the waiting period in seconds, after which the Auto-Disable function enables the port again.

Possible values:

Ø (default setting)

The timer is inactive. The port remains disabled.

30..4294967295 (2³²-1) If the parameters are no longer being exceeded, then the Auto-Disable function enables the port again after the waiting period specified here.

Error time

Displays when the device disabled the port due to the parameters being exceeded.

Remaining time [s]

Displays the remaining time in seconds, until the Auto-Disable function enables the port again.

Component

Displays the software component in the device that disabled the port.

Possible values:

PORT_MON Port Monitor See the Diagnostics > Ports > Port Monitor dialog.
PORT_ML Port Security See the Network Security > Port Security dialog.
DHCP_SNP DHCP Snooping See the Network Security > DHCP Snooping dialog.
D0T1S BPDU guard See the Switching > L2-Redundancy > Spanning Tree > Global dialog.
DAI Dynamic ARP Inspection See the Network Security > Dynamic ARP Inspection dialog.

Reason

Displays the monitored parameter that led to the port being disabled.

Possible values:

none

No monitored parameter. The port is enabled.

- Link flap Too many link changes. See the Diagnostics > Ports > Port Monitor dialog, Link flap tab.
- CRC error

Too many CRC/fragment errors are detected. See the *Diagnostics > Ports > Port Monitor* dialog, *CRC/Fragments* tab.

DupLex mismatch Duplex mismatch detected. See the Diagnostics > Ports > Port Monitor dialog, Global tab.

▶ DHCP snooping

Too many DHCP packages from untrusted sources. See the *Network Security > DHCP Snooping >* Configuration dialog, *Port* tab.

- ARP rate Too many ARP packages from untrusted sources. See the Network Security > Dynamic ARP Inspection > Configuration dialog, Port tab.
- BPDU rate STP-BPDUs received. See the Switching > L2-Redundancy > Spanning Tree > Global dialog.
- MAC-based port security Too many data packets from undesired senders. See the Network Security > Port Security dialog.
- Overload detection Overload. See the Diagnostics > Ports > Port Monitor dialog, Overload detection tab.
- Speed dupLex Impermissible combination of speed and duplex mode detected. See the Diagnostics > Ports > Port Monitor dialog, Link speed/Duplex mode detection tab.
- Loop protection

A layer 2 network loop detected on the port. See the *Diagnostics > Loop Protection* dialog, *Loop detected* column.

Active

Displays if the port is currently disabled due to the parameters being exceeded.

Possible values:

- marked
 - The port is currently disabled.
- unmarked The port is enabled.

[Status]

This tab displays the monitored parameters for which the Auto-Disable function is active.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Reason

Displays the parameters that the device monitors.

Mark the adjacent checkbox so that the *Auto-Disable* function disables and, when applicable, enables the port again if the monitored parameters are exceeded.

Category

Displays which function the adjacent parameter belongs to.

Possible values:

port monitor

The parameter belongs to the functions in the *Diagnostics > Ports > Port Monitor* dialog.

network security

The parameter belongs to the functions in the Network Security dialog.

L2 redundancy

The parameter belongs to the functions in the *Switching* > *L*2-*Redundancy* dialog or to the *Loop Protection* function, see the *Diagnostics* > *Loop Protection* dialog.

Auto-disable

Displays if the Auto-Disable function is active/inactive for the adjacent parameter.

Possible values:

marked

The *Auto-Disable* function for the adjacent parameters is active.

The *Auto-Disable* function disables and, when applicable, enables the relevant port again if the monitored parameters are exceeded.

unmarked (default setting) The Auto-Disable function for the adjacent parameters is inactive.

6.5.5 Port Mirroring

[Diagnostics > Ports > Port Mirroring]

The *Port Mirroring* function lets you copy received and sent data packets from selected ports to a destination port. You can watch and process the data stream using an analyzer or an *RMON probe*, connected to the destination port. The data packets remain unmodified on the source port.

Note: To enable the access to the device management using the destination port, mark the checkbox *Allow management* in the *Destination port* frame before you enable the *Port Mirroring* function.

Operation

Buttons



Resets the settings in the dialog to the default settings and restores the previously applied settings.

Operation

Enables/disables the Port Mirroring function.

Possible values:

- ▶ On
 - The *Port Mirroring* function is enabled. The device copies the data packets from the selected source ports to the destination port.
- *Off* (default setting) The *Port Mirroring* function is disabled.

Destination port

Primary port

Specifies the destination port.

Suitable ports are those ports that are not used for the following purposes:

- Source port
- Uplink port on which a Layer 2 redundancy protocol is active

Possible values:

- (default setting) No destination port selected.
- <Port number>

Number of the destination port. The device copies the data packets from the source ports to this port.

On the destination port, the device adds a VLAN tag to the data packets that the source port sends. The destination port sends the unmodified data packets that the source port receives.

Note: The destination port needs sufficient bandwidth to absorb the data stream. If the copied data stream exceeds the bandwidth of the destination port, then the device discards superfluous data packets on the destination port.

Allow management

Activates/deactivates the access to the device management using the destination port.

Possible values:

marked

The access to the device management using the destination port is active.

The device lets users have access to the device management using the destination port without interrupting the active *Port Mirroring* session.

- The device duplicates multicasts, broadcasts and unknown unicasts on the destination port.
- The VLAN settings on the destination port remain unchanged. The prerequisite for access to the device management using the destination port is that the destination port is not a member of the VLAN of the device management.
- unmarked (default setting)

The access to the device management using the destination port is inactive. The device prohibits the access to the device management using the destination port.

VLAN mirroring

The *VLAN mirroring* function lets you copy ingress data packets in a specific VLAN to the selected destination port. The device forwards the data stream out of the specified destination port.

Note: The VLAN mirroring function is only available on the primary port.

Source VLAN ID

Specifies the VLAN from which the device mirrors data to the destination port.

Possible values:

- 0 (default setting)
 Disables the VLAN mirroring function.
- 2..4042

The device lets you specify a VLAN only if no source port is specified.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Source port

Displays the port number.

Enabled

Activates/deactivates the copying of the data packets from this source port to the destination port.

Possible values:

- marked The copying of the data packets is active. The port is specified as a source port.
- unmarked (default setting)
 The copying of the data packets is inactive.
- (Grayed-out display) It is not possible to copy the data packets for this port. Possible causes:
 - The port is already specified as a destination port.
 - The port is a logical port, not a physical port.

Note: The device lets you activate every physical port as source port except for the destination port.

Туре

Specifies which data packets the device copies to the destination port.

On the destination port, the device adds a VLAN tag to the data packets that the source port sends. The destination port sends the unmodified data packets that the source port receives.

Possible values:

- none (default setting) No data packets.
- > tx

Data packets that the source port sends.

► rx

Data packets that the source port receives.

▶ txrx

Data packets that the source port sends.

Note: With the *txrx* setting the device copies each transmitted data packet. The destination ports needs at least a bandwidth that corresponds to the sum of the send and receive channel of the source ports. For example, for similar ports the destination port is at 100 % capacity when the send and receive channel of a source port are at 50 % capacity respectively.

6.5.6 **RSPAN**

[Diagnostics > Ports > RSPAN]

In this dialog, you specify the settings for the *RSPAN* function. The *RSPAN* function is an extension of the local mirroring function and uses multiple devices in specific roles to forward mirrored data packets to a single *Destination switch*. For that, RSPAN uses an RSPAN VLAN reserved specifically for this purpose.

Using the *RSPAN* function, a *Source switch* mirrors data packets that it receives or sends on the ports or the *Source VLAN* you have selected and sends them on the RSPAN VLAN to a device in another role. An optional *Intermediate switch* transfers the mirrored data packets in the direction of the *Destination switch*. The *Destination switch* makes the data packets accessible on a local port for monitoring and analysis.

Before you set up the *RSPAN* function, decide on the role that the device will operate in:

- Source switch
- The device forwards the data packets received or sent on the selected *Source ports* or the *Source VLAN* to the RSPAN VLAN.
- Destination switch

The device receives the data packets from the *Source switches* or *Intermediate switches* on the RSPAN VLAN and makes the packets accessible for monitoring and analysis.

Intermediate switch

If you use one or more *Intermediate switches* on the path between the *Source switch* and *Destination switch*, then the *Port Mirroring* function is not required for this role. You only set up the RSPAN VLAN and make the *Destination port* that is connected to the *Destination switch* or to another *Intermediate switch* a member of this VLAN. See the *Switching* > VLAN > *Configuration* dialog.

Operation

Buttons

Reset config

Resets the settings in the dialog to the default settings.

Operation

Enables/disables the RSPAN function.

Possible values:

▶ On

The RSPAN function is enabled.

The device operates in the *Source switch* or *Destination switch* role, depending on the settings in the *Role* frame.

Off (default setting)

The RSPAN function is disabled.

The device does not take part in the *RSPAN* function, or it operates in the *Intermediate switch* role, for which no settings are necessary in this dialog.

Role

In the *Role* frame, you specify whether the device operates in the *Source switch* or *Destination switch* role. Depending on your selection, further settings are possible in this dialog either in the [Source switch] tab or the [Destination switch] tab.

Role

Specifies the role that the device will operate in.

Possible values:

- Source switch (default setting) The device will operate in the Source switch role.
- Destination switch The device will operate in the Destination switch role.

[Source switch]

For this role, you specify the *Source ports* or the *Source VLAN*. The device will forward the data packets received or sent on the *Source ports* or on the *Source VLAN* to the *Reflector port* or to the *Destination port*. The device sends the mirrored data packets with the RSPAN VLAN tag.

Reflector port

Reflector port

Specifies the port to which the device internally sends the mirrored data packets. The *Reflector port* then forwards the mirrored data packets to the RSPAN VLAN.

Preparatory steps:

- Specify an existing VLAN ID in the RSPAN frame.
- Specify the value in the *Destination port* frame.

- (default setting) No port selected.
- <Port number>

RSPAN

RSPAN Destination VLAN ID

The device tags the mirrored data packets with this VLAN ID and then forwards them to the *Reflector port* or to the *Destination port*. The VLAN 1 is the default VLAN for the device management and cannot be used as the RSPAN VLAN.

Prerequisites:

- In the Switching > VLAN > Configuration dialog, the VLAN is already set up.
- In the Switching > VLAN > Configuration dialog, the RSPAN VLAN column, the checkbox is marked for the particular VLAN.

Possible values:

Ø (default setting)

The RSPAN VLAN is inactive as it is not connected to any monitoring session.

2...4042

Verify that the same VLAN is set up on the Intermediate switches and on the Destination switch.

Destination port

Destination port

The device forwards the mirrored data packets from the *Source ports* or the *Source VLAN* to this port. The prerequisite is that in the *Reflector port* frame the value - is selected.

Possible values:

- (default setting) No port selected.
- <Port number>

This port needs sufficient bandwidth to accommodate the data stream. If the mirrored data stream exceeds the bandwidth of this port, then the device discards superfluous data packets on the port.

The prerequisite is that the port is not used for any of the following purposes:

- Mirroring source port
- Layer 2 redundancy protocols

VLAN mirroring

Using VLAN mirroring, the device mirrors data packets that it receives in a specific VLAN to the destination port.

Source VLAN ID

Specifies the VLAN whose data packets the device mirrors to the *Destination port*, if none of the *Source ports* is active.

Prerequisites:

- In the Switching > VLAN > Configuration dialog, the VLAN is already set up.
- No source port is active.

Possible values:

```
    0 (default setting)
The VLAN mirroring function is disabled.
    1..4042
```

Table

Source port

Displays the port number.

Active

Activates/deactivates the mirroring of data packets that the port receives and sends.

Possible values:

- marked The device mirrors the data packets that the port receives and sends. The device can mirror up to 8 ports simultaneously.
- unmarked (default setting) The device does not mirror the data packets that the port receives and sends. Use this setting for the *Reflector port* and the *Destination port*.

Туре

Specifies which data packets the device mirrors on this port.

Possible values:

- none (default setting)
 - The device does not mirror the data packets that the port receives and sends.
- 🕨 tx

The device mirrors the data packets that the port sends.

► rx

The device mirrors the data packets that the port receives.

▶ txrx

The device mirrors the data packets that the port receives and sends.

[Destination switch]

In the *Destination switch* role, the device serves as the destination for mirrored data packets originating from other devices.

RSPAN

RSPAN Source VLAN ID

The device forwards each data packet received in this VLAN to the specified *Destination port*. The VLAN 1 is used to access the device management and cannot be used as the RSPAN VLAN.

Prerequisites:

- In the Switching > VLAN > Configuration dialog, the VLAN is already set up.
- In the Switching > VLAN > Configuration dialog, the RSPAN VLAN column, the checkbox is marked for the particular VLAN.

Possible values:

Ø (default setting)

The RSPAN VLAN is inactive as it is not connected to any monitoring session.

▶ 2..4042

Verify that the same VLAN is set up on the Intermediate switches and on the Destination switch.

Destination port

Destination port

The device forwards the RSPAN data packets that it receives from the *Source switches* or *Intermediate switches* to this port.

Possible values:

 - (default setting) No port selected.

<Port number>

This port needs sufficient bandwidth to accommodate the data stream. If the mirrored data stream exceeds the bandwidth of this port, then the device discards superfluous data packets on the port.

The prerequisite is that the port is not used for any of the following purposes:

- Mirroring source port
- Layer 2 redundancy protocols

6.6 LLDP

[Diagnostics > LLDP]

The device lets you gather information about neighboring devices. For this, the device uses the Link Layer Discovery Protocol (LLDP). This information lets a network management station map the structure of the network.

This menu lets you set up the topology discovery and to display the information received in tabular form.

The menu contains the following dialogs:

- LLDP Configuration
- LLDP Topology Discovery

6.6.1 LLDP Configuration

[Diagnostics > LLDP > Configuration]

This dialog lets you set up the topology discovery for every port.

Operation

Operation

Enables/disables the *LLDP* function.

Possible values:

 On (default setting) The LLDP function is enabled. The topology discovery using LLDP is active in the device.
 Off The LLDP function is disabled.

Configuration

Transmit interval [s]

Specifies the interval in seconds at which the device sends LLDP data packets.

Possible values:

▶ 5..32768 (2¹⁵) (default setting: 30)

Transmit interval multiplier

Specifies the factor for determining the time-to-live value for the LLDP data packets.

Possible values:

2..10 (default setting: 4)

The time-to-live value coded in the LLDP header results from multiplying this value with the value in the *Transmit interval* [s] field.

Reinit delay [s]

Specifies the delay in seconds for the reinitialization of a port.

Possible values:

1..10 (default setting: 2)

If in the *Operation* column the value *Off* is specified, then the device tries to reinitialize the port after the time specified here has elapsed.

Transmit delay [s]

Specifies the delay in seconds for transmitting successive LLDP data packets after the device settings change.

Possible values:

1..8192 (default setting: 2)

The recommended value is between a minimum of 1 and a maximum of a quarter of the value in the *Transmit interval* [s] field.

Notification interval [s]

Specifies the interval in seconds for transmitting LLDP notifications.

Possible values:

▶ 5..3600 (default setting: 5)

After transmitting a notification trap, the device waits for a minimum of the time specified here before transmitting the next notification trap.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Operation

Specifies if the port transmits LLDP data packets.

Possible values:

transmit

The port sends LLDP data packets but does not save any information about neighboring devices.

receive

The port receives LLDP data packets but does not send any information to neighboring devices.

receive and transmit (default setting)

The port transmits LLDP data packets and saves information about neighboring devices.

disabled

The port does not send LLDP data packets and does not save information about neighboring devices.

Notification

Activates/deactivates the LLDP notifications on the port.

Possible values:

- marked
 - LLDP notifications are active on the port.
- unmarked (default setting) LLDP notifications are inactive on the port.

Transmit port description

Activates/deactivates the transmitting of a TLV (Type Length Value) with the port description.

Possible values:

- marked (default setting) The transmitting of the TLV is active. The device sends the TLV with the port description.
- unmarked
 - The transmitting of the TLV is inactive. The device does not send a TLV with the port description.

Transmit system name

Activates/deactivates the transmitting of a TLV (Type Length Value) with the device name.

Possible values:

- marked (default setting) The transmitting of the TLV is active. The device sends the TLV with the device name.
- unmarked

The transmitting of the TLV is inactive.

The device does not send a TLV with the device name.

Transmit system description

Activates/deactivates the transmitting of the TLV (Type Length Value) with the system description.

Possible values:

- marked (default setting) The transmitting of the TLV is active. The device sends the TLV with the system description.
- unmarked

The transmitting of the TLV is inactive.

The device does not send a TLV with the system description.

Transmit system capabilities

Activates/deactivates the transmitting of the TLV (Type Length Value) with the system capabilities.

Possible values:

 marked (default setting) The transmitting of the TLV is active. The device sends the TLV with the system capabilities.
 unmarked The transmitting of the TLV is inactive.

The device does not send a TLV with the system capabilities.

Neighbors (max.)

Limits the number of neighboring devices to be recorded for this port.

Possible values:

1..50 (default setting: 10)

FDB mode

Specifies which function the device uses to record neighboring devices on this port.

Possible values:

LLdpOnLy

The device uses only LLDP data packets to record neighboring devices on this port.

macOnLy

The device uses learned MAC addresses to record neighboring devices on this port. The device uses the MAC address only if there is no other entry in the MAC address table (forwarding database) for this port.

▶ both

The device uses LLDP data packets and learned MAC addresses to record neighboring devices on this port.

autoDetect (default setting)
If the device receives LLDB date peckets at this per

If the device receives LLDP data packets at this port, then the device operates the same as with the *LLdpOnLy* setting. Otherwise, the device operates the same as with the *macOnLy* setting.

6.6.2 LLDP Topology Discovery

[Diagnostics > LLDP > Topology Discovery]

Devices in networks send notifications in the form of packets which are also known as "LLDPDU" (LLDP data units). The data that is sent and received through LLDPDUs is useful for many reasons. Thus the device detects which devices in the network are neighbors and through which ports they are connected.

The dialog lets you display the network and to detect the connected devices along with their specific features.

The dialog contains the following tabs: ▶ [LLDP] ▶ [LLDP-MED]

[LLDP]

This tab displays the collected LLDP information for the neighboring devices. This information lets a network management station map the structure of the network.

When devices both with and without an active topology discovery function are connected to a port, the topology table hides the devices without active topology discovery.

When only devices without active topology discovery are connected to a port, the table contains one line for this port to represent every device. This line contains the number of connected devices.

The MAC address table (forwarding database) contains MAC addresses of devices that the topology table hides for the sake of clarity.

When you use one port to connect several devices, for example through a hub, the table shows one line for each connected device.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Neighbor identifier

Displays the chassis ID of the neighboring device. This can be the basis MAC address of the neighboring device, for example.

FDB

Displays if the connected device has active LLDP support.

Possible values:

- marked
 - The connected device does not have active LLDP support.
 - The device uses information from its MAC address table (forwarding database)
- unmarked The connected device has active LLDP support.

Neighbor address

Displays the IPv4 address or hostname with which the access to the neighboring device management is possible.

Neighbor IPv6 address

Displays the IPv6 address with which the access to the neighboring device management is possible.

Neighbor port description

Displays a description for the port of the neighboring device.

Neighbor system name

Displays the device name of the neighboring device.

Neighbor system description

Displays a description for the neighboring device.

Port ID

Displays the ID of the port through which the neighboring device is connected to the device.

Autonegotiation supported

Displays if the port of the neighboring device supports auto-negotiation.

Autonegotiation

Displays if auto-negotiation is active on the port of the neighboring device.

PoE supported

Displays if the port of the neighboring device supports Power over Ethernet (PoE).

PoE enabled

Displays if Power over Ethernet (PoE) is active on the port of the neighboring device.

[LLDP-MED]

LLDP for Media Endpoint Devices (LLDP-MED) is an extension to LLDP that operates between endpoint devices and network devices. It specifically provides support for VoIP applications. In this support rule, it provides an additional set of common advertisement, Type Length Value (TLV), messages. The device uses the TLVs for capabilities discovery such as network policy, Power over Ethernet, inventory management and location information.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Device class

Displays the device class of the remotely connected device.

Possible values:

- notDefined The device has capabilities not covered by any of the LLDP-MED classes.
- endpointClass1 The device has endpointClass1 capabilities.
- endpointClass2 The device has endpointClass2 capabilities.
- endpointClass3
 The device has endpointClass3 capabilities.
- networkConnectivity The device has network connectivity device capabilities.

VLAN ID

Displays the extension of the VLAN Identifier for the remote system connected to this port, as defined in IEEE 802.3.

• 0

Priority tagged packets Only the 802.1D priority is significant and the device uses the default VLAN ID of the ingress port.

```
1..4042
Valid Port VLAN ID
```

Priority

Displays the value of the 802.1D Priority which is associated with the remote system connected to the port.

DSCP

Displays the value of the *Differentiated Service Code Point (DSCP)* which is associated with the remote system connected to the port.

Unknown bit status

Displays the Unknown Bit Status of incoming data packets.

Possible values:

🕨 true

The network policy for the specified application type is currently unknown. In this case, the device ignores the Layer 2 priority and value of the *DSCP* field.

► false

Indicates a specified network policy.

Tagged bit status

Displays the tagged bit status.

Possible values:

▶ true

The application uses a tagged VLAN.

► false

For the specific application the device uses untagged VLAN operation. In this case, the device ignores both the VLAN ID and the Layer 2 priority fields. The DSCP value on Layer 3, however, is relevant.

Hardware revision

Displays the vendor-specific hardware revision string as advertised by the remote endpoint.

Firmware revision

Displays the vendor-specific firmware revision string as advertised by the remote endpoint.

Software revision

Displays the vendor-specific software revision string as advertised by the remote endpoint.

Serial number

Displays the vendor-specific serial number as advertised by the remote endpoint.

Manufacturer name

Displays the vendor-specific manufacturer name as advertised by the remote endpoint.

Model name

Displays the vendor-specific model name as advertised by the remote endpoint.

Asset ID

Displays the vendor-specific asset tracking identifier as advertised by the remote endpoint.

6.7 Loop Protection

[Diagnostics > Loop Protection]

The *Loop Protection* function helps protect against layer 2 network loops.

A network loop can lead to a standstill of the network due to overload. A possible reason is the continuous duplication of data packets due to a misconfiguration. The cause could be, for example, a poorly connected cable or an incorrect setting in the device.

For example, a layer 2 network loop can occur in the following cases, if no redundancy protocols are active:

- Two ports of the same device are directly connected to each other.
- More than one active connection is established between two devices.

In redundant network topologies, multiple redundancy protocols are typically active. You usually disable the *Spanning Tree* function on the ports involved in other redundancy protocols. The redundancy protocols already help to avoid loops.

Operation

Operation

Enables/disables the Loop Protection function.

Possible values:

▶ On

- The *Loop Protection* function is enabled.
- On active and passive ports, the device evaluates received *loop detection* packets.
 On active ports, the device sends *loop detection* packets at regular intervals as specified in the *Transmit interval* field.
 - The prerequisite is that the *Loop Protection* function is active on the port.
- The device lets you monitor Ethernet loops with the signal contact. See the *Diagnostics* > Status Configuration > Signal Contact > Signal Contact 1 dialog, checkbox for the *Ethernet loops* parameter.
- Off (default setting)

The Loop Protection function is disabled.

The device neither sends loop detection packets nor evaluates received loop detection packets.

Configuration

Auto-disable

Activates/deactivates the Auto-Disable function for Loop Protection.

Possible values:

marked

The Auto-Disable function for Loop Protection is active.

The prerequisite for disabling the port is that in the *Action* column the value *auto-disable* or *all* is specified.

The device lets you specify the waiting period in seconds after which the *Auto-Disable* function enables the port again. To do this, in the *Diagnostics > Ports > Auto-Disable* dialog, specify the waiting period in the *Reset timer* [s] column.

unmarked (default setting) The Auto-Disable function for Loop Protection is inactive.

Global

Transmit interval

Specifies the interval in seconds at which the device sends *loop detection* packets if the *Loop Protection* function is active on the port.

Possible values:

1..10 (default setting: 5)

Receive threshold

Specifies the threshold value for the number of consecutive *loop detection* packets received. If the number reaches or exceeds this threshold value, then the device will perform the action specified in the *Action* column.

Possible values:

1..50 (default setting: 1)

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Clear port statistics

Resets the values in the following columns:

Loops

- Sent frames
- Received frames

Port

Displays the port number.

Active

Activates/deactivates the Loop Protection function on the port.

Possible values:

marked

The Loop Protection function is active on the port.

Activate the function only on ports which are not part of a redundant network path. This helps avoid an accidental shutdown of redundant network paths.

If the device receives a *loop detection* packet on this port, sent from another port on the same device, then the device performs the action specified in the *Action* column.

unmarked (default setting) The Loop Protection function is inactive on the port. The port neither sends loop detection packets nor evaluates received loop detection packets.

Mode

Specifies the behavior of the Loop Protection function on the port.

Possible values:

active

The device sends loop detection packets and evaluates received loop detection packets.

passive (default setting)

The device evaluates received loop detection packets.

Action

Specifies the action the device performs when it detects a layer 2 network loop on this port.

Possible values:

🕨 trap

The device sends a trap.

auto-disable (default setting)

The device disables the port using the *Auto-Disable* function.

The prerequisite for disabling the port is that in the *Configuration* frame the *Auto-disable* checkbox is marked.

🕨 all

The device sends a trap. Then the device disables the port using the *Auto-Disable* function. The prerequisite for disabling the port is that in the *Configuration* frame the *Auto-disable* checkbox is marked.

VLAN ID

Specifies the VLAN in which the device sends the loop detection packets.

Possible values:

Ø (default setting)

The device sends the loop detection packets without a VLAN tag.

1..4042

The device sends the *loop detection* packets in the specified VLAN. The prerequisite is that in the *Switching* > *VLAN* > *Port* dialog the VLAN is already set up and that the port is a member of the VLAN.

Loop detected

Displays if the device has detected a layer 2 network loop on the port.

Possible values:

- 🕨 yes
 - The device has detected a layer 2 network loop on the port.
 - After the loop has ended and the port is enabled again, the device resets the value to no.

🕨 no

The device has not detected a layer 2 network loop on the port.

Loops

Displays the number of loops the device has detected on the port since the last port statistics reset or since the last system startup.

Last loop time

Displays the time at which the device detected the last loop on the port.

The prerequisite for the correct evaluation of the value is that in the *Time > Basic Settings* dialog the system time of the device is synchronized with the appropriate reference time.

Sent frames

Displays the number of *loop detection* packets sent on the port since the last port statistics reset or since the last system startup.

Received frames

Displays the number of sent and received back *loop detection* packets on the port since the last port statistics reset or since the last system startup.

Discarded frames

Displays the number of discarded loop detection packets on the port.

Examples of reasons for discarded packets:

- The device detects packets with an incorrect format.
- The device detects packets with expired timestamps (packets received more than 5 seconds after sending).
- The device received a data packet with an unexpected VLAN information.
- The device detects received packets on a port that is disabled.

6.8 SFlow

[Diagnostics > SFlow]

sFlow is a standard protocol for monitoring networks. The device contains the sFlow feature which gives you visibility into network activity, allowing for effective management and control of network resources.

The sFlow monitoring system consists of an sFlow agent and a central sFlow collector. The agent uses the following forms of sampling:

- statistical packet-based sampling of packet flows
- time-based sampling of counters

The device combines both types of samples into datagrams. sFlow uses the datagrams to forward the sampled data packet statistics to an sFlow collector for analysis.

To perform packet flow sampling, you set up an instance with a sampling rate. You then set up the instance with a polling interval for counter sampling.

The menu contains the following dialogs:

- SFlow Configuration
- SFlow Receiver

6.8.1 SFlow Configuration

[Diagnostics > SFlow > Configuration]

This dialog displays device parameters and lets you set up sFlow instances.

The dialog contains the following tabs:

- ▶ [Global]
- ▶ [Sampler]
- ▶ [Poller]

[Global]

Information

Version

Displays the MIB version, the organization responsible for agent implementation, and the device software revision.

IP address

Displays the IP address associated with the agent providing SNMP connectivity.

[Sampler]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the physical source of data for the sampler.

Receiver

Specifies the receiver index associated with the sampler.

Possible values:

- (default setting)

▶ (1)..(8)

The value refers to the corresponding *Index* settings specified in the *Diagnostics* > *SFlow* > Receiver dialog.

Sampling rate

Specifies the static sampling rate for the sampling of the packets from this source.

Possible values:

- Ø (default setting)
 - Deactivates the sampling.
- > 256..65536

When you click the \checkmark button after changing the value, the device changes the value to the closest value that the device hardware supports. When the ports receive data, the device increments to the set value and then samples the data.

Max. header size [byte]

Specifies the maximum header size in bytes copied from a sampled packet.

Possible values:

20..256 (default setting: 128)

[Poller]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the physical source of data for the poller counter.

Receiver

Specifies the receiver index associated with the query counter.

Possible values:

- (default setting)
- ▶ (1)..(8)

The value refers to the corresponding *Index* settings specified in the *Diagnostics* > *SFlow* > Receiver dialog.

Interval [s]

Specifies the maximum number of seconds between successive samples of the counters which are associated with this data source.

Possible values:

▶ 0..86400 (default setting: 0)

A sampling interval with the value 0 deactivates the sampling of the counters.

6.8.2 SFlow Receiver

[Diagnostics > SFlow > Receiver]

To help avoid a condition where 2 persons or organizations attempt to assume control of the same sampler, the person or organization sets both the *Name* and *Timeout* [s] parameters in the same *SNMP Set request*.

When releasing a sampler, the controlling person or organization deletes the value in the *Name* column. The controlling person or organization also restores the other parameters in this row to their default settings.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Index

Displays the index number to which the table row relates.

Name

Specifies the name of the person or company which controls the receiver. An empty field indicates that the item is currently unused. Edit this field before making changes to other sampler parameters.

Possible values:Alphanumeric ASCII character string with 0..127 characters

Timeout [s]

Specifies the time, in seconds, remaining before the sampler is released and stops sampling.

- Ø (default setting)
- 1..2147483647 (2³¹-1)

Datagram size [byte]

Specifies the maximum number of data bytes that are sent in one sample datagram.

Possible values:

200..3996 (default setting: 1400)

IP address

Specifies the IP address of the sFlow collector.

Possible values:Valid IPv4 address (default setting: 0.0.0.0)

Destination UDP port

Specifies the number of the UDP port for sFlow datagrams.

Possible values:

1..65535 (2¹⁶-1) (default setting: 6343) Exception: Port 2222 is reserved for internal functions.

Datagram version

Displays the version of sFlow datagrams requested.

6.9 Report

[Diagnostics > Report]

The menu contains the following dialogs:

- Report Global
- Persistent Logging
- System Log
- Audit Trail

6.9.1 **Report Global**

[Diagnostics > Report > Global]

The device lets you log specific events using the following outputs:

- on the console
- on one or more syslog servers
- on a connection to the Command Line Interface set up using SSH
- on a connection to the Command Line Interface set up using Telnet

In this dialog, you specify the required settings. By assigning the severity you specify which events the device registers.

The dialog lets you save a ZIP archive with detailed device information for support purposes on your PC.

Console logging

Download support information

Generates a ZIP archive which the web browser lets you download from the device.

The ZIP archive contains files with detailed device information for support purposes. For further information, see "Support Information: Files in ZIP archive" on page 502.

Operation

Enables/disables the Console logging function.

Possible values:

▶ On

The Console logging function is enabled.

The device logs the events on the console.

Off (default setting) The Console logging function is disabled.

Severity

Specifies the minimum severity for the events. The device logs events with this severity and with more urgent severities. For further information, see "Meaning of the event severities" on page 502.

The device outputs the messages on the serial interface.

- emergency
- alert
- critical
- error
- warning (default setting)
- notice

informational

debug

SNMP logging

When you enable the logging of SNMP requests, the device sends these as events with the preset severity *notice* to the list of syslog servers. The preset minimum severity for a syslog server entry is *critical*.

To send SNMP requests to a syslog server, you have a number of options to change the default settings. Select the ones that meet your requirements best.

- Set the severity for which the device generates SNMP requests as events to *warning* or *error*. Change the minimum severity for a syslog entry for one or more syslog servers to the same value.
 - You also have the option of adding a separate syslog server entry for this.
- Set only the severity for SNMP requests to *critical* or higher. The device then sends SNMP requests as events with the severity *critical* or higher to the syslog servers.
- Set only the minimum severity for one or more syslog server entries to *notice* or lower. Then it is possible that the device sends many events to the syslog servers.

Log SNMP get request

Enables/disables the logging for the reception of SNMP Get requests.

Possible values:

▶ On

The logging is enabled. The device logs each received *SNMP Get request* as an event in the syslog. From the *Severity get request* drop-down list, you select the severity for this event.

off (default setting) The logging is disabled.

Log SNMP set request

Enables/disables the logging for the reception of SNMP Set requests.

Possible values:

▶ On

The logging is enabled. The device logs each received *SNMP Set request* as an event in the syslog. From the *Severity set request* drop-down list, you select the severity for this event.

Off (default setting) The logging is disabled.

Severity get request

Specifies the severity of the event that the device logs for received *SNMP Get requests*. For further information, see "Meaning of the event severities" on page 502.

- emergency
- 🕨 alert
- critical

error

- warning
- notice (default setting)
- informational
- debug

Severity set request

Specifies the severity of the event that the device logs for received *SNMP Set requests*. For further information, see "Meaning of the event severities" on page 502.

Possible values:

- emergency
- alert
- critical
- error
- warning
- notice (default setting)
- informational
- debug

Buffered logging

The device buffers logged events in 2 separate storage areas so that the log entries for urgent events are kept.

This dialog lets you specify the minimum severity for events that the device buffers in the storage area with a higher priority.

Severity

Specifies the minimum severity for the events. The device buffers log entries for events with this severity and with more urgent severities in the storage area with a higher priority. For further information, see "Meaning of the event severities" on page 502.

- emergency
- 🕨 alert
- critical
- 🕨 error
- warning (default setting)
- notice
- informational
- debug

CLI logging

Operation

Enables/disables the *CLI logging* function.

Possible values:

▶ On

The CLI logging function is enabled.

The device logs every command received using the Command Line Interface.

Off (default setting)
 The *CLI logging* function is disabled.

Support Information: Files in ZIP archive

File name	Format	Comments
audittrail.html	HTML	Contains the chronological recording of the system events and saved user changes in the <i>Audit Trail</i> protocol.
config.xml	XML	Contains the settings of the device saved in the "Selected" configuration profile.
defaultconfig.xml	XML	Contains the default settings of the device.
script	TEXT	Contains the output of the command show running-config script.
runningconfig.xml	XML	Contains the current operating settings of the device.
supportinfo.html	HTML	Contains device internal service information.
systeminfo.html	HTML	Contains information about the current settings and operating parameters.
systemlog.html	HTML	Contains the logged events in the Log file. See the <i>Diagnostics</i> > Report > <i>System Log</i> dialog.

Meaning of the event severities

Severity	Meaning
emergency	Device not ready for operation
alert	Immediate user intervention required
critical	Critical status
error	Error status
warning	Warning
notice	Significant, normal status
informational	Information message
debug	Debug message

6.9.2 Persistent Logging

[Diagnostics > Report > Persistent Logging]

The device lets you save log entries permanently in a file in the external memory. Therefore, even after the device is restarted you have access to the log entries.

In this dialog, you limit the size of the log file and specify the minimum severity for the events to be saved. When the log file reaches the specified size, the device archives this file and saves the following log entries in a newly generated file.

In the table the device displays you the log files held in the external memory. As soon as the specified maximum number of files has been attained, the device deletes the oldest file and renames the remaining files. This helps ensure that there is enough memory space in the external memory.

Note: Verify that an external memory is connected. To verify if an external memory is connected, see the *Status* column in the *Basic Settings > External Memory* dialog. We recommend to monitor the external memory connection using the *Device Status* function, see the *External memory removal* parameter in the *Diagnostics > Status Configuration > Device Status* dialog.

Operation

Operation

Enables/disables the Persistent Logging function.

Only activate this function if the external memory is available in the device.

Possible values:

On (default setting)
 The *Persistent Logging* function is enabled.
 The device saves the log entries in a file in the external memory.

► Off

The Persistent Logging function is disabled.

Configuration

Max. file size [kbyte]

Specifies the maximum size of the log file in KBytes. When the log file reaches the specified size, the device archives this file and saves the following log entries in a newly generated file.

Possible values:

0..4096 (default setting: 1024)

The value 0 deactivates saving of log entries in the log file.

Files (max.)

Specifies the number of log files that the device keeps in the external memory.

As soon as the specified maximum number of files has been attained, the device deletes the oldest file and renames the remaining files.

Possible values:

▶ 0..25 (default setting: 4)

The value 0 deactivates saving of log entries in the log file.

Severity

Specifies the minimum severity of the events. The device saves the log entry for events with this severity and with more urgent severities in the log file in the external memory.

Possible values:

- emergency
- 🕨 alert
- critical
- 🕨 error
- warning (default setting)
- notice
- informational
- debug

Log file target

Specifies the external memory device for logging.

Possible values:

- sd (default setting)
 External SD memory (ACA31)
- 🕨 usb
 - External USB memory (ACA21/ACA22)

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Clear persistent log file

Removes the log files from the external memory.

Index

Displays the index number to which the table row relates.

Possible values:

▶ 1..25

The device automatically assigns this number.

File name

Displays the file name of the log file in the external memory.

Possible values:

messages

messages.X

File size [byte]

Displays the size of the log file in the external memory in bytes.

6.9.3 System Log

[Diagnostics > Report > System Log]

This dialog displays the System Log file. The device logs device-internal events in the System Log file. The device keeps the logged events even after a restart.

To search the System Log file, use the search function of your web browser.

The dialog lets you download a copy of the System Log file onto your computer. The device provides the file to be downloaded in HTML format.

Buttons

Save log file

Downloads a copy of the System Log file onto your computer, based on the web browser settings.



Clear log file

Clears the System Log file on the device.

6.9.4 Audit Trail

[Diagnostics > Report > Audit Trail]

This dialog displays the Audit Trail. The dialog lets you save the log file as an HTML file on your PC.

To search the log file for search terms, use the search function of your web browser.

The device logs system events and writing user actions in the device. This lets you keep track of WHO changes WHAT in the device and WHEN. The prerequisite is that the access role auditor or administrator is assigned to your user account.

The device logs the following user actions, among others:

- A user logging into the device management with the Command Line Interface (local or remote)
- A user logging off manually
- Automatic logging off of a user in the Command Line Interface after a specified period of inactivity
- Device restart
- · Locking of a user account due to too many consecutive unsuccessful login attempts
- · Locking of the access to the device management due to unsuccessful login attempts
- Commands executed in the Command Line Interface, apart from show commands
- Changes to configuration variables
- · Changes to the system time
- · File transfer operations, including device software updates
- Configuration changes using HiDiscovery
- Device software updates and automatic configuration of the device through the external memory
- Opening and closing of SNMP through an HTTPS tunnel

The device does not log passwords. The logged entries are write-protected and remain saved in the device after a restart.

Note: During the system startup, access to the system monitor is possible using the default settings of the device. If an attacker gains physical access to the device, then he is able to reset the device settings to its default values using the system monitor. After this, the device and log file are accessible using the standard password. Take appropriate measures to restrict physical access to the device. Otherwise, deactivate access to the system monitor. See the *Diagnostics* > *System* > Selftest dialog, *SysMon1 is available* checkbox.

Buttons



Save audit trail file

Saves the HTML page on your PC using the web browser dialog.

7 Advanced

The menu contains the following dialogs:

- DHCP
- DNS
- Industrial Protocols
- ► Tracking
- Command Line Interface

7.1 DHCP

[Advanced > DHCP]

The menu contains the following dialogs:

- DHCP Server
- ▶ DHCP L2 Relay

7.1.1 DHCP Server

[Advanced > DHCP > DHCP Server]

The Dynamic Host Configuration Protocol (DHCP) lets a server assign the IP settings to the devices on the network (clients). The DHCP server stores and assigns the available IP addresses and further settings, if specified.

The DHCP server in the device listens for requests on UDP port 67 and responds to the client devices on UDP port 68. When the device receives a DHCP request, it validates the IP address to be assigned before leasing the IP address and other IP settings to the requesting client device.

The menu contains the following dialogs:

- DHCP Server Global
- ► DHCP Server Pool
- ► DHCP Server Lease Table

7.1.1.1 DHCP Server Global

[Advanced > DHCP > DHCP Server > Global]

This dialog lets you activate the *DHCP Server* function either globally or per port according to your requirements.

Operation

Operation

Enables/disables the DHCP Server function of the device globally.

Possible values:

► On

Off (default setting)

Configuration

IP probe

Activates/deactivates the probing for unique IP addresses. Before assigning an IP address, the device sends an *ICMP echo request* packet to check whether this IP address is already in use on the network.

Possible values:

- marked (default setting) The *IP probe* function is active.
- unmarked The *IP probe* function is inactive.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the number of the physical port on which the device listens for DHCP requests and reponds to the client devices.

DHCP server active

Activates/deactivates the DHCP Server function on this port.

The prerequisite is that you enable the function globally.

Possible values:

- marked (default setting) The DHCP Server function is active.
- unmarked The DHCP Server function is inactive.

7.1.1.2 DHCP Server Pool

[Advanced > DHCP > DHCP Server > Pool]

In this dialog, you specify the settings for assigning a certain IP address to client devices from which the device receives a DHCP request.

The device assigns an IP address from a specific pool (address range) depending on which physical port the requesting client device is connected to or in which VLAN it is a member. The MAC address of the requesting client device is a further criterion for the pool from which the device assigns an IP address.

If specified, the device processes further information to assign an IP address from a certain pool to the client device. This can be, for example, the following information in the DHCP request:

- Client ID
- Remote ID
- Circuit ID

The device provides a maximum of 128 pools. Up to 1000 client devices can receive their IP settings from the device.

The device manages the IP settings in two types of pools.

- Static pools
- To assign the same IP address to a specific device each time, the device manages the relevant IP settings in a pool whose address range is exactly one IP address.
- Static pools are useful, for example, to assign a fixed IP address to a server, NAS, or printer. Dynamic pools
- To assign IP addresses from a certain address range, the device manages the relevant IP settings in a pool whose address range includes multiple IP addresses.
- Dynamic pools are useful, for example, to assign a certain IP address to client devices that belong to a certain VLAN.

In addition to the IP settings, the device can assign further parameters (DHCP options) to the client devices. Assigning such parameters is an smart way to automatically set up client devices as they obtain their IP settings. The device lets you specify such parameters for each pool.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons

H Add

Adds a table row.



Removes the selected table row.

Index

Displays the index number to which the table row relates. The device automatically assigns the value when you add a table row.

Active

Activates/deactivates the DHCP server function on this port.

Possible values:

marked

The DHCP server function is active.

unmarked (default setting) The DHCP server function is inactive.

IP range start

Specifies the fixed IP address for a static pool or the start IP address of an address range.

Possible values:

Valid IPv4 address (default setting: 0.0.0.0)

IP range end

Specifies the end IP address of an address range. For a static pool, keep the default setting or add the same value as specified in the *IP range start* column.

Possible values:

Valid IPv4 address (default setting: 0.0.0.0)

Port

Specifies the number of the physical port on which the requesting client device is connected.

Possible values:

► ALL (default setting)

The device assigns an IP address to the requesting client device regardless of the port on which the local device receives the DHCP request.

> <Port number>

The device assigns an IP address to the requesting client device only if the local device receives the DHCP request on the specified port.

The prerequisite is that the item - is selected from the drop-down list in the VLAN ID column.

VLAN ID

Specifies the VLAN to which the table row relates. The prerequisite is that the item *ALL* is selected from the drop-down list in the *Port* column.

Possible values:

- (default setting)
- 1...4042

The value 1 represents the VLAN in which device management is accessible in the default setting.

MAC address

Specifies the MAC address of the requesting client device.

Possible values:

- (default setting)
- For the IP address assignment, the server ignores this variable.
- Valid Unicast MAC address Specify the value with a colon separator, for example 00:11:22:33:44:55.

DHCP relay

Specifies the IP address of the DHCP relay through which the clients transmit their requests to the DHCP server. When the device receives a DHCP request through a different DHCP relay, it ignores this DHCP request.

Possible values:

- (default setting)
 - No DHCP relay specified.
- Valid IPv4 address IP address of the DHCP relay.

Client ID

Specifies the customized identifier for the client instead of the MAC address.

Possible values:

- (default setting)

The device ignores the parameter during assignment of an IP address from the pool.

Sequence of hexadecimal character pairs with 1..254 pairs separated by a space. Example: 41 42 43 44 4F

Note: If you have high security requirements and do not want to trust the clients implicitly, consider using the *remote ID* or the *circuit ID* instead of the *client ID*. The *remote ID* and the *circuit ID* are inserted by a DHCP relay and are therefore harder to spoof.

Remote ID

Specifies the remote ID. The DHCP relay inserts the remote ID into the DCHP request.

Possible values:

- (default setting)
 - The device ignores the parameter during assignment of an IP address from the pool.
- Sequence of hexadecimal character pairs with 1..254 pairs separated by a space. Example: 41 42 43 44 4F

Circuit ID

Specifies the *circuit ID*. The DHCP relay inserts the *circuit ID* into the DCHP request.

Possible values:

- default setting)
 - The device ignores the parameter during assignment of an IP address from the pool.
- Sequence of hexadecimal character pairs with 1..254 pairs separated by a space. Example: 41 42 43 44 4F

Hirschmann device

Activates/deactivates the Hirschmann multicasts. If the device in this IP address range serves only Hirschmann client devices, then activate this function.

Possible values:

marked

In this IP address range, the device serves only Hirschmann client devices. The Hirschmann multicasts are activated.

unmarked (default setting) In this IP address range, the device serves client devices of different manufacturers. The Hirschmann multicasts are deactivated.

Configuration URL

Specifies the protocol to be used as well as the name and path of the configuration file.

Possible values:

Alphanumeric ASCII character string with 0..70 characters Example: tftp://192.9.200.1/cfg/config.xml

When you leave this field blank, the device leaves this option field blank in the DHCP message.

Lease time [s]

Specifies the limited period in seconds for which the device leases each IP address.

The client device is responsible for renewing the IP address before the period expires. If the client device does not renew its IP address in time, then the IP address returns to the address pool.

Possible values:

▶ 60..220752000 (2555 d) (default setting: 86400)

▶ 4294967295 (2³²-1)

Use this value for assignments unlimited in time, and for assignments using BOOTP.

Default gateway

Specifies the IP address of the *default gateway*.

A value of 0.0.0.0 disables the attachment of the option field in the DHCP message.

Possible values:

Valid IPv4 address (default setting: 0.0.0.0)

Netmask

Specifies the mask of the network to which the client belongs.

A value of 0.0.0.0 disables the attachment of the option field in the DHCP message.

Possible values:Valid IPv4 netmask (default setting: 255.255.25.0)

WINS server

Specifies the IP address of the Windows Internet Name Server which converts NetBIOS names.

A value of 0.0.0.0 disables the attachment of the option field in the DHCP message.

Possible values:

Valid IPv4 address (default setting: 0.0.0.0)

DNS server

Specifies the IP address of the DNS server.

A value of 0.0.0.0 disables the attachment of the option field in the DHCP message.

Possible values:

Valid IPv4 address (default setting: 0.0.0.0)

Hostname

Specifies the hostname.

When you leave this field blank, the device leaves this option field blank in the DHCP message.

Possible values:

Alphanumeric ASCII character string with 0..64 characters

7.1.1.3 DHCP Server Lease Table

[Advanced > DHCP > DHCP Server > Lease Table]

This dialog displays the currently assigned IP addresses for each port.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the number of the port through which the device to which the IP address is assigned is connected.

IP address

Displays the IP address to which the table row relates.

Status

Displays the lease phase.

According to the standard for DHCP operations, there are 4 phases when assigning an IP address: Discovery, Offer, Request, and Acknowledgement.

Possible values:

► BOOTP

A DHCP client is attempting to discover a DHCP server for IP address allocation.

offering

The DHCP server is validating that the IP address is suitable for the client.

requesting

The DHCP client is acquiring the offered IP address.

bound

The DHCP server is leasing the IP address to a client.

renewing The DHCD eligent is requesting an external

The DHCP client is requesting an extension to the lease.

rebinding

The DHCP server is assigning the IP address to the client after a successful renewal.

- declined The DHCP server denied the request for the IP address.
- released

The IP address is available for other clients.

Remaining lifetime

Displays how long the assigned IP address is still valid.

Leased MAC address

Displays the MAC address of the device to which the IP address is assigned.

Gateway	Displays the Gateway IP address of the device to which the IP address is assigned.
Client ID	Displays the <i>client ID</i> of the device to which the IP address is assigned.
Remote ID	Displays the <i>remote ID</i> of the device to which the IP address is assigned.
Circuit ID	

Displays the circuit ID of the device to which the IP address is assigned.

7.2 DHCP L2 Relay

[Advanced > DHCP L2 Relay]

A network administrator uses the DHCP L2 *Relay Agent* to add DHCP client information. L3 *Relay Agents* and DHCP servers need the DHCP client information to assign an IP address and a configuration to the clients.

When active, the relay adds *Option 82* information configured in this dialog to the packets before it relays DHCP requests from the clients to the server. The *Option 82* fields provide unique information about the client and relay. This unique identifier consists of a *Circuit ID* for the client and a *Remote ID* for the relay.

In addition to the type, length, and multicast fields, the *Circuit ID* includes the VLAN ID, unit number, slot number, and port number for the connected client.

The *Remote ID* consists of a type and length field and either a MAC address, IP address, client identifier, or a user-defined device description. A client identifier is the user-defined system name for the device.

For the DHCPv6 protocol, the device uses a *Relay Agent* to add *Relay Agent* options to DHCPv6 packets exchanged between a client and a DHCPv6 server. The Lightweight DHCPv6 Relay Agent (LDRA) is described in RFC 6221.

The LDRA processes 2 types of messages:

Relay-Forward messages

The *Relay Agent* forwards *Relay-Forward* messages that contain unique information about the client. The client information includes the peer-address, meaning the IPv6 link-local address of the client and the *Interface-ID* information. The *Interface-ID* information, also known as *Option 18*, provides information that identifies the interface on which the client request was sent.

Relay-Reply messages
 The DHCPv6 server sends Relay-Reply messages. The Relay Agent validates the messages to include the information encapsulated in the initial Relay-Forward message. If the information is valid, then the Relay Agent forwards the packet to the client.

The menu contains the following dialogs:

- DHCP L2 Relay Configuration
- DHCP L2 Relay Statistics

7.2.1 DHCP L2 Relay Configuration

[Advanced > DHCP L2 Relay > Configuration]

This dialog lets you activate the relay function on an interface and VLAN. When you activate this function on a port, the device either relays the *Option 82* information or drops the information on untrusted ports. Furthermore, the device lets you specify the remote identifier.

The *Option 82* information is specific to DHCPv4 L2 Relay function. For DHCPv6 L2 Relay function, the *Option 18* information is used in the packet exchange between the client and DHCPv6 server. The device discards DHCPv6 packets received on ports that do not contain *Option 18* information.

The dialog contains the following tabs:

[Interface][VLAN ID]

Operation

Operation

Enables/disables the DHCP L2 Relay function of the device globally.

With this function enabled, DHCPv4 L2 Relay and DHCPv6 L2 Relay functions can operate at the same time in the device.

Possible values:

 On Enables the DHCP L2 Relay function in the device.
 Off (default setting)

Disables the DHCP L2 Relay function in the device.

[Interface]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Active

Activates/deactivates the DHCP L2 Relay function on the port.

The prerequisite is that you enable the function globally.

Possible values:

- marked The DHCP L2 Relay function is active.
- unmarked (default setting) The DHCP L2 Relay function is inactive.

Trusted port

Activates/deactivates the secure DHCP L2 Relay mode for the corresponding port.

Possible values:

- marked The device accepts DHCPv4 packets with Option 82 information. The device accepts DHCPv6 packets with Option 18 information.
- unmarked (default setting)
 The device discards DHCPv4 packets received on non-secure ports that contain Option 82 information.
 The device discards DHCPv6 packets received on ports that do not contain Option 18 information.

[VLAN ID]

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

VLAN ID

VLAN to which the table row relates.

Active

Activates/deactivates the DHCP L2 Relay function in this VLAN.

The prerequisite is that you enable the function globally.

Possible values:

- marked The DHCP L2 Relay function is active.
- unmarked (default setting) The DHCP L2 Relay function is inactive.

Circuit ID

Activates or deactivates the addition of the Circuit ID to the Option 82 information.

Possible values:

- marked (default setting)
 - Enables Circuit ID and Remote ID to be sent together.
- unmarked The device sends only the Remote ID.

Remote ID type

Specifies the components of the *Remote ID* for this VLAN. The *Remote ID* field displays the string the device uses as *Remote ID*.

Possible values:

▶ ip

Specifies the IP address of the device as Remote ID.

- mac (default setting) Specifies the MAC address of the device as Remote ID.
- client-id

Specifies the system name of the device as Remote ID.

▶ other

When you select this item, enter any character string in the Remote ID column.

Remote ID

Displays the *Remote ID* that the device uses for this VLAN. If the item other is selected from the *Remote ID type* drop-down list, then enter any character string.

Possible values:

▶ Alphanumeric ASCII character string with 1..32 characters

The device enters ASCII code values into the packet. If the item *client-id* or other is selected from the *Remote ID type* drop-down list, then the device processes the ASCII code of the characters. For example, when you enter the string abc, the device enters the value 616263 into the packet.

If the device does not accept the string you entered, then perform the following steps:

- \Box Click the old C button to undo the unsaved changes in the current dialog.
- □ From the *Remote ID type* drop-down list, select the item *other*.
- \Box Click the \checkmark button without modifying the string.
- □ Enter the arbitrary string.

7.2.2 DHCP L2 Relay Statistics

[Advanced > DHCP L2 Relay > Statistics]

The device monitors the data stream on the ports and displays the results in tabular form.

This table is divided into various categories to aid you in data stream analysis.

The DHCPv6 relay options are not displayed in the statistics table.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Resets the counter for the statistics to 0.

Port

Displays the port number.

Untrusted server messages with Option 82

Displays the number of DHCP server messages received with *Option 82* information on the untrusted interface.

Untrusted client messages with Option 82

Displays the number of DHCP client messages received with *Option 82* information on the untrusted interface.

Trusted server messages without Option 82

Displays the number of DHCP server messages received without *Option 82* information on the trusted interface.

Trusted client messages without Option 82

Displays the number of DHCP client messages received without *Option 82* information on the trusted interface.

7.3 DNS

[Advanced > DNS]

The menu contains the following dialogs: DNS Client

7.3.1 DNS Client

[Advanced > DNS > Client]

DNS (Domain Name System) is a service in the network that translates hostnames into IP addresses. This name resolution lets you contact other devices using their hostnames instead of their IP addresses.

Using the *Client* function the device sends requests for resolving hostnames in IP addresses to a DNS server.

The menu contains the following dialogs:

- DNS Client Global
- DNS Client Current
- DNS Client Static
- DNS Client Static Hosts

7.3.1.1 DNS Client Global

[Advanced > DNS > Client > Global]

In this dialog, you enable the *Client* function and the *Cache* function.

Operation

Operation

Enables/disables the *Client* function.

Possible values:

▶ On

The *Client* function is enabled. The device sends requests for resolving hostnames in IP addresses to a DNS server.

Off (default setting) The *Client* function is disabled.

Cache

Buttons

Flush cache

Deletes every entry from the DNS cache.

Cache

Enables/disables the Cache function.

Possible values:

On (default setting)

The *Cache* function is enabled.

The device caches up to 128 DNS server responses (hostname and corresponding IP address). When the cache contains a matching entry, the hostname of a new request the device resolves itself. This makes sending a new query to the DNS server unnecessary.

► Off

The Cache function is disabled.

7.3.1.2 DNS Client Current

[Advanced > DNS > Client > Current]

This dialog displays to which DNS servers the device sends requests for resolving hostnames in IP addresses.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Index

```
Displays the sequential number of the DNS server.
```

Address

Displays the IP address of the DNS server. The device forwards requests for resolving hostnames in IP addresses to the DNS server with this IP address.

7.3.1.3 DNS Client Static

[Advanced > DNS > Client > Static]

In this dialog, you specify the DNS servers to which the device forwards requests for resolving hostnames in IP addresses.

The device lets you specify up to 4 IP addresses yourself or to transfer the IP addresses from a DHCP server.

Configuration

Source

Specifies the source from which the device obtains the IP address of DNS servers to which the device addresses requests.

Possible values:

🕨 user

The device uses the IP addresses specified in the table.

mgmt-dhcp (default setting) The device uses the IP addresses which the DHCP server delivers to the device.

Domain name

Specifies the domain name according to RFC 1034 which the device adds to hostnames without a domain suffix.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Request timeout [s]

Specifies the time interval in seconds for sending again a request to the server.

Possible values:

▶ 0

Deactivates the function. The device does not send a request to the server again.

1..3600 (default setting: 3)

Request retransmits

Specifies, how many times the device retransmits a request.

The prerequisite is that in the Request timeout [s] field a value >0 is specified.

Possible values:

▶ 0..100 (default setting: 2)

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

- In the *Index* field, you specify the index number.
 - Possible values:

- 1..4

- The device lets you specify up to 4 external DNS servers.
- ▶ In the *IP address* field, you specify the IP address of the DNS server.
 - Possible values:
 - Valid IPv4 address
 - Valid IPv6 address



Removes the selected table row.

Index

Displays the sequential number of the DNS server. You specify the index number when you add a table row.

IP address

Specifies the IP address of the DNS server.

Possible values:

- Valid IPv4 address
- Valid IPv6 address

Active

Activates/deactivates the table row.

Prerequisites:

- In the Advanced > DNS > Client > Global dialog the DNS client function is enabled.
- In the Configuration frame, the item user is selected from the Source drop-down list.

Possible values:

- marked (default setting)
 - The table row is active.

The device sends requests to the DNS server specified in the first active table row. When the device does not receive a response from this server, it sends the requests to the DNS server specified in the next active table row. The relevant timeout is specified in the *Configuration* frame, *Request timeout* [s] field.

unmarked

The table row is inactive.

The device does not send requests to this DNS server.

7.3.1.4 DNS Client Static Hosts

[Advanced > DNS > Client > Static Hosts]

This dialog lets you specify up to 64 hostnames which you link with one IP address each. Upon a request for resolving hostnames in IP addresses, the device searches this table for a corresponding entry. When the device does not find a corresponding entry, it forwards the request.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

- In the *Index* field, you specify the index number.
 - Possible values:
 - 1..64

The device lets you specify up to 64 static hosts.

- In the Name field, you specify the hostname of the related device. Possible values:
 - Alphanumeric ASCII character string with 1..255 characters
- ▶ In the *IP* address field, you specify the IP address of the related device.

Possible values:

- Valid IPv4 address
- Valid IPv6 address



Removes the selected table row.

Index

Displays the index number to which the table row relates. You specify the index number when you add a table row.

Name

Specifies the hostname.

Possible values:

Alphanumeric ASCII character string with 1..255 characters

IP address

Specifies the IP address under which the host is reachable.

Possible values:

- Valid IPv4 address
- Valid IPv6 address

Active

Activates/deactivates the table row.

Possible values:

marked (default setting) The table row is active.

When the device receives a request for this hostname, it provides the requesting client device with the associated IP address.

unmarked

The table row is inactive.

When the device receives a DNS request for this hostname, it forwards the request to a DNS server specified in the *Advanced* > *DNS* > *Client* > *Static* dialog.

7.4 Industrial Protocols

[Advanced > Industrial Protocols]

The menu contains the following dialogs:

- IEC61850-MMS
- Modbus TCP
- EtherNet/IP
- OPC UA Server
- Service Discovery
- ▶ PROFINET

7.4.1 IEC61850-MMS

[Advanced > Industrial Protocols > IEC61850-MMS]

The IEC61850-MMS is a standardized industrial communication protocol from the International Electrotechnical Commission (IEC). For example, automatic switching equipment uses this protocol when communicating with power station equipment.

The packet orientated protocol defines a uniform communication language based on the transport protocol, TCP/IP. The protocol uses a Manufacturing Message Specification (MMS) server for client server communications. The protocol includes functions for SCADA, Intelligent Electronic Device (IED) and the network control systems.

Note: IEC61850/MMS does not provide any authentication mechanisms. If the write access for IEC61850/MMS is activated, then every client that can access the device using TCP/IP is capable of changing the settings of the device. As a result, incorrect device settings and potential network interruptions may occur.

Activate the write access only if you have taken additional measures (for example Firewall, VPN, etc.) to reduce possible unauthorized access.

This dialog lets you specify the following MMS server settings:

- Activates/deactivates the MMS server.
- Activates/deactivates the write access to the MMS server.
- The MMS server TCP Port.
- The maximum number of MMS server sessions.

Operation

Operation

Enables/disables the IEC61850-MMS server.

Possible values:

🕨 On

The IEC61850-MMS server is enabled.

off (default setting) The *IEC61850-MMS* server is disabled. The IEC61850 MIBs stay accessible.

Information

Status

Displays the current *IEC61850-MMS* server status.

Possible values:

- unavailable
- starting
- running
- stopping

haltederror

Active sessions

Displays the number of active MMS server connections.

Configuration

Buttons



Copies the ICD file to your PC.

Write access

Activates/deactivates the write access to the MMS server.

Possible values:

marked

The write access to the MMS server is activated. This setting lets you change the device settings using the IEC 61850 MMS protocol.

unmarked (default setting) The write access to the MMS server is deactivated. The MMS server is accessible as read-only.

Technical key

Specifies the IED name.

The IED name is eligible independently of the system name.

Possible values:

Alphanumeric ASCII character string with 0..32 characters The device accepts the following characters:

- -- 0..9
- 0...s
- A...Z (default setting: KEY)

To get the MMS server to use the IED name, click the \checkmark button and restart the MMS server. The connection to connected clients is then interrupted.

TCP port

Specifies TCP port for MMS server access.

Possible values:

```
    1..65535 (2<sup>16</sup>-1) (default setting: 102)
Exception: Port 2222 is reserved for internal functions.
```

Note: The server restarts automatically after you change the port. In the process, the device terminates open connections to the server.

Sessions (max.)

Specifies the maximum number of MMS server connections.

Possible values:

1..15 (default setting: 5)

7.4.2 Modbus TCP

[Advanced > Industrial Protocols > Modbus TCP]

Modbus TCP is a protocol used for Supervisory Control and Data Acquisition (SCADA) system integration. *Modbus TCP* is a vendor-neutral protocol used to monitor and control industrial automation equipment such as Programmable Logic Controllers (PLC), sensors and meters.

This dialog lets you specify the parameters of the protocol. To monitor and control the parameters of the device, you need an application with an Human-Machine Interface and the memory mapping table. Refer to the tables located in the "Configuration" user manual for the supported objects and memory mapping.

In the dialog, you can enable the function, activate the write access, and specify on which TCP port the Human-Machine Interface polls for data. You can also specify the number of sessions that can be open at the same time.

Note: Activating the *Modbus TCP* write-access can cause an unavoidable security risk, because the protocol does not authenticate user access.

To help minimize the unavoidable security risks, specify the IP address range located in the *Device* Security > Management Access dialog. Enter only the IP addresses assigned to your devices before enabling the function. Furthermore, the default setting for monitoring function activation in the *Diagnostics* > Status Configuration > Security Status dialog, Global tab, is active.

Operation

Operation

Enables/disables the *Modbus TCP* server in the device.

Possible values:

▶ On

The *Modbus TCP* server is enabled.

Off (default setting)
 The Modbus TCP server is disabled.

Configuration

Write access

Activates/deactivates the write access to the Modbus TCP parameters.

Note: Activating the *Modbus TCP* write-access can cause an unavoidable security risk, because the protocol does not authenticate user access.

Possible values:

marked (default setting)

The *Modbus TCP* server read/write access is active. This lets you change the device settings using the *Modbus TCP* function.

unmarked The Modbus TCP server read-only access is active.

TCP port

Specifies the TCP port number that the Modbus TCP server uses for communication.

Possible values:

<TCP Port number> (default setting: 502) Specifying 0 is not allowed.

Sessions (max.)

Specifies the maximum number of concurrent sessions that the Modbus TCP server maintains.

Possible values:

▶ 1..5 (default setting: 5)

7.4.3 EtherNet/IP

[Advanced > Industrial Protocols > EtherNet/IP]

This dialog lets you specify the *EtherNet/IP* settings. You have the following options:

- Enable/disable the *EtherNet/IP* function in the device.
- Specify a VLAN which forwards the *EtherNet/IP* packets exclusively.
- Activate/deactivate the read/write capability of the *EtherNet/IP* function.
- Download the Electronic Data Sheet (EDS) file from the device.

Operation

Operation

Enables/disables the *EtherNet/IP* function in the device.

Possible values:

► On

- The *EtherNet/IP* function is enabled.
- *Off* (default setting)
 The *EtherNet/IP* function is disabled.

Configuration

Buttons



Copies the following information in a zip file onto your PC:

- · Electronic Data Sheet (EDS) with device related information
- Device icon

Write access

Activates/deactivates the read/write capability of the EtherNet/IP function.

Possible values:

marked

The EtherNet/IP function accepts set/get requests.

unmarked (default setting) The *EtherNet/IP* function accepts only get requests.

VLAN Configuration

VLAN ID

Specifies the VLAN to be used for the *EtherNet/IP* function.

Possible values:

mgmt (default setting)

The *EtherNet/IP* function uses the VLAN, in which the device management is accessible through the network. You specify this VLAN in the *Basic Settings > Network > Global* dialog, *Management interface* frame, *VLAN ID* field.

▶ 1..4042

The *EtherNet/IP* function uses the selected VLAN. Prerequisites:

- The VLAN is already set up in the device.
 See the Switching > VLAN > Configuration dialog.
- The port over which the device forwards the *EtherNet/IP* packets is a member of the VLAN you assign and transmits the data packets with a VLAN tag.
- See the Switching > VLAN > Configuration dialog.
 The IP Access Restriction function is enabled.
 See the Device Security > Management Access > IP Access Restriction dialog.

7.4.4 OPC UA Server

[Advanced > Industrial Protocols > OPC UA Server]

The protocol *OPC UA* is a standardized protocol for industrial communication defined in the standard IEC 62541. The *OPC UA Server* function monitors the *OPC UA* information model data for the industrial automation equipments such as Programmable Logic Controllers (PLC), sensors and meters.

To monitor the OPC UA information model data of the connected end devices, use an OPC UA client application.

In this dialog, you enable the *OPC UA Server* function and specify the required settings. You can also specify the number of sessions allowed to be open at the same time. The dialog lets you manage the *OPC UA* user accounts required to access the device using a *OPC UA* client application. Every *OPC UA* user requires an active *OPC UA* user account to gain access to the *OPC UA* server of the device.

Operation

Operation

Enables/disables the OPC UA Server function in the device.

Possible values:

▶ On

The OPC UA Server function is enabled.

Off (default setting)
 The OPC UA Server function is disabled.

Configuration

Listening port

Specifies the TCP port number that the OPC UA Server server uses for communication.

Possible values:

 1..65535 (2¹⁶-1) (default setting: 4840) Exception: Port 2222 is reserved for internal functions. Sessions (max.)

Specifies the maximum number of *OPC UA* connections to the device that can be set up simultaneously. Each accessing *OPC UA* client application establishes a separate *OPC UA* connection to the device.

Possible values:

1..5 (default setting: 5)

Security policy

Specifies the authentication and encryption protocol that the device applies for the OPC UA user.

Possible values:

- none (default setting) The OPC UA user does not need to authenticate oneself.
- basic128Rsa15 The OPC UA user authenticates using the Basic128Rsa15 protocol.
- basic256 The OPC UA user authenticates using the Basic256 protocol.

basic256Sha256 The OPC UA user authenticates using the Basic256Sha256 protocol.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the *Create* window to add a table row. The device lets you specify up to 4 *OPC UA* user accounts.

In the *User name* field, you specify the name of the *OPC UA* user account. Possible values: Alphanumeric ASCII character string with 1..32 characters

The device accepts the following characters:

a..z
A..Z
0..9

× Remove

Removes the selected table row.

User name

Displays the name of the OPC UA user having access to the device using an OPC UA client application.

Password

Specifies the password that the user applies to access the device using an OPC UA client application.

Displays ***** (asterisks) instead of the password with which the user logs in. To change the password, click the relevant field.

Possible values:

- Alphanumeric ASCII character string with 6..64 characters The device accepts the following characters:
 - a..z
 A..Z
 0..9
 !#\$%&'()*+,-./:;<=>?@[\]^_`{}~

Access role

Specifies the role that regulates the access of the OPC UA user using an OPC UA client application.

Possible values:

readOnLy (default setting)

The OPC UA user account has read-only access to the device. The OPC UA user can view the OPC UA information model data of the connected end devices.

Active

Activates/deactivates the OPC UA user account in the device.

Possible values:

marked

The OPC UA user account is active. The device accepts the login of an OPC UA user with this user name.

unmarked (default setting)

The OPC UA user account is inactive. The device rejects the login of an OPC UA user with this user name.

7.4.5 Service Discovery

[Advanced > Industrial Protocols > Service Discovery]

Service Discovery is part of a series of technologies summarized by the term Zero-configuration networking (zeroconf). Service Discovery uses multicast DNS (mDNS) and DNS service discovery (DNS-SD) to advertise the services offered by the device to other devices in the network that request the service. The device currently supports the *ITxPT Module Inventory* service. Additional services may follow in future releases.

Devices that support Service Discovery can automatically discover the available services on the network without having information about which devices are available. In public transportation, for example, such devices can be ticketing systems, passenger information systems, or vehicle tracking systems.

Devices that subscribe to the services will detect a new device as soon as you connect it to the network, and read its service data. For example, when you install a ticketing system in the network of a public transportation vehicle, the ticketing system needs to communicate with the existing passenger information system to deliver real-time updates on ticket sales and availability.

In this dialog, you select and set up the services that the device will advertise.

The dialog contains the following tabs: [ITxPT Module Inventory]

[ITxPT Module Inventory]

The *ITxPT Module Inventory* service is part of the Information Technology for Public Transport (ITxPT) specification.

The intended use of the *ITxPT Module Inventory* service is module inventory in networks of vehicles. The *ITxPT Module Inventory* service lets devices subscribing to the service automatically inventory the modules installed in the on-board IP network of vehicles. Modules in the sense of ITxPT might be other Hirschmann devices or devices from the on-board network of the vehicle. For example, the on-board passenger information system. The service lets you collect information about the modules and monitor their status.

The device provides the information through SRV records and TXT records.

- The SRV record contains the location.
- The device provides the TXT record through mDNS.
- The TXT record contains information about the service.

The device transmits the *TXT record* once in the following cases:

- After an mDNS query containing the address _itxpt_socket._tcp.local. The device transmits the *TXT record* in response to multicast or unicast requests in the network for services offered by the device.
- Without a request
 - As soon as the Service Discovery function and the *ITxPT Module Inventory* service are enabled.
 See the Operation frame.
 - If the Service Discovery function and the *ITxPT Module Inventory* service are enabled, and the device detects changes regarding the global status or the port status of other devices in the network. Other devices might be other Hirschmann devices or devices from the on-board network of the vehicle. For example, the on-board passenger information system.

Operation

Operation

Enables/disables the *Service Discovery* function. Simultaneously, the device activates/deactivates the *ITxPT Module Inventory* service to monitor the link status or the PoE status of the device.

Possible values:

► On

The Service Discovery function is enabled. The *ITxPT Module Inventory* service is active.

The device performs the following actions:

- On ports for which the checkbox in the *Link* column is marked: Monitoring the link status.
- Writing the link status into the *xstatus* attribute of the *TXT record*.
- On ports for which the checkbox in the *PoE* column is marked: Monitoring the PoE status.
- Writing the PoE status into the xstatus attribute of the TXT record.

• The device sends the TXT record one time to the devices subscribing to this service.

The device sends the *TXT record* without a request in the following cases:

- When you enable the Service Discovery function.
- or
- When the device detects a change regarding the global status or the port status of other devices in the network. Other devices might be other Hirschmann devices or devices from the on-board network of the vehicle. For example, the on-board passenger information system.

Off (default setting)

The Service Discovery function and the ITxPT Module Inventory service are disabled.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port

Displays the port number.

Link

Activates/deactivates the ITxPT Module Inventory service to monitor the link status of this port.

Possible values:

marked

The device performs the following actions:

- Monitoring the link status of this port.
- Writing the link status into the *xstatus* attribute of the *TXT record*.
- Transmitting the TXT record once, without a request being required.

Other devices subscribing to this service data can analyze the data contained in the *TXT record*. Other devices might be other Hirschmann devices or devices from the on-board network of the vehicle. For example, the on-board passenger information system.

unmarked (default setting) The device does not monitor the link status of this port. Activates/deactivates the ITxPT Module Inventory service to monitor the PoE status of this port.

Possible values:

marked

The device performs the following actions:

- Monitoring the PoE status of this port.
- Writing the PoE status into the *xstatus* attribute of the *TXT record*.

• Transmitting the *TXT record* once, without a request being required.

Other devices subscribing to this service data can analyze the data contained in the *TXT record*. Other devices might be other Hirschmann devices or devices from the on-board network of the vehicle. For example, the on-board passenger information system.

unmarked (default setting)

The device does not monitor the PoE status of this port.

PoE

7.4.6 **PROFINET**

[Advanced > Industrial Protocols > PROFINET]

This dialog lets you set up the PROFINET protocol on this device used in conjunction with PROFINET Controllers and PROFINET devices. The device bases the *PROFINET* function on the Siemens V2.2 PROFINET stack for common Ethernet controllers. The PROFINET protocol implemented in the device conforms to Class B for real time responses according to IEC 61158.

Prerequisites for using the PROFINET function

Functions that directly affect the *PROFINET* function require the following default values to be changed. If you have obtained the device as a specially available *PROFINET* variant, then these values are already predefined:

PROFINET

Advanced > Industrial Protocols > PROFINET dialog

- Operation frame
 Operation = 0n
- Configuration frame Name of station field = <empty>

Network

Basic Settings > Network > IPv4 dialog

- Management interface frame IP address assignment radio button = Local
- HiDiscovery protocol v1/v2 frame Access drop-down list = read0nly
- IP parameter frame
 IP address field = 0.0.0.0
 Netmask field = 0.0.0.0
 Gateway address field = 0.0.0.0

VLAN

Switching > Global dialog

Configuration frame
 VLAN-unaware mode checkbox = marked

LLDP

Diagnostics > LLDP > Configuration dialog

 Configuration frame Transmit interval [s] field = 5 Transmit delay [s] field = 1

Operation

Operation

Enables/disables the *PROFINET* function in the device.

Possible values:

▶ On

The *PROFINET* function is enabled.

Off (default setting)
 The *PROFINET* function is disabled.

Configuration

Buttons



Copies the GSDML file onto your PC.

Name of station

Specifies the name of the device.

Possible values:

Alphanumeric ASCII character string with 0..240 characters The device prohibits you from using a number as the first character.

Information

Active application relations

Displays how many application relations are active.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Port


Displays the port number.

DCP mode

Specifies the data stream direction on the port to monitor for DCP packets.

The Programmable Logic Controllers (PLCs) detects PROFINET devices using the Discovery and Configuration Protocol (DCP).

The DCP identify request packets are multicast, the responses from the agents are unicast. Regardless of the settings, the device forwards the received DCP packets to other ports whose setting is either *egress* or *both*.



Possible values:

▶ none

The agent does not respond to packets received on this port. The port does not forward packets received on other ports.

ingress

The agent responds to packets received on this port. The port does not forward packets received on other ports.

egress

The agent does not respond to packets received on this port. The port forwards packets received on other ports.

both (default setting)

The agent responds to packets received on this port. The port forwards packets received on other ports.

7.5 Tracking

[Advanced > Tracking]

The tracking function lets you monitor what are known as tracking objects. Examples of monitored tracking objects are the link status of an interface or the reachability of a remote router or end device.

The device forwards status changes of the tracking objects to the registered applications, for example to the routing table or to a VRRP instance. The applications then react to the status changes:

- In the routing table, the device activates/deactivates the route linked to the tracking object.
- The VRRP instance linked to the tracking object reduces the priority of the virtual router so that a backup router takes over the role of the master.
- When the status of the tracking object changes, the device enables/disables the interface linked to the tracking object. The device displays the corresponding application in the *Advanced* > Tracking > *Applications* dialog.

If you set up the tracking objects in the *Advanced* > *Tracking* > *Configuration* dialog, then you can link applications with the tracking objects:

- You link static routes with a tracking object in the *Routing > Routing Table* dialog, *Track name* column.
- You link virtual routers with a tracking object in the *Routing* > *L3-Redundancy* > *VRRP* > *Tracking*

dialog. Click the $\stackrel{\text{\tiny HH}}{+}$ button to open the *Create* window and select the tracking object from the *Track name* drop-down list.

• You link the interface status with a tracking object in the *Basic Settings > Port* dialog, *Track name* column.

The menu contains the following dialogs:

- Tracking Configuration
- Tracking Applications

7.5.1 Tracking Configuration

[Advanced > Tracking > Configuration]

In this dialog, you set up the tracking objects.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Buttons



Opens the Create window to add a table row.

From the *Type* drop-down list, you select the type of the tracking object.

Possible values:

interface

The device monitors the link status of its physical ports or of its link aggregation, LRE or VLAN router interface.

Logical

The device monitors tracking objects logically linked to each other and thus enables complex monitoring tasks.

 In the *Track ID* field, you specify the identification number of the tracking object. Possible values:

▶ 1..256

x Remove

Removes the selected table row.

Туре

Specifies the type of the tracking object.

Possible values:

▶ interface

The device monitors the link status of its physical ports or of its link aggregation, LRE or VLAN router interface.

Logical

The device monitors tracking objects logically linked to each other and thus enables complex monitoring tasks.

Track ID

Specifies the identification number of the tracking object.

Possible values:

▶ 1..256

This range is available to every type (*interface*, *ping* and *logical*).

Track name

Displays the name of the tracking object made up of the values displayed in the *Type* and *Track ID* columns.

Active

Activates/deactivates the monitoring of the tracking object.

Possible values:

- marked
 - Monitoring is active. The device monitors the tracking object.
- unmarked (default setting) Monitoring is inactive.

Description

Specifies the description.

Here you describe what the device uses the tracking object for.

Possible values:

Alphanumeric ASCII character string with 0..255 characters

Status

Displays the monitoring result of the tracking object.

Possible values:

🕨 up

The monitoring result is positive:

- The link status is active.
 - or
- The remote router or end device is reachable.
 - or
- The result of the logical link is TRUE.
- 🕨 down

The monitoring result is negative:

- The link status is inactive.
- or
- The remote router or end device is not reachable.

or

The result of the logical link is FALSE.

notReady

The monitoring of the tracking object is inactive. You activate the monitoring in the *Active* column.

Changes

Displays the number of status changes since the tracking object has been activated.

Last changed

Displays the time of the last status change.

Send trap

Activates/deactivates the sending of an SNMP trap when someone activates or deactivates the tracking object.

Possible values:

marked

If someone activates or deactivates the tracking object in the *Active* column, then the device sends an SNMP trap.

unmarked (default setting) The device does not send an SNMP trap.

Port

Specifies the interface to be monitored for tracking objects of the *interface* type.

Possible values:

- <Interface number>
 - Number of the physical ports or of the link aggregation, LRE or VLAN router interface.
- no Port

No tracking object of the *interface* type.

Link up delay [s]

Specifies the period in seconds after which the device evaluates the monitoring result as positive. If the link has been active on the interface for longer than the period specified here, then the *Status* column displays the value *up*.

Possible values:

```
0..255
-
```

No tracking object of the *Logical* type.

```
Link down delay [s]
```

Specifies the period in seconds after which the device evaluates the monitoring result as negative. If the link has been inactive on the interface for longer than the period specified here, then the *Status* column displays the value *down*.

Possible values:

0..255

-

No tracking object of the *interface* type.

If the link to every aggregated port is interrupted, then Link aggregation, LRE and VLAN router interfaces have a negative monitoring result.

If the link to every physical port and link-aggregation interface which is a member of the VLAN is interrupted, then a VLAN router interface has a negative monitoring result.

Logical operand A

Specifies the first operand of the logical link for tracking objects of the *LogicaL* type.

Possible values:

Tracking objects set up

No tracking object of the *logical* type.

Logical operand B

Specifies the second operand of the logical link for tracking objects of the *LogicaL* type.

Possible values:

Tracking objects set up

- -

No tracking object of the *logical* type.

Operator

Links the tracking objects specified in the Logical operand A and Logical operand B fields.

Possible values:

► and

Logical AND link

l or

Logical OR link

No tracking object of the *Logical* type.

7.5.2 Tracking Applications

[Advanced > Tracking > Applications]

In this dialog, you see which applications are linked with the tracking objects.

The following applications can be linked with tracking objects:

- You link static routes with a tracking object in the *Routing > Routing Table* dialog, *Track name* column.
- You link virtual routers with a tracking object in the *Routing > L3-Redundancy > VRRP > Tracking* dialog. Click the ## button to open the *Create* window and select the tracking object from the
- Track name drop-down list.
- You link the interface status with a tracking object in the *Basic Settings > Port* dialog, *Track name* column.

Table

For information on how to customize the appearance of the table, see "Working with tables" on page 18.

Туре

Displays the type of the tracking object.

Track ID

Displays the identification number of the tracking object.

Application

Displays the name of the application that is linked with the tracking object.

Possible values:

- Tracking objects of the *logical* type
- Static routes
- Virtual router of a VRRP instance
- Interface status

Track name

Displays the name of the tracking object made up of the values displayed in the *Type* and *Track ID* columns.

7.6 Command Line Interface

[Advanced > CLI]

This dialog lets you access the device using the Command Line Interface.

Prerequisites:

- In the Device Security > Management Access > Server dialog, SSH tab the SSH server is enabled.
- On your workstation, install a SSH-capable client application which registers a handler for URLs starting with ssh:// in your operating system.

Buttons

Open SSH connection

Opens the SSH-capable client application.

When you click the button, the web application passes the URL of the device starting with ssh:// and the user name of the currently logged in user.

If the web browser finds an SSH-capable client application, then the SSH-capable client establishes a connection to the device management using the SSH protocol.

A Index

0-9
802.1D/p mapping
802.1X
Α
Access control
Access control lists
Access restriction
ACL
Address conflict detection
Aging time
Alarm
ARP
ARP inspection
ARP table
Audit trail
Authentication history
Authentication list
Auto disable
B
Boundary clock
Bridge
C
C CA (Certification Authority)
C CA (Certification Authority) Cable diagnosis 458
C CA (Certification Authority) Cable diagnosis Certificate 23, 46, 130, 147, 148, 412, 443, 452
C CA (Certification Authority) Cable diagnosis Certificate Certificate 23, 46, 130, 147, 148, 412, 443, 452 Certificate Revocation List (CRL)
C CA (Certification Authority) Cable diagnosis Certificate Cartificate Revocation List (CRL) Certification Authority (CA)
C CA (Certification Authority) Cable diagnosis Certificate Castron Castron
C CA (Certification Authority) Cable diagnosis Certificate 23, 46, 130, 147, 148, 412, 443, 452 Certificate Revocation List (CRL) 130, 443, 452 Certification Authority (CA) 130, 443, 452 CLI Command line interface
C CA (Certification Authority) Cable diagnosis Certificate 23, 46, 130, 147, 148, 412, 443, 452 Certificate Revocation List (CRL) Certification Authority (CA) Certification Authority (CA) Command line interface 155 Community names
C CA (Certification Authority) 130, 443, 452 Cable diagnosis 458 Certificate 23, 46, 130, 147, 148, 412, 443, 452 Certificate Revocation List (CRL) 130, 443, 452 Certification Authority (CA) 130, 443, 452 CLI 155 Command line interface 155 Community names 157 Configuration check 431
C CA (Certification Authority) Cable diagnosis Certificate 23, 46, 130, 147, 148, 412, 443, 452 Certificate Revocation List (CRL) Certification Authority (CA) Certification Authority (CA) Command line interface 155 Community names

D

Daylight saving time
Default gateway
Device software
Device software backup
Device status
DHCP L2 Relay
DHCP server
DHCP snooping
DHCPv6 L2 Relay
Digital certificate
DLR (depends on hardware) 328
DNS
DNS cache
DNS client
Domain name system
DoS 197
Download EDS for EtherNet/IP 536
DSCP
Duplicate Address Detection
Dynamic ARP inspection
E

APOL	82
gress rate limiter	44
nail notification	41
	42
NVM	04
herNet/IP	36
herNet/IP, Download EDS	36
herNet/IP, Read/write capability	36
herNet/IP, VLAN	36
<i>v</i> ent severity	02
ternal memory	04
-	

F

AQ	
Fast MRP	384
DB (MAC address table)	247
Filter MAC addresses	247
Fingerprint	148
Flash memory	430
Flow control	241

G

0																							
GARP	 	 	 	 	 		 	 	 	 		 			 				 	 		 27	73
GMRP	 	 	 	 	 		 	 	 	 		 			 				 	 		 27	74
Guards	 	 	 	 	 		 	 	 	 	-	 			 				 	 		 36	39
GVRP	 	 	 	 	 	•	 	 	 •	 	•	 		•	 • •	•	 -		 •	 		 27	76

н				
Hardware clock			 	 75
Hardware state			 	
HiDiscovery			 	 30, 411, 507
HIPER Ring			 	
HSR (depends	on hard	lware)	 	
HTML			 	
HTTP			 	
				409
HTTPS			 	

L

IAS 125, 1 IEC61850-MMS 412, 5 IEEE 802.1X 1 IGMP snooping 72, 2	
IEEE 802.1X	86
	531
IGMP speeping 72.2	
	249
Industrial HiVision	
Ingress filtering	313
Ingress rate limiter	
Integrated authentication server	
IP access restriction	50
IP address conflict detection 4	33
IP DSCP mapping	282
IPv4 rule	221

L

Relay (DHCP)	518
)AP	125
nk aggregation	374
nk backup	381
DP	481
ad/save	42
g file	506
gin banner	159
op protection	418
ops	352

м

IN	
MAC Address Conflict Detection	
MAC flood	
MAC rule	
MAC spoof	
MAC address table (forwarding database)	72, 247
Management access	
Management access statistics	72
Management VLAN	
Manufacturing message specification	531
Media redundancy protocol	
MMRP	
MMS	531
Modbus TCP	412, 534
Modules	403, 417
MRP	
MRP-IEEE	
MSTP	
MTU	60
MVRP	

Ν		
Network load		. 62
NVM	18, 4 ⁻	1, 47
Ρ		
Parallel redundancy protocol (depends on hardware)		
Password		
Password length		
Persistent log file		
Persistent logging		
PoE		
Port clients		
Port configuration		
Port mirroring		
Port monitor		
Port priority		
Port security		
Port statistics		
Port VLAN		
Port-based access control		
Power over Ethernet		
Power supply		
Pre-Login banner		
Priority queue		
PROFINET		
PRP (depends on hardware)		331
Q		
Queue management		284
Queues		
		2.0
R		
RADIUS	. 125,	187
RAM		. 46
RAM test		439
Rate limiter		244
RCP		397
Read/write capability for EtherNet/IP		536
Reboot		
Redundant coupling protocol		397
Relay (DHCP)		518
Request interval		
Ring structure		
Ring/Network coupling		
RNC		
Root bridge		
RSTP	. 352,	353

S

Secure Shell (SSH)	
Self-test	
Serial interface	410
Settings	. 42
Severity	, 502
sFlow	494
SFP module	457
Signal contact	, 414
SNMP server	,
SNMP traps 60, 65, 67, 167, 353, 378, 402, 407, 416, 422, 435, 463,	, 550
SNMPv1/v2	
SNTP	
SNTP client	
SNTP server	
Software backup	
Software update	
Spanning tree protocol	
SSH server	
Sub Ring	
Support information	
Support information (ZIP archive)	
Syslog	
System information	
System log	
System monitor	
System time	. 75
T	
Technical questions	
Telnet server	
Temperature	
Threshold values network load	
Topology discovery	
Tracking	
Training courses	
Transparent clock	
Trap destination	
Traps	
Trust mode	
Twisted-pair	458
U	
Unaware mode	2/1
Unsigned device software (allow upload)	
Uptime	
User administration	
Utilization	
UIIIZauun	. 02
V	
Virtual local area network	306
VLAN	
VLAN configuration	
VLAN for EtherNet/IP	
· • • • • • • • • • • • • • • • • • • •	536
VLAN ports	

W

	,
Web server	145. 146
Watchdog	. 42, 51

Z

ZIP archive with support information	

B Technical support

Technical questions

For technical questions, please contact any Hirschmann dealer in your area or Hirschmann directly. You find the addresses of our partners on the Internet at www.belden.com.

For technical support, visit hirschmann-support.belden.com. This site also includes a free of charge knowledge base and a software download section.

Technical Documents

The current manuals and operating instructions for Hirschmann products are available at doc.hirschmann.com.

Customer Innovation Center

The Customer Innovation Center is ahead of its competitors on three counts with its complete range of innovative services:

- Consulting incorporates comprehensive technical advice, from system evaluation through network planning to project planning.
- Training offers you an introduction to the basics, product briefing and user training with certification. You find the training courses on technology and products currently available at www.belden.com/solutions/customer-innovation-center.
- Support ranges from the first installation through the standby service to maintenance concepts.

With the Customer Innovation Center, you decide against any compromise in any case. Our clientcustomized package leaves you free to choose the service components you want to use.

C Readers' Comments

What is your opinion of this manual? We are constantly striving to provide as comprehensive a description of our product as possible, as well as important information to assist you in the operation of this product. Your comments and suggestions help us to further improve the quality of our documentation.

Your assessment of this manual:

	Very Good	Good	Satisfactory	Mediocre	Poor
Precise description	0	0	0	0	0
Readability	0	0	0	0	0
Understandability	0	0	0	0	0
Examples	0	0	0	0	0
Structure	0	0	0	0	0
Comprehensive	0	0	0	0	0
Graphics	0	0	0	0	0
Drawings	0	0	0	0	0
Tables	0	0	0	0	0

Did you discover any errors in this manual? If so, on what page?

Suggestions for improvement and additional information:

General comments:

Sender:

Company / Department:

Name / Telephone number:

Street:

Zip code / City:

E-mail:

Date / Signature:

Dear User,

Please fill out and return this page

- as a fax to the number +49(0)7127/14-1600 or
- per mail to
 - Hirschmann Automation and Control GmbH Department IRD-NT Stuttgarter Str. 45-51 72654 Neckartenzlingen Germany





User Manual

Configuration Rail Switch Power Enhanced HiOS-2A The naming of copyrighted trademarks in this manual, even when not specially indicated, should not be taken to mean that these names may be considered as free in the sense of the trademark and tradename protection law and hence that they may be freely used by anyone.

© 2024 Hirschmann Automation and Control GmbH

Manuals and software are protected by copyright. All rights reserved. The copying, reproduction, translation, conversion into any electronic medium or machine scannable form is not permitted, either in whole or in part. An exception is the preparation of a backup copy of the software for your own use.

The performance features described here are binding only if they have been expressly agreed when the contract was made. This document was produced by Hirschmann Automation and Control GmbH according to the best of the company's knowledge. Hirschmann reserves the right to change the contents of this document without prior notice. Hirschmann can give no guarantee in respect of the correctness or accuracy of the information in this document.

Hirschmann can accept no responsibility for damages, resulting from the use of the network components or the associated operating software. In addition, we refer to the conditions of use specified in the license contract.

You find the latest user documentation for your device at: doc.hirschmann.com

Hirschmann Automation and Control GmbH Stuttgarter Str. 45-51 72654 Neckartenzlingen Germany

Contents

	Safety instructions	13
	About this Manual	15
	Кеу	
	Replacing a device	17
1	User interfaces	
1.1	Graphical User Interface	19
1.2	Command Line Interface	20
1.2.1	Preparing the data connection	20
1.2.2	Access to the Command Line Interface using the Secure Shell (SSH)	20
1.2.3	Access to the Command Line Interface using the serial interface	
1.2.4	Mode-based command hierarchy	24
1.2.5	Executing the commands	
1.2.6	Structure of a command	
1.2.7	Examples of commands	31
1.2.8	Input prompt	
1.2.9	Key combinations	
1.2.10	Data entry elements	
1.2.11	Use cases	
1.2.12	Service Shell	
1.3	System monitor	
1.3.1	Functional scope	
1.3.2	Starting the System Monitor	40
2	Specifying the IP parameters	43
2.1	IP parameter basics	43
2.1.1	IPv4	
2.1.2	IPv6	47
2.2	Specifying the IP parameters using the Command Line Interface	52
2.2.1	IPv4	
2.2.2	IPv6	
2.3	Specifying the IP parameters using HiDiscovery	
2.4	Specifying the IP parameters using the Graphical User Interface	
2.4.1	IPv4	
2.4.2	IPv6	
2.5	Specifying the IP parameters using BOOTP	59
2.6	Specifying the IP parameters using DHCP	
2.6.1		
2.6.2	IPv6	
2.7	Management address conflict detection.	
2.7.1	Active and passive detection	
2.8	Duplicate Address Detection function	
2.0		04
3	Access to the device	65
3.1	First login (Password change)	65

3.2	Authentication lists	6
3.2.1	Applications \ldots \ldots \ldots ε	
3.2.2	Policies	
3.2.3	Managing authentication lists	
3.2.4	Adjusting the settings	
3.3	User management	39
3.3.1	Access roles	39
3.3.2	Managing user accounts	′1
3.3.3	Default user accounts	
3.3.4	Changing default passwords	′1
3.3.5	Setting up a new user account	
3.3.6	Deactivating the user account	′3
3.3.7	Adjusting policies for passwords	′4
3.4	LDAP function	'6
3.4.1	Coordination with the server administrator	' 6
3.4.2	Setting up LDAP.	77
3.5	SNMP access.	30
3.5.1	SNMPv1/v2 access	30
3.5.2	SNMPv3 access	30
3.5.3	SNMPv3 traps	31
4	Synchronizing the system time in the network	35
- 4.1	Setting the time	
4.2	Automatic daylight saving time changeover	
4.2.1	Setting daylight saving time using pre-defined profiles	
4.2.2	Setting daylight saving time manually	
4.3	Synchronizing time in the network with SNTP	
4.3.1	Preparation.	
4.3.2 4.3.3	Defining settings of the SNTP client.	
	Specifying SNTP server settings	
4.4	Synchronizing time in the network with PTP	
4.4.1	Types of clocks	
4.4.2	Best Master Clock algorithm	
4.4.3	Delay measurement.	
4.4.4	PTP domains	
4.4.5	Using PTP	
4.5	Synchronizing time in the network with 802.1AS	
4.5.1	Instances and domains	
4.5.2	Best Master Clock algorithm	
4.5.3	Enabling the 802.1AS function.	
4.5.4	Disabling the 802.1AS function globally.	
4.5.5	Disabling the 802.1AS function for an instance	
4.5.6	Disabling the 802.1AS function on a port10	10
5	Managing configuration profiles	
5.1	Detecting changed settings	
5.1.1	Volatile memory (RAM) and non-volatile memory (NVM)	
5.1.2	External memory (ACA) and non-volatile memory (NVM))2
5.2	Saving the settings)3
5.2.1	Saving the configuration profile in the device)3
5.2.2	Saving the configuration profile in the external memory)5
5.2.3	Backing up the configuration profile on a remote server)5
5.2.4	Exporting a configuration profile)6

5.3 5.3.1 5.3.2	Loading settingsActivating a configuration profile	108 108
5.3.3	Importing a configuration profile	
5.4	Resetting the device to the default setting	
5.4.1	Using the Graphical User Interface or Command Line Interface	
5.4.2	Using the System Monitor	113
6	Updating the device software	115
6.1	Loading a previous device software version	115
6.2	Software update from the PC	116
6.3	Software update from a server	117
6.3.1	Software update from an FTP server	117
6.3.2	Software update from a TFTP server	
6.3.3	Software update from an SFTP server	
6.3.4	Software update from an SCP server	
6.4	Software update from the external memory	
6.4.1	Manually—initiated by the administrator	
6.4.2	Automatically—initiated by the device	122
7	Configuring the ports	125
7.1	Enabling/Disabling the port	125
7.2	Selecting the operating mode	126
8	Assistance in the protection from unauthorized access	127
8.1	Changing the SNMPv1/v2 community	
8.2	Disabling write access for SNMPv1/v2	
8.3	Disabling SNMPv1/v2	
8.4	Disabling HTTP	
8.5	Disabling Telnet	
8.6	Disabling the HiDiscovery access	
8.7	Restricting access to device management.	
8.7.1	Restricting access from a specific IP address range	
8.8	Adjusting the session timeouts.	
8.9	Deactivating the unused modules	
8.10	Making SSH hosts known to the device	
9	Controlling the data traffic	1/1
9 .1	Helping protect against DoS attacks	
9.1.1	Filters for <i>TCP</i> and <i>UDP</i> packets	
9.1.1	Filters for <i>IP</i> packets	
9.1.2	Filters for <i>ICMP</i> packets	
9.2	ACL	
9.2.1	Creating and editing IPv4 rules	
9.2.2	Creating and configuring an IP ACL using the Command Line Interface	
9.2.3	Creating and editing MAC rules	
9.2.4	Creating and configuring a MAC ACL using the Command Line Interface	
9.2.5	Assigning ACLs to a port or VLAN	
9.3	MAC authentication bypass	154

10	Network load control	155
10.1	Direct packet distribution	155
10.1.1	Learning MAC addresses.	155
10.1.2	Aging of learned MAC addresses	155
10.1.3	Static address entries.	156
10.2	Multicasts	159
10.2.1	Example of a Multicast application.	
10.2.2	IGMP snooping	
10.3	Rate limiter	
10.4	QoS/Priority	165
10.4.1	Description of prioritization.	
10.4.2	Handling of received priority information	
10.4.3	VLAN tagging	
10.4.4	IP ToS (Type of Service)	
10.4.5	Handling of <i>traffic classes</i>	
10.4.6	Queue management	
10.4.7	Management prioritization	
10.4.8	Setting prioritization	
10.5	Differentiated services	
10.5.1	Application example for the DiffServ function	
10.6	Flow control	
10.6.1	Flow Control with a half-duplex link	
10.6.2	Flow Control with a full-duplex link	
10.6.3	Setting up the Flow Control	
10.0.5		100
11	VLANs	181
11.1	Examples of VLANs	
11.1.1	Application example of a simple port-based VLAN	182
11.1.2	Application example of a complex VLAN setup	185
11.2	Guest VLAN / Unauthenticated VLAN	190
11.3	RADIUS VLAN assignment	192
11.4	Creating a Voice VLAN	193
11.5	MAC based VLANs	194
11.6	IP subnet-based VLANs	195
11.7	Protocol-based VLAN.	
11.8	VLAN unaware mode	
11.0		137
12	Redundancy	
12.1	Network Topology vs. Redundancy Protocols	
12.1.1	Network topologies.	
12.1.2	Redundancy Protocols	
12.1.3	Combinations of redundancy protocols	201
12.2	Media Redundancy Protocol (MRP)	203
12.2.1	Network structure	203
12.2.2	Reconfiguration time	204
12.2.3	Advanced mode	204
12.2.4	Prerequisites for MRP	204
12.2.5	Advanced Information	
12.2.6	Application example of an MRP Ring	207
12.2.7	MRP over LAG	211

12.3	HIPER Ring Client	
12.3.1	VLANS on the HIPER Ring	
12.3.2	Advanced Information	
12.3.3	HIPER Ring over LAG	217
12.4	Parallel Redundancy Protocol (PRP) (depends on hardware)	218
12.4.1	Implementation	218
12.4.2	LRE functionality	219
12.4.3	PRP Network structure.	220
12.4.4	Connecting RedBoxes and DANPs to a PRP network	220
12.4.5	Application example of a PRP Network	221
12.5	High-availability Seamless Redundancy (HSR) (depends on hardware)	224
12.5.1	Implementation.	224
12.5.2	HSR Network structure	225
12.6	Device Level Ring (DLR)	232
12.6.1	Device Roles	
12.6.2	Error Detection	
12.6.3	Neighbor Check process	
12.6.4	Sign On Process	
12.6.5	Application example for DLR	
12.7	Spanning Tree	
12.7.1	Basics.	
12.7.2	Rules for Creating the Tree Structure	
12.7.2	Examples	
	•	
12.8	Rapid Spanning Tree Protocol	
12.8.1	Port roles	
12.8.2	Port states	
12.8.3	Spanning Tree Priority Vector	
12.8.4	Fast reconfiguration	
12.8.5	Configuring the device	
12.8.6	Guards	
12.8.7	Ring only mode function.	
12.8.8	RSTP over HSR	
12.9	Link Aggregation	
12.9.1	Methods of Operation.	258
12.9.2	Link Aggregation Example	259
12.10	Link Backup	260
12.10.1	Fail Back Description	260
12.10.2	Application example for the Link Backup function	260
12.11	FuseNet function	262
12.12	Sub Ring	263
12.12.1	Sub Ring description	
12.12.2	Advanced Information	
12.12.3	Sub Ring example	
12.12.4	Application example for the Sub Ring function	
12.12.5	Cascaded Sub Rings example	
12.12.6	Sub Ring with LAG.	
12.13	Ring/Network Coupling function	
12.13	Methods of Ring/Network Coupling	
12.13.1	Advanced Information	
12.13.2	Prepare the Ring/Network Coupling.	
12.10.0		202

12.14.1 Prerequisites for RCP 296 12.14.3 Advanced Information 297 13 Tracking 303 13.1 Interface tracking 303 13.2 Logical tracking 303 13.3 Configuring the tracking 306 13.4 Interface tracking 306 13.3 Configuring interface tracking 306 13.4.1 Special conditions during use 307 13.4.1 Special conditions during use 307 13.4.1 Special conditions during use 309 14.1 Operation diagnosis 309 14.1 Sending SMMP traps 309 14.1.1 List of SMMP traps 309 14.1.2 SNMP traps setting 311 14.1.3 SNMP traps setting 311 14.1.4 ICMP messaging 312 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.3 Security Status 316	12.14	RCP function	. 295
12.14.3 Application example for RCP coupling.	12.14.1		
13 Tracking 303 13.1 Interface tracking 303 13.2 Logical tracking 305 13.3 Configuring the tracking 306 13.4 Interface status application 307 13.4.1 Special conditions during use 307 13.4.2 Example for the Interface status application 307 13.4.2 Example for the Interface status application 307 14.1 Operation diagnosis 309 14.1 Sending SNMP traps 309 14.1.1 List of SNMP traps for configuration activity 311 14.1.2 SNMP traps for configuration activity 311 14.1.3 SNMP traps for configuration activity 311 14.1.4 ICMP messaging 312 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.2.3 Displaying the Device Status 314 14.2.3 Displaying the Security Status 317 14.3.1 Events which can be monitored <	12.14.2	Advanced Information	. 297
13.1 Interface tracking 303 13.2 Logical tracking 305 13.3 Configuring the tracking 306 13.4 Configuring interface tracking 306 13.4.1 Special conditions during use 307 13.4.1 Special conditions during use 307 13.4.2 Example for the Interface tracking 309 14.1 Sending SNMP traps 309 14.1 List of SNMP traps 309 14.1.1 List of SNMP traps 309 14.1.2 SNMP traps for configuration activity 311 14.1.2 SNMP traps setting 311 14.1.4 ICMP messaging 312 14.2 Vonitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.3 Displaying the Device Status 314 14.3 Security Status 317 14.3 Security Status 318 14.3 Security Status 318 14.3 Displaying the Socurity Status 320 14.4 Out-of-Band signaling <	12.14.3	Application example for RCP coupling	. 298
13.2 Logical tracking	13	Tracking	. 303
13.3 Configuring the tracking 306 13.4.1 Interface tracking 306 13.4 Interface status application 307 13.4.1 Special conditions during use 307 13.4.2 Example for the Interface status application 307 14.1 Operation diagnosis 309 14.1 Sending SNMP traps 309 14.1.1 List of SNMP traps 310 14.1.2 SNMP traps for configuration activity 311 14.1.3 SNMP traps esting 311 14.1.4 ICMP messaging 312 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.2.3 Displaying the Device Status 314 14.2.3 Displaying the Security Status 314 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Security Status 320 14.4 Out-of-Band signaling 321 1	13.1	Interface tracking	. 303
13.3.1 Configuring interface tracking 306 13.4.1 Interface status application 307 13.4.2 Example for the Interface status application 307 13.4.2 Example for the Interface status application 307 14 Operation diagnosis 309 14.1 Sending SNMP traps 309 14.1.1 List of SNMP traps for configuration activity 311 14.1.2 SNMP traps for configuration activity 311 14.1.4 ICMP messaging 311 14.1.2 Nonitoring the Device Status 313 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.2.3 Displaying the Device Status 317 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Displaying the Security Status 318 14.3.4 Controlling the Signal contact 321 14.4 Controlling the Signal contact 321 14.4	13.2	Logical tracking	. 305
13.4 Interface status application 307 13.4.1 Special conditions during use 307 13.4.2 Example for the Interface status application 307 14 Operation diagnosis 309 14.1 Sending SNMP traps 309 14.1 List of SNMP traps 310 14.1.2 SNMP traps for configuration activity 311 14.1.3 SNMP traps setting 311 14.1.4 ICMP messaging 312 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.3 Security Status 315 14.3 Security Status 316 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Displaying the Security Status 318 14.3.4 Out-of-Band signaling 321 14.4.1 Controlling the Signal contact 321 14.4.1 Controlling the Device and Security Statuses 322	13.3	Configuring the tracking	. 306
13.4.1 Special conditions during use	13.3.1	Configuring interface tracking	. 306
13.4.2 Example for the Interface status application 307 14 Operation diagnosis 309 14.1 Sending SNMP traps 309 14.1 List of SNMP traps 309 14.1.1 List of SNMP traps 310 14.1.2 SNMP traps for configuration activity. 311 14.1.3 SNMP trap setting 311 14.1.4 ICMP messaging 311 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.2.3 Displaying the Device Status 314 14.3 Security Status 317 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 320 14.4 Out-of-Band signaling 321 14.4 Controlling the Signal contact 321 14.4.1 Controlling the Security Status 322 14.4 Monitoring the Device and Security Status 322 <t< td=""><td>13.4</td><td>Interface status application</td><td>. 307</td></t<>	13.4	Interface status application	. 307
14 Operation diagnosis 309 14.1 Sending SNMP traps 309 14.1.1 List of SNMP traps 310 14.1.2 SNMP traps for configuration activity 311 14.1.3 SNMP traps etting 311 14.1.4 ICMP messaging 312 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.2.3 Displaying the Device Status 314 14.2.3 Configuring the Security Status 317 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Displaying the Security Status 320 14.4 Outof-Band signaling 321 14.4 Outof-Band signaling 321 14.4.4 Controlling the Security Statuses 322 14.5 Port event counter 325 14.5.1 Detecting non-matching duplex modes 325	13.4.1	Special conditions during use	. 307
14.1 Sending SNMP traps 309 14.1.1 List of SNMP traps for configuration activity. 311 14.1.2 SNMP traps setting 311 14.1.3 SNMP traps setting 311 14.1.4 ICMP messaging 312 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 313 14.2.3 Displaying the Device Status 314 14.3.3 Security Status 315 14.3 Security Status 316 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Displaying the Security Status 320 14.4 Out-of-Band signaling 321 14.4 Out-of-Band signaling 321 14.4.1 Controlling the Device and Security Statuses 322 14.4 Out-of-Band signaling 321 14.4.1 Controlling the Signal contact 321 14.4.2 Monitoring the Device and Security Statuses 322 <td>13.4.2</td> <td>Example for the Interface status application</td> <td>. 307</td>	13.4.2	Example for the Interface status application	. 307
14.1.1 List of SNMP traps 310 14.1.2 SNMP traps for configuration activity. 311 14.1.3 SNMP traps setting. 311 14.1.4 ICMP messaging. 312 14.2 Monitoring the Device Status. 313 14.2.1 Events which can be monitored. 313 14.2.2 Configuring the Device Status. 314 14.2.3 Displaying the Device Status. 314 14.2.4 Monitoring the Device Status. 314 14.2.2 Configuring the Device Status. 314 14.3.3 Security Status. 317 14.3.1 Events which can be monitored. 317 14.3.3 Security Status. 316 14.3.3 Displaying the Security Status 320 14.4 Out-of-Band signaling 321 14.4.4 Out-of-Band signal contact 321 14.4.2 Monitoring the Device and Security Statuses 322 14.4.2 Monitoring the SPF status 322 14.5.1 Detecting non-matching duplex modes 325 14.6 Auto-Disable 327	14	Operation diagnosis	. 309
14.1.2 SNMP traps for configuration activity. 311 14.1.3 SNMP traps setting. 311 14.1.4 ICMP messaging. 312 14.2 Monitoring the Device Status. 313 14.2.1 Events which can be monitored. 313 14.2.2 Configuring the Device Status. 314 14.2.3 Displaying the Device Status. 315 14.3 Security Status. 317 14.3.1 Events which can be monitored. 317 14.3.1 Events which can be monitored. 317 14.3.2 Configuring the Security Status. 318 14.3.3 Displaying the Security Status. 320 14.4 Out-of-Band signaling 321 14.4.1 Controlling the Signal contact. 322 14.4.2 Monitoring the Device and Security Statuses 322 14.5 Port event counter 325 14.4.2 Monitoring the SFP status 320 14.4 Displaying the SFP status 320 14.5 Port event counter 325 14.6 Auto-Disable. 327 <	14.1	Sending SNMP traps	. 309
14.1.3 SNMP trap setting 311 14.1.4 ICMP messaging 312 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.2.3 Displaying the Device Status 314 14.3.4 Events which can be monitored 317 14.3.5 Security Status 317 14.3.6 Configuring the Security Status 316 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Displaying the Security Status 320 14.4 Out-of-Band signaling 321 14.4.4 Controlling the Signal contact 321 14.4.2 Monitoring the Device and Security Statuses 322 14.5 Port event counter 325 14.5 Port event counter 325 14.6 Auto-Disable 327 14.7 Displaying the SFP status 330 14.8.1 Displaying the Topology discovery results 3330 <tr< td=""><td></td><td></td><td></td></tr<>			
14.1.4 ICMP messaging 312 14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.2.3 Displaying the Device Status 314 14.2.3 Displaying the Device Status 315 14.3 Security Status 317 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Displaying the Security Status 320 14.4 Out-of-Band signaling 321 14.4.1 Controlling the Signal contact 321 14.4.2 Monitoring the Device and Security Statuses 322 14.5 Port event counter 325 14.5.1 Detecting non-matching duplex modes 325 14.6 Auto-Disable 327 14.7 Displaying the SFP status 329 14.8 Topology discovery 330 14.8.1 Displaying the Topology discovery results 331 14.9 Detecting loops 331			
14.2 Monitoring the Device Status 313 14.2.1 Events which can be monitored 313 14.2.2 Configuring the Device Status 314 14.2.3 Displaying the Device Status 314 14.2.4 Device Status 315 14.3 Security Status 317 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Displaying the Security Status 318 14.3.3 Displaying the Security Status 320 14.4 Out-of-Band signaling 321 14.4.4 Controlling the Signal contact 321 14.4.2 Monitoring the Device and Security Statuses 322 14.5 Port event counter 325 14.6 Auto-Disable 327 14.7 Displaying the SPP status 320 14.8 Topology discovery 330 14.8.1 Displaying the Topology discovery results 330 14.8 Topology discovery results 331 14.9 Detecting loops 332 14	-		
14.2.1Events which can be monitored31314.2.2Configuring the Device Status31414.2.3Displaying the Device Status31514.3Security Status31714.3.1Events which can be monitored31714.3.2Configuring the Security Status31814.3.3Displaying the Security Status31814.3.4Out-of-Band signaling32014.4Out-of-Band signaling32114.4.2Monitoring the Signal contact32114.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.6Auto-Disable32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.11Specifying the ender address33614.11.1Specifying the sender address33614.11.2Specifying the sender address33614.11.3Changing the recipients33814.11.4Specifying the ereing loops33814.11.6Enabling/Disabling the Email Notification function33814.11.6Enabling/Disabling the Email Notification function338			
14.2.2Configuring the Device Status31414.2.3Displaying the Device Status31514.3Security Status31714.3.1Events which can be monitored31714.3.2Configuring the Security Status31814.3.3Displaying the Security Status31814.3.4Out-of-Band signaling32014.4Out-of-Band signaling32114.4.1Controlling the Signal contact32114.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.5.1Detecting non-matching duplex modes32514.6Auto-Disable32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.11Specifying the sender address33614.11.1Specifying the triggering events33614.11.3Changing the recipients33814.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function338	· ··-	•	
14.2.3Displaying the Device Status31514.3Security Status31714.3.1Events which can be monitored31714.3.2Configuring the Security Status31814.3.3Displaying the Security Status32014.4Out-of-Band signaling32114.4.1Controlling the Signal contact32114.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.6Auto-Disable32714.7Displaying the SFP status32014.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.11Specifying the sender address33614.11.1Specifying the triggering events33614.11.2Specifying the triggering events33614.11.3Changing the recipients33814.11.4Specifying the triggering events33814.11.6Enabling/Disabling the Email Notification function338			
14.3 Security Status 317 14.3.1 Events which can be monitored 317 14.3.2 Configuring the Security Status 318 14.3.3 Displaying the Security Status 320 14.4 Out-of-Band signaling 321 14.4 Controlling the Signal contact 321 14.4.1 Controlling the Device and Security Statuses 322 14.4.2 Monitoring the Device and Security Statuses 322 14.5.1 Detecting non-matching duplex modes 325 14.6 Auto-Disable 327 14.7 Displaying the SFP status 329 14.8 Topology discovery 330 14.8.1 Displaying the Topology discovery results 330 14.8.2 LDP-Med 331 14.9 Detecting loops 333 14.10 Helping avoid layer 2 network loops 333 14.10.2 Recommendations for redundant ports 335 14.11 Specifying the sender address 336 14.11.1 Specifying the recipients 336 14.11.3 Changing the sending interval <		• •	
14.3.1Events which can be monitored31714.3.2Configuring the Security Status31814.3.3Displaying the Security Status32014.4Out-of-Band signaling32114.4.1Controlling the Signal contact32114.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.5.1Detecting non-matching duplex modes32514.6Auto-Disable.32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.3Changing the recipients33814.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function338	-		
14.3.2Configuring the Security Status31814.3.3Displaying the Security Status32014.4Out-of-Band signaling32114.4.1Controlling the Signal contact32114.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.5.1Detecting non-matching duplex modes32514.6Auto-Disable.32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.11.1Specifying the sender address33614.11.2Specifying the sender address33614.11.3Changing the recipients33714.11.4Specifying the recipients33814.11.5Specifying the real interval33814.11.6Enabling/Disabling the Email Notification function338	-		
14.3.3Displaying the Security Status32014.4Out-of-Band signaling32114.4.1Controlling the Signal contact32114.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.6Auto-Disable32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.11Specifying the Email Notification function33614.11.3Changing the sender address33614.11.4Specifying the triggering events33614.11.5Specifying the triggering interval33714.11.6Enabling/Disabling the Email Notification function33814.11.6Enabling/Disabling the Email Notification function338	-		
14.4Out-of-Band signaling32114.4.1Controlling the Signal contact32114.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.5.1Detecting non-matching duplex modes32514.6Auto-Disable32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.11Specifying the sender address33614.11.1Specifying the sender address33614.11.3Changing the triggering events33614.11.4Specifying the triggering events33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function338			
14.4.1Controlling the Signal contact32114.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.5.1Detecting non-matching duplex modes32514.6Auto-Disable32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the recipients33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function338			
14.4.2Monitoring the Device and Security Statuses32214.5Port event counter32514.5Detecting non-matching duplex modes32514.6Auto-Disable.32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results.33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the mail server33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function338			
14.5Port event counter32514.5.1Detecting non-matching duplex modes32514.6Auto-Disable.32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33614.11.1Using the Email Notification function33614.11.2Specifying the sender address33614.11.3Changing the sending interval33714.11.4Specifying the mail server33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function338		• •	
14.5.1Detecting non-matching duplex modes32514.6Auto-Disable.32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.2Specifying the sender address33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function338			
14.6Auto-Disable.32714.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.2Specifying the sender address33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function338	-		
14.7Displaying the SFP status32914.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33614.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the mail server33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.8Topology discovery33014.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33714.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.8.1Displaying the Topology discovery results33014.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33714.11.3Changing the sending interval33714.11.4Specifying the mail server33814.11.5Specifying the Email Notification function33814.11.6Enabling/Disabling the Email Notification function339			
14.8.2LLDP-Med33114.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.9Detecting loops33214.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.10Helping avoid layer 2 network loops33314.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.10.1Helping avoid layer 2 network loops33314.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.10.2Recommendations for redundant ports33514.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339	-		
14.11Using the Email Notification function33614.11.1Specifying the sender address33614.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339	-		
14.11.1Specifying the sender address.33614.11.2Specifying the triggering events.33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function.339	-	•	
14.11.2Specifying the triggering events33614.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339		-	
14.11.3Changing the sending interval33714.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.11.4Specifying the recipients33814.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.11.5Specifying the mail server33814.11.6Enabling/Disabling the Email Notification function339			
14.11.6 Enabling/Disabling the Email Notification function			
8 8			

14.12	Reports	
14.12.1	Global settings	
14.12.2	Syslog	
14.12.3	System Log	
14.12.4	Syslog over TLS	
14.12.5	Audit Trail	
14.13	Network analysis with TCPdump	348
14.14	Monitoring the data stream with Port Mirroring	349
14.14.1	Peculiarities in connection with redundancy protocols (depends on hardware)	349
14.14.2	Enabling the Port Mirroring function	350
14.15	Monitoring the data stream with VLAN mirroring	351
14.15.1	Application example for the VLAN mirroring function.	351
14.16	Monitoring data streams with RSPAN	353
14.16.1	Purpose	353
14.16.2	RSPAN topologies	353
14.16.3	RSPAN VLAN properties	356
14.16.4	RSPAN device roles.	357
14.16.5	RSPAN uplinks	359
14.16.6	Reflector port on a source device	359
14.16.7	Use of underlying redundancy protocols	
14.16.8	Peculiarities in connection with redundancy protocols (depends on hardware)	
14.16.9	Packet prioritization	
14.16.10	Starting point for the examples	
14.16.11	Example: RSPAN with a <i>reflector port</i>	
14.16.12	Example: RSPAN without a <i>reflector port</i>	
14.17	Self-test	370
14.18	Copper cable test	372
14.19	Network monitoring with sFlow	373
		. 070
15	Advanced functions of the device	
15 15.1	Advanced functions of the device	. 375
	u u u u u u u u u u u u u u u u u u u	. 375 . 375
15.1	Advanced functions of the device	375 375 375
15.1 15.1.1 15.1.2	Advanced functions of the device	375 375 375 375 375
15.1 15.1.1	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay	375 375 375 375 375 378
15.1 15.1.1 15.1.2 15.2	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs	375 375 375 375 375 378 378
15.1 15.1.1 15.1.2 15.2 15.2.1 15.2.2	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration	375 375 375 375 375 378 378 378
15.1 15.1.1 15.1.2 15.2 15.2.1	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client.	. 375 . 375 . 375 . 375 . 378 . 378 . 378 . 379 . 381
15.1 15.1.1 15.1.2 15.2 15.2.1 15.2.2 15.3	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function	. 375 . 375 . 375 . 375 . 378 . 378 . 378 . 379 . 381 . 381
15.1 15.1.1 15.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host.	375 375 375 375 378 378 378 379 381 381 381
15.1 15.1.1 15.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function	375 375 375 375 378 378 378 379 381 381 381 382 383
15.1 15.1.1 15.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP.	375 375 375 375 378 378 378 378 378 378 378 378 378 378
15.1 15.1.1 15.1.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1 15.4.2	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP	375 375 375 375 378 378 378 379 381 381 381 382 383 383 383 383
15.1 15.1.1 15.1.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1 15.4.1 15.4.2 15.5	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP MRP-IEEE	375 375 375 375 378 378 379 381 381 381 382 383 383 383 384 385
15.1 15.1.1 15.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1 15.4.2 15.5.1	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP MRP-IEEE MRP operation	375 375 375 375 378 378 378 378 378 378 381 381 381 383 383 383 383 384 385
15.1 15.1.1 15.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1 15.4.2 15.5 15.5.1 15.5.1	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP MRP-IEEE MRP timers	375 375 375 375 378 378 378 378 378 381 381 381 382 383 383 383 383 383 385 385
15.1 15.1.1 15.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1 15.4.2 15.5.1	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP MRP-IEEE MRP operation	375 375 375 378 378 378 379 381 381 382 383 383 383 383 384 385 385 385 385
$15.1 \\ 15.1.1 \\ 15.1.2 \\ 15.2 \\ 15.2.1 \\ 15.2.2 \\ 15.3 \\ 15.3.1 \\ 15.3.2 \\ 15.4 \\ 15.4.1 \\ 15.4.2 \\ 15.5 \\ 15.5.1 \\ 15.5.2 \\ 15.5.3 \\ 15.5.3 \\ 15.5.4 $	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP MRP-IEEE MRP timers MMRP MVRP.	375 375 375 378 378 378 379 381 381 381 382 383 383 383 383 384 385 385 385 385 385 386 387
15.1 15.1.1 15.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1 15.4.2 15.5 15.5.1 15.5.2 15.5.3 15.5.3 15.5.4	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP. MRP-IEEE MRP timers MMRP MVRP. Industry Protocols	375 375 375 378 378 378 378 378 378 381 381 381 382 383 383 383 383 383 385 385 385 385 385
15.1 15.1.1 15.1.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1 15.4.2 15.5 15.5.1 15.5.2 15.5.3 15.5.3 15.5.4 16 16.1	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP MRP-IEEE MRP operation MMRP. MVRP. Industry Protocols IEC 61850/MMS	375 375 375 378 378 378 379 381 381 381 382 383 383 383 383 383 385 385 385 385 385
15.1 15.1.1 15.2 15.2 15.2.1 15.2.2 15.3 15.3.1 15.3.2 15.4 15.4.1 15.4.2 15.5 15.5.1 15.5.2 15.5.3 15.5.3 15.5.4 16	Advanced functions of the device DHCP server Settings that the server assigns to the clients Pools DHCP L2 Relay Circuit and Remote IDs DHCP L2 Relay configuration Using the device as a DNS client. Setting up the DNS client function Setting up a static host. GARP function Configuring GMRP. Configuring GVRP. MRP-IEEE MRP timers MMRP MVRP. Industry Protocols	375 375 375 378 378 378 379 381 381 381 382 383 383 383 383 384 385 385 385 385 385 385 385 385 385 385

16.2	Modbus TCP function	
16.2.1	Client/Server Modbus TCP/IP Mode	
16.2.2	Supported Functions and Memory Mapping	
16.2.3	Application example for the Modbus TCP function	
16.3	EtherNet/IP function	
16.3.1	Integration into a Control System	
16.3.2	EtherNet/IP Entity Parameters	
16.4	PROFINET function	
16.4.1	Device Models for PROFINET GSDML Version 2.41	
16.4.2	Graphical User Interface and Command Line Interface	
16.4.3 16.4.4	Integrating the device into a Control System Incorporating the device in the configuration	
16.4.4	PROFINET parameters	
16.5	OPC UA Server	
16.5.1	Enabling the OPC UA server	
16.5.2	Setting up an OPC UA user account	
16.5.3	Deactivating an OPC UA user account	
16.5.4	Deleting an OPC UA user account.	
16.6	Service Discovery	
16.6.1	ITxPT Module Inventory	
16.6.2	Application example.	
Α	Setting up the configuration environment.	
A.1	Setting up a DHCP/BOOTP server	495
A.2	Setting up a DHCP server with Option 82	
A.3	Preparing access using SSH	501
A.3.1	Generating a key in the device	
A.3.2	Transferring your own key onto the device	
A.3.3	Preparing the SSH client program	
A.4	HTTPS certificate	
A.4.1	HTTPS certificate management.	
A.4.2	Access through HTTPS	505
в	Appendix	507
B.1	Literature references	
B.2	Maintenance	
B.3	Management Information Base (MIB)	
B.4	List of RFCs	
B.5	Underlying IEEE Standards	
B.6		
B.0 B.7		
	Underlying ANSI Norms	
B.8		
16.6.3 16.6.4	Switching	
16.6.5	Access Control Lists (ACL)	
B.9		
	Copyright of integrated Software	
B.10	Abbreviations used.	519

С	Index	521
D	Technical support	529
E	Readers' Comments	530

Safety instructions

WARNING

UNCONTROLLED MACHINE ACTIONS

To avoid uncontrolled machine actions caused by data loss, configure all the data transmission devices individually.

Before you start any machine which is controlled via data transmission, be sure to complete the configuration of all data transmission devices.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

About this Manual

The "Configuration" user manual contains the information you need to start operating the device. It takes you step by step from the first startup operation through to the basic settings for operation in your environment.

The "Installation" user manual contains a device description, safety instructions, a description of the display, and the other information that you need to install the device.

The "Graphical User Interface" reference manual contains detailed information on using the graphical user interface to operate the individual functions of the device.

The "Command Line Interface" reference manual contains detailed information on using the Command Line Interface to operate the individual functions of the device.

The Industrial HiVision Network Management software provides you with additional options for smooth configuration and monitoring:

- Auto-topology discovery
- Browser interface
- Client/server structure
- Event handling
- Event log
- Simultaneous configuration of multiple devices
- Graphical user interface with network layout
- SNMP/OPC gateway

Key

The designations used in this manual have the following meanings:

	List
	Work step
Link	Cross-reference with link
Note:	A note emphasizes a significant fact or draws your attention to a dependency.
Courier	Representation of a CLI command or field contents in the graphical user interface

Execution in the Graphical User Interface

Execution in the Command Line Interface

Replacing a device

The device provides the following plug-and-play solutions for replacing a device with a device of the same type, for instance, if a failure was detected or for preventive maintenance:

- The new device loads the configuration profile of the replaced device from the external memory. See "Loading the configuration profile from the external memory" on page 108.
- The new device gets its IP address using DHCP Option 82. See "DHCP L2 Relay" on page 378. See "Setting up a DHCP server with Option 82" on page 498.

With each solution, upon reboot, the new device gets the same IP settings that the replaced device had.

- For accessing the device management using HTTPS, the device uses a digital certificate. You have the option to transfer your own digital certificate onto the device. See "HTTPS certificate management" on page 504.
- For accessing the device management using SSH, the device uses an RSA host key. You have the option to import your own host key in PEM format to the device. See "Transferring your own key onto the device" on page 501.

1 User interfaces

The device lets you specify the settings of the device using the following user interfaces.

 Table 1:
 User interfaces for accessing the device management

User interface	Can be reached through	Prerequisite
Graphical User Interface	Ethernet (In-Band)	Web browser
Command Line Interface	Ethernet (In-Band) Serial interface (Out-of-Band)	Terminal emulation software
System monitor	Serial interface (Out-of-Band)	Terminal emulation software

1.1 Graphical User Interface

System requirements

To open the Graphical User Interface, you need the desktop version of a web browser with HTML5 support.

Note: Third-party software applications such as web browsers validate digital certificates based on criteria such as their expiration date and current cryptographic parameter recommendations. Outdated certificates may cause issues due to invalid or outdated information. Example: A digital certificate has expired or the cryptographic recommendations have changed. To solve validation conflicts with third-party software applications, transfer your own up-to-date digital certificate onto the device or regenerate a self-signed digital certificate with the latest device software.

Starting the Graphical User Interface

The prerequisite for starting the Graphical User Interface is that the IP parameters are set up in the device. See "Specifying the IP parameters" on page 43.

Perform the following steps:

- □ Start your web browser.
- Type the IP address of the device in the address field of the web browser.
 Use the following form: https://xxx.xxx.xxx
 The web browser sets up the connection to the device and displays the login dialog.
- When you want to change the language of the Graphical User Interface, click the appropriate link in the top right corner of the login dialog.
- □ Enter the user name.
- Enter the password.
 - The default password is private.

After you enter the default password for the first time, the device will prompt you to assign a new password.

Click the Login button.

The web browser displays the Graphical User Interface.

1.2 Command Line Interface

The Command Line Interface lets you use the functions of the device through a local or remote connection.

The Command Line Interface provides IT specialists with a familiar environment for configuring IT devices. As an experienced user or administrator, you have knowledge about the basics and about using Hirschmann devices.

1.2.1 Preparing the data connection

Information for assembling and starting up your device can be found in the "Installation" user manual.

□ Connect the device with the network. The prerequisite for a successful data connection is the correct setting of the network parameters.

You can access the user interface of the Command Line Interface for example, with the freeware program *PuTTY*. You can download the software from www.chiark.greenend.org.uk/~sgtatham/ putty/.

□ Install the *PuTTY* program on your computer.

1.2.2 Access to the Command Line Interface using the Secure Shell (SSH)

In the following example, you use the *PuTTY* program. Another option to access your device using SSH is the OpenSSH Suite.

Perform the following steps: Start the *PuTTY* program on your computer.

🕵 PuTTY Configuration		?	Х
Category:			
Session	Basic options for your PuT	TY session	
Logging	Specify the destination you want to cor	nnect to	
Keyboard	Host <u>N</u> ame (or IP address)	Port	
- Bell Features	<mark>192.168.1.5</mark>	22	
-Window	Connection type:		
Appearance	<mark>◉<u>s</u>SH</mark> ○Se <u>r</u> ial ○Other:	Telnet	\sim
Behaviour Translation	I oad save or delete a stored session		
	Saved Sessions		
Colours			
Data	Default Settings	∧ Load	
Proxy		Eoud	
		Sa <u>v</u> e	
Telnet		Delete	e
		~	
SOPDOP			
	Close window on exit:		
	○ Always ○ Never ● Onl	y on clean exit	
		-	
<u>A</u> bout <u>H</u> elp	<u>O</u> pen	Cance	el 👘

Figure 1:PuTTY input screen

- In the Host Name (or IP address) field you enter the IP address of your device.
 The IP address consists of 4 decimal numbers with values from 0 to 255. The 4 decimal numbers are separated by points.
- □ To specify the connection type, select the *SSH* radio button in the *Connection type* option list. After selecting and setting the required parameters, the device lets you set up the data connection using SSH.
- Click the Open button to set up the data connection to your device.

Depending on the device and the time at which SSH was set up, establishing the connection takes up to a minute.

When you first log into the device management, towards the end of the connection setup, the *PuTTY* program displays a security alert message and lets you check the fingerprint of the key.

PuTTY Seco	urity Alert	×
?	The server's host key is not cached in the registry. You have no guarantee that the server is the computer you think it is.	
	The server's rsa2 key fingerprint is: ssh-rsa 2048 SHA256:1GepSdba8L0wRvKRLvDJ9iVeNEpFOu4sDCWXdYGK14Y	
	If you trust this host, press "Accept" to add the key to PuTTY's cache and carry on connecting.	
	If you want to carry on connecting just once, without adding the key to the cache, press "Connect Once".	
	If you do not trust this host, press "Cancel" to abandon the connection.	
Hel	p More info Accept Connect Once Cancel	

Figure 2:Security alert prompt for the fingerprint

□ Check the fingerprint.

This helps protect yourself from unwelcome guests.

□ When the fingerprint matches the fingerprint of the device key, click the Yes button.

The device lets you display the finger prints of the device keys with the command show ssh or in the *Device Security > Management Access > Server* dialog, *SSH* tab.

The Command Line Interface appears on the screen with a window for entering the user name. The device enables up to 5 users to have access to the Command Line Interface at the same time.

- Enter the user name.
- The default user name is admin.
- □ Press the <Enter> key.

Enter the password.
 The default password is private.
 After you enter the default password for the first time, the device will prompt you to assign a new password.

□ Press the <Enter> key.

login as: admin admin@192.168.1.5's password:

Copyright (c) 2011-2024 Hirschmann Automation and Control GmbH All rights reserved RSPE20 Release HiOS-2A-10.0.00 (Build date 2024-08-24 16:49) System Name : RSPE20-ECE555d6e980 Management IP : 192.168.1.5 Subnet Mask : 255.255.0 Base MAC : EC:E5:55:01:02:03 System Time : 2024-08-26 20:00:58 NOTE: Enter '?' for Command Help. Command help displays all options that are valid for the particular mode. For the syntax of a particular command form, please consult the documentation.

```
RSPE>
```

Figure 3: Start screen of the Command Line Interface

1.2.3 Access to the Command Line Interface using the serial interface

The serial interface is used to locally connect an external network management station (VT100 terminal or PC with terminal emulation). The interface lets you set up a data connection to the Command Line Interface and to the system monitor.

VT 100 terminal settings	
Speed	9600 bit/s
Data	8 bit
Stopbit	1 bit
Handshake	off
Parity	none

Perform the following steps:

- Connect the device to a terminal using the serial interface. As an alternative, connect the device to a COM port of your PC using terminal emulation based on VT100 and press any key.
- As an alternative, you set up the serial data connection to the device with the serial interface using the *PuTTY* program. Press the <Enter> key.

Real PuTTY Configuration		?	\times
Category:			
- Session	Basic options for your PuTTY ses	sion	
Logging	Specify the destination you want to connect to		
Keyboard	Serial li <u>n</u> e	S <u>p</u> eed	_
- Bell Features	COM1	9600	
Window	Connection type:		_
Appearance	○SH ●Serial ○Other: Telnet	t	\sim
Behaviour Translation Selection Colours Connection Data Proxy SSH Serial Telnet Rlogin SUPDUP	Load, save or delete a stored session Savgd Sessions Default Settings	Load Sa <u>v</u> e Delete	
	Close window on exit. Always Never Only on cle	an exit	
<u>A</u> bout <u>H</u> elp	Open _N	<u>C</u> ancel	

Figure 4:Serial data connection with the serial interface using the PuTTY program

- Press any key on your terminal keyboard a number of times until the login screen indicates the CLI mode.
- Enter the user name. The default user name is admin.
- □ Press the <Enter> key.

Enter the password.
 The default password is private.
 After you enter the default password for the first time, the device will prompt you to assign a new password.

□ Press the <Enter> key.

Copyright (c) 2011-2024 Hirschmann Automation and Control GmbH All rights reserved RSPE20 Release HiOS-2A-10.0.00 (Build date 2024-08-24 16:49) System Name : RSPE20-ECE555d6e980 Management IP : 192.168.1.5 Subnet Mask : 255.255.0 Base MAC : EC:E5:55:01:02:03 System Time : 2024-08-26 20:00:58 NOTE: Enter '?' for Command Help. Command help displays all options that are valid for the particular mode. For the syntax of a particular command form, please consult the documentation.


Figure 5: Start screen of the Command Line Interface

1.2.4 Mode-based command hierarchy

In the Command Line Interface, the commands are grouped in the related modes, according to the type of the command. Every command mode supports specific Hirschmann software commands.

The commands available to you as a user depend on your privilege level (*administrator*, *operator*, *guest*, *auditor*). They also depend on the mode in which you are currently working. When you switch to a specific mode, the commands of the mode are available to you.

The *User Exec* mode commands are an exception. The Command Line Interface also lets you execute these commands in the *Privileged Exec* mode.



The following figure displays the modes of the Command Line Interface.

Figure 6: Structure of the Command Line Interface

The Command Line Interface supports, depending on the user level, the following modes: *User Exec* mode

When you log into the device management with the Command Line Interface, you are in the *User Exec* mode. The *User Exec* mode contains a limited range of commands. Command prompt: (RSPE) >

Privileged Exec mode To access the entire range of commands, you change to the Privileged Exec mode. The prerequisite for changing to the Privileged Exec mode is that you log into the device management as a privileged user. In the Privileged Exec mode, you are able to execute the User Exec mode commands, too.

- Command prompt:(RSPE) #
- VLAN mode The VLAN mode contains VLAN-related commands. Command prompt: (RSPE) (VLAN)#
- Service Shell The Service Shell is for service purposes only. Command prompt: /mnt/fastpath #

	<i>Global Config</i> mode The <i>Global Config</i> mode lets you perform modifications to the current configuration. This mode groups general setup commands.
	Command prompt: (RSPE) (config)#
	Interface Range mode
-	The commands in the Interface Range mode affect a specific port, a selected group of multiple
	ports or all port of the device. The commands modify a value or switch a function on/off on one
	or more specific ports.
	 All physical ports in the device
	Command prompt: (RSPE) ((interface) all)#
	Example: When you switch from the <i>Global Config</i> mode to the <i>Interface Range</i> mode, the command prompt changes as follows:
	(RSPE) (config)#interface all
	(RSPE) ((Interface)all)#
	 A single port on one interface
	Command prompt: (RSPE) (interface <slot port="">)#</slot>
	Example: When you switch from the Global Config mode to the Interface Range mode, the
	command prompt changes as follows:
	(RSPE) (config)#interface 2/1
	(RSPE) (interface 2/1)#
	 A range of ports on one interface
	Command prompt: (RSPE) (interface <interface range="">)#</interface>
	Example: When you switch from the <i>Global Config</i> mode to the <i>Interface Range</i> mode, the command prompt changes as follows:
	(RSPE) (config)#interface 1/2-1/4
	(RSPE) ((Interface)1/2-1/4)#
	 A list of single ports
	Command prompt: (RSPE) (interface <interface list="">)#</interface>
	Example: When you switch from the Global Config mode to the Interface Range mode, the
	command prompt changes as follows:
	(RSPE) (config)#interface 1/2,1/4,1/5
	(RSPE) ((Interface)1/2,1/4,1/5)#
	 A list of port ranges and single ports
	Command prompt: (RSPE) (interface <complex range="">)#</complex>
	Example: When you switch from the <i>Global Config</i> mode to the <i>Interface Range</i> mode, the
	command prompt changes as follows:
	(RSPE) (config)#interface 1/2-1/4,1/6-1/9
	(RSPE) ((Interface)1/2-1/4,1/6-1/9)

The following table displays the command modes, the command prompts (input request characters) visible in the corresponding mode, and the option with which you quit this mode.

Table 2: Command modes

Command mode	Access method	Quit or start next mode
<i>User Exec</i> mode	First access level. Perform basic tasks and list system information.	To quit you enter logout: (RSPE) >logout Are you sure (Y/N) ?y
<i>Privileged Exec</i> mode	From the User Exec mode, you enter the command enable: (RSPE) >enable (RSPE) #	To quit the <i>Privileged Exec</i> mode and return to the <i>User Exec</i> mode, you enter exit: (RSPE) #exit (RSPE) >

Command mode	Access method	Quit or start next mode
VLAN mode	From the <i>Privileged Exec</i> mode, you enter the command vlan database: (RSPE) #vlan database (RSPE) (Vlan)#	To end the VLAN mode and return to the <i>Privileged Exec</i> mode, you enter exit or press <ctrl>+<z>. (RSPE) (Vlan)#exit (RSPE) #</z></ctrl>
<i>Global Config</i> mode	From the <i>Privileged Exec</i> mode, you enter the command configure: (RSPE) #configure (RSPE) (config)# From the <i>User Exec</i> mode, you enter the command enable, and then in <i>Privileged Exec</i> mode, enter the command Configure: (RSPE) >enable (RSPE) #configure (RSPE) (config)#	To quit the <i>Global Config</i> mode and return to the <i>Privileged Exec</i> mode, you enter exit: (RSPE) (config)#exit (RSPE) # To then quit the <i>Privileged Exec</i> mode and return to the <i>User Exec</i> mode, you enter exit again: (RSPE) #exit (RSPE) >
<i>Interface Range</i> mode	<pre>From the Global Config mode you enter the command interface {all <slot port=""> <interface range=""> <interface list=""> <complex range="">}. (RSPE) (config)#interface <slot port=""> (RSPE) (interface slot/port)#</slot></complex></interface></interface></slot></pre>	To quit the <i>Interface Range</i> mode and return to the <i>Global Config</i> mode, you enter exit. To return to the <i>Privileged</i> <i>Exec</i> mode, you press <ctrl>+<z>. (RSPE) (interface slot/port)#exit (RSPE) #</z></ctrl>

Table 2: Command modes

When you enter a question mark (?) after the prompt, the Command Line Interface displays a list of the available commands and a short description of the commands.

cli	Set the CLI preferences.
enable	Turn on privileged commands.
help	Display help for various special keys.
history	Show a list of previously run commands.
logout	Exit this session.
ping	Send ICMP echo packets to a specified IP address.
show	Display device options and settings.
telnet	Establish a telnet connection to a remote host.

Figure 7: Commands in the User Exec mode

1.2.5 Executing the commands

Syntax analysis

When you log into the device management with the Command Line Interface, you are in the *User Exec* mode. The Command Line Interface displays the prompt (RSPE)> on the screen.

When you enter a command and press the <Enter> key, the Command Line Interface starts the syntax analysis. The Command Line Interface searches the command tree for the desired command.

When the command is outside the Command Line Interface command range, a message informs you of the detected error.

Example:

You want to execute the show system info command, but enter info without f and press the <Enter> key.

The Command Line Interface then displays a message:

(RSPE)>show system ino

Error: Invalid command 'ino'

Command tree

The commands in the Command Line Interface are organized in a tree structure. The commands, and where applicable the related parameters, branch down until the command is completely defined and therefore executable. The Command Line Interface checks the input. When you entered the command and the parameters correctly and completely, you execute the command with the <Enter> key.

After you entered the command and the required parameters, the other parameters entered are treated as optional parameters. When one of the parameters is unknown, the Command Line Interface displays a syntax message.

The command tree branches for the required parameters until the required parameters have reached the last branch in the structure.

With optional parameters, the command tree branches until the required parameters and the optional parameters have reached the last branch in the structure.

1.2.6 Structure of a command

This section describes the syntax, conventions and terminology, and uses examples to represent them.

Format of commands

Most of the commands include parameters.

When the command parameter is missing, the Command Line Interface informs you about the detection of an incorrect command syntax.

This manual displays the commands and parameters in the Courier font.

Parameters

The sequence of the parameters is relevant for the correct syntax of a command.

Parameters are required values, optional values, selections, or a combination of these things. The representation indicates the type of the parameter.

Commands in pointed brackets (<>) are obligatory. <command> Commands in square brackets ([]) are optional. [command] Parameters in pointed brackets $(\langle \rangle)$ are obligatory. <parameter> Parameters in square brackets ([]) are optional. [parameter] An ellipsis (3 points in sequence without spaces) after an element . . . indicates that you can repeat the element. [Choice1 | Choice2] A vertical line enclosed in brackets indicates a selection option. Select one value. Elements separated by a vertical line and enclosed in square brackets indicate an optional selection (Option1 or Option2 or no selection). Curved brackets ({}) indicate that a parameter is to be selected from {list} a list of options. Elements separated by a vertical line and enclosed in curved {Choice1 | Choice2} brackets ({}) indicate an obligatory selection option (option1 or option2). Displays an optional parameter that contains an obligatory selection. [param1 {Choice1 | Choice2}] Small letters are wild cards. You enter parameters with the notation <a.b.c.d> a.b.c.d with decimal points (for example IP addresses) You press the <Enter> key to insert a line break (carriage return). <cr>

Table 3: Parameter and command syntax

The following list displays the possible parameter values within the Command Line Interface:

Table 4: Parameter values in the Command Line Interface

Value	Description
IP address	This parameter represents a valid IPv4 address. The address consists of 4 decimal numbers with values from 0 to 255. The 4 decimal numbers are separated by a decimal point. The IP address 0.0.0.0 is a valid entry.
MAC address	This parameter represents a valid MAC address. The address consists of 6 hexadecimal numbers with values from 00 to FF. The numbers are separated by a colon, for example, 00:F6:29:B2:81:40.
string	User-defined text with a length in the specified range, for example a maximum of 32 characters.

Value	Description
character string	Use double quotation marks to indicate a character string, for example "System name with space character".
number	Whole integer in the specified range, for example 0999999.
date	Date in format YYYY-MM-DD.
time	Time in format HH:MM:SS.

Table 4: Parameter values in the Command Line Interface

Network addresses

Network addresses are a requirement for establishing a data connection to a remote work station, a server, or another network. You distinguish between IP addresses and MAC addresses.

The IP address is an address allocated by the network administrator. The IP address is unique in one network area.

The MAC addresses are assigned by the hardware manufacturer. MAC addresses are unique worldwide.

The following table displays the representation and the range of the address types:

Table 5: Format and range of network addresses

Address Type	Format	Range	Example
IP address	nnn.nnn.nnn.nnn	nnn: 0 to 255 (decimal)	192.168.11.110
MAC address	mm:mm:mm:mm:mm	mm: 00 to ff (hexadecimal number pairs)	A7:C9:89:DD:A9:B3

Strings

A string is indicated by quotation marks. For example, "System name with space character". Space characters are not valid user-defined strings. You enter a space character in a parameter between quotation marks.

Example:

*(RSPE)#cli prompt Device name Error: Invalid command 'name'

*(RSPE)#cli prompt 'Device name'

*(Device name)#

1.2.7 Examples of commands

Example 1: clear arp-table-switch

Command for clearing the ARP table of the management agent (cache).

clear arp-table-switch is the command name. The command is executable without any other parameters by pressing the <Enter> key.

Example 2: radius server timeout

Command to specify the RADIUS server timeout value. (RSPE) (config)#radius server timeout <1..30> Timeout in seconds (default: 5).

radius server timeout is the command name.

The parameter is required. The value range is 1..30.

Example 3: radius server auth modify <1..8>

Command to set the parameters for RADIUS authentication server 1.

	1
(RSPE) (config)#radius	server auth modify 1
[name]	RADIUS authentication server name.
[port]	RADIUS authentication server port.
	(default: 1812).
[msgauth]	Enable or disable the message authenticator
	attribute for this server.
[primary]	Configure the primary RADIUS server.
[status]	Enable or disable a RADIUS authentication
	server entry.
[secret]	Configure the shared secret for the RADIUS
	authentication server.
[encrypted]	Configure the encrypted shared secret.
<cr></cr>	Press Enter to execute the command.

radius server auth modify is the command name.

The parameter <1..8> (RADIUS server index) is required. The value range is 1..8 (integer).

The parameters [name], [port], [msgauth], [primary], [status], [secret] and [encrypted] are optional.

1.2.8 Input prompt

Command mode

With the input prompt, the Command Line Interface displays which of the three modes you are in:

- (RSPE) >
- User Exec mode
 (RSPE) #
- (RSPE) #
- Privileged Exec mode
 (RSPE) (config)#
- Global Config mode
- (RSPE) (Vlan)#
 VLAN Database mode
- (RSPE) ((Interface)all)#
- Interface Range mode / All ports of the device
- (RSPE) ((Interface)2/1)# Interface Range mode / A single port on one interface
- (RSPE) ((Interface)1/2-1/4)# Interface Range mode / A range of ports on one interface
- (RSPE) ((Interface)1/2,1/4,1/5)#
 Interface Range mode / A list of single ports
- (RSPE) ((Interface)1/1-1/2,1/4-1/6)# Interface Range mode / A list of port ranges and single ports

Asterisk, pound sign and exclamation point

Asterisk *

An asterisk * in the first or second position of the input prompt displays you that the settings in the volatile memory and the settings in the non-volatile memory are different. In your configuration, the device has detected modifications which have not been saved. *(RSPE)>

Pound sign #

A pound sign # at the beginning of the input prompt displays you that the boot parameters and the parameters during the boot phase are different.

- *#(RSPE)>
- Exclamation point !

An exclamation point ! at the beginning of the input prompt displays: the password for the admin user account corresponds with the default setting. !(RSPE)>

Wildcards

The device lets you change the command line prompt.

The Command Line Interface supports the following wildcards:

Table 6: Using wildcards within the Command Line Interface input prompt

Wildcard	Description
%d	System date
%t	System time

Wildcard	Description
%i	IP address of the device
%m	MAC address of the device
%р	Product name of the device

Table 6: Using wildcards within the Command Line Interface input prompt

!(RSPE)>enable

!(RSPE)#cli prompt %i

!192.168.1.5#cli prompt (RSPE)%d

!*(RSPE)2024-08-26#cli prompt (RSPE)%d%t

!*(RSPE)2024-08-26 20:00:58#cli prompt %m

!*AA:BB:CC:DD:EE:FF#

1.2.9 Key combinations

The following key combinations make it easier for you to work with the Command Line Interface: *Table 7: Key combinations in the Command Line Interface*

Key combination	Description
<ctrl> + <h>, <backspace></backspace></h></ctrl>	Delete previous character
<ctrl> + <a></ctrl>	Go to beginning of line
<ctrl> + <e></e></ctrl>	Go to end of line
<ctrl> + <f></f></ctrl>	Go forward one character
<ctrl> + </ctrl>	Go backward one character
<ctrl> + <d></d></ctrl>	Delete current character
<ctrl> + <u>, <x></x></u></ctrl>	Delete to beginning of line
<ctrl> + <k></k></ctrl>	Delete to end of line
<ctrl> + <w></w></ctrl>	Delete previous word
<ctrl> + <p></p></ctrl>	Go to previous line in history buffer
<ctrl> + <r></r></ctrl>	Rewrite or paste the line
<ctrl> + <n></n></ctrl>	Go to next line in history buffer
<ctrl> + <z></z></ctrl>	Return to root command prompt
<ctrl> + <g></g></ctrl>	Aborts running tcpdump session
<tab>, <space></space></tab>	Command line completion
Exit	Go to next lower command prompt
	List choices

The Help command displays the possible key combinations in Command Line Interface on the screen:

```
(RSPE) #help
HELP:
Special keys:
 Ctrl-H, BkSp delete previous character
 Ctrl-A .... go to beginning of line
 Ctrl-E .... go to end of line
 Ctrl-F .... go forward one character
 Ctrl-B .... go backward one character
 Ctrl-D .... delete current character
 Ctrl-U, X .. delete to beginning of line
 Ctrl-K .... delete to end of line
 Ctrl-W .... delete previous word
 Ctrl-P .... go to previous line in history buffer
 Ctrl-R \hfill \ldots rewrites or pastes the line
 Ctrl-N .... go to next line in history buffer
 Ctrl-Z .... return to root command prompt
 Ctrl-G .... aborts running tcpdump session
 Tab, <SPACE> command-line completion
  Exit
        .... go to next lower command prompt
          .... list choices
  ?
(RSPE) #
```

Figure 8: Listing the key combinations with the Help command

1.2.10 Data entry elements

Command completion

To simplify typing commands, the Command Line Interface lets you use command completion (Tab Completion). Thus you are able to abbreviate key words.

- Type in the beginning of a keyword. When the characters entered identify a keyword, the Command Line Interface completes the keyword after you press the tab key or the space key. When there is more than one option for completion, enter the letter or the letters necessary for uniquely identifying the keyword. Press the tab key or the space key again. After that, the system completes the command or parameter.
- When you make a non-unique entry and press <Tab> or <Space> twice, the Command Line Interface provides you with a list of options.
- On a non-unique entry and pressing <Tab> or <Space>, the Command Line Interface completes the command up to the end of the uniqueness. When several commands exist and you press <Tab> or <Space> again, the Command Line Interface provides you with a list of options. Example:

(RSPE) (Config)#lo

(RSPE) (Config)#log

logging logout

When you enter lo and <Tab> or <Space>, the Command Line Interface completes the command up to the end of the uniqueness to log.

When you press <Tab> or <Space> again, the Command Line Interface provides you with a list of options (logging logout).

Possible commands/parameters

You can obtain a list of the commands or the possible parameters by entering help or ?, for example by entering (RSPE) >show ?

When you enter the command displayed, you get a list of the parameters available for the command show.

When you enter the command without space character in front of the question mark, the device displays the help text for the command itself:

!*#(RSPE)(Config)#show?

show Display device options and settings.

1.2.11 Use cases

Saving the Configuration

To help ensure that your password settings and your other configuration changes are kept after the device is reset or after an interruption of the voltage supply, you save the configuration. To do this, perform the following steps:

- □ Enter enable to change to the *Privileged Exec* mode.
- □ Enter the following command:
- save [profile]
- □ Execute the command by pressing the <Enter> key.

Syntax of the "radius server auth add" command

Use this command to add a RADIUS authentication server.

- Mode: Global Config mode
- Privilege Level: administrator
- Format: radius server auth add <1..8> ip <a.b.c.d> [name <string>] [port <1..65535>]
 - [name]: RADIUS authentication server name.
 - [port]: RADIUS authentication server port (default value: 1813).

Parameter	Meaning	Possible values
<18>	RADIUS server index.	18
<a.b.c.d></a.b.c.d>	RADIUS accounting server IP address.	IP address
<string></string>	Enter a user-defined text, max. 32 characters.	
<165535>	Enter port number between 1 and 65535.	165535

Mode and Privilege Level:

- Prerequisites for executing the command:
 - You are in the *Global Config* mode.
 - See "Mode-based command hierarchy" on page 24.
 - You have the access role *administrator*.

Syntax of commands and parameters: See "Structure of a command" on page 28.

Examples for executable commands:

- radius server auth add 1 ip 192.168.30.40
- radius server auth add 2 ip 192.168.40.50 name radiusserver2
- radius server auth add 3 ip 192.168.50.60 port 1813
- radius server auth add 4 ip 192.168.60.70 name radiusserver4 port 1814

1.2.12 Service Shell

The Service Shell is for service purposes only.

The Service Shell lets users have access to internal functions of the device. When you need assistance with your device, the service personnel use the Service Shell to monitor internal conditions for example, the switch or CPU registers.

Do not execute internal functions without service technician instructions. Executing internal functions such as deleting the content of the non-volatile memory (*NVM*) **possibly leads to an inoperable device**.

Start the Service Shell

The prerequisite is that you are in User Exec mode: (RSPE) >

Perform the following steps:

- □ Enter enable and press the <Enter> key.
 - To reduce the effort when typing:
 - Enter e and press the <Tab> key.
- □ Enter serviceshell start and press the <Enter> key.
 - To reduce the effort when typing:
 - Enter ser and press the <Tab> key.
 - Enter s and press the <Tab> key.

!RSPE >enable

```
!*RSPE #serviceshell start
WARNING! The service shell offers advanced diagnostics and functions.
Proceed only when instructed by a service technician.
```

You can return to the previous mode using the 'exit' command.

BusyBox v1.31.0 (2024-08-26 20:00:58 UTC) built-in shell (ash) Enter 'help' for a list of built-in commands.

!/mnt/fastpath #

Working with the Service Shell

When the Service Shell is active, the timeout of the Command Line Interface is inactive. To help prevent configuration inconsistencies, end the Service Shell before any other user starts transferring a new configuration to the device.

Display the Service Shell commands

The prerequisite is that you already started the Service Shell.

Perform the following steps: Enter help and press the <Enter> key.

End the Service Shell

Perform the following steps: □ Enter exit and press the <Enter> key.

Deactivate the Service Shell permanently in the device

When you deactivate the Service Shell, you are still able to configure the device. However, you limit the possibilities of service personnel to perform system diagnostics. The service technician will no longer be able to access internal functions of your device.

The deactivation is irreversible. The Service Shell remains permanently deactivated. **To reactivate the Service Shell, the device requires disassembly by the manufacturer.**

The prerequisites are:

- The Service Shell is not started.
- You are in User Exec mode: (RSPE) >

Perform the following steps:

- □ Enter enable and press the <Enter> key.
 - To reduce the effort when typing:
 - Enter e and press the <Tab> key.

Enter serviceshell deactivate and press the <Enter> key.
 To reduce the effort when typing:

- Enter ser and press the <Tab> key.
- Enter dea and press the <Tab> key.
- □ **This step is irreversible!** Press the <Y> key.

!RSPE >enable

!*RSPE #serviceshell deactivate
Notice: If you continue, then the Service Shell is permanently deactivated.
This step is irreversible!
For details, refer to the Configuration Manual.
Are you sure (Y/N) ?

1.3 System monitor

The System Monitor lets you set basic operating parameters before starting the operating system.

1.3.1 Functional scope

In the System Monitor, you carry out the following tasks, for example:

- Managing the operating system and verifying the device software image
- Starting the operating system
- Deleting configuration profiles, resetting the device to the factory settings
- Checking boot code information

1.3.2 Starting the System Monitor

Prerequisites:

- > Terminal cable for connecting the device to your PC (available as an optional accessory).
- PC with VT100 terminal emulation (such as the *PuTTY* program) or serial terminal

Perform the following steps:

- Use the terminal cable to connect the serial interface of the device with the COM port of the PC.
- Start the VT100 terminal emulation on the PC.
- □ Specify the following transmission parameters:

VT 100 terminal settings					
Speed	9600 bit/s				
Data	8 bit				
Stopbit	1 bit				
Handshake	off				
Parity	none				

\Box Set up a connection to the device.

- Turn on the device. When the device is already on, reboot it. The screen displays the following message after rebooting:
 Press <1> to enter System Monitor 1.
- Press the <1> key within 3 seconds.
 The device starts the System Monitor. The screen displays the following view:

System Monitor 1 (Selected OS: ...-10.0 (2024-08-24 16:49))

- 1 Manage operating system
- 3 Start selected operating system
- 4 Manage configurations
- 5 Show boot code information
- q End (reset and reboot)

sysMon1>

Figure 9: System Monitor 1 view

- □ Select a menu item by entering the number.
- □ To leave a submenu and return to the main menu, press the <ESC> key.

2 Specifying the IP parameters

When you install the device for the first time, specify the IP parameters.

The device provides the following options for entering the IP parameters during the first installation: Entry using the Command Line Interface.

- When you preconfigure your device outside its operating environment, or restore the network access ("In-Band") to the device, choose this "Out-of-Band" method.
- Entry using the HiDiscovery protocol. When you have a previously installed network device or you have another Ethernet connection between your PC and the device, you choose this "In-Band" method.
- Configuration using the external memory. When you are replacing a device with a device of the same type and have already saved the configuration in the external memory, you choose this method.
- Using BOOTP. To set up the installed device to use BOOTP, you choose this In-Band method. You need a BOOTP server for this method. The BOOTP server assigns the configuration data to the device using the MAC address of the device. The DHCP mode is the default mode for the configuration data reference.
- Configuration using DHCP. To set up the installed device to use DHCP, you choose this In-Band method. You need a DHCP server for this method. The DHCP server assigns the configuration data to the device using the MAC address or the system name of the device.
- Configuration using the Graphical User Interface. When the device already has an IP address and is reachable using the network, the Graphical User Interface provides you with another option for configuring the IP parameters.

2.1 IP parameter basics

2.1.1 IPv4

IP address

The IP addresses consist of 4 bytes. Write these 4 bytes in decimal notation, separated by a decimal point.

RFC 1340 written in 1992, defines 5 IP address classes.

Class	Network address	Host address	Address range
А	1 Byte	3 Bytes	0.0.0.0127.255.255.255
В	2 Bytes	2 Bytes	128.0.0.0191.255.255.255
С	3 Bytes	1 Byte	192.0.0.0223.255.255.255
D			224.0.0.0239.255.255.255
E			240.0.0255.255.255.255

Table 8:	IP address classes
10010 0.	11 aaa1000 01a0000

The first byte of an IP address is the network address. The worldwide leading regulatory board for assigning network addresses is the Internet Assigned Numbers Authority (IANA). When you require an IP address block, contact your Internet Service Provider (ISP). Your ISP contacts their local higher-level organization to reserve an IP address block:

- APNIC (Asia Pacific Network Information Center) Asia/Pacific Region
- ARIN (American Registry for Internet Numbers) Americas and Sub-Sahara Africa
- LACNIC (Regional Latin-American and Caribbean IP Address Registry) Latin America and some Caribbean Islands
- RIPE NCC (Réseaux IP Européens) Europe and Surrounding Regions

0		Net ID - 7 bits				Host ID - 24 bits		
Т	0	Net ID - 14 bits			6	Hos	st ID - 16 bits	Class B
Т	I	0	Net ID - 21 bits			Host ID - 8 bit s		Class C
Ι	T	T	0	Multicast Group ID -			28 bits	Class D
Ι	I	T	I	reserved for future use - 28 b its			Class E	

Figure 10: Bit representation of the IP address

When the first bit of an IP address is 0, it belongs to class A. The first octet is less than 128.

When the first bit of an IP address is 1 and the second bit is 0, it belongs to class B. The first octet is between 128 and 191.

When the first 2 bits of an IP address are 1, it belongs to class C. The first octet is higher than 191.

Assigning the address of the host (*Host ID*) is the responsibility of the network operator. The network operator alone is responsible for the uniqueness of the assigned IP addresses.

Netmask

Routers and *Gateways* subdivide large networks into subnets. The netmask assigns the IP addresses of the individual devices to a particular subnet.

You perform subnet division using the netmask in much the same way as the division of the network addresses (net id) into classes A to C.

Set the bits of the host address (host id) that represent the mask to one. Set the remaining host address bits to zero (see the following examples).

Example of a subnet mask:

Decimal notation 255.255.192.0

Binary notation 11111111111111111111000000.00000000 _______Subnetwork mask bits ______Class B Example of applying the subnet mask to IP addresses for subnet assignment:

Decimal notation 129.218.65.17
128 < 129 191 › Class B
Binary notation 10000001.11011010.01000001.00010001
Subnetwork 1 Network address
Decimal notation 129.218.129.17
128 < 129 191 › Class B
Binary notation 10000001.11011010.10000001.00010001
Subnetwork 2

How to use the netmask

In a large network it is possible that *Gateways* and routers separate the management agent from its network management station. How does addressing work in such a case?




Figure 11: The management agent is separated from its network management station by a router

The network management station "Romeo" wants to send data to the management agent "Juliet". Romeo knows Juliet's IP address and also knows that the router "Lorenzo" knows the way to Juliet.

Romeo therefore puts his message in an envelope and writes Juliet's IP address as the destination address; for the source address he writes his own IP address on the envelope.

Romeo then places this envelope in a second one with Lorenzo's MAC address as the destination and his own MAC address as the source. This process is comparable to going from Layer 3 to Layer 2 of the ISO/OSI base reference model.

Finally, Romeo puts the entire data packet into the mailbox which is comparable to going from Layer 2 to Layer 1, that means to sending the data packet over the Ethernet.

Lorenzo receives the letter, removes the outer envelope and recognizes from the inner envelope that the letter is meant for Juliet. He places the inner envelope in a new outer envelope and searches his address list (the ARP table) for Juliet's MAC address; he writes her MAC address on the outer envelope as the destination address and his own MAC address as the source address. He then places the entire data packet in the mail box.

Juliet receives the letter and removes the outer envelope. She finds the inner envelope with Romeo's IP address. Opening the inner envelope and reading its contents corresponds to transferring the message to the higher protocol layers of the ISO/OSI layer model.

Juliet would now like to send a reply to Romeo. She places her reply in an envelope with Romeo's IP address as destination and her own IP address as source. But where is she to send the answer? For she did not receive Romeo's MAC address. It was lost, because Lorenzo replaced the outer envelope.

In the MIB, Juliet finds Lorenzo listed under the variable hmNetGatewayIPAddr as a means of communicating with Romeo. She therefore puts the envelope with the IP addresses in a further envelope with Lorenzo's MAC destination address.

The letter now travels back to Romeo through Lorenzo, the same way the first letter traveled from Romeo to Juliet.

Classless Inter-Domain Routing

Class C with a maximum of 254 (2^{8} -2) addresses was too small, and class B with a maximum of 65534 (2^{16} -2) addresses was too large for most users, resulting in an ineffective usage of the available class B addresses.

Class D contains reserved Multicast addresses. Class E is for experimental purposes. A nonparticipating *Gateway* ignores experimental datagrams with these destination addresses.

Since 1993, RFC 1519 has been using Classless Inter-Domain Routing (CIDR) to provide a solution. CIDR overcomes these class boundaries and supports classless address ranges.

With CIDR, you specify the number of bits that designate the IP address range. You represent the IP address range in binary form and count the mask bits that designate the netmask. The mask bits equal the number of bits used for the subnet in a given IP address range.

Example:

IP address, decimal	Network mask, decimal	IP address, binary		
192.168.112.1 192.168.112.127	255.255.255.128	11000000	01110000 01110000	
CIDR notation: 1	92.168.112.0/25	Mask bits		

The term "supernetting" refers to combining a number of class C address ranges. Supernetting lets you subdivide class B address ranges to a fine degree.

2.1.2 IPv6

IP parameter basics

The Internet Protocol version 6 (IPv6) is the new version of the Internet Protocol version 4 (IPv4). The need to implement IPv6 was due to the fact that IPv4 addresses are not sufficient in the context of the growing Internet today. The IPv6 protocol is described in RFC 8200.

Some of the differences between IPv6 and IPv4 are:

- Address representation and length
- Absence of the broadcast address type
- Simplified header structure
- Fragmentation performed only by the source host
- Added capabilities for packet flow identification in the network

Both IPv4 and IPv6 protocols can operate at the same time in the device. This is possible with the use of the Dual IP Layer technique, also referred to as Dual Stack.

Note: If you want the device to operate only using the IPv4 function, then disable the IPv6 function in the device.

In the device, the IPv6 protocol has the following restrictions:

- > You can specify a maximum number of 8 IPv6 unicast addresses as follows:
 - 4 IPv6 addresses using manual configuration
 - 2 IPv6 addresses when the Auto radio button is selected
 - 1 IPv6 address using the DHCPv6 server
 - 1 link-local address
- The IPv6 function can be enabled only on the management interface. The total number of configurable IPv6 addresses can be used at the same time on the interface.
- The IPv6 addresses can be used to set the management IP address of the device. Other services where IPv6 addresses can be used include for example, SNTP, SYSLOG, DNS, and LDAP.

Address representation

The IPv6 address consists of 128 bits. It is represented as 8 groups of 4 hexadecimal digits, each group representing 16 bits, further referred to as a hextet. The hextets are separated by colons (:). IPv6 addresses are not case-sensitive and you can write them in either lowercase or uppercase.

In accordance with RFC 4291, the preferred format for an IPv6 address is x:x:x:x:x:x:x:x:x. Each "x" consists of 4 hexadecimal values and represents a hextet. An example of a preferred format of an IPv6 address is shown in the figure below.




Figure 12: IPv6 address representation

As you can see in the figure above, usually an IPv6 address contains many zeros. To shorten IPv6 addresses that contain 0 bits, it is necessary to follow 2 writing rules:

- The first rule is to discard the leading zeros in every hextet. This rule is only applied to leading zeros and not to the trailing zeros of a hextet. If the trailing zeros are also discarded, then the resulting address is ambiguous.
- The second rule uses a special syntax to compress the zeros. You can use 2 adjacent colons "::" to replace a string of adjacent hextets that contain only zeros. The "::" sign can be used only one time in an address. If the "::" sign is used more than one time in an address representation, then there can be more than one possible address expanded from that notation.

When the two rules are applied, the result is commonly known as the compressed format.

In the table below you can find 2 examples of how these rules are applied:

Preferred	CC03:0000:0000:0001:AB30:0400:FF02		
No leading zeros	CC03: 0: 0: 1:AB30: 400:FF02		
Compressed CC03::1:AB30:400:FF02			
Preferred 2008:00B7:0000:DEF0:DDDD:0000:E604:0001			
No leading zeros	2008: B7: 0:DEF0:DDDD: 0:E604: 1		
Compressed	2008:B7::DEF0:DDDD:0:E604:1		

 Table 9:
 IPv6 address compression

Prefix length

Unlike an IPv4 address, an IPv6 address does not use a subnet mask to identify the subnet part of the address. Instead, the IPv6 protocol uses the prefix length.

The text representation of IPv6 address prefixes is similar to the way IPv4 address prefixes are written in Classless Inter-Domain Routing (CIDR):

```
<ipv6-address>/<prefix-length>
```

The prefix length range is 0..128. The typical IPv6 prefix length for LANs and other types of networks is /64. This means that the network portion of the address is 64 bits in length. The remaining 64 bits represent the Interface ID, similar to the host portion of the IPv4 address.

In the figure below you can find an example of prefix length bits allocation.

64 bits prefix length	64 bits interface ID	
Address example: 2009:0CB8:0000:0004::10 / 64		
2009:0CB8:0000:0004	0000:0000:0000:0010	

Address types

The IPv6 address types are described in RFC 4291.

The IPv6 address types are identified by the high-order bits of the address, as in the table below: *Table 10: IPv6 address types*

Address type	Binary prefix	IPv6 notation	
Unspecified	000 (128 bits)	::/128	
Loopback	001 (128 bits)	::1/128	
Multicast	1111111	FF00::/8	
Link-local Unicast	111111010	FE80::/10	
Global Unicast	(everything else)		

Unspecified address

The IPv6 address with every bit set to 0 is called the Unspecified address, which corresponds to 0.0.0.0 in IPv4. The Unspecified address is used only to indicate the absence of an address. It is typically used as a source address when a unique address is not determined yet.

Note: The Unspecified address cannot be assigned to an interface or used as a destination address.

Loopback address

The unicast address 0:0:0:0:0:0:0:0:0:1 is called the Loopback address. The Loopback address can be used by a device to send an IPv6 packet to itself. The Loopback address cannot be assigned to a physical interface.

Multicast address

IPv6 does not have a broadcast address like IPv4. But there is an IPv6 all-nodes Multicast address that essentially gives the same result.

An IPv6 Multicast address is used to send an IPv6 packet to multiple destinations. The structure of a Multicast address is as follows: The next 4 bits identify the scope of the Multicast address (how far the packet is transmitted):

- The first 8 bits are set to FF.
- ▶ The next 4 bits are the lifetime of the address: 0 is permanent and 1 is temporary.
- The next 4 bits identify the scope of the Multicast address, meaning how far the packets are transmitted through the network.

Link-Local address

The Link-Local address is used to communicate with other devices on the same link. The term "link" refers to a subnet. Routers do not forward packets with link-local source or destination addresses to other links.

Link-local addresses are used to transmit packets on a single link for scopes such as automatic address configuration, neighbor discovery, or when no routers are present. They have the following format:

Table 11: Link-Local Address format

10 bits	54 bits	64 bits
111111010	0	Interface ID

The Link-Local address is specified and cannot be changed.

Global Unicast address

A Global Unicast address is globally unique and can be routed over the Internet. This type of addresses are equivalent to public IPv4 addresses. Currently, only Global Unicast addresses with the first three bits of 001 or 2000::/3 are assigned.

A Global Unicast address has 3 parts:

- Global Routing Prefix
- Subnet ID
- Interface ID

The Global Routing Prefix is the network portion of the address.

The Subnet ID is used by an organization to identify its subnets and it has up to 16 bits in length. The length of the Subnet ID is given by the length of the Global Routing Prefix.

The Interface ID identifies an interface of a particular node. The term Interface ID is used because one host can have multiple interfaces, each having one or more IPv6 addresses.

The general format for IPv6 Global Unicast addresses is represented in the figure below.




Figure 13: IPv6 Global Unicast address general format

2.2 Specifying the IP parameters using the Command Line Interface

2.2.1 IPv4

There are the following methods you enter the IP parameters:

- ▶ BOOTP/DHCP
- HiDiscovery protocol
- External memory
- Command Line Interface using the serial connection

The device lets you specify the IP parameters using the HiDiscovery protocol or using the Command Line Interface over the serial interface.




Figure 14: Flow chart for entering IP addresses

Note: If a terminal or PC with terminal emulation is unavailable in the vicinity of the installation location, you can set up the device at your own workstation, then take it to its final installation location.

Perform the following steps:

Set up a connection to the device.



Deactivate DHCP. Enter the IP parameters. Local IP address In the default setting, the local IP address is 0.0.0.0. Netmask When you divided the network into subnets, and these are identified with a netmask, enter the netmask here. In the default setting, the local netmask is 0.0.0.0. IP address of the gateway. This entry is only required in cases where the device and the network management station or TFTP server are located in different subnets (see on page 45 "How to use the netmask"). Specify the IP address of the gateway between the subnet with the device and the path to the network management station. In the default setting, the IP address is 0.0.0.0. □ Save the configuration specified using copy config running-config nvm. enable To change to the Privileged EXEC mode. network protocol none To deactivate DHCP. To assign the device the IP address 10.0.1.23 and network parms 10.0.1.23 255.255.255.0 the netmask 255.255.255.0. You have the option of also assigning a Gateway address. copy config running-config nvm To save the current settings in the non-volatile

After entering the IP parameters, you easily set up the device using the Graphical User Interface.

memory (nvm) in the "Selected" configuration profile.


2.2.2 IPv6

The device lets you specify the IPv6 parameters using the Command Line Interface over the serial interface. Another option to access the Command Line Interface is using a SSH connection with the use of the IPv4 management address.

Perform the following steps:

Set up a connection to the device.

The start screen appears.



□ Enable the IPv6 protocol if the protocol is disabled.

- \Box Enter the IPv6 parameters.
 - IPv6 address

Valid IPv6 address. The IPv6 address is displayed in a compressed format.

Prefix length

Unlike an IPv4 address, an IPv6 address does not use a subnet mask to identify the subnet part of the address. This role is performed in IPv6 by the prefix length (see on page 49 "Prefix length"). EUI option function You can use the EUI option function to automatically specify the Interface ID of the IPv6 address. The device uses the MAC address of its interface with the values ff and fe added between byte 3 and byte 4 to generate a 64 bit Interface ID. You can only select this option for IPv6 addresses that have a prefix length equal to 64. IPv6 Gateway address The IPv6 Gateway address is the address of a router through which the device accesses other devices outside its own network. You can specify any IPv6 address except loopback and Multicast addresses. In the default setting, the IPv6 Gateway address is ::. enable To change to the Privileged EXEC mode. network ipv6 operation To enable the IPv6 protocol if the protocol is

	disabled. In the default setting, the IPv6 protocol is enabled.
network ipv6 address add 2001::1 64 eui-64	To assign the IPv6 address 2001::1 and the prefix length 64. The eui-64 parameter is optional. You have the option of also assigning a Gateway address.
copy config running-config nvm	To save the current settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

After entering the IPv6 parameters, you easily set up the device using the Graphical User Interface. To use an IPv6 address in a URL, use the following URL syntax: https://[<ipv6_address>].

2.3 Specifying the IP parameters using HiDiscovery

The HiDiscovery protocol lets you assign IP parameters to the device using the Ethernet.

You easily set up other parameters using the Graphical User Interface.

Perform the following steps:

- □ Install the HiDiscovery program on your computer.
- □ Start the HiDiscovery program.

File Edit Options ?						
	2 WW Teli	l 👽 🍣 net Ping Resca	n Preferences			
d 🛦 🛛 MAC Address	Writable	IP Address	Net Mask	Default Gateway	Product	Name
1 00:80:63:A4:CC:00		10.115.0.76	255.255.224.0	10.115.0.3		
2 00:80:63:C0:50:00		10.115.0.33	255.255.224.0	10.115.0.3		
3 00:80:63:A3:40:00		10.115.0.70	255.255.224.0	10.115.0.3		
4 00:80:63:98:14:00		10.115.0.17	255.255.224.0	10.115.0.3		
5 00:80:63:96:E4:00		0.0.0.0	0.0.0.0	0.0.0.0		
6 00:80:63:46:00:06	1	192.168.2.181	255.255.255.0	192.168.2.1		
7 00:80:63:A3:40:40		10.115.0.59	255.255.224.0	10.115.0.3		
8 00:80:63:A4:CC:40		10.115.0.81	255.255.224.0	10.115.0.3		
9 00:80:63:6E:38:4E	7	192.168.2.174	255.255.255.0	192.168.2.1		
10 00:80:63:1B:2A:61	1	192.168.2.170	255.255.255.0	192.168.2.1		
11 00:80:63:A3:40:80		10.115.0.66	255.255.224.0	10.115.0.3		
12 00:80:63:A4:CC:80		10.115.0.80	255.255.224.0	10.115.0.3		
13 00:80:63:61:AC:81	7	192.168.2.176	255.255.255.0	192.168.2.1		
14 00:80:63:98:10:95		10.115.0.22	255.255.224.0	10.115.0.3		
15 00:80:63:61:AC:AB	7	192.168.2.40	255.255.255.0	192.168.2.1		
16 00:80:63:38:5C:BD	1	192.168.2.178	255.255.255.0	192.168.2.1		
17 00:80:63:A3:40:C0		10.115.0.72	255.255.224.0	10.115.0.3		
18 00:80:63:8F:2C:BE		10.115.0.40	255.255.224.0	10.115.0.3		
19 00:80:63:88:38:EC	~	192.168.110.92	255.255.255.0	0.0.0.0		
20 00:80:63:98:11:00		10.115.0.35	255.255.224.0	10.115.0.3		
21 00:80:63:A4:CD:00		10.115.0.77	255.255.224.0	10.115.0.3		
22 00:80:63:99:41:08		10.115.0.13	255.255.224.0	10.115.0.3		
23 00:80:63:17:35:08	~	192.168.2.164	255.255.255.0	192.168.2.1		
24 00:80:63:44:19:2E	V	10.115.5.130	255.255.224.0	10.115.0.3		

Figure 15: HiDiscovery

When HiDiscovery is started, HiDiscovery automatically searches the network for those devices which support the HiDiscovery protocol.

HiDiscovery uses the first network interface found for the PC. When your computer has several network interfaces, you can select the desired network interface in the HiDiscovery toolbar.

HiDiscovery displays a line for every device that responds to a HiDiscovery protocol inquiry.

HiDiscovery lets you identify the devices displayed.

- □ Select a device line.
- □ To set the LEDs to flashing for the selected device, click the *Signal* button on the tool bar. To stop the flashing, click the *Signal* button again.
- By double-clicking a line, you open a window in which you specify the device name and the IP parameter.

Properties 🛛 🗙			
MAC Address: 00:8	D:63:A3:40:00		
Name: Pow	er Unit 1 Switch 2		
IP Configuration			
IP Address:	10 . 115 . 0 . 70	Set Default ()	
Net Mask:	255 . 255 . 224 . 0	Set Default ()	
Default Gateway:	10 . 115 . 0 . 3	Set Default ()	
Save As Default			
Ok Cancel			

Figure 16: HiDiscovery – assigning IP parameters

Note: Disable the HiDiscovery function in the device, after you have assigned the IP parameters to the device.

Note: Save the settings so that you will still have the entries after a restart.

2.4 Specifying the IP parameters using the Graphical User Interface

2.4.1 IPv4

Perform the following steps:

□ Open the *Basic Settings > Network > Global* dialog.

In this dialog, you specify the VLAN in which the device management can be accessed and set up the HiDiscovery access.

□ In the *VLAN ID* column you specify the VLAN in which the device management can be accessed over the network.

Note here that you can only access the device management using ports that are members of the relevant VLAN.

The *MAC address* field displays the MAC address of the device with which you access the device over the network.

- □ In the *HiDiscovery protocol v1/v2* frame you specify the settings for accessing the device using the HiDiscovery software.
- □ The HiDiscovery protocol lets you allocate an IP address to the device on the basis of its MAC address. Activate the HiDiscovery protocol if you want to allocate an IP address to the device from your PC with the HiDiscovery software.
- □ Open the *Basic Settings* > *Network* > *IPv4* dialog.

In this dialog, you specify the source from which the device gets its IP parameters after starting.

- □ In the *Management interface* frame you first specify where the device gets its IP parameters from:
- In the BOOTP mode, the configuration is using a BOOTP or DHCP server on the basis of the MAC address of the device.
- In the DHCP mode, the configuration is using a DHCP server on the basis of the MAC address or the name of the device.
- In the Local mode, the device uses the network parameters from the internal device memory.

Note: When you change the allocation mode of the IP address, the device activates the new

mode immediately after you click the \checkmark button.

- □ If required, you enter the IP address, the netmask and the *Gateway* in the *IP parameter* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

2.4.2 IPv6

Perform the following steps:

- □ Open the *Basic Settings > Network > IPv*6 dialog.
- □ The IPv6 protocol is enabled by default. Verify if the *0n* radio button is selected in the *Operation* frame.
- □ In the *Configuration* frame you specify where the device gets its IPv6 parameters from:
- If the None radio button is selected, then the device receives its IPv6 parameters manually. You can manually specify a maximum number of 4 IPv6 addresses. You cannot specify loopback, link-local, and Multicast addresses as static IPv6 addresses.
- If the Auto radio button is selected, then the device receives its IPv6 parameters dynamically for example, with the use of a Router Advertisement Daemon (radvd). The device receives a maximum of 2 IPv6 addresses.
- If the DHCPv6 radio button is selected, then the device receives its IPv6 parameters from a DHCPv6 server.
 - The device can receive only one IPv6 address from the DHCPv6 server.
- If the All radio button is selected, then the device receives its IPv6 parameters using every alternative for both dynamic and manual assignments.

Note: When you change the allocation mode of the IPv6 address, the device activates the new

mode immediately after you click the \checkmark button.

□ If necessary, you enter the *Gateway address* in the *IP parameter* frame.

Note: If the *Auto* radio button is selected and you use a Router Advertisement Daemon (radvd), then the device automatically receives a link-local type *Gateway address* with a higher metric than the manually set *Gateway address*.

□ In the *Duplicate Address Detection* frame you can specify the number of consecutive *Neighbor Solicitation* messages that the device sends for the *Duplicate Address Detection* function (see on page 64 "Duplicate Address Detection function").

Apply the settings temporarily. To do this, click the \checkmark button.

Manually specify an IPv6 address. To do this, perform the following steps:

- □ Open the *Basic Settings* > *Network* > *IPv*6 dialog.
- \Box Click the $\overset{\blacksquare}{+}$ button.

The dialog displays the Create window.

- □ Enter the IPv6 address in the *IP* address field.
- Enter the IPv6 address prefix length in the *PrefixLength* field.
- Click the Ok button.
 - The device adds a table row.

2.5 Specifying the IP parameters using BOOTP

With the *BOOTP* function activated the device sends a boot request message to the BOOTP server. The boot request message contains the Client ID specified in the *Basic Settings > Network > IPv4* dialog. The BOOTP server enters the Client ID into a database and assigns an IP address. The server answers with a boot reply message. The boot reply message contains the assigned IP address.

2.6 Specifying the IP parameters using DHCP

2.6.1 IPv4

The Dynamic Host Configuration Protocol (DHCP) is a further development of BOOTP, which it has replaced. The DHCP additionally lets the configuration of a DHCP client using a name instead of using the MAC address.

For the DHCP, this name is known as the *Client Identifier* in accordance with RFC 2131.

The device uses the name entered under *sysName* in the system group of the MIB II as the *Client Identifier*. You can change the system name using the Graphical User Interface (see dialog *Basic Settings* > *System*), the Command Line Interface or SNMP.

The device sends its system name to the DHCP server. The DHCP server then uses the system name to allocate an IP address as an alternative to the MAC address.

In addition to the IP address, the DHCP server sends

- the netmask
- ▶ the default *Gateway* (if available)
- ▶ the TFTP URL of the configuration file (if available).

The device applies the configuration data to the appropriate parameters. When the DHCP Sever assigns the IP address, the device permanently saves the configuration data in non-volatile memory.

Options	Meaning
1	Subnet Mask
2	Time Offset
3	Router
4	Time server
12	Hostname
42	NTP server
61	Client Identifier
66	TFTP Server Name
67	Bootfile Name

Table 12: DHCP options which the device requests

The advantage of using DHCP instead of BOOTP is that the DHCP server can restrict the validity of the configuration parameters ("Lease") to a specific time period (known as dynamic address allocation). Before this period ("Lease Duration") elapses, the DHCP client can attempt to renew this lease. As an alternative, the client can negotiate a new lease. The DHCP server then allocates a random free address.

To help avoid this, DHCP servers provide the explicit configuration option of assigning a specific client the same IP address based on a unique hardware ID (known as static address assignment).

In the default setting, DHCP is activated. As long as DHCP is active, the device attempts to obtain an IP address. When the device cannot find a DHCP server after restarting, it will not have an IP address. The *Basic Settings > Network > IPv4* dialog lets you activate or deactivate DHCP.

Note: When using Industrial HiVision network management, verify that DHCP allocates the original IP address to every device.

The appendix contains an example configuration of the BOOTP/DHCP-server.

Example of a DHCP-configuration file:

```
# /etc/dhcpd.conf for DHCP Daemon
subnet 10.1.112.0 netmask 255.255.240.0 {
option subnet-mask 255.255.240.0;
option routers 10.1.112.96;
}
#
# Host berta requests IP configuration
# with her MAC address
#
host berta {
hardware ethernet 00:80:63:08:65:42;
fixed-address 10.1.112.82;
}
#
# Host hugo requests IP configuration
# with his client identifier.
host hugo {
option dhcp-client-identifier "hugo";
option dhcp-client-identifier 00:68:75:67:6f;
fixed-address 10.1.112.83;
server-name "10.1.112.11";
filename "/agent/config.dat";
}
```

Lines beginning with the # character, contain comments.

The lines preceding the individually listed devices refer to settings that apply to the following device.

The fixed-address line assigns a permanent IP address to the device.

For further information, see the DHCP server manual.

2.6.2 IPv6

The Dynamic Host Configuration Protocol version 6 (DHCPv6) is a network protocol that is used to dynamically specify IPv6 addresses. This protocol is the IPv6 equivalent of the Dynamic Host Configuration Protocol (DHCP) for IPv4. DHCPv6 is described in RFC 8415.

The device uses a DHCP Unique Identifier (DUID) to send a request to the DHCPv6 server. In the device, the DUID represents the *Client ID* that the DHCPv6 server uses to identify the device that requested an IPv6 address.

The Client ID is displayed in the Basic Settings > Network > IPv6 dialog, in the DHCP frame.

The device can receive only one IPv6 address from the DHCPv6 server, with a *PrefixLength* of 128. No *Gateway address* information is provided. If needed, you can manually specify *Gateway address* information.

In the default setting, DHCPv6 protocol is deactivated. You can activate or deactivate the protocol in the *Basic Settings > Network > IPv6* dialog. Verify that the *DHCPv6* radio button is selected in the *Configuration* frame.

If you want to dynamically get an IPv6 address with a *PrefixLength* other than 128, then select the *Auto* radio button. An example here is the use of a Router Advertisement Daemon (radvd). The radvd uses *Router Solicitation* and *Router Advertisement* messages to automatically set up an IPv6 address.

In the default setting, the *Auto* radio button is selected. You can select or deselect the *Auto* radio button in the *Basic Settings > Network > IPv6* dialog, in the *Configuration* frame.

If the *All* radio button is selected, then the device receives its IPv6 parameters using every alternative for both dynamic and manual assignments.

2.7 Management address conflict detection

You assign an IP address to the device using several different methods. This function helps the device detect IP address conflicts on a network after the system startup and the device also checks periodically during operation. This function is described in RFC 5227.

When enabled, the device sends an SNMP trap informing you that it detected an IP address conflict.

The following list contains the default settings for this function:

- Operation: On
- Detection mode: active and passive
- Send periodic ARP probes: marked
- Detection delay [ms]: 200
- Release delay [s]: 15
- Address protections: 3
- Protection interval [ms]: 200
- Send trap: marked

2.7.1 Active and passive detection

Actively checking the network helps prevent the device from connecting to the network with a duplicate IP address. After connecting the device to a network or after configuring the IP address, the device immediately checks if its IP address exists within the network. To check the network for address conflicts, the device sends 4 ARP probes with the detection delay of 200 ms into the network. When the IP address exists, the device attempts to return to the previous configuration, and make another check after the specified release delay time.

When you disable active detection, the device sends 2 gratuitous ARP announcements in 2 s intervals. Using the ARP announcements with passive detection enabled, the device polls the network to determine if there is an address conflict. After resolving an address conflict or after expired release delay time, the device reconnects to the network. Following 10 detected conflicts, when the specified release delay interval is less than 60 s, the device sets the release delay interval to 60 s.

After the device performs active detection or you disable the active detection function, with passive detection enabled the device listens on the network for other devices using the same IP address. When the device detects a duplicate IP address, it initially defends its address by employing the ACD mechanism in the passive detection mode and sends out gratuitous ARPs. The number of protections that the device sends and the protection interval are configurable. To resolve conflicts, if the remote device remains connected to the network, then the network interface of the local device disconnects from the network.

When a DHCP server assigns an IP address to the device and an address conflict occurs, the device returns a DHCP decline message.

The device uses the ARP probe method. This has the following advantages:

- ARP caches on other devices remain unchanged
- ▶ the method is robust through multiple ARP probe transmissions

2.8 Duplicate Address Detection function

The *Duplicate Address Detection* function determines the uniqueness of an IPv6 unicast address on an interface. The function is performed when an IPv6 address is set up manually, or using the *DHCPv6*, or *Auto* methods. The function is also triggered by a change in a link status, for example, a link status change from down to up.

The *Duplicate Address Detection* function uses *Neighbor Solicitation* and *Neighbor Advertisement* messages. You have the option to set the number of consecutive *Neighbor Solicitation* messages that the device sends. To do this, perform the following steps:

□ Open the <i>Basic Settings > Network > IPv</i> 6 dialog.	
 In the Duplicate Address Detection frame set the new solicitants field. Possible values: 	ecessary value in the <i>Number of neighbor</i>
- 0	
The function is disabled.	
 15 (default setting: 1) 	
\Box Apply the settings temporarily. To do this, click t	he 🗸 button.
enable To chang	e to the Privileged EXEC mode.
message	e number of <i>Neighbor Solicitation</i> s that the device sends. e ∂ disables the function.

Note: If the *Duplicate Address Detection* function discovers that an IPv6 address is not unique on a link, then the device does not log this event in the log file (System Log).

3 Access to the device

3.1 First login (Password change)

To help prevent undesired access to the device, it is imperative that you change the default password during initial setup.

Perform the following steps:

- □ Open the Graphical User Interface, the HiView application, or the Command Line Interface the first time you log into the device management.
- Log into the device management with the default password.
- The device prompts you to type in a new password.
- Type in your new password.
 To help increase security, choose a password that contains at least 8 characters which includes upper-case characters, lower-case characters, numerical digits, and special characters.
- □ When you log into the device management through the Command Line Interface, the device prompts you to confirm your new password.
- □ Log into the device management again with your new password.

Note: If you lost your password, then contact your local support team.

For further information, see hirschmann-support.belden.com.

3.2 Authentication lists

When a user accesses the device management using a specific connection, the device verifies the login credentials of the user through an authentication list which contains the policies that the device applies for authentication.

The prerequisite for a user to access the device management is that at least one policy is assigned to the authentication list of the application through which access is performed.

3.2.1 Applications

The device provides an application for each type of connection through which someone accesses the device:

- Access to the Command Line Interface using a serial connection: Console(V.24)
- Access to the Command Line Interface using SSH: SSH
- Access to the Command Line Interface using Telnet: Telnet
- Access to the Graphical User Interface: WebInterface

The device also provides an application to control the access to the network from connected end devices using port-based access control: 8021x

3.2.2 Policies

When a user logs in with valid login data, the device lets the user have access to its device management. The device authenticates the users using the following policies:

- User management of the device
- LDAP
- RADIUS

When the end device logs in with valid login data, the device lets the connected end devices have access to the network with the port-based access control according to IEEE 802.1X. The device authenticates the end devices using the following policies:

- RADIUS
- IAS (Integrated Authentication Server)

The device gives you the option of a fall-back solution. For this, you specify more than one policy in the authentication list. When authentication is unsuccessful using the current policy, the device applies the next specified policy.

3.2.3 Managing authentication lists

You manage the authentication lists in the Graphical User Interface or in the Command Line Interface. To do this, perform the following steps:

Open the Device Security > Authentication List dialog. The dialog displays the authentication lists that are set up. show authlists To display the authentication lists that are set up.

- Deactivate the authentication list for those applications by means of which no access to the device is performed, for example 8021x.
 - □ In the *Active* column of the authentication list defaultDot1x8021AuthList, unmark the checkbox.
 - \Box Apply the settings temporarily. To do this, click the \checkmark button.

```
authlists disable defaultDot1x8021AuthList To deactivate the authentication list defaultDot1x8021AuthList.
```

3.2.4 Adjusting the settings

Example: Set up a separate authentication list for the application WebInterface which is by default included in the authentication list defaultLoginAuthList.

The device forwards authentication requests to a RADIUS server in the network. As a fall-back solution, the device authenticates users using the local user management. To do this, perform the following steps:

□ Create an authentication list loginGUI.

Open the Device Security > Authentication List dialog.	
 Click the button. The dialog displays the <i>Create</i> window. Enter a meaningful name in the <i>Name</i> field. In this example, enter the name loginGUI. Click the <i>Ok</i> button. The device adds a table row. 	
enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
authlists add loginGUI	To add the authentication list loginGUI.

□ Select the policies for the authentication list loginGUI.

- □ In the *Policy 1* column, select the value *radius*.
- □ In the *Policy* 2 column, select the value *LocaL*.
- □ In the *Policy* 3 to *Policy* 5 columns, select the value *reject* to help prevent further fall-back.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

authlists set-policy loginGUI radius local reject reject reject show authlists

To assign the policies radius, local and reject to the authentication list loginGUI. To display the authentication lists that are set up.

Assign an application to the authentication list loginGUI.

□ Open the *Device Security* > *Authentication List* dialog. \Box In the table, select the authentication list loginGUI. \Box Click the \blacksquare button. The dialog displays the Allocate applications window. □ Click the application WebInterface to highlight it. Click the Ok button. The dialog displays the updated settings: The Dedicated applications column of authentication list loginGUI displays the application WebInterface. The Dedicated applications column of authentication list defaultLoginAuthList does not display the application WebInterface anymore. \Box Apply the settings temporarily. To do this, click the \checkmark button. show appllists To display the applications and the allocated lists. appllists set-authlist WebInterface

loginGUI

To assign the loginGUI application to the authentication list WebInterface.

3.3 User management

When a user logs in with valid login data, the device lets the user have access to its device management. The device authenticates the users either using the local user management or with a RADIUS server in the network. To get the device to use the user management, assign the *Local* policy to an authentication list, see the *Device Security > Authentication List* dialog.

In the local user management, you manage the user accounts. One user account is usually allocated to each user.

3.3.1 Access roles

The device lets you use a role-based authorization model to specifically control the access to the device management. Users to whom a specific authorization profile is allocated are allowed to use commands and functions from the same authorization profile or a lower one.

The device uses the authorization profiles on every application with which the device management can be accessed.

Note: The following applies to the Command Line Interface: Users to whom a specific authorization profile is assigned are allowed to use commands and functions from this authorization profile or a lower level role. The commands available to a user also depend on the Command Line Interface mode in which the user is currently working. See "Mode-based command hierarchy" on page 24.

Every user account is linked to an access role that regulates the access to the individual functions of the device. Depending on the planned activity for the respective user, you assign a pre-defined access role to the user. The device differentiates between the following access roles.




Figure 17: Access roles for user accounts

Role	Description	Authorized for the following activities
administrator	The user is authorized to monitor and administer the device.	 All activities with read/write access, including the following activities reserved for an administrator: Add, modify or delete user accounts Activate, deactivate or unlock user accounts Change every password Set up the password management Set or change system time Load files to the device, for example, device settings, certificates, or device software images Reset settings and security-related settings to the state on delivery Set up the RADIUS server and authentication lists Apply scripts using the Command Line Interface Enable/disable CLI logging and SNMP logging External memory activation and deactivation System monitor activation and deactivation Set up access restrictions to the Graphical User Interface Set up acdet activation and Line Interface
operator	The user is authorized to monitor and set up the device, with the exception of security-related settings.	All activities with read/write access, with the exception of the above-named activities, which are reserved for an administrator:
auditor	The user is authorized to monitor the device and to save the log file in the <i>Diagnostics > Report > Audit</i> <i>Trail</i> dialog.	Monitoring activities with read access.
guest	The user is authorized to monitor the device - with the exception of security-related settings.	Monitoring activities with read access.
unauthorized	 No access to the device possible. As an administrator you assign this access role to temporarily lock a user account. If an administrator assigns a different access role to the user account and an error is detected, then the device assigns this access role to the user account. 	No activities allowed.

3.3.2 Managing user accounts

You manage the user accounts in the Graphical User Interface or in the Command Line Interface. To do this, perform the following steps:

Open the Device Security > User Management dialog. The dialog displays the user accounts that are set up.

show users

To display the user accounts that are set up.

3.3.3 Default user accounts

In the default setting, the user account admin is set up in the device.

Table 14: Settings of the default user account

Parameter	Default setting
User name	admin
Password	private
Role	administrator
User locked	unmarked
Policy check	unmarked
SNMP auth type	hmacmd5
SNMP encryption type	des

Change the password for the admin user account before making the device available in the network.


3.3.4 Changing default passwords

To help prevent undesired access, change the password of the default user account. To do this, perform the following steps:

□ Change the password for the admin user account.

- Open the Device Security > User Management dialog. The dialog displays the user accounts that are set up.
 - □ To require a specified minimum complexity for the passwords, mark the checkbox in the
 - Policy check column.

Before saving it, the device checks the password according to the policy specified in the *Password policy* frame.




3.3.5 Setting up a new user account

Allocate a separate user account to each user that accesses the device management. In this way you can specifically control the authorizations for the access.

In the following example, you set up the user account for a user USER with the access role *operator*. Users with the access role *operator* are authorized to monitor and set up the device, with the exception of security-related settings. To do this, perform the following steps: □ Create a user account.

- □ Open the *Device Security* > *User Management* dialog.
- □ Click the [₩]/_↓ button.
 The dialog displays the *Create* window.
- Enter the name in the User name field. In this example, you give the user account the name USER.
- Click the Ok button.
- □ To require a specified minimum complexity for the passwords, mark the checkbox in the *Policy check* column.

Before saving it, the device checks the password according to the policy specified in the *Password policy* frame.



Note: When you are setting up a new user account in the Command Line Interface, remember to allocate the password.

3.3.6 Deactivating the user account

After a user account is deactivated, the device denies the related user access to the device management. In contrast to completely deleting it, deactivating a user account lets you keep the settings and reuse them in the future. To do this, perform the following steps:

- To keep the user account settings and reuse them in the future, you temporarily deactivate the user account.
 - Open the *Device Security > User Management* dialog. The dialog displays the user accounts that are set up.
 In the table row for the relevant user account, unmark the checkbox in the *Active* column.
 Apply the settings temporarily. To do this, click the v button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
users disable <user></user>	To disable user account.
show users	To display the user accounts that are set up.
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

□ To permanently deactivate the user account settings, you delete the user account.

Select the table row of the relevant user account.
 Click the T button.
 users delete <user>

 show users
 To delete the user account <user>.
 To display the user accounts that are set up.
 save
 To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

3.3.7 Adjusting policies for passwords

The device lets you check if the passwords for the user accounts match the specified policy. When the passwords match the policy, you obtain a higher complexity for the passwords.

The user management of the device lets you activate or deactivate the check separately in each user account. When you mark the checkbox and the new password fulfills the requirements of the policy, the device accepts the password change.

In the default settings, practical values for the policy are set up in the device. You have the option of adjusting the policy to meet your requirements. To do this, perform the following steps: Adjust the policy for passwords to meet your requirements.

□ Open the *Device Security* > *User Management* dialog.

In the *Configuration* frame you specify the number of consecutive unsuccessful login attempts before the device locks out the user. You also specify the minimum number of characters that defines a password.

Note: The device lets only users with the *administrator* authorization remove the lock.

The number of consecutive unsuccessful login attempts as well as the possible lockout of the user apply only when accessing the device management through:

- the Graphical User Interface
- the SSH protocol
- ▶ the Telnet protocol

Note: Accessing the device management using the Command Line Interface through the serial connection, the number of login attempts is unlimited.

- □ Specify the values to meet your requirements.
 - In the Login attempts field you specify the number of times that a user can attempt to log into the device management. The field lets you define this value in the range 0..5. In the above example, the value 0 deactivates the function.
 - The Min. password length field lets you enter values in the range 1...64.

The dialog displays the policy set up in the Password policy frame.

- Adjust the values to meet your requirements.
 - Values in the range 1 through 16 are allowed. The value 0 deactivates the relevant policy.

To apply the entries specified in the *Configuration* and *Password policy* frames, mark the checkbox in the *Policy check* column for a particular user.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable		To change to the Privileged EXEC mode.
confi	jure	To change to the Configuration mode.
passwo	ords min-length 6	To specify the policy for the minimum length of the password.
passwo	ords min-lowercase-chars 1	To specify the policy for the minimum number of lower-case letters in the password.
passwo	ords min-numeric-chars 1	To specify the policy for the minimum number of digits in the password.
passwo	ords min-special-chars 1	To specify the policy for the minimum number of special characters in the password.
passwo	ords min-uppercase-chars 1	To specify the policy for the minimum number of upper-case letters in the password.
show p	passwords	To display the policies that are set up.
save		To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

3.4 LDAP function

Server administrators manage *Active Directories* which contain user login credentials for applications used in the office environment. The *Active Directory* is hierarchical in nature, containing user names, passwords, and the authorized read/write permission levels for each user.

This device uses the Lightweight Directory Access Protocol (LDAP) to retrieve user login information and permission levels from a *Active Directory*. This provides a "single sign on" for network devices. Retrieving the login credentials from an *Active Directory* lets the user log in with the same login credentials used in the office environment.

An LDAP session starts with the device contacting the Directory System Agent (DSA) to search the *Active Directory* of an LDAP server. If the server finds multiple entries in the *Active Directory* for a user, then the server sends the higher permission level found. The DSA listens for information requests and sends responses on TCP port 389 for LDAP, or on TCP port 636 for LDAP over SSL (LDAPS). Clients and servers encode LDAPS requests and responses using the Basic Encoding Rules (BER). The device opens a new connection for every request and closes the connection after receiving a response from the server.

The device lets you transfer a digital certificate to the device. The certificate helps the device to verify the server for Secure Socket Layer (SSL) and Transport Layer Security (TLS) connections. For security reasons, Hirschmann recommends using only digital certificates signed by a Certification Authority (CA).

The device lets you specify up to 4 authentication servers. An authentication server authenticates and authorizes the user when the device forwards the login data to the server.

The device is able to cache login credentials for up to 1024 users in memory. If the active directory servers are unreachable, then the users are still able to log in using their office login credentials.

3.4.1 Coordination with the server administrator

Configuring the *LDAP* function requires that the network administrator request the following information from the server administrator:

- ▶ The server name or IP address
- ▶ The location of the *Active Directory* on the server
- ► The type of connection used
- ► The TCP listening port
- When required, the location of the digital certificate
- ▶ The name of the attribute containing the user login name
- > The names of the attribute containing the user permission levels

The server administrator can assign permission levels individually using an attribute such as description, or to a group using the memberOf attribute. In the *Device Security* > *LDAP* > *Role Mapping* dialog you specify which attributes receive the various permission levels.

You also have the option to retrieve the name of the attributes containing the user login name and permission levels using a LDAP browser such as JXplorer or Softerra.

3.4.2 Setting up LDAP

The device is able to establish an encrypted link to a local server using only the server name or to a server on a different network using an IP address. The server administrator uses attributes to identify login credentials of a user and assign individual and group permission levels.

Using information received from the server administrator, you specify which attributes in the *Active Directory* contain the user login credentials and the permission level. The device then compares the user login credentials with the permission levels specified in the device and lets the user log into the device management at the assigned permission level.




Figure 18: Application example of an LDAP setup

For this example, the server administrator sent the following information:

Information	Primary Server	Backup Server
The server name or IP address	local.server	10.16.1.2
The location of the <i>Active Directory</i> on the server	Country/City/User	Country/Company/User
The type of connection used	TLS (with digital certificate)	SSL
The server administrator sent the digital certificate in an email.	Digital certificate for primary server saved locally	Digital certificate for backup server saved locally
The TCP listening port	389 (tls)	636 (ssl)
Name of the attribute containing the user name	userPrincipalName	userPrincipalName
The names of the attribute containing the user permission levels	OPERATOR ADMINISTRATOR	OPERATOR ADMINISTRATOR

Perform the following steps:

- □ Open the Device Security > Authentication List dialog.
- □ To set up the device to retrieve the user login credentials from the first *Active Directory*, specify for the defaultLoginAuthList list the value *Ldap* in the *Policy 1* column.
- □ Open the *Device Security* > *LDAP* > *Configuration* dialog.
- □ The device lets you specify the length of time that it saves the user login credentials in the cache. To cache user login credentials for a day, in the *Configuration* frame, *Client cache timeout [min]* field, specify the value 1440.
- □ The *Bind user* entry is optional. When specified, users enter only their user name to log in. The service user can be anyone with login credentials listed in the *Active Directory* under the attribute specified in the *User name attribute* column. In the *Bind user* column, specify the user name and the domain.

- □ The *Base DN* is a combination of the domain component (dc) and the organizational unit (ou). The *Base DN* lets the device locate a server in a domain (dc) and find the *Active Directory* (ou). Specify the location of the *Active Directory*. In the *Base DN* column, specify the value ou=Users,ou=City,ou=Country,dc=server,dc=local.
- □ In the *User name attribute* column, enter the value userPrincipalName to specify the attribute under which the server administrator lists the users.

The device uses a digital certificate to verify the identity of the server.

- When the file is located on your PC or on a network drive, drag and drop it onto the area. As an alternative, click in the area to select the file.
- $\hfill\square$ To transfer the file to the device, click the *Start* button.
- \Box To add a table row, click the \blacksquare button.
- □ To specify a description, enter the value Primary AD Server in the *Description* column.
- □ To specify the server name and domain of the primary server, in the *Address* column, enter the value local.server.
- □ The primary server uses the TCP port 389 for communication which is the *Destination TCP port* default value.
- □ The primary server uses TLS for encrypting communication and a digital certificate for server validation. In the *Connection security* column, specify the value startTLS.
- \Box To activate the table row, mark the checkbox in the *Active* column.
- □ Using the information received from the Backup server administrator, add and activate another table row, then specify the settings in the corresponding columns.
- □ Open the *Device Security* > *LDAP* > *Role Mapping* dialog.
- \Box To add a table row, click the $\overset{\blacksquare}{+}$ button.

When a user logs into the device management, with LDAP set up and enabled, the device searches the *Active Directory* for the login credentials of the user. If the device finds the user name and the password is correct, then the device searches for the value specified in the *Type* column. If the device finds the attribute and the text in the *Parameter* column matches the text in the *Active Directory*, then the device lets the user log into the device management with the assigned permission level. When the value attribute is specified in the *Type* column, specify the value in the *Parameter* column in the following form: attributeName=attributeValue.

- $\hfill\square$ In the Role column, enter the value operator to specify the access role.
- $\hfill\square$ To activate the table row, mark the checkbox in the Active column.
- \Box Click the $\overset{\blacksquare}{+}$ button.

The dialog displays the Create window.

Enter the values received from the server administrator for the access role *administrator*. To activate the table row, mark the checkbox in the *Active* column.

- □ Open the *Device Security* > *LDAP* > *Configuration* dialog.
- □ To enable the function, select the *0n* radio button in the *Operation* frame.

The following table describes how to set up the *LDAP* function in the device using the Command Line Interface. The table displays the commands for *Index*=1. To set up other indexes, use the same commands and substitute the appropriate information.

enableTo change to the Privileged EXEC mode.configureTo change to the Configuration mode.ldap cache-timeout 1440To specify the device to flush the non-volatile
memory after a day.

Access to the device 3.4 LDAP function

ldap client server add 1 local.server To add a connection to the remote authentication port 389 client server with the hostname local.server and the UDP port 389. ldap client server modify 1 security To specify the type of security used for the startTLS connection. ldap client server modify 1 description To specify the configuration name of the entry. Primary_AD_Server ldap basedn To specify the Base Domain Name used to find the ou=Users,ou=City,ou=Country,dc=server,dc=1 Active Directory on the server. ocal ldap search-attr userPrincipalName To specify the attribute to search for in the Active Directory which contains the login credential of the users. ldap bind-user user@company.com To specify the name and domain of the service user. ldap bind-passwd Ur-123456 To specify the password of the service user. ldap client server enable 1 To enable the remote authentication client server connection. ldap mapping add 1 access-role operator To add a remote authentication role mapping entry mapping-type attribute mapping-parameter for the access role *operator*. Map the access role OPERATOR operator to the attribute containing the word OPERATOR. ldap mapping enable 1 To enable the remote authentication role mapping entry. ldap operation To enable the remote authentication function.

3.5 SNMP access

The Simple Network Management Protocol (SNMP) lets you work with a network management system to monitor the device over the network and change its settings.

3.5.1 SNMPv1/v2 access

Using SNMPv1 or SNMPv2 the network management system and the device communicate unencrypted. Every SNMP packet contains the *community name* in plain text and the IP address of the sender.

The community names public for read-only access and private for read and write access are preset in the device. If SNMPv1/v2 is enabled, then the device lets anyone who knows the community name have access to the device.

Make undesired access to the device more difficult. To do this, perform the following steps:

- □ Change the default *community names* in the device.
- Treat the community names with discretion.

Anyone who knows the *community name* for write access, has the ability to change the settings of the device.

- Specify a different *community name* for *read and write* access than for *read-only* access.
- □ Use SNMPv1 or SNMPv2 only in environments protected from eavesdropping. The protocols do not use encryption.
- □ Deactivate the write access for the SNMPv1/v2 Write community.
- □ We recommend using SNMPv3 and disabling the access using SNMPv1 and SNMPv2 in the device.

3.5.2 SNMPv3 access

Using SNMPv3 the network management system and the device communicate encrypted. The network management system authenticates itself with the device using the login credentials of a user. The prerequisite for the SNMPv3 access is that in the network management system uses the same settings that are defined in the device.

The device lets you specify the *SNMP auth type* and *SNMP encryption type* parameters individually in each user account.

When you set up a new user account in the device, the parameters are preset so that the network management system Industrial HiVision reaches the device immediately.

The user accounts set up in the device use the same passwords in the Graphical User Interface, in the Command Line Interface, and for SNMPv3.

To adapt the SNMPv3 parameters of the user account settings to the settings in the network management system, perform the following steps:

□ Open the *Device Security* > *User Management* dialog. The dialog displays the user accounts that are set up. □ Click the table row of the relevant user account in the SNMP auth type field. Select the desired setting. □ Click the table row of the relevant user account in the SNMP encryption type field. Select the desired setting. \Box Apply the settings temporarily. To do this, click the \checkmark button. enable To change to the Privileged EXEC mode. configure To change to the Configuration mode. To assign the HMAC-MD5 or HMACSHA protocol users snmpv3 authentication <user> md5 | sha1 for authentication requests to the user account <user>. users snmpv3 encryption <user> des | To assign the DES or AES-128 algorithm to the aescfb128 | none user account <user>. With this algorithm, the device encrypts authentication requests. The value none removes the encryption. show users To display the user accounts that have been set up. To save the settings in the non-volatile memory save (nvm) in the "Selected" configuration profile.

3.5.3 SNMPv3 traps

SNMP version 3 lets the device use encrypted communication with a network management system.

For this, you need to set up the following roles in the device:

- SNMPv3 trap users
- SNMPv3 trap hosts

SNMPv3 trap users

An SNMPv3 trap user has the permission to send SNMPv3 traps to the specified SNMPv3 trap hosts.

An *SNMPv3 trap* user is exclusively for sending *SNMPv3 traps* to *SNMPv3 trap* hosts. Do not confuse *SNMPv3 trap* users with device user accounts. See section "Managing user accounts" on page 71.

The device supports encryption and authentication for sending *SNMPv3 traps*. The device lets you set up *SNMPv3 trap* users.

The device supports the following authentication and encryption types:

auth-no-priv

The user needs to authenticate to send *SNMPv3 traps*. The device sends the *SNMPv3 traps* unencrypted.

auth-priv

The user needs to authenticate to send *SNMPv3 traps*. The device sends the *SNMPv3 traps* encrypted.

no-auth

For security reasons, not recommended.

The device sends the SNMPv3 traps unencrypted without authentication.

To add an SNMPv3 trap user, perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>snmp notification user add <name1> auth- priv auth sha1 <passphrase1> priv des <passphrase2></passphrase2></passphrase1></name1></pre>	 To add the SNMPv3 trap user <name1>:</name1> With authentication and encryption SNMPv3 authentication parameters SHA1 as the cryptographic hash function for SNMPv3 trap user authentication <passphrase1> as passphrase</passphrase1> SNMPv3 encryption parameters DES as the SNMPv3 trap encryption algorithm <passphrase2> as passphrase.</passphrase2>
show snmp notification users	To display the SNMPv3 trap user settings.
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

To modify an existing *SNMPv3 trap* user, delete the user and add a new user with the desired settings.

To delete an SNMPv3 trap user, perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>snmp notification user delete <name1></name1></pre>	To delete the SNMPv3 trap user <name1>.</name1>
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

SNMPv3 trap hosts

An SNMPv3 trap host is the destination for an SNMPv3 trap that the device sends.

The device supports a maximum of 10 SNMP trap hosts.

To specify an SNMPv3 trap host, perform the following steps:

enableTo change to the Privileged EXEC mode.configureTo change to the Configuration mode.

<pre>snmp notification host add <hostname1> a.b.c.d user <name2> auth-priv</name2></hostname1></pre>	 To add the SNMPv3 trap host <hostname1></hostname1> With the IPv4 address <a.b.c.d></a.b.c.d> Username <name2></name2> With authentication and encryption
show snmp notification hosts	To display the SNMPv3 trap host settings.
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

To modify an existing *SNMPv3 trap* host, delete the host and add a new host with the desired settings.

To delete an *SNMPv3 trap* host, perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>snmp notification host delete <hostname1></hostname1></pre>	To delete the SNMPv3 trap host <hostname1>.</hostname1>
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

4 Synchronizing the system time in the network

Many applications rely on a time that is as correct as possible. The necessary accuracy, and thus the allowable deviation from the actual time, depends on the application area.

Examples of application areas include:

- Log entries
- Time stamping of production data
- Process control

The device lets you synchronize the time in the network using the following options:

- The Simple Network Time Protocol (SNTP) is a simple solution for low accuracy requirements. Under ideal conditions, the Simple Network Time Protocol (SNTP) achieves accuracy in the millisecond range. The accuracy depends on the signal delay.
- The Precision Time Protocol (PTP) along with IEEE 1588 achieves accuracy on the order of sub-microseconds. This protocol is suitable for demanding applications up to and including process control.

When the involved devices support the Precision Time Protocol (PTP), it is the better choice. The Precision Time Protocol (PTP) is more accurate, has advanced methods of error correction, and causes only a low network load. The implementation of the Precision Time Protocol (PTP) is comparatively easy.

Note: According to the Precision Time Protocol (PTP) and Simple Network Time Protocol (SNTP) standards, both protocols can operate in parallel in the same network. However, since both protocols can influence the system time of the device, situations can occur in which the two protocols conflict with each other.

4.1 Setting the time

When there is no reference time source available to you, you can manually set the system time in the device.

When you start the device after it has been powered down for some time, it initializes the clock with January 1 2024, 01:00 UTC+1. After powered down, the device buffers the settings of its real-time clock for up to 24 hours.

As an alternative, you can set up the device to obtain the current time using one of the following protocols:

- Simple Network Time Protocol
- Precision Time Protocol

Perform the following steps:

- □ Open the *Time* > *Basic* Settings dialog.
- The System time (UTC) field displays the current date and time with reference to Universal Time Coordinated (UTC). UTC is the same worldwide and does not take local time shifts into account.
- The time in the System time field comes from the System time (UTC) plus the Local offset [min] value and a possible shift due to daylight saving time.

Note: PTP sends the International Atomic Time (TAI). As of July 1, 2020, the TAI time is 37 s ahead of the Universal Time Coordinated (UTC). When the PTP reference time source of the UTC offset is set correctly, the device automatically corrects this difference on the display in the *System time (UTC)* field.

□ To make the device apply the time of your computer to the *System time* field, click the *Set time from PC* button.

Based on the value in the *Local offset* [*min*] field, the device calculates the time in the *System time* (*UTC*) field: The *System time* (*UTC*) comes from the *System time* minus the *Local offset* [*min*] value and a possible shift due to daylight saving time.

The Time source field displays the origin of the time data. The device automatically selects the source with the greatest accuracy.

The source is initially *Local*.

When SNTP is active and the device receives a valid SNTP packet, the device sets its time source to *sntp*.

When PTP is active and the device receives a valid PTP message, the device sets its time source to ptp. The device prioritizes PTP ahead of SNTP.

- The Local offset [min] value specifies the difference in minutes between Universal Time Coordinated (UTC) and local time.
- □ To cause the device to determine the time zone on your PC, click the Set time from PC button. The device calculates the difference between local time and Universal Time Coordinated (UTC), and enters the difference into the Local offset [min] field.

Note: The device provides the option to obtain the local offset from a DHCP server.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
clock set <yyyy-mm-dd> <hh:mm:ss></hh:mm:ss></yyyy-mm-dd>	To set the system time of the device.
clock timezone offset <-780840>	To enter the difference in minutes between the local time and the received Universal Time Coordinated (UTC).
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

4.2 Automatic daylight saving time changeover

When you operate the device in a time zone with a summer time change, the device lets you set up the automatic daylight saving time changeover.

If the *Daylight saving time* mode is enabled, the device advances the local system time by one hour during the summer time. At the end of summer time, the device sets the local system time back again by one hour.

4.2.1 Setting daylight saving time using pre-defined profiles

The device lets you specify the start and end of daylight saving time using pre-defined profiles.

The device includes the following pre-defined profiles:

- *EU*
- Daylight saving time settings as applicable in the European Union.
- USA
 - Daylight saving time settings as applicable in the United States of America.

To select the *EU* profile for the daylight saving time settings, perform the following steps:

- □ Open the *Time* > *Basic Settings* dialog, *Daylight saving time* tab.
- □ In the *Operation* frame, click the *Profile...* button.
- Select the *EU* item from the *Profile...* list.
 Selecting a profile overwrites the settings specified in the *Summertime begin* and *Summertime end* frames.
- Click the Ok button.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
clock summer-time mode eu	To enable the <i>Daylight saving time</i> mode with the profile eu.

4.2.2 Setting daylight saving time manually

The network administrator wants to specify the following daylight saving time settings:

Summertime begin

- Week = Last
- Day = Sunday
- Month = March
- System time = 02:00

Summertime end

- Week = Last
- Day = Sunday

– Month = October

- System time = 03:00

For the purpose described above, perform the following steps:

- □ Open the *Time* > *Basic Settings* dialog, *Daylight saving time* tab.
- □ Enable the *Daylight saving time* mode. To do this, in the *Operation* frame, select the *0n* radio button.
- □ In the *Summertime begin* frame, specify the following settings:
 - Week = Last
 - Day = Sunday
 - Month = March
 - System time = 02:00
- □ In the *Summertime end* frame, specify the following settings:
 - Week = Last
 - Day = Sunday
 - Month = October
 - System time = 03:00

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
clock summer-time mode recurring	To enable the <i>Daylight saving time</i> mode.
clock summer-time recurring start last sun mar 02:00	To specify the time at which the device sets the clock forward from standard time to summer time. ¹ last To specify the <i>Last</i> week in the month. ^{sun} To specify the day <i>Sunday</i> . ^{mar} To specify the month <i>March</i> . ⁹ 02:00 To specify the time 02:00.
clock summer-time recurring end last sun oct 03:00	 To specify the time at which the device resets the clock from summer time to standard time. last last To specify the <i>Last</i> week in the month. sun sun To specify the day <i>Sunday</i>. oct oct To specify the month <i>October</i>. Ø3:00 To specify the time Ø3:00.

4.3 Synchronizing time in the network with SNTP

The Simple Network Time Protocol (SNTP) lets you synchronize the system time in the network. The device supports the SNTP client and the SNTP server function.

The SNTP server makes the Universal Time Coordinated (UTC) available. UTC is the time relating to the coordinated world time measurement. UTC is the same worldwide and does not take local time shifts into account.

SNTP is a simplified version of Network Time Protocol (NTP). The data packets are identical with SNTP and NTP. Accordingly, both NTP and SNTP servers serve as a time source for SNTP clients.

Note: Statements in this chapter relating to external SNTP servers also apply to NTP servers.

SNTP knows the following operation modes for the transmission of time:

- Unicast
- In *Unicast* operation mode, an SNTP client sends requests to an SNTP server and expects a response from this server.
- Broadcast

In *Broadcast* operation mode, an SNTP server sends SNTP messages to the network in specified intervals. SNTP clients receive these SNTP messages and evaluate them.

In an IPv6 environment, the *Broadcast* operation mode operates as follows:

- The SNTP client listens only for SNTP server messages that have the IPv6 Multicast address set to ff05::101 as the IPv6 destination address.
- The SNTP server sends only SNTP messages to the *Multicast* address ff05::101. The SNTP server does not send SNTP messages with the link-local address as the IPv6 source address.

Table 15: Target IPv4 address classes for Broadcast operation mode

IPv4 destination address	Send SNTP packets to
0.0.0.0	Nobody
224.0.1.1	Multicast address for SNTP messages
255.255.255.255	Broadcast address


Note: An SNTP server in *Broadcast* operation mode also responds to direct requests using *Unicast* from SNTP clients. In contrast, SNTP clients work in either *Unicast* or *Broadcast* operation mode.

4.3.1 Preparation

Perform the following steps:

□ To get an overview of how the time is passed on, draw a network plan with the devices participating in SNTP.

When planning, bear in mind that the accuracy of the time depends on the delays of the SNTP messages. To minimize delays and their variance, place an SNTP server in each network segment. Each of these SNTP servers synchronizes its own system time as an SNTP client with its parent SNTP server (SNTP cascade). The highest SNTP server in the SNTP cascade has the most direct access to a reference time source.



Note: For precise time distribution, between SNTP servers and SNTP clients you preferably use network components (routers and switches) that forward the SNTP packets with a low and uniform transmission time (latency).

An SNTP client sends its requests to up to 4 set-up SNTP servers. When there is no response from the first SNTP server, the SNTP client sends its requests to the second SNTP server. When this request is also unsuccessful, it sends the request to the 3rd and finally to the 4th SNTP server. If none of these SNTP servers respond, the SNTP client loses its synchronization. The SNTP client periodically sends requests to each SNTP server until a server delivers a valid time.

Note: The device provides the option of obtaining a list of SNTP server IP addresses from a DHCP server.

□ If no reference time source is available to you, then determine a device with an SNTP server as a reference time source. Adjust its system time at regular intervals.

4.3.2 Defining settings of the SNTP client

As an SNTP client, the device obtains the time information from SNTP or NTP servers and synchronizes its system clock accordingly. To do this, perform the following steps:

- □ Open the *Time* > *SNTP* > *Client* dialog.
- □ Set the SNTP operation mode.
 - In the Configuration frame, select one of the following values in the Mode field:
 - unicast
 - The device sends requests to an SNTP server and expects a response from this server. *broadcast*
 - The device waits for *Broadcast* or *Multicast* messages from SNTP servers on the network.
- □ To synchronize the time only once, mark the *Disable client after successful sync* checkbox. After synchronization, the device disables the *Client* function.
- ▶ The table displays the SNTP server to which the SNTP client sends a request in *Unicast* operation mode. The table contains up to 4 SNTP server definitions.
- \Box To add a table row, click the $\overset{\blacksquare}{+}$ button.
- □ Specify the connection data of the SNTP server.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- ▶ The State field displays the current status of the Client function.

Table 16:	SNTP	client settings	for the	example
-----------	------	-----------------	---------	---------

Device	192.168.1.1	192.168.1.2	192.168.1.3	192.168.1.11	192.168.1.12
Client function	0ff	On	On	On	On

Device	192.168.1.1	192.168.1.2	192.168.1.3	192.168.1.11	192.168.1.12
Configuration: Mode	unicast	unicast	unicast	unicast	unicast
Request interval [s]	30	30	30	30	30
Server address(es)	-	192.168.1.1	192.168.1.21 92.168.1.1		192.168.1.31 92.168.1.219 2.168.1.1

Table 16:	SNTP client settings for the example (cont.)
-----------	----------------------------------------------

4.3.3 Specifying SNTP server settings

When operating as an SNTP server, the device distributes its system time as Universal Time Coordinated (UTC) to the network. To do this, perform the following steps:

- \Box Open the *Time* > *SNTP* > *Server* dialog.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- To enable the *Broadcast* operation mode, select the *Broadcast admin mode* radio button in the *Configuration* frame.
 In *Broadcast* operation mode, the SNTP server sends SNTP messages to the network in specified intervals. The SNTP server also responds to the requests from SNTP clients in *Unicast* operation mode.
 - □ In the *Broadcast destination address* field, you set the IPv4 address to which the SNTP server sends the SNTP packets. Set a *Broadcast* address or a *Multicast* address. In an IPv6 environment, you cannot set the IPv6 address to which the SNTP server sends the SNTP packets. The SNTP server uses the *Multicast* address ff05::101 as the IPv6 destination address.
 - □ In the *Broadcast UDP port* field, you specify the number of the UDP port to which the SNTP server sends the SNTP packets in *Broadcast* operation mode.
 - □ In the *Broadcast VLAN ID* field, you specify the VLAN to which the SNTP server sends the SNTP packets in *Broadcast* operation mode.
 - □ In the *Broadcast send interval* [s] field, you specify the time interval at which the SNTP server of the device sends SNTP *Broadcast* packets.

Note: Except for the *Broadcast destination address* field, the remaining settings are applicable for both IPv4 and IPv6 SNTP servers.

- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- ▶ The State field displays the current status of the Server function.

Device	192.168.1.1	192.168.1.2	192.168.1.3	192.168.1.11	192.168.1.12
Server function	On	On	On	0ff	0ff
UDP port	123	123	123	123	123
Broadcast admin mode	unmarked	unmarked	unmarked	unmarked	unmarked
Broadcast destination address	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0
Broadcast UDP port	123	123	123	123	123

Table 17: Settings for the example

Device	192.168.1.1	192.168.1.2	192.168.1.3	192.168.1.11	192.168.1.12
Broadcast VLAN ID	1	1	1	1	1
Broadcast send interval [s]	128	128	128	128	128
Disable server at local time source	unmarked	unmarked	unmarked	unmarked	unmarked

Table 17: Settings for the example (cont.)

4.4 Synchronizing time in the network with PTP

For LAN-controlled applications to operate without latency, precise time management is required. With Precision Time Protocol (PTP), IEEE 1588 describes a method that enables precise synchronization of clocks in the network.

PTP permits synchronization with an accuracy of a few 100 ns. PTP uses Multicasts for the synchronization messages, which keeps the network load low.

4.4.1 Types of clocks

PTP defines the roles of "master" and "slave" for the clocks in the network:

- A master clock (reference time source) distributes its time.
- A slave clock synchronizes itself with the timing signal received from the master clock.

Boundary clock

The transmission time (latency) in routers and switches has a measurable effect on the precision of the time transmission. To correct such inaccuracies, PTP defines what are known as boundary clocks.

In a network segment, a boundary clock is the reference time source (master clock) to which the subordinate slave clocks synchronize. Typically routers and switches take on the role of boundary clock.

The boundary clock in turn obtains the time from a higher-level reference time source (Grandmaster).




Figure 20: Position of the boundary clock in a network

Transparent Clock

Switches typically take on the *Transparent Clock* role to enable high accuracy across the cascades. The *Transparent Clock* is a *Slave* clock that corrects its own transmission time when it forwards received synchronization messages.

Ordinary Clock

PTP designates the clock in a end device as an Ordinary Clock. An Ordinary Clock functions either as a master clock or slave clock.

4.4.2 Best Master Clock algorithm

The devices participating in PTP designate a device in the network as a reference time source (Grandmaster). Here the *Best Master Clock* algorithm is used, which determines the accuracy of the clocks available in the network.

The Best Master Clock algorithm evaluates the following criteria:

- Priority 1
- Clock class
- Clock accuracy
- Clock variance
- Priority 2

The algorithm first evaluates the value in the *Priority 1* field of the participating devices. The device with the numerically lowest *Priority 1* value becomes the reference time source (*Grandmaster*). When the value is the same for multiple devices, the algorithm takes the next criterion. When this is also the same, it takes the next criterion after this one. If these values are the same for multiple devices, then the numerically lowest *Clock identity* value decides which device becomes the reference time source (*Grandmaster*).

In the settings of the boundary clock, the device lets you individually specify the values for *Priority* 1 and *Priority* 2. This lets you influence which device will be the reference time source (*Grandmaster*) in the network.

4.4.3 Delay measurement

The delay of the synchronization messages between the devices affects the accuracy. The delay measurement lets the devices take into account the average delay.

PTP version 2 offers the following methods for delay measurement:

▶ *e2e* (End to End)

The slave clock measures the delay of synchronization messages to the master clock.

e2e-optimized

The slave clock measures the delay of synchronization messages to the master clock. This method is available only for transparent clocks. The device forwards the synchronization messages sent using Multicast only to the master clock, keeping the network load low. When the device receives a synchronization message from another master clock, it forwards the synchronization messages only to this new port.

When the device knows no master clock, it forwards synchronization messages to every port. ▶ *p2p* (Peer to Peer)

The slave clock measures the delay of synchronization messages to the master clock. In addition, the master clock measures the delay to each slave clock, even across blocked ports. This requires that the master and slave clock support Peer-to-Peer (p2p).

In case of interruption of a redundant ring, for example, the slave clock becomes the master clock and the master clock becomes the slave clock. This switch occurs without loss of precision, because the clocks already know the delay in the other direction.

4.4.4 **PTP domains**

The device transmits synchronization messages only from and to devices in the same PTP domain. The device lets you set the domain for the boundary clock and for the transparent clock individually.




Figure 21: Example of PTP domains

4.4.5 Using PTP

To synchronize the clocks precisely with PTP, only use switches with a boundary clock or transparent clock as nodes.

Perform the following steps:

- □ To gain an overview of the distribution of clocks, draw a network plan with the devices involved in PTP.
- □ Specify the role for each participating switch (boundary clock or transparent clock). In the device, this setting is called *PTP mode*.

Table 18: Possible settings for PTP mode

PTP mode	Application
v2-boundary-clock	As a boundary clock, the device distributes synchronization messages to the slave clocks in the subordinate network segment. The boundary clock in turn obtains the time from a higher-level reference time source (Grandmaster).
v2-transparent- cLock	As a transparent clock, the device forwards received synchronization messages after they have been corrected by the delay of the transparent clock.

□ Enable PTP on each participating switch.

PTP then sets itself up on a largely automatic basis.

□ Enable PTP on the end devices.

□ The device lets you influence which device in the network becomes the reference clock (Grandmaster). Therefore, change the default value in the *Priority 1* and *Priority 2* fields for the *Boundary Clock*.

4.5 Synchronizing time in the network with 802.1AS

Some LAN-based applications require the internal clocks of the participating devices to be precisely synchronized. The IEEE 802.1AS-2020 protocol describes a method that enables precise synchronization of the clocks of time-aware devices in the network.

The IEEE 802.1AS-2020 protocol is based on Precision Time Protocol (PTP) and is tailored for Ethernet-based Time-Sensitive Networking (TSN) environments.

The *802.1AS* function in the device permits synchronization with an accuracy of a few 100 ns. The *802.1AS* function uses Multicasts for the synchronization messages, therefore keeping the network load low.

4.5.1 Instances and domains

Each *PTP domain* operates independently and helps ensure that the clocks of the time-aware devices within the *PTP domain* are synchronized. The devices are synchronized to the reference time source (*Grandmaster*) of the respective domain. You can use different domains to synchronize the time for different groups of devices within a network.

The device can be part of multiple *PTP domains*. In the device, the *802.1AS* function supports 2 instances: *Instance 0* and *Instance 1*, each operating within separate *PTP domains*.

You set up each instance separately:

Instance 0

- for synchronizing device clocks and transmitting time synchronization messages
- Instance 1 only for transmitting time synchronization messages

4.5.2 Best Master Clock algorithm

The devices participating in PTP designate a device in the *PTP domain* as a reference time source (*Grandmaster*). The *Best Master Clock* algorithm is used to determine the accuracy of the clocks available in the *PTP domain*.

The Best Master Clock algorithm evaluates the following criteria for each participating device:

- Priority 1
- Clock class
- Clock accuracy
- Clock variance
- Priority 2
- Clock identity

The algorithm first evaluates the value in the *Priority 1* field of the participating devices. The device with the numerically lowest value in the *Priority 1* field is designated as the reference time source (*Grandmaster*). If the value is the same for multiple devices, then the algorithm takes the next criterion. If this is also the same, then the algorithm takes the next criterion after this one. If these values are the same for multiple devices, then the numerically lowest value in the *Clock identity* field decides which device is designated as the reference time source (*Grandmaster*). The value in the *Clock identity* field is based on the device MAC address which is supposed to be globally unique. The value in the *Clock identity* field serves as the final tie-break for the algorithm.

4.5.3 Enabling the 802.1AS function

The 802.1AS function and the PTP function cannot be enabled simultaneously on the device.

In the default setting, the *802.1AS* function is disabled. Enabling the *802.1AS* function lets time-aware devices within the same *PTP domain* synchronize.

Perform the following steps on each device within the same PTP domain:

- \Box Open the *Time* > 802.1AS > Global dialog.
- Enable the 802.1AS function globally.
 Select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Time* > 802.1AS > Port dialog.
- Enable the 802.1AS function for Instance 0.
 Select the Instance 0 tab.
 Select the *0n* radio button in the *Operation* frame.
- □ Enable the 802.1AS function on the interface. In the Active column of the desired interface, mark the checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dotlas operation enable	To enable the 802.1AS function globally.
dot1as instance 0 operation enable	To enable the 802.1AS function for Instance 0.
interface 1/1	To change to the interface configuration mode of interface 1/1.
dotlas instance 0 operation enable	To enable the 802.1AS function on interface 1/1 for <i>Instance 0</i> .
show dotlas data-port-set instance 0 port 1/1	To check the status of <i>Instance 0</i> on interface $1/1$.
show dotlas current instance 0	To check the status of Instance 0.
exit	To change to the Configuration mode.
exit	To change to the Privileged EXEC mode.

To save the settings permanently, see section "Saving a configuration profile" on page 103.

4.5.4 Disabling the 802.1AS function globally

When disabling the *802.1AS* function globally, you disable time synchronization for both instances and for the respective ports allocated to them. This disables time synchronization on the instance and port levels even if the *802.1AS* function is enabled on the instances and on the individual ports.

Perform the following steps on each device within the same PTP domain:

\Box Apply the settings temporarily. To do this, click the \checkmark button.	
EC mode.	
mode.	
globally.	
EC mode.	
mo glo	

To save the settings permanently, see section "Saving a configuration profile" on page 103.

4.5.5 Disabling the 802.1AS function for an instance

You disable the 802.1AS function on an instance, for example, in the following situations:

- to disable time synchronization for the ports allocated to the respective instance in one go
- · to reallocate a port from one instance to another instance
- to reduce the network load generated by the transmission of synchronization messages

Perform the following steps:

- □ Open the *Time* > 802.1AS > Port dialog.
- Disable the 802.1AS function for Instance 0.
 Select the Instance 0 tab.
 Select the 0ff radio button in the Operation frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dot1as instance 0 operation disable	To disable the 802.1AS function for Instance 0.
exit	To change to the Privileged EXEC mode.

To save the settings permanently, see section "Saving a configuration profile" on page 103.

4.5.6 Disabling the 802.1AS function on a port

You disable the 802.1AS function on an individual port, for example, in the following situations:

- When the port is connected to a device that is not time-aware and, therefore, does not require time synchronization.
- When you allocate the port to another instance. Before you allocate a port to another instance, we recommend you disable the *802.1AS* function on the port.

Perform the following steps:

Open the <i>Time</i> > 802.1AS > Port dialog Select the <i>Instance 0</i> tab.	l.
 Deactivate the 802.1AS function on interface 1/1. Unmark the checkbox in the Active column. 	
\Box Apply the settings temporarily. To do this, click the \checkmark button.	
enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
dotlas instance 0 operation disable	To disable the 802.1AS function on interface 1/1 for <i>Instance</i> 0.
exit	To change to the Configuration mode.
exit	To change to the Privileged EXEC mode.

To save the settings permanently, see section "Saving a configuration profile" on page 103.

5 Managing configuration profiles

If you change the settings of the device during operation, then the device stores the changes in its memory (*RAM*). After a reboot the settings are lost.

To keep the changes after a reboot, the device lets you save the settings in a configuration profile in the non-volatile memory (*NVM*). To make it possible to quickly switch to other settings, the non-volatile memory offers storage space for multiple configuration profiles.

If an external memory is connected, then the device automatically saves a copy of the configuration profile in the external memory (*ENVM*). You can disable this function.

5.1 Detecting changed settings

The device stores changes made to settings during operation in its volatile memory (RAM). The configuration profile in the non-volatile memory (NVM) remains unchanged until you save the changed settings explicitly. Until then, the configuration profiles in memory and non-volatile memory are different. The device helps you recognize changed settings.

5.1.1 Volatile memory (RAM) and non-volatile memory (NVM)

You can recognize if the settings in the volatile memory (*RAM*) differ from the settings of the "selected" configuration profile in the non-volatile memory (*NVM*). To do this, perform the following steps:

Check the banner of the Grap	hical User Interface:
------------------------------	-----------------------

- When the 🛃 icon is visible, the settings differ.
- When no **.** icon is visible, the settings match.

	`		
()	r	î

□ Open the *Basic Settings > Load/Save* dialog.

- Check the status of the checkbox in the *Information* frame:
 - When the checkbox is marked, the settings match.
 - When the checkbox is unmarked, the settings differ.

show config status

Configuration Storage sync State
running-config to NVout of sync

5.1.2 External memory (ACA) and non-volatile memory (NVM)

You can recognize if the settings copied to the external memory (ACA) differ from the settings of the configuration profile in the non-volatile memory (NVM). To do this, perform the following steps:

□ Open the <i>Basic Settings</i> > <i>Load/Save</i> dialog.
 Check the status of the checkbox in the <i>Information</i> frame: When the checkbox is marked, the settings match. When the checkbox is unmarked, the settings differ.
show config status
Configuration Storage sync State
•••
NV to ACAout of sync
•••

5.2 Saving the settings

5.2.1 Saving the configuration profile in the device

If you change the settings of the device during operation, then the device stores the changes in its memory (RAM). To keep the changes after a reboot, save the configuration profile in the non-volatile memory (*NVM*).

Saving a configuration profile

The device stores the settings in the "selected" configuration profile in the non-volatile memory (*NVM*).

Perform the following steps:

□ Open the <i>Basic Settings > Load/Save</i> dialog.	
 Verify that the required configuration profile is "Selected". You can recognize the "Selected" configuration profile because the checkbox in the Selected column is marked. 	
□ Click the 🖬 button.	
show config profiles nvm	To display the configuration profiles contained in the non-volatile memory (nvm).
enable	To change to the Privileged EXEC mode.
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

Copying settings to a configuration profile

The device lets you store the settings saved in the memory (RAM) in a configuration profile other than the "selected" configuration profile. In this way the device adds a configuration profile in the non-volatile memory (NVM) or overwrites an existing one.

Perform the following steps:

- □ Open the *Basic Settings* > *Load/Save* dialog.
- □ In the *Name* field, change the name of the configuration profile. If you keep the proposed name, the device will overwrite an existing configuration profile of the same name.
- Click the Ok button.

The new configuration profile is designated as "Selected".

show config profiles nvm	To display the configuration profiles contained in the non-volatile memory (nvm).
enable	To change to the Privileged EXEC mode.
copy config running-config nvm profile <string></string>	To save the current settings in the configuration profile named <string> in the non-volatile memory (nvm). If present, the device overwrites a configuration profile of the same name. The new configuration profile is designated as "Selected".</string>

Selecting a configuration profile

When the non-volatile memory (*NVM*) contains multiple configuration profiles, you have the option to select any configuration profile there. The device stores the settings in the "Selected" configuration profile. During the system startup, the device loads the settings of the "Selected" configuration profile into the memory (RAM).

Perform the following steps:

□ Open the <i>Basic Settings > Load/Save</i> dialog.		
The table displays the configuration profiles present in the device. You can recognize the "Selected" configuration profile because the checkbox in the <i>Selected</i> column is marked.		
Select the table row of the desired configuration profile stored in the non-volatile memory (NVM).		
\Box Click the \blacksquare button and then the <i>Select</i> item.		
In the <i>Selected</i> column, the checkbox of the configuration profile is now marked.		
enable	To change to the Privileged EXEC mode.	
show config profiles nvm	To display the configuration profiles contained in the non-volatile memory (nvm).	
configure	To change to the Configuration mode.	
config profile select nvm 1	To select the configuration profile. Take note of the adjacent name of the configuration profile.	
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.	

5.2.2 Saving the configuration profile in the external memory

When an external memory is connected and you save a configuration profile, the device automatically saves a copy in the *Selected external memory*. In the default setting, the function is enabled. You can disable this function.

Perform the following steps:

- □ Open the *Basic Settings > External Memory* dialog.
- □ Mark the checkbox in the *Backup config when saving* column to enable the device to automatically save a copy in the external memory during the saving process.
- □ To deactivate the function, unmark the checkbox in the *Backup config when saving* column.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
config envm config-save sd config envm config-save usb	To enable the function. When you save a configuration profile, the device saves a copy in the external memory. <i>sd</i> = External SD memory <i>usb</i> = External USB memory
no config envm config-save sd no config envm config-save usb	To disable the function. The device does not save a copy in the external memory. <i>sd</i> = External SD memory <i>usb</i> = External USB memory
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

5.2.3 Backing up the configuration profile on a remote server

The device lets you automatically back up the configuration profile to a remote server. The prerequisite is that you activate the function before you save the configuration profile.

After you save the configuration profile in the non-volatile memory (*NVM*), the device sends a copy to the specified URL.

Perform the following steps:

- Open the Basic Settings > Load/Save dialog.
 In the Backup config on a remote server when saving frame, perform the following steps:
- □ In the *URL* field, specify the server as well as the path and file name of the backed up configuration profile.
- Click the Set credentials button.
 The dialog displays the Credentials window.

□ Enter the login credentials needed to authenticate on the remote server.

□ In the *Operation* option list, enable the function.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
show config remote-backup	To check the status of the function.
configure	To change to the Configuration mode.
config remote-backup destination {URL}	To enter the destination URL for the configuration profile backup (max. 128 chars).
config remote-backup username {username}	To enter the user name to authenticate on the remote server (max. 128 chars).
<pre>config remote-backup password {password}</pre>	To enter the password to authenticate on the remote server (max. 128 chars).
config remote-backup operation	To enable the function.

If the transfer to the remote server is unsuccessful, then the device logs this event in the System Log.

5.2.4 Exporting a configuration profile

The device lets you save a configuration profile to a server as an XML file. If you use the Graphical User Interface, then you have the option to save the XML file directly to your PC.

Prerequisites:

- To save the file on a server, you need a server available on the network.
- To save the file to an SCP or SFTP server, you also need the user name and password for accessing this server.
- Remember to make the SCP or SFTP server known to the device before the device accesses the server for the first time. See the *Device Security* > SSH Known Hosts dialog.

Perform the following steps:

Open the Basic Settings > Load/Save dialog.

 $\hfill\square$ Select the table row of the desired configuration profile.

Export the configuration profile to your PC. To do this, perform the following steps:

Click the link in the *Profile name* column.
 The configuration profile is downloaded and saved as an XML file on your PC.

Export the configuration profile to a remote server. To do this, perform the following steps:

- □ In the *URL* field, specify the file URL on the remote server:
 - □ To save the file on an FTP server, specify the URL for the file in the following form: ftp://<user>:<password>@<IP address>[:port]/<file name> This option is not recommended if you transmit data over untrusted networks.
 - To save the file on a TFTP server, specify the URL for the file in the following form: tftp://<IP address>/<path>/<file name>
 - This option is not recommended if you transmit data over untrusted networks.
 - □ To save the file on an SCP or SFTP server, specify the URL for the file in one of the following forms:

scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name>
scp:// or sftp://<IP address>/<path>/<file name>
Remember to make the SCP or SFTP server known to the device before the device

accesses the server for the first time. See the *Device Security* > *SSH Known Hosts* dialog. When you click the *Ok* button, the device displays the *Credentials* window. There you enter *User name* and *Password* to log into the server.

Click the Ok button.

The configuration profile is now saved as an XML file in the specified location.

show config profiles nvm	To display the configuration profiles contained in the non-volatile memory (nvm) .
enable	To change to the Privileged EXEC mode.
<pre>copy config running-config remote tftp:// <ip_address>/ <path>/<file_name></file_name></path></ip_address></pre>	To save the current settings on a TFTP server. This option is not recommended if you transmit data over untrusted networks.
copy config nvm remote sftp:// <user_name>:<password>@<ip_address>/ <path>/<file_name></file_name></path></ip_address></password></user_name>	To save the "Selected" configuration profile in the non-volatile memory (nvm) on a SFTP server.
<pre>copy config nvm profile config3 remote tftp://<ip_address>/ <path>/ <file_name></file_name></path></ip_address></pre>	To save the configuration profile config3 in the non-volatile memory (nvm) on a TFTP server. This option is not recommended if you transmit data over untrusted networks.
<pre>copy config nvm profile config3 remote ftp://<ip_address>[:port]/<path>/ <file_name></file_name></path></ip_address></pre>	To save the configuration profile config3 in the non-volatile memory (nvm) on an FTP server. This option is not recommended if you transmit

data over untrusted networks.

5.3 Loading settings

If you save multiple configuration profiles in the memory, then you have the option to load a different configuration profile.

5.3.1 Activating a configuration profile

The non-volatile memory of the device can contain multiple configuration profiles. If you activate a configuration profile stored in the non-volatile memory (NVM), then you immediately change the settings in the device. The device does not require a reboot.

Perform the following steps:

□ Open the *Basic Settings > Load/Save* dialog.

□ Select the table row of the desired configuration profile.

 \Box Click the \blacksquare button and then the *Activate* item.

The device copies the settings to the memory (RAM) and disconnects from the Graphical User Interface. The device immediately uses the settings of the configuration profile.

□ Reload the Graphical User Interface.

Log in again.

In the *Selected* column, the checkbox of the configuration profile that was activated before is marked.

show config profiles nvm	To display the configuration profiles contained in the non-volatile memory (nvm).
enable	To change to the Privileged EXEC mode.
copy config nvm profile config3 running- config	To activate the settings of the configuration profile config3 in the non-volatile memory (nvm). The device copies the settings into the volatile memory and disconnects the connection to the Command Line Interface. The device immediately uses the settings of the configuration profile config3.

5.3.2 Loading the configuration profile from the external memory

If an external memory is connected, then the device loads a configuration profile from the external memory during the system startup automatically. The device lets you save these settings in a configuration profile in non-volatile memory.

When the external memory contains the configuration profile of an identical device, you have the possibility to transfer the settings from one device to another.

Perform the following steps:

□ Verify that the device loads a configuration profile from the external memory during the system startup.

In the default setting, the function is enabled. If the function is disabled, enable it again as follows:

□ Open the Basic Settings > External Memory dialog.

□ In the *Config priority* column, select the value *first*.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable			To change to the Privileged EXEC mode.
configure			To change to the Configuration mode.
config env	m load-priority	sd first	To enable the function. During the system startup, the device loads a configuration profile from the external memory. <i>sd</i> = External SD memory
config env	m load-priority	usb first	To enable the function. During the system startup, the device loads a configuration profile from the external memory. <i>usb</i> = External USB memory
show confi	g envm settings		To display the settings of the external memory (envm).
Type Sta	tus Auto Up	odate Save Config	g Config Load Prio
sd ok	[x]	[x]	second
usb ok	[x]	[x]	first
save			To save the settings in a configuration profile in the non-volatile memory (<i>NVM</i>) of the device.

Using the Command Line Interface, the device lets you copy the settings from the external memory directly into the non-volatile memory (NVM).

show config profiles nvm	To display the configuration profiles contained in the non-volatile memory (nvm).
enable	To change to the Privileged EXEC mode.
copy config envm profile config3 nvm	To copy the configuration profile config3 from the external memory (envm) to the non-volatile memory (nvm).

The device can also automatically load a configuration profile from a script file during the system startup.

Prerequisites:

- ▶ Verify that the external memory is connected before you start the device.
- The root directory of the external memory contains a text file startup.txt with the content script=<file_name>. The placeholder <file_name> represents the script file that the device executes during the system startup.
- ▶ The root directory of the external memory contains the script file. You have the option to save the script with a user-specified name. Save the file with the file extension .cli.

Note: Verify that the script saved in the external memory is not empty. If the script is empty, then the device loads the next configuration profile as per the configuration priority settings.

After applying the script, the device automatically saves the configuration profile from the script file as an XML file in the external memory. When you type the appropriate command into the script file, you have the option to disable this function:

no config envm config-save sd

The device does not save a copy in the external SD memory.

□ no config envm config-save usb

The device does not save a copy in the external USB memory.

When the script file contains an incorrect command, the device does not apply this command during the system startup. The device logs the event in the System Log.

5.3.3 Importing a configuration profile

The device lets you import from a server a configuration profile saved as an XML file. If you use the Graphical User Interface, then you can import the XML file directly from your PC.

Prerequisites:

- ▶ To import a file from a server, you need a server available on the network.
- To import a file from an SCP or SFTP server, you also need the user name and password for accessing this server.
- Remember to make the SCP or SFTP server known to the device before the device accesses the server for the first time. See the Device Security > SSH Known Hosts dialog.

Perform the following steps:

- □ Open the *Basic Settings > Load/Save* dialog.
- □ From the *Select source* drop-down list, select the location from where the device imports the configuration profile.
 - PC/URL
 - The device imports the configuration profile from the local PC or from a remote server. *External memory*
 - The device imports the configuration profile from the selected external memory.

Import the configuration profile from the local PC or from a remote server. To do this, perform the following steps:

- □ Import the configuration profile:
 - If the file is on an FTP server, then specify the URL in the following form: ftp://<user>:<password>@<IP address>[:port]/<file name> This antian is not recommended if you transmit data over untrusted nature
 - This option is not recommended if you transmit data over untrusted networks. If the file is on a TFTP server, then specify the URL in the following form: tftp://<IP address>/<path>/<file name>
 - This option is not recommended if you transmit data over untrusted networks.
 - □ If the file is on an SCP or SFTP server, then specify the URL in one of the following forms:
 - scp:// or sftp://<IP address>/<path>/<file name>
 - When you click the *Start* button, the device displays the *Credentials* window. There you enter *User name* and *Password* to log into the server.
 - scp:// or sftp://<user>:<password>@<IP address>/<path>/<file name>
 Remember to make the SCP or SFTP server known to the device before the device
 accesses the server for the first time. See the Device Security > SSH Known Hosts dialog.
- □ In the *Destination* frame, specify where the device saves the imported configuration profile:
 - □ In the *Profile name* field, specify the name under which the device saves the configuration profile.
 - □ In the *Storage* field, specify the storage location for the configuration profile.
- Click the Ok button.

The device copies the configuration profile into the specified memory.

If you specified the value ram in the *Destination* frame, then the device disconnects the Graphical User Interface and uses the settings immediately.

Import the configuration profile from the external memory. To do this, perform the following steps:

- □ In the *Import profile from external memory* frame, select the name of the configuration profile to be imported from the *Profile name* drop-down list.
 - The prerequisite is that the external memory contains an exported configuration profile.
- In the *Destination* frame, specify where the device saves the imported configuration profile:
 In the *Profile name* field, specify the name under which the device saves the configuration profile.
- Click the Ok button.

The device copies the configuration profile into the non-volatile memory (NVM) of the device.

If you specified the value ram in the *Destination* frame, then the device disconnects the Graphical User Interface and uses the settings immediately.

enable	To change to the Privileged EXEC mode.
<pre>copy config remote ftp:// <ip_address>[:port]/<path>/<file_name> running-config</file_name></path></ip_address></pre>	To import and activate the settings of a configuration profile saved on an FTP server. This option is not recommended if you transmit data over untrusted networks. The device copies the settings into the volatile memory and disconnects the connection to the Command Line Interface. The device immediately uses the settings of the imported configuration profile.
<pre>copy config remote tftp://<ip_address>/</ip_address></pre>	To import and activate the settings of a configuration profile saved on a TFTP server. This option is not recommended if you transmit data over untrusted networks. The device copies the settings into the volatile memory and disconnects the connection to the Command Line Interface. The device immediately uses the settings of the imported configuration profile.
<pre>copy config remote sftp:// <user name="">:<password>@<ip_address>/ <path>/<file_name> running-config</file_name></path></ip_address></password></user></pre>	To import and activate the settings of a configuration profile saved on a SFTP server. The device copies the settings into the volatile memory and disconnects the connection to the Command Line Interface. The device immediately uses the settings of the imported configuration profile.
<pre>copy config remote ftp:// <ip_address>[:port]/<path>/<file_name> nvm profile config3</file_name></path></ip_address></pre>	To import the settings of a configuration profile saved on an FTP server and save the settings in the configuration profile config3 in the non-volatile memory (nvm). This option is not recommended if you transmit data over untrusted networks.
<pre>copy config remote tftp://<ip_address>/ <path>/<file_name> nvm profile config3</file_name></path></ip_address></pre>	To import the settings of a configuration profile saved on a TFTP server and save the settings in the configuration profile config3 in the non-volatile memory (nvm). This option is not recommended if you transmit data over untrusted networks.

Note: Upgrading from Classic to HiOS? Convert your device configuration files using our online tool: https://convert.hirschmann.com

5.4 **Resetting the device to the default setting**

If you reset the settings in the device to the delivery state, then the device deletes the configuration profiles in the volatile memory and in the non-volatile memory.

If an external memory is connected, then the device also deletes the configuration profiles saved in the external memory.

The device then reboots and loads the factory settings.

5.4.1 Using the Graphical User Interface or Command Line Interface

Perform the following steps:

□ Open the *Basic Settings > Load/Save* dialog.

- Click the Ok button.

The device deletes the configuration profiles in the memory (RAM) and in the non-volatile memory (NVM).

If an external memory is connected, then the device also deletes the configuration profiles saved in the external memory.

After a brief period, the device restarts and loads the delivery settings.

enable	To change to the Privileged EXEC mode.
clear factory	To delete the configuration profiles from the non- volatile memory and from the external memory. If an external memory is connected, then the device also deletes the configuration profiles saved in the external memory. After a brief period, the device restarts and loads the delivery settings.

5.4.2 Using the System Monitor

Prerequisite:

Your PC is connected with the serial connection of the device using a terminal cable.

Perform the following steps:

- Restart the device.
- □ To change to the System Monitor, press the <1> key within 3 seconds when prompted during reboot.
 - The device loads the System Monitor.
- □ To change from the main menu to the Manage configurations menu, press the <4> key.
- $\hfill\square$ To execute the Clear configs and boot params command, press the <1> key.

 \Box To load the factory settings, press the <Enter> key.

The device deletes the configuration profiles in the memory (RAM) and in the non-volatile memory (NVM).

If an external memory is connected, then the device also deletes the configuration profiles saved in the external memory.

- \Box To change to the main menu, press the <q> key.
- \Box To reboot the device with factory settings, press the <q> key.

6 Updating the device software

Hirschmann is continually working on improving and developing their software. Check regularly if there is an updated version of the device software that provides you with additional benefits. You find information and software downloads on the Hirschmann product pages on the Internet at www.hirschmann.com.

The device gives you the following options to update the device software:

- Loading a previous device software version
- Software update from the PC
- Software update from a server
- Software update from the external memory

Note: The device settings are kept after you update the device software.

You see the version of the installed device software in the login dialog of the Graphical User Interface.

To display the version of the installed device software when you are already logged into the device management, perform the following steps:

Open the Basic Settings > Software dialog. The Running version field displays the version number and creation date of the currently running device software that the device loaded during the last system startup.

enable show system info To change to the Privileged EXEC mode.

To display the system information such as the version number and creation date of the currently running device software that the device loaded during the last system startup.

6.1 Loading a previous device software version

The device lets you replace the device software with a previous version. The basic settings in the device are kept after replacing the device software.

Note: Only the settings for functions which are available in the newer device software version are lost.

6.2 Software update from the PC

The device lets you update the device software, if a suitable device software image is saved on a storage medium which is accessible from your PC.

To remain logged in to the device management during the software update, move the mouse pointer occasionally. As an alternative, before you start the software update, specify a sufficiently high value in the *Device Security > Management Access > Web* dialog, *Web interface session timeout [min]* field.

Perform the following steps:

- □ Navigate to the folder where the device software image is saved.
- □ Open the *Basic Settings* > *Software* dialog.
- Drag and drop the file into the 1 area. As an alternative, click in the area to select the file.
- Start the software update. To do this, click the *Start* button.
 - The device transfers the previously used device software to the backup memory.
 - The device transfers the selected file to the flash memory, replacing the previously used device software.

As soon as the update procedure is completed successfully, the device displays a success notification.

During the next startup, the device boots with the device software that you have transferred.

6.3 Software update from a server

The device lets you update its software if you have access to a server where a suitable device software image is saved.

The device gives you the following options to update the device software:

- Software update from an FTP server
- Software update from a TFTP server
- Software update from an SFTP server
- Software update from an SCP server

To remain logged in to the device management during the software update, move the mouse pointer occasionally. As an alternative, before you start the software update, specify a sufficiently high value in the *Device Security > Management Access > Web* dialog, *Web interface session timeout [min]* field.

6.3.1 Software update from an FTP server

This option lets you update the device software image from an FTP server. This option is not recommended if you transmit data over untrusted networks.

The prerequisite is that the access role administrator is assigned to the user account you use to perform the actions on the device.

Perform the following steps:

- □ Open the *Basic Settings* > *Software* dialog.
- □ In the *Software update* frame, *URL* field, specify the URL for the device software image using the following format:

ftp://user:password@IP_address:port/path/to/software_image.bin You can also specify the URL without the user name and password. In this case, enter them in the *Credentials* window after clicking the *Start* button.

- Click the *Start* button.
 - The device transfers the previously used device software to the backup memory.
 - The device transfers the selected file to the flash memory, replacing the previously used device software.

As soon as the update procedure is completed successfully, the device displays an information that the device software was successfully updated.

During the next startup, the device boots with the device software that you have transferred.

enable

copy firmware remote ftp:// user:password@10.0.1.159:21/path/to/ software_image.bin system To change to the Privileged EXEC mode.

To transfer the device software image from an FTP server to the flash memory of the device.

- copy firmware remote To copy the device software image from a remote location.
- ftp://user:password@10.0.1.159:21/path/to/ software_image.bin

URL of the FTP server where the device software image file is saved.

You can also specify the URL without the user name and password. In this case, the device will prompt you to enter the missing information afterwards.

- ftp://
 - Protocol for the file transfer
- user
- User account name of the FTP server
- password
 - User account password
- 10.0.1.159
- IP address of the FTP server
- 21
 - Default port for FTP
- _ /path/to/
 - The path to the device software image on the FTP server
 - software_image.bin
 - Name of the device software image
- system

To transfer the copied device software image to the flash memory.

6.3.2 Software update from a TFTP server

This option lets you update the device software image from a TFTP server. This option is not recommended if you transmit data over untrusted networks.

The prerequisite is that the access role administrator is assigned to the user account you use to perform the actions on the device.

Perform the following steps:

- □ Open the *Basic Settings* > *Software* dialog.
- □ In the *Software update* frame, *URL* field, specify the URL for the device software image using the following format:
 - tftp://IP_address/path/to/software_image.bin
- Click the *Start* button.
 - The device transfers the previously used device software to the backup memory.
 - The device transfers the selected file to the flash memory, replacing the previously used device software.
 - As soon as the update procedure is completed successfully, the device displays an information that the device software was successfully updated.
 - During the next startup, the device boots with the device software that you have transferred.

enable

copy firmware remote tftp://0.0.1.159/
path/to/software_image.bin system

To change to the Privileged EXEC mode.

To transfer the device software image from a TFTP server to the flash memory of the device.

- copy firmware remote To copy the device software image from a remote location.
- tftp://10.0.1.159/path/to/software_image.bin URL of the TFTP server where the device software image is saved.
 - tftp://
 - Protocol for the file transfer
 - 10.0.1.159
 - IP address of the TFTP server
 - /path/to/
 - The path to the device software image on the TFTP server
 - software_image.bin
 Name of the device software image
- system
 - To transfer the copied device software image to the flash memory.

6.3.3 Software update from an SFTP server

This option lets you update the device software image from an SFTP server.

Prerequisites:

- The access role administrator is assigned to the user account you use to perform the actions on the device.
- The SFTP server is known to the device. See the Device Security > SSH Known Hosts dialog.

Perform the following steps:

□ Open the *Basic Settings* > *Software* dialog.

□ In the *Software update* frame, *URL* field, specify the URL for the device software image using the following format:

sftp://user:password@IP_address/path/to/software_image.bin

You can also specify the URL without the user name and password. In this case, enter them in the *Credentials* window after clicking the *Start* button.

- Click the *Start* button.
 - The device transfers the previously used device software to the backup memory.
 - The device transfers the selected file to the flash memory, replacing the previously used device software.

As soon as the update procedure is completed successfully, the device displays an information that the device software was successfully updated.

During the next startup, the device boots with the device software that you have transferred.

enable

copy firmware remote sftp:// user:password@10.0.1.159:21/path/to/ software_image.bin system To change to the Privileged EXEC mode.

To transfer the device software image from an SFTP server to the flash memory of the device.

- copy firmware remote To copy the device software image from a remote location.
- sftp://user:password@10.0.1.159:21/path/to/ software_image.bin

URL of the SFTP server where the device software image is saved.

You can also specify the URL without the user name and password. In this case, the device will prompt you to enter the missing information afterwards.

- sftp://
 - Protocol for the file transfer
- user
 - User account name of the SFTP server
- password
 - User account password
- 10.0.1.159
- IP address of the SFTP server
 - /path/to/ The path to the device software
- The path to the device software image on the SFTP server
- software_image.bin
- Name of the device software image

system

To transfer the copied device software image to the flash memory.

6.3.4 Software update from an SCP server

This option lets you update the device software image from an SCP server.

Prerequisites:

- The access role administrator is assigned to the user account you use to perform the actions on the device.
- The SCP server is known to the device. See the Device Security > SSH Known Hosts dialog.

Perform the following steps:

- □ Open the *Basic Settings* > *Software* dialog.
- □ In the *Software update* frame, *URL* field, specify the URL for the device software image using the following format:

scp://user:password@IP_address/path/to/software_image.bin
You can also specify the URL without the user name and password. In this case, enter
them in the Credentials window after clicking the Start button.

- Click the *Start* button.
 - The device transfers the previously used device software to the backup memory.
 - The device transfers the selected file to the flash memory, replacing the previously used device software.

As soon as the update procedure is completed successfully, the device displays an information that the device software was successfully updated. During the next startup, the device boots with the device software that you have transferred.

enable

copy firmware remote scp://
user:password@10.0.1.159:21/path/to/
software_image.bin system

To change to the Privileged EXEC mode.

To transfer the device software image from an SCP server to the flash memory of the device.

- copy firmware remote
 To copy the device software image from a remote location.
- user:password@10.0.1.159:21/path/to/ software_image.bin
 URL of the SCP server where the device software image is saved.

You can also specify the URL without the user name and password. In this case, the device will prompt you to enter the missing information afterwards.

- scp://

Protocol for the file transfer

- user User account name of the SCP server
- password
 - User account password
- 10.0.1.159
 - IP address of the SCP server
 - /path/to/ The path to the device software image on the SCP server
 - software_image.bin
 - Name of the device software image

system

To transfer the copied device software image to the flash memory.

6.4 Software update from the external memory

6.4.1 Manually—initiated by the administrator

The device lets you update the device software with a few mouse clicks, if a suitable device software image is saved on the selected external memory.

To remain logged in to the device management during the software update, move the mouse pointer occasionally. As an alternative, before you start the software update, specify a sufficiently high value in the *Device Security > Management Access > Web* dialog, *Web interface session timeout [min]* field.

Perform the following steps:

- □ Open the *Basic Settings* > *Load/Save* dialog.
- □ In the *External memory* frame, verify that the relevant external memory is selected from the *Selected external memory* drop-down list.
- □ Open the *Basic Settings* > *Software* dialog.
- □ Mark the table row for which the *File location* column displays the value *sd-card* or *usb*.
- \Box Start the software update. To do this, click the 1 button.
 - The device transfers the previously used device software to the backup memory.
 - The device transfers the selected file to the flash memory, replacing the previously used device software.

As soon as the update procedure is completed successfully, the device displays a success notification.

During the next startup, the device boots with the device software that you have transferred.

6.4.2 Automatically—initiated by the device

When the following files are located in the external memory during the system startup, the device updates the device software automatically:

- ▶ the device software image
- a text file startup.txt with the content autoUpdate=<software_image_file_name>.bin

The prerequisite is that in the *Basic Settings > External Memory* dialog, you mark the checkbox in the *Software auto update* column. This is the default setting in the device.

Perform the following steps:

- □ Transfer the new device software image into the main directory of the external memory. Use only a device software image suitable for the device.
- □ Create a text file startup.txt in the main directory of the external memory.
- □ Open the startup.txt file in the text editor and add the following line:
- autoUpdate=<software_image_file_name>.bin
- □ Install the external memory in the device.
- Restart the device.
 - During the booting process, the device checks automatically the following criteria:
 - Is an external memory connected?
 - Is a startup.txt file in the main directory of the external memory?

- Does the device software image exist which is specified in the startup.txt file?
- Is the version of the device software image more recent than the device software that the device is currently using?

When the criteria are fulfilled, the device starts the update procedure.

The device copies the currently running device software into the backup memory.

As soon as the update procedure is completed successfully, the device reboots automatically and loads the new device software version.

- □ Check the result of the update procedure. The log file in the *Diagnostics* > *Report* > *System Log* dialog contains one of the following messages:
 - S_watson_AUTOMATIC_SWUPDATE_SUCCESS
 - Software update completed successfully
 - S_watson_AUTOMATIC_SWUPDATE_ABORTED
 Software update aborted
 - S_watson_AUTOMATIC_SWUPDATE_ABORTED_WRONG_FILE
 Software update aborted due to a wrong device software image
 - S_watson_AUTOMATIC_SWUPDATE_ABORTED_SAVING_FILE
 Software update aborted because the device did not save the device software image.

7 Configuring the ports

The following port configuration functions are available.

- Enabling/Disabling the port
- Selecting the operating mode

7.1 Enabling/Disabling the port

In the default setting, every port is enabled. For a higher level of access security, disable unconnected ports. To do this, perform the following steps:

Open the Basic Settings > Port dialog, Configuration tab.	
-----------------------------------------------------------	--

- $\hfill\square$ To enable a port, mark the checkbox in the *Port on* column.
- $\hfill\square$ To disable a port, unmark the checkbox in the *Port on* column.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
no shutdown	To enable the interface.

7.2 Selecting the operating mode

In the default setting, the ports are set to Autoneg operating mode.

Note: The active automatic configuration has priority over the manual configuration.

Perform the following steps:

- □ Open the *Basic Settings > Port* dialog, *Configuration* tab.
- □ If the device connected to this port requires a fixed setting, then perform the following steps:
 - Deactivate the function. Unmark the checkbox in the *Autoneg* column.
 - □ In the *Manual configuration* column, specify the desired operating mode (transmission rate, duplex mode).

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
no auto-negotiate	To disable the automatic configuration mode.
speed 100 full	To set port speed 100 Mbit/s and full-duplex.

8 Assistance in the protection from unauthorized access

The device offers functions that help you protect the device against unauthorized access.

After you set up the device, carry out the following steps to reduce possible unauthorized access to the device.

- Changing the SNMPv1/v2 community
- Disabling write access for SNMPv1/v2
- Disabling SNMPv1/v2
- Disabling HTTP
- Using your own HTTPS certificate
- Using your own SSH key
- Disabling Telnet
- Disabling HiDiscovery
- Restricting access to device management
- Adjusting the session timeouts
- Deactivating the unused modules
- Making SSH hosts known to the device

8.1 Changing the SNMPv1/v2 community

SNMPv1 and SNMPv2 work unencrypted. Every SNMP packet contains the IP address of the sender and the plaintext *community name* with which the sender accesses the device. If the *SNMPv1* and/or *SNMPv2* function is active, then the device lets anyone who knows the *community name* access the device. Treat the *community names* with discretion.

The *community names* public for *read-only* access and private for *read and write* access are preset. If you are using SNMPv1 or SNMPv2, then change the default *community name*. To do this, perform the following steps:

- Open the Device Security > Management Access > SNMPv1/v2 Community dialog. The dialog displays the communities that are set up.
- □ For the Write community, specify in the *Name* column the *community name*.
 - Up to 64 alphanumeric characters are allowed.
 - The device differentiates between upper and lower case.
 - Specify a different community name than for read-only access.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>snmp community rw <community name=""></community></pre>	To specify the community for <i>read and write</i> access.
show snmp community	To display the communities that have been set up.
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

8.2 Disabling write access for SNMPv1/v2

To reduce possible unauthorized access to the device, you can disable the write access for the Write community, while the *read-only* access remains enabled. To do this, perform the following steps:

- □ Open the Device Security > Management Access > SNMPv1/v2 Community dialog, Configuration tab.
- Deactivate the write access for the Write community. To do this, mark the SNMP V1/V2 readOnly checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable		To change to the Privileged EXEC mode.
configure		To change to the Configuration mode.
snmp community rw priva	te read-only	To deactivate the write access for the private community.
show snmp community		To display the SNMP access mode of the SNMPv1/v2 communities.
SNMP V1/V2 community	Access mode	
public	read-only	
private	read-only	
save		To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

8.3 Disabling SNMPv1/v2

If you need SNMPv1 or SNMPv2, then use these protocols only in environments protected from eavesdropping. SNMPv1 and SNMPv2 do not use encryption. The SNMP packets contain the community in clear text. We recommend using SNMPv3 in the device and disabling the access using SNMPv1 and SNMPv2. To do this, perform the following steps:


- □ Open the *Device Security* > *Management Access* > *Server* dialog, *SNMP* tab. The dialog displays the settings of the SNMP server.
- □ To deactivate the SNMPv1 protocol, you unmark the SNMPv1 checkbox.
- □ To deactivate the SNMPv2 protocol, you unmark the SNMPv2 checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
no snmp access version v1	To deactivate the SNMPv1 protocol.
no snmp access version v2	To deactivate the SNMPv2 protocol.
show snmp access	To display the SNMP server settings.
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

8.4 Disabling HTTP

The web server provides the Graphical User Interface with the protocol HTTP or HTTPS. HTTPS connections are encrypted, while HTTP connections are unencrypted.

The HTTP protocol is enabled by default. If you disable HTTP, then no unencrypted access to the Graphical User Interface is possible. To do this, perform the following steps:



If the HTTP protocol is disabled, then you can reach the Graphical User Interface of the device only by HTTPS. In the address bar of the web browser, enter the string https://before the IP address of the device.

If the HTTPS protocol is disabled and you also disable HTTP, then the Graphical User Interface is unaccessible. To work with the Graphical User Interface, enable the HTTPS server using the Command Line Interface. To do this, perform the following steps:

enable configure https server To change to the Privileged EXEC mode. To change to the Configuration mode. To enable the HTTPS protocol.

8.5 Disabling Telnet

The device lets you remotely access the device management using Telnet or SSH. Telnet connections are unencrypted, while SSH connections are encrypted.

The Telnet server is enabled in the device by default. If you disable Telnet, then unencrypted remote access to the Command Line Interface is no longer possible. To do this, perform the following steps:

Open the *Device Security > Management Access > Server* dialog, *Telnet* tab.
 To disable the Telnet server, select the *Off* radio button in the *Operation* frame.
 Apply the settings temporarily. To do this, click the ✓ button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
no telnet server	To disable the Telnet server.

If the SSH server is disabled and you also disable Telnet, then access to the Command Line Interface is only possible through the serial interface of the device. To work remotely with the Command Line Interface, enable SSH. To do this, perform the following steps:

□ Open the *Device Security* > *Management Access* > *Server* dialog, *SSH* tab.

□ To enable the SSH server, select the *0n* radio button in the *Operation* frame.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
ssh server	To enable the SSH server.

8.6 Disabling the HiDiscovery access

HiDiscovery lets you assign IP parameters to the device over the network during commissioning. HiDiscovery communicates in the device management VLAN without encryption and authentication.

After the device is commissioned, we recommend to set HiDiscovery to read-only or to disable HiDiscovery access completely. To do this, perform the following steps:

- □ Open the *Basic Settings > Network > Global* dialog.
- □ To take away write permission from the HiDiscovery software, in the *HiDiscovery protocol v1/* v2 frame, specify the value *readOnLy* in the *Access* field.
- □ To disable HiDiscovery access completely, select the *0ff* radio button in the *HiDiscovery protocol v*1/*v*2 frame.

enable	To change to the Privileged EXEC mode.
network hidiscovery mode read-only	To disable write permission of the HiDiscovery software.
no network hidiscovery operation	To disable HiDiscovery access.

8.7 **Restricting access to device management**

In the default setting, everyone can access the device management from any IP address using any protocol. The device lets you restrict access to device management for selected protocols from a specific IP address range.

8.7.1 Restricting access from a specific IP address range

In the following example, the device is to be accessible only from the company network using the Graphical User Interface. The administrator has additional remote access using SSH. The company network has the address range 192.168.1.0/24 and remote access from a mobile network with the IP address range 109.237.176.0/24. The SSH application program knows the fingerprint of the RSA key.

Parameter	Company network	Mobile phone network
Network address	192.168.1.0	109.237.176.0
Netmask	24	24
Desired protocols	https, snmp	ssh

Table 19: Para	meters for the IP	access restriction
----------------	-------------------	--------------------

Perform the following steps:

- □ Open the Device Security > Management Access > IP Access Restriction dialog.
- Unmark the checkbox in the Active column for the table row. This entry lets users have access to the device from any IP address and the supported protocols.

Address range of the company network:

- \Box To add a table row, click the $\overset{\blacksquare}{+}$ button.
- □ Specify the address range of the company network in the *IP* address range column: 192.168.1.0/24
- □ For the address range of the corporate network, deactivate the undesired protocols. The *HTTPS*, *SNMP*, and *Active* checkboxes remain marked.

Address range of the mobile phone network:

- \Box To add a table row, click the $\overset{\blacksquare}{+}$ button.
- □ Specify the address range of the mobile network in the *IP* address range column: 109.237.176.0/24
- □ For the address range of the mobile network, deactivate the undesired protocols. The *SSH* and *Active* checkboxes remain marked.

Note: Before you enable the access restriction, verify that the table contains at least one active rule that grants you access to the device management. Otherwise, access to device management is only possible using the Command Line Interface through the serial connection.

□ To enable the access restriction, select the *0n* radio button in the *Operation* frame.

enable	To change to the Privileged EXEC mode.
show network management access global	To display if the access restriction is enabled or disabled.
show network management access rules	To display the entries that have been configured.
no network management access operation	To disable the IP access restriction.
network management access add 2	To add a rule with index 2 for the address range of the company network.
network management access modify 2 ip 192.168.1.0	To specify the IP address of the company network.
network management access modify 2 mask 24	To specify the netmask of the company network.
network management access modify 2 ssh disable	To deactivate SSH for the address range of the company network. Repeat the operation for every unwanted protocol.
network management access add 3	To add a rule with index 3 for the address range of the mobile phone network.
network management access modify 3 ip 109.237.176.0	To specify the IP address of the mobile phone network.
network management access modify 3 mask 24	To specify the netmask of the mobile phone network.
network management access modify 3 snmp disable	To deactivate SNMP for the address range of the mobile phone network. Repeat the operation for every unwanted protocol.
no network management access status 1	To deactivate the default entry. This entry lets users have access to the device from any IP address and the supported protocols.
network management access status 2	To activate the rule with index 2 for the address range of the company network.
network management access status 3	To activate the rule with index 3 for the address range of the mobile phone network.
show network management access rules	To display the entries that have been configured.
network management access operation	To enable the access restriction.

8.8 Adjusting the session timeouts

The device lets you automatically terminate the session upon inactivity of the user that is logged in. The session timeout is the period of inactivity after the last user action.

You can specify a session timeout for the following applications:

- Command Line Interface sessions using an SSH connection
- Command Line Interface sessions using a Telnet connection
- Command Line Interface sessions using a serial connection
- Graphical User Interface

Timeout for Command Line Interface sessions using a SSH connection

Perform the following steps:

□ Open the *Device Security > Management Access > Server* dialog, *SSH* tab.

□ Specify the timeout period in minutes in the *Configuration* frame, *Session timeout [min]* field.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
ssh timeout <0160>	To specify the timeout period in minutes for Command Line Interface sessions using an SSH connection.

Timeout for Command Line Interface sessions using a Telnet connection

Perform the following steps:

□ Open the *Device Security > Management Access > Server* dialog, *Telnet* tab.

□ Specify the timeout period in minutes in the Configuration frame, Session timeout [min] field.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
telnet timeout <0160>	To specify the timeout period in minutes for Command Line Interface sessions using a Telnet connection.

Timeout for Command Line Interface sessions using a serial connection

Perform the following steps:

□ Open the Device Security > Management Access > CLI dialog, Global tab.

- Specify the timeout period in minutes in the *Configuration* frame, *Serial interface timeout [min]* field.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
cli serial-timeout <0160>	To specify the timeout period in minutes for Command Line Interface sessions using a serial connection.

Session timeout for the Graphical User Interface

Perform the following steps:

- □ Open the Device Security > Management Access > Web dialog.
- Specify the timeout period in minutes in the *Configuration* frame, *Web interface session timeout* [*min*] field.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable

network management access web timeout <0..160> To change to the Privileged EXEC mode. To specify the timeout period in minutes for Graphical User Interface sessions

8.9 **Deactivating the unused modules**

The default settings of a media module slot allow access to the network. If a media module is inserted into an empty slot, the media module ports will establish network connections by default.

To help prevent unauthorized network access, deactivate the unused slots. To do this, perform the following steps:

- □ Open the *Basic Settings* > *Modules* dialog.
- □ To deactivate the slot and deny network access, unmark the *Active* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

8.10 Making SSH hosts known to the device

The device permits SSH-based connections only to remote servers that are known to the device. In the state on delivery, no remote server is set up as a known host on the device.

When downloading a device software image or importing a configuration profile from an SCP or SFTP server, these protocols use an underlying SSH connection. For SSH, you make remote servers known by using their public key fingerprint. The device verifies the identity of the remote server by comparing the public key fingerprint stored on the device with the fingerprint calculated from the public key which the remote server actually sent. If the calculated public key fingerprint does not match the stored public key fingerprint, the device terminates the connection.

You can find out the public key fingerprint of the remote server and the key type, as follows:

- from the administrator of a known SSH server
- from the error message following an unsuccessful software update in the Software dialog due to the mismatch between the public key fingerprint stored in the device and the fingerprint calculated from the public key which the remote server actually sent. This option is not recommended if you transmit data over untrusted networks.

The device provides the following setting options:

- Adding an SSH Known Hosts entry
- Updating an SSH Known Hosts entry
- Deactivating an SSH Known Hosts entry
- Deleting an SSH Known Hosts entry

Adding an SSH Known Hosts entry

You can set up a maximum of 50 entries containing the server address and the public key fingerprint. If a remote server has several keys set up, for different encryption algorithms, add each of the public key fingerprints as a separate entry.

Verify that the public key fingerprints you store on the device are from a trustworthy source, the SSH server administrator, for example.

Perform the following steps:

- □ Open the *Basic Settings > Port* dialog.
- \Box Click the $\overset{\blacksquare}{\Psi}$ button.

The dialog displays the Create window.

- □ In the *Index* field, specify the index value. Assign a unique value.
- □ In the *Address* field, specify the IPv4 or IPv6 address, or the DNS hostname of the remote server.
- □ In the *Key fingerprint* field, enter the public key fingerprint of the remote server.
- □ From the *Key type* drop-down list, select the corresponding key type. This is the algorithm that the administrator of the remote server used to generate the server key pair.
- Click the Ok button.
 The device adds a table row.

The device accepts establishing a connection to the remote server from now on.

enable configure	To change to the Privileged EXEC mode. To change to the Configuration mode.
ssh known-hosts add {index} address {ipv4 ipv6 dns} key-type {rsa dsa ecdsa ed25519} key-fingerprint {string_base64}	To add an entry with index, address of the remote server, key type, and public key fingerprint of the remote server.
show ssh known-hosts	To display the set up entries.
exit	To change to the Privileged EXEC mode.

To save the settings permanently, see section "Saving a configuration profile" on page 103.

Updating an SSH Known Hosts entry

If the public key of the remote server changes, then you need to update the fingerprint in the respective table row.

Perform the following steps:

- □ Open the *Basic Settings > Port* dialog.
- Unmark the checkbox in the *Active* column.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ In the *Key fingerprint* column, enter the new public key fingerprint of the remote server.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ To activate the entry, mark the checkbox in the *Active* column.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>ssh known-hosts modify {index} status disable</pre>	To deactivate the entry.
<pre>ssh known-hosts modify {index} key- fingerprint {string_base64}</pre>	To modify the entry with the index number you have entered.
<pre>ssh known-hosts modify {index} status enable</pre>	To activate the entry.
<pre>show ssh known-hosts {index}</pre>	To check the updated entry.
exit	To change to the Privileged EXEC mode.

To save the settings permanently, see section "Saving a configuration profile" on page 103.

Deactivating an SSH Known Hosts entry

You deactivate an entry, for example, when the current server key will soon become invalid due to the rotation of the server key.

Perform the following steps:

○ Open the Basic Settings > Port dialog.
 ○ In the table row for the relevant entry, unmark the checkbox in the Active column.
 ○ Apply the settings temporarily. To do this, click the ✓ button.
 enable
 configure
 ssh known-hosts modify {index} status disable
 show ssh known-hosts {index}
 exit

To change to the Privileged EXEC mode.
To change to the Configuration mode.
To deactivate the entry with the index number you have entered.
To check if the entry is inactive.
To change to the Privileged EXEC mode.

To save the settings permanently, see section "Saving a configuration profile" on page 103.

Deleting an SSH Known Hosts entry

If the device is no longer permitted to contact a remote server or the public key is no longer valid, then you can delete the corresponding entry.

Perform the following steps:

□ Open the *Basic Settings > Port* dialog. □ In the table row for the relevant entry, mark the checkbox in the *Index* column. Click the 🕎 button. enable To change to the Privileged EXEC mode. To change to the Configuration mode. configure ssh known-hosts delete {index} To delete the entry with the index number you have entered. show ssh known-hosts {index} To check if the entry has been deleted. SSH known hosts information No entry. exit To change to the Privileged EXEC mode.

To save the settings permanently, see section "Saving a configuration profile" on page 103.

9 Controlling the data traffic

The device checks the data packets to be forwarded in accordance with defined rules. Data packets to which the rules apply are either forwarded by the device or blocked. If data packets do not correspond to any of the rules, then the device blocks the packets.

Routing ports to which no rules are assigned allow packets to pass. As soon as a rule is assigned, the assigned rules are processed first. After that, the specified standard action of the device takes effect.

The device provides the following functions for controlling the data stream:

- Service request control (Denial of Service (DoS))
- Denying access to devices based on their IP or MAC address (ACL)

The device observes and monitors the data stream. The device takes the results of the observation and the monitoring and combines them with the rules for the network security to generate what is known as a status table. Based on this status table, the device decides whether to accept, drop or reject data.

The data packets go through the filter functions of the device in the following sequence:

- DoS ... if permit or accept, then progress to the next rule
- ACL ... if permit or accept, then progress to the next rule

9.1 Helping protect against DoS attacks

Denial of Service (DoS) is a cyberattack that aims to make certain services or devices unusable. Attackers as well as network administrators can use the port scan method to discover open ports in a network to find vulnerable devices. The function helps you protect the network against invalid or falsified data packets targeted at certain services or devices. You have the option of specifying filters to restrict the data stream for protection against DoS attacks. The filters check the received data packets. The device discards a data packet if it matches the filter criteria.

To help protect the device itself and other devices in the network from DoS attacks, the device lets you specify the following options:

- Filters for TCP and UDP packets
- Filters for *IP packets*
- Filters for *ICMP packets*

The filters help prevent an attacking station from:

- Detecting services and applications that use the open ports
- Detecting active devices in a network
- Accessing sensitive data in a network
- Detecting active security devices like a firewall used in a network

Note: You can combine the filters in any way. When you activate several filters, the device applies the filters in the order in which they are specified in the IP table. If an incoming data packet matches a filter, the device discards the respective data packet and then stops further processing.

9.1.1 Filters for TCP and UDP packets

To selectively process TCP and UDP packets, the device offers you the following filters:

- Activating the Null Scan filter function
- Activating the Xmas filter function
- Activating the SYN/FIN filter function
- Activating the TCP Offset protection function
- Activating the TCP SYN protection function
- Activating the L4 Port protection function
- Activating the Min. Header Size filter function

Activating the Null Scan filter function

With the *Null Scan* method, the attacking station sends data packets with the following properties: • No *TCP* flags are set.

• The *TCP* sequence number is 0.

The device uses the *Null Scan filter* function to discard incoming *TCP* packets that contain malicious properties.

In the default setting, the *Null Scan filter* function is disabled. To activate the *Null Scan filter* function, perform the following steps:

- □ Open the *Network Security > DoS > Global* dialog.
- □ Activate the *Null Scan filter* function. To do this, in the *TCP/UDP* frame, mark the *Null Scan filter* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos tcp-null	To activate the Null Scan filter function.
no dos tcp-null	To deactivate the Null Scan filter function.

Activating the Xmas filter function

With the Xmas method, the attacking station sends data packets with the following properties:

- The *TCP* flags *FIN*, *URG*, and *PSH* are simultaneously set.
- The *TCP* sequence number is 0.

The device uses the *Xmas filter* function to discard incoming *TCP* packets that contain malicious properties.

In the default setting, the *Xmas filter* function is disabled. To activate the *Xmas filter* function, perform the following steps:

- Open the *Network Security > DoS > Global* dialog.
 Activate the *Xmas filter* function. To do this, in the *TCP/UDP* frame, mark the *Xmas filter* checkbox.
 - $\hfill\square$ Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos tcp-xmas	To activate the Xmas filter function.
no dos tcp-xmas	To deactivate the Xmas filter function.

Activating the SYN/FIN filter function

With the *SYN/FIN* method, the attacking station sends data packets with the *TCP* flags *SYN* and *FIN* set simultaneously. The device uses the *SYN/FIN filter* function to discard incoming packets with the *TCP* flags *SYN* and *FIN* set simultaneously.

In the default setting, the SYN/FIN filter function is disabled. To activate the SYN/FIN filter function, perform the following steps:

□ Open the *Network Security > DoS > Global* dialog.

□ Activate the SYN/FIN filter function. To do this, in the TCP/UDP frame, mark the SYN/FIN filter checkbox.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos tcp-syn-fin	To activate the SYN/FIN filter function.
no dos tcp-syn-fin	To deactivate the SYN/FIN filter function.

Activating the TCP Offset protection function

With the *TCP Offset* method, the attacking station sends data packets whose fragment offset is equal to 1. The fragment offset is a field in the *IP* header which helps to identify the sequence of fragments in received data packets. The device uses the *TCP Offset protection* function to discard incoming *TCP* data packets whose fragment offset field in the *IP* header is equal to 1.

Note: The device accepts *UDP* and *ICMP* packets whose fragment offset field of the *IP* header is equal to 1.

In the default setting, the *TCP Offset protection* function is disabled. To activate the *TCP Offset protection* function, perform the following steps:

- □ Open the *Network Security* > *DoS* > *Global* dialog.
- □ Activate the *TCP Offset protection* function. To do this, in the *TCP/UDP* frame, mark the *TCP Offset protection* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos tcp-offset	To activate the TCP Offset protection function.
no dos tcp-offset	To deactivate the TCP Offset protection function.

Activating the TCP SYN protection function

With the *TCP* SYN method, the attacking station sends data packets with the *TCP* flag SYN set and an L4 (layer 4) source port <1024. The device uses the *TCP* SYN protection function to discard incoming packets with the *TCP* flag SYN set and an L4 (layer 4) source port <1024.

In the default setting, the *TCP SYN protection* function is disabled. To activate the *TCP SYN protection* function, perform the following steps:

□ Open the *Network Security* > *DoS* > *Global* dialog.

Activate the TCP SYN protection function. To do this, in the TCP/UDP frame, mark the TCP SYN protection checkbox.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos tcp-syn	To activate the TCP SYN protection function.
no dos tcp-syn	To deactivate the TCP SYN protection function.

Activating the L4 Port protection function

An attacking station can send *TCP* or *UDP* data packets whose source port number and destination port number are identical. The device uses the *L4 Port protection* function to discard incoming *TCP* and *UDP* packets whose L4 source port and destination port number are identical.

In the default setting, the *L4 Port protection* function is disabled. To activate the *L4 Port protection* function, perform the following steps:

- □ Open the *Network Security* > *DoS* > *Global* dialog.
- □ Activate the *L4 Port protection* function. To do this, in the *TCP/UDP* frame, mark the *L4 Port protection* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos 14-port	To activate the L4 Port protection function.
no dos 14-port	To deactivate the <i>L4 Port protection</i> function.

Activating the Min. Header Size filter function

The Min. Header Size filter function detects received data packets with the following properties:

(*IP* payload length in the *IP* header - *IP* header outer size) < minimum *TCP* header size.

If the received packet is the first fragment that the device detects, then the device discards the data packet.

In the default setting, the *Min. Header Size filter* function is disabled. To activate the *Min. Header Size filter* function, perform the following steps:

- □ Open the *Network Security* > *DoS* > *Global* dialog.
- □ Activate the *Min. Header Size filter* function. To do this, in the *TCP/UDP* frame, mark the *Min. Header Size filter* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos tcp-min-header	To activate the Min. Header Size filter function.
no dos tcp-min-header	To deactivate the Min. Header Size filter function.

9.1.2 Filters for IP packets

To selectively process *IP* packets, the device offers you the following filters: • Activating the Land Attack filter function

Activating the Land Attack filter function

With the *Land Attack* method, the attacking station sends data packets whose source and destination addresses are identical to the *IP* address of the recipient. The device uses the *Land Attack filter* function to discard received packets whose source and destination addresses are identical.

In the default setting, the *Land Attack filter* function is disabled. To activate the *Land Attack filter* function, perform the following steps:

- □ Open the *Network Security > DoS > Global* dialog.
- □ Activate the *Land Attack filter* function. To do this, in the *IP* frame, mark the *Land Attack filter* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos ip-land enable	To activate the Land Attack filter function.
no dos ip-land disable	To deactivate the Land Attack filter function.

9.1.3 Filters for ICMP packets

To selectively process ICMP packets, the device offers you the following filters:

- Activating the Fragmented packets filter function
- Activating the Packet size filter function
- Activating the Drop broadcast ping function

Activating the Fragmented packets filter function

The device uses the *Fragmented packets filter* function to protect the network from attacking stations that send fragmented *ICMP* packets. Fragmented *ICMP* packets can cause the destination device to fail if the destination device processes fragmented *ICMP* packets incorrectly. The device uses the *Fragmented packets filter* function to discard fragmented *ICMP* packets.

In the default setting, the *Fragmented packets filter* function is disabled. To activate the *Fragmented packets filter* function, perform the following steps:

- □ Open the *Network Security > DoS > Global* dialog.
- □ Activate the *Fragmented packets filter* function. To do this, in the *ICMP* frame, mark the *Fragmented packets filter* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos icmp-fragmented	To activate the Fragmented packets filter function.
no dos icmp-fragmented	To deactivate the Fragmented packets filter function.

Activating the Packet size filter function

The device uses the *Packet size filter* to discard data packets whose payload size exceeds the size specified in the *Allowed payload size [byte]* field.

The *Packet size filter* function helps protect the network from attacking stations that send *ICMP* packets whose payload size exceeds the size specified in the *Allowed payload size [byte]* field.

In the default setting, the *Packet size filter* function is disabled. To activate the *Packet size filter* function, perform the following steps:

- □ Open the *Network Security > DoS > Global* dialog.
- □ Activate the *Packet size filter* function. To do this, in the *ICMP* frame, mark the *Packet size filter* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos icmp payload-check	To activate the Packet size filter function.
no dos icmp payload-check	To deactivate the Packet size filter function.

Activating the Drop broadcast ping function

The *Drop broadcast ping* function helps protect the network from broadcast ping attacks, also known as ICMP Smurf attacks. With the Broadcast ping method, the attacker floods a target device (the victim) by sending a large number of *ICMP echo request* packets to the IPv4 broadcast address. These packets contain a spoofed IP source address which is the IP address of the victim. Stations responding to the Broadcast ping send their replies to the victim, thus flooding the victim and possibly causing instability.

The device uses the Drop broadcast ping function to discard the Broadcast pings.

In the default setting, the *Drop broadcast ping* function is disabled. To activate the *Drop broadcast ping* function, perform the following steps:

- □ Open the *Network Security > DoS > Global* dialog.
- Activate the Drop broadcast ping function. To do this, in the ICMP frame, mark the Drop broadcast ping checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dos icmp-smurf-attack	To activate the Drop broadcast ping function.
no dos icmp-smurf-attack	To deactivate the Drop broadcast ping function.

9.2 ACL

In this menu you can enter the parameters for the Access Control Lists (ACLs).

The device uses ACLs to filter data packets received on VLANs or on individual or multiple ports. In a ACL, you specify rules that the device uses to filter data packets. When such a rule applies to a packet, the device applies the actions specified in the rule to the packet. The available actions are as follows:

- allow (permit)
- ▶ discard (deny)
- redirect to a certain port (see Redirection port field)
- mirror (see Mirror port field)

The list below contains criteria that you can apply to filter the data packets:

- Source or destination address of a packet (MAC)
- Source or destination address of a data packet (IPv4)
- Type of the transmitting protocol (MAC/IPv4)
- Source or destination port of a data packet (IPv4)
- Service class of a packet (MAC)
- Membership of a specific VLAN (MAC)
- DSCP classification (IPv4)
- ToS classification (IPv4)
- Packet Fragmentation (IPv4)

You can specify the following ACL types:

- IP ACLs for VLANs
- IP ACLs for ports
- MAC ACLs for VLANs
- MAC ACLs for ports

When you assign both an IP ACL and MAC ACL to the same interface, the device first uses the IP ACL to filter the data stream. The device applies the MAC ACL rules only after the packets are filtered through the IP ACL. The priority of an ACL is independent of the index of a rule.

Within an ACL, the device processes the rules in order. The index of the respective rule determines the order in which the device filters the data stream. When you assign an ACL to a port or VLAN, you can specify its priority with the index. The lower the number, the higher the priority. The device processes the rule with the higher priority first.

If none of the rules specified in an ACL applies to a data packet, then the implicit deny rule applies. As a result, the device drops the received data packets.

Keep in mind that the device directly implements the implicit deny rule.

Note: The number of available ACLs depends on the device. For further information about the ACL values, see chapter "Technical Data" on page 517.

Note: You can assign a single ACL to any number of ports or VLANs.

Note: If you activate the *Packet fragmented* function for a rule, then the rule processes IPv4 fragments with the offset other than zero. The rule processes every IPv4 fragment except for the initial IPv4 fragment.

The ACL menu contains the following dialogs:

- IPv4 Rule
- MAC Rule
- Assignment

These dialogs provide the following options:

- To specify the rules for the various ACL types.
- To provide the rules with the required priorities.
- ▶ To assign the ACLs to ports or VLANs.

9.2.1 Creating and editing IPv4 rules

When filtering IPv4 data packets, the device lets you:

- add new groups and rules
- add new rules to existing groups
- edit an existing rule
- activate and deactivate groups and rules
- delete existing groups and rules
- change the order of existing rules

Note: You cannot apply IP ACL rules and DiffServ rules together in the same direction on a port.

Perform the following steps:

- □ Open the *Network Security* > *ACL* > *IPv4 Rule* dialog.
- □ Specify the name of the ACL (group).
 - □ To add the rule in an existing ACL, click the *Group name* field and select the name from the drop-down list.
 - $\hfill\square$ To add the rule in a new ACL, specify a meaningful name in the Group name field and

click the 🕂 icon.

- □ In the *Index* field you specify the number for the rule within the ACL. This number defines the priority of the rule.
- Click the Ok button.
 The device adds the rule to the ACL (group) in the table.
 The rule is active immediately.
 - \Box To remove a rule, select the desired table row and click the \mathbf{x} button.
- Edit the rule parameters in the table. To change a value, double-click the relevant field.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

Note: The device lets you use wildcards with the *Source IP address* and *Destination IP address* parameters. If you enter for example, 192.168.?.?, then the device allows addresses that start with 192.168.

Note: The prerequisite for changing the values in the *Source TCP/UDP port* and *Destination TCP/UDP port* column is that you specify the value tcp or udp in the *Protocol* column.

Note: The prerequisite for changing the value in the *Redirection port* and *Mirror port* column is that you specify the value permit in the *Action* column.

9.2.2 Creating and configuring an IP ACL using the Command Line Interface

In the following example, you set up ACLs to block the communication from computers B and C to computer A, based on the IP address (TCP/UDP port, etc.).




Figure 22: Application example of an IPACL

Perform the following steps:

6 1	
enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>ip access-list extended name filter1 deny src 10.0.1.11-0.0.0 dst 10.0.1.158- 0.0.0.0 assign-queue 1</pre>	To add an IP ACL with name filter1. To add a rule denying IP data packets from 10.0.1.11 to 10.0.1.158. Priority 1 (highest priority).
ip access-list extended name filter1 permit src any dst any	To add a rule to the IP ACL admitting IP data packets.
show access-list ip filter1	To display the rules of the IP ACL filter1.
ip access-list extended name filter2 deny src 10.0.1.13-0.0.0.0 dst 10.0.1.158- 0.0.0.0 assign-queue 1	To add an IP ACL with name filter2. To add a rule denying IP data packets from 10.0.1.13 to 10.0.1.158. Priority 1 (highest priority).
show access-list ip filter2	To display the rules of the IP ACL filter2.

9.2.3 Creating and editing MAC rules

When filtering MAC data packets, the device lets you:

- add new groups and rules
- add new rules to existing groups
- edit an existing rule
- activate and deactivate groups and rules
- delete existing groups and rules
- change the order of existing rules

Perform the following steps:

□ Open the *Network Security* > *ACL* > *MAC Rule* dialog. \Box Click the $\overset{\blacksquare}{+}$ button. The dialog displays the Create window. □ Specify the name of the ACL (group). □ To add the rule in an existing ACL, click the Group name field and select the name from the drop-down list. □ To add the rule in a new ACL, specify a meaningful name in the Group name field and click the + icon. □ In the *Index* field you specify the number for the rule within the ACL. This number defines the priority of the rule. Click the Ok button. The device adds the rule to the ACL (group) in the table. The rule is active immediately. \Box To remove a rule, select the desired table row and click the \clubsuit button. □ Edit the rule parameters in the table. To change a value, double-click the relevant field. \Box Apply the settings temporarily. To do this, click the \checkmark button. Note: In the Source MAC address and Destination MAC address fields you can use wildcards in the

FF:??:??????????? or ??:?????????0:01 form. Use capital letters here.

9.2.4 Creating and configuring a MAC ACL using the Command Line Interface

In the following example, AppleTalk and IPX are to be filtered out from the entire network. To do this, perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
mac acl add 1 macfilter	To add an MAC ACL with the ID 1 and the name macfilter.
mac acl rule add 1 1 deny src any any dst any any etype appletalk	To add a rule to position 1 of the MAC ACL with the ID 1 rejecting packets with EtherType 0x809B (AppleTalk).
mac acl rule add 1 2 deny src any any dst any any etype ipx-old	To add a rule to position 2 of the MAC ACL with the ID 1 rejecting packets with EtherType 0x8137 (IPX alt).
mac acl rule add 1 3 deny src any any dst any any etype ipx-new	To add a rule to position 3 of the MAC ACL with the ID 1 rejecting packets with EtherType 0x8138 (IPX).
mac acl rule add 1 4 permit src any any dst any any	To add a rule to position 4 of the MAC ACL with the ID 1 forwarding packets.
show acl mac rules 1	To display the rules of the MAC ACL with the ID 1.
interface 1/1,1/2,1/3,1/4,1/5,1/6	To change to the interface configuration mode of the interfaces $1/1$ to $1/6$.

```
acl mac assign 1 in 1To assign the MAC ACL with the ID 1 to incoming<br/>data packets (1/1) on interfaces 1/6 to in.exitTo leave the interface mode.show acl mac assignment 1To display the assignment of the MAC ACL with the<br/>ID 1 to interfaces or VLANs.
```

9.2.5 Assigning ACLs to a port or VLAN

When you assign ACLs to a port or VLAN, the device gives you the following options:

- To select the port or VLAN.
- ► To specify the ACL priority.
- ▶ To select the ACL using the group name.

Perform the following steps:

□ Open the <i>Network Security</i> > <i>ACL</i> > <i>Assignment</i> dialog.
□ Click the 🛱 button.
The dialog displays the <i>Create</i> window.
In the Port/VLAN field, specify the desired port or the desired VLAN.
In the <i>Priority</i> field, specify the priority.
□ In the <i>Direction</i> field, specify the data packets to which the device applies the rule.
In the Group name field, specify the rule the device assigns to the port or the VLAN
\Box Click the Ok button.
\Box Apply the settings temporarily. To do this, click the \checkmark button.

9.3 MAC authentication bypass

The *MAC authorized bypass* function lets clients that do not support 802.1X, such as printers and fax machines, authenticate to the network using their MAC address. The device lets you specify the format of the MAC address used to authenticate the clients on the RADIUS server.

Example:

Split the MAC address into 6 groups of 2 characters. Use uppercase letters and a colon character as separator: AA:BB:CC:DD:EE:FF

Use the password xY-45uM_e. To do this, perform the following steps:

- \Box Open the *Network Security* > 802.1X > Global dialog.
- In the MAC authentication bypass format options frame, perform the following steps:
- □ From the *Group size* drop-down list, select the item 2. The device splits the MAC address into 6 groups of 2 characters.
- □ From the *Group separator* drop-down list, select the item :.
- □ From the *Upper or lower case* drop-down list, select the item *upper-case*.
- □ In the *Password* field, enter the password xY-45uM_e. The device uses this password for every client that authenticates to the RADIUS server. If you leave the field empty, then the device uses the formatted MAC address also as the password.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dot1x mac-authentication-bypass format group-size 2	To specify the group size 2.
<pre>dot1x mac-authentication-bypass format group-separator :</pre>	To specify the group separator :.
dot1x mac-authentication-bypass format letter-case upper-case	To specify that the device formats the authentication data in uppercase letters.
dot1x mac-authentication-bypass password xY-45uM_e	To specify the password xY-45uM_e. The device uses this password to authenticate every client on the RADIUS server.

10 Network load control

The device features a number of functions that can help you reduce the network load:

- Direct packet distribution
- Multicasts
- Rate limiter
- Prioritization QoS
- Flow control

10.1 Direct packet distribution

The device reduces the network load with direct packet distribution.

On each of its ports, the device learns the sender MAC address of received data packets. The device stores the combination "port and MAC address" in its MAC address table (forwarding database).

By applying the *Store and Forward* method, the device buffers data received and checks it for validity before forwarding it. The device rejects invalid and corrupt data packets.

10.1.1 Learning MAC addresses

When the device receives a data packet, it checks if the MAC address of the sender is already stored in the MAC address table (forwarding database). When the MAC address of the sender is unknown, the device generates an entry. The device then compares the destination MAC address of the data packet with the entries stored in the MAC address table (forwarding database):

- The device forwards packets with a known destination MAC address directly to ports that have already received data packets from this MAC address.
- The device floods data packets with unknown destination addresses, that is, the device forwards these data packets to every port.

10.1.2 Aging of learned MAC addresses

Addresses that have not been detected by the device for an adjustable period of time (aging time) are deleted from the MAC address table (forwarding database) by the device. A reboot or resetting the MAC address table (forwarding database) deletes the entries in the MAC address table (forwarding database).

10.1.3 Static address entries

In addition to learning the sender MAC address, the device also provides the option to set MAC addresses manually. These MAC addresses remain set up and survive resetting of the MAC address table (forwarding database) as well as rebooting of the device.

Static address entries allow the device to forward data packets directly to selected ports. If you do not specify a destination port, then the device discards the corresponding data packets.

You manage the static address entries in the Graphical User Interface or in the Command Line Interface.

Perform the following steps:

Create a static address entry.

- Open the Switching > Filter for MAC Addresses dialog.
- □ Add a user-configurable MAC address:

 - Click the the button. The dialog displays the *Create* window.
 - In the MAC address field, specify the destination MAC address.
 - In the VLAN ID field, specify the VLAN ID.
 - In the Port list, select the ports to which the device forwards data packets with the specified destination MAC address in the specified VLAN. When you have defined a Unicast MAC address in the MAC address field, select only one port.

When you have defined a Multicast MAC address in the MAC address field, select one or more ports.

If you want the device to discard data packets with the destination MAC address, then do not select any port.

Click the Ok button.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.


enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
mac-filter <mac address=""> <vlan id=""></vlan></mac>	To add the MAC address filter, consisting of a MAC address and VLAN ID.
interface 1/1	To change to the interface configuration mode of interface 1/1.
mac-filter <mac address=""> <vlan id=""></vlan></mac>	To assign the port to a previously added MAC address filter.
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

- □ Convert a learned MAC address into a static address entry.
 - □ Open the *Switching* > *Filter for MAC Addresses* dialog.
 - □ To convert a learned MAC address into a static address entry, select the value *Permanent* in the *Status* column.
 - $\hfill\square$ Apply the settings temporarily. To do this, click the \checkmark button.
- □ Disable a static address entry.
 - □ Open the *Switching* > *Filter for MAC Addresses* dialog.
 - □ To disable a static address entry, remove it from the table. To do this, select the table row that contains the value *Permanent* in the *Status* column, then click the \clubsuit button.
 - \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
no mac-filter <mac address=""> <vlan id=""></vlan></mac>	To cancel the assignment of the MAC address filter on the port.
exit	To change to the Configuration mode.
no mac-filter <mac address=""> <vlan id=""></vlan></mac>	To delete the MAC address filter, consisting of a MAC address and a VLAN ID.
exit	To change to the Privileged EXEC mode.
save	To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

□ Delete learned MAC addresses.

- To delete the learned addresses from the MAC address table (forwarding database), click the button.
 - As an alternative, open the *Basic Settings > Restart* dialog and click the *Clear FDB* button.



To delete the learned MAC addresses from the MAC address table (forwarding database).

10.2 Multicasts

By default, the device floods data packets with a Multicast address, that is, the device forwards the data packets to every port. This leads to an increased network load.

The use of IGMP snooping can reduce the network load caused by Multicast data packets. IGMP snooping lets the device send Multicast data packets only on those ports to which devices "interested" in Multicast are connected.

10.2.1 Example of a Multicast application

Surveillance cameras transmit images to monitors in the machine room and in the monitoring room. With an IP Multicast transmission, the cameras transmit their graphic data over the network in Multicast packets.

The Internet Group Management Protocol (IGMP) organizes the data streams between the Multicast routers and the monitors. The switches in the network between the Multicast routers and the monitors monitor the IGMP data packets continuously (IGMP Snooping).

Switches register logins for receiving a Multicast stream (IGMP report). The device then adds an entry in the MAC address table (forwarding database) and forwards Multicast packets only to the ports on which it has previously received IGMP reports.

10.2.2 IGMP snooping

The Internet Group Management Protocol (IGMP) describes the distribution of Multicast information between routers and connected receivers on Layer 3. IGMP Snooping describes the function of a switch of continuously monitoring IGMP data packets and optimizing its own transmission settings for these data packets.

The *IGMP Snooping* function in the device operates according to RFC 4541 (*Considerations for Internet Group Management Protocol (IGMP) and Multicast Listener Discovery (MLD) Snooping Switches*).

Multicast routers with an active *IGMP* function periodically request (query) registration of Multicast streams to determine the associated IP Multicast group members. IP Multicast group members reply with a Report message. This Report message contains the parameters required by the *IGMP* function. The Multicast router enters the IP Multicast group address from the Report message in its routing table. This causes it to forward data packets with this IP Multicast group in the destination address field according to its routing table.

When leaving a Multicast group (IGMP version 2 and higher), receivers log out with a "Leave" message and do not send any more Report messages. If it does not receive any more Report messages from this receiver within a certain time (aging time), then the Multicast router removes the routing table entry of a receiver.

When several IGMP Multicast routers are in the same network, the device with the smaller IP address takes over the query function. When there are no Multicast routers on the network, you have the option to enable the query function in an appropriately equipped switch.

A switch that connects one Multicast receiver with a Multicast router analyzes the IGMP information with the IGMP snooping method.

The IGMP snooping method also makes it possible for switches to use the *IGMP* function. A switch stores the MAC addresses derived from IP addresses of the Multicast receivers as recognized Multicast addresses in its MAC address table (forwarding database). In addition, the switch identifies the ports on which it has received reports for a specific Multicast address. In this way, the switch forwards Multicast packets only to ports to which Multicast receivers are connected. The other ports do not receive these packets.

A special feature of the device is the possibility of determining the processing of data packets with unknown Multicast addresses. Depending on the setting, the device discards these data packets or forwards them to every port. By default, the device transmits the data packets only to ports with connected devices, which in turn receive query packets. You also have the option of additionally sending known Multicast packets to query ports.

Setting IGMP snooping

Perform the following steps:

□ Open the *Switching* > *IGMP Snooping* > *Global* dialog.

□ To enable the function, select the *0n* radio button in the *Operation* frame.

When the IGMP Snooping function is disabled, the device behaves as follows:

- The device ignores the received query and report messages.
- The device forwards (floods) received data packets with a Multicast address as the destination address to every port.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Specifying the settings for a port:
 - □ Open the Switching > IGMP Snooping > Configuration dialog, Port tab.
 - □ To activate the *IGMP Snooping* function on a port, mark the checkbox in the *Active* column for the relevant port.
 - \Box Apply the settings temporarily. To do this, click the \checkmark button.
- \Box Specifying the settings for a VLAN:
 - □ Open the Switching > IGMP Snooping > Configuration dialog, VLAN ID tab.
 - □ To activate the *IGMP Snooping* function for a specific VLAN, mark the checkbox in the *Active* column for the relevant VLAN.
 - \Box Apply the settings temporarily. To do this, click the \checkmark button.

Setting the IGMP querier function

The device itself optionally sends active query messages. As an alternative, the device responds to query messages or detects other Multicast queriers in the network (*Querier* function).

Prerequisite:

The IGMP Snooping function is globally enabled.

Perform the following steps:

- □ Open the Switching > IGMP Snooping > Querier dialog.
- □ In the *Operation* frame, enable/disable the *Querier* function of the device globally.
- □ To activate the *Querier* function for a specific VLAN, mark the checkbox in the *Active* column for the relevant VLAN.
- The device carries out a simple selection process: When the IP source address of the other Multicast querier is lower than its own, the device switches to the passive state, in which it does not send out any more query requests.
- In the IP address column, you specify the IP Multicast address that the device inserts as the sender address in generated query requests. You use the address of the Multicast router.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

IGMP snooping enhancements (table)

The *Switching* > *IGMP Snooping* > *Snooping Enhancements* dialog provides you access to enhanced settings for the *IGMP Snooping* function. You activate or deactivate the settings on a per port basis in a VLAN.

The following settings are possible:

Static

Use this setting to set the port as a static query port. The device forwards every IGMP message on a static query port, even if it has previously received no IGMP query messages on this port. When the static option is disabled and the device has previously received IGMP query messages, it forwards IGMP messages on this port. When this is the case, the entry displays L (for learned).

Learn by LLDP

A port with this setting automatically discovers other Hirschmann devices using the Link Layer Discovery Protocol (LLDP). The device then learns the IGMP query status of this port from these Hirschmann devices and sets up the *Querier* function accordingly. The ALA entry indicates that the *Learn by LLDP* function is active. When the device has found another Hirschmann device on this port in this VLAN, the entry also displays an A (for automatic).

Forward all

With this setting, the device forwards the data packets addressed to a Multicast address to this port. The setting is suitable in the following situations, for example:

- For diagnostic purposes.
- For devices in an MRP Ring: After the ring is switched, the *Forward all* function makes it
 possible to reconfigure the network rapidly for data packets with registered Multicast
 destination addresses. Activate the *Forward all* function on every ring port.

Prerequisite:

The IGMP Snooping function is globally enabled.

Perform the following steps:

Open the Switching > IGMP Snooping > Snooping Enhancements dialog.

Double-click the desired port in the desired VLAN.

□ To activate one or more functions, select the corresponding options.
 □ Click the Ok button.
 □ Apply the settings temporarily. To do this, click the ✓ button.
 enable
 vlan database
 igmp-snooping vlan-id 1 forward-all 1/1
 To change to the VLAN configuration mode.
 To activate the Forward All function for port 1/1 in VLAN 1.

Setting up Multicasts

The device lets you set up the exchange of Multicast data packets. The device provides different options depending on whether the data packets are to be sent to unknown or known Multicast receivers.

The settings for unknown Multicast addresses are global for the entire device. The following options can be selected:

- The device discards unknown multicasts.
- The device forwards unknown multicast data to every port.
- The device forwards unknown Multicasts only to ports that have previously received query messages (query ports).

Note: The exchange settings for unknown Multicast addresses also apply to the reserved IP addresses from the *Local Network Control Block* (224.0.0.0..224.0.0.255). This behavior can affect higher-level routing protocols.

IGMP Snooping explicitly ignores the following Multicast IP addresses because their mapped Multicast MAC addresses have special functions:

Table 20: Multicast IP addresses ignored by IGMP Snooping

Multicast IP address(es)	Multicast MAC address(es)	Protocols (Block)
224.0.0.0224.0.0.255	01:00:5e:00:00:0001:00:5e:00:00:ff	Local Network Control Block
224.0.1.1	01:00:5e:00:01:01	NTP/SNTP (Internetwork Control Block)
224.0.1.129224.0.1.132	01:00:5e:00:01:8101:00:5e:00:01:84	PTP (Internetwork Control Block)
239.255.16.12	01:00:5e:7f:10:0c	HiDiscovery v2 (Administratively Scoped Block)

Note: According to RFC 1112 (*Host Extensions for IP Multicasting*), up to 32 Multicast IP addresses are mapped to the same Multicast MAC address. The table contains only the commonly used Multicast IP address for a Multicast MAC address, omitting the 31 further possible Multicast IP addresses.

For each VLAN, you specify the sending of Multicast packets to known Multicast addresses individually. The following options can be selected:

- The device forwards known Multicasts to the ports that have previously received query messages (query ports) and to the registered ports. Registered ports are ports with Multicast receivers registered with the corresponding Multicast group. This option helps ensure that the transfer works with basic applications without further configuration.
- ► The device forwards known Multicasts only to the registered ports. The advantage of this setting is that it uses the available bandwidth optimally through direct distribution.

Prerequisite:

The IGMP Snooping function is globally enabled.

Perform the following steps:

- □ Open the *Switching* > *IGMP Snooping* > *Multicasts* dialog.
- □ In the *Configuration* frame, you specify how the device forwards data packets to unknown Multicast addresses.
- □ In the table, you specify how the device forwards data packets to known Multicast addresses.
 - send to query and registered ports The device forwards data packets with a known MAC/IP Multicast address to the query ports and to the registered ports.
 - send to registered ports The device forwards data packets with a known MAC/IP Multicast address to registered ports.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

10.3 Rate limiter

The rate limiter function helps ensure stable operation even with high data volumes by limiting the amount of data packets on the ports. The rate limitation is performed individually for each port, as well as separately for inbound and outbound data packets.

If the data rate on a port exceeds the defined limit, then the device discards the overload on this port.

Rate limitation occurs entirely on Layer 2. In the process, the rate limiter function ignores protocol information on higher levels such as IP or TCP. This can affect the TCP data packets.

To minimize these effects, use the following options:

- Limit the rate limitation to certain packet types, for example, Broadcasts, Multicasts, and Unicasts with an unknown destination address.
- Limit the amount of outbound data packets instead of the inbound data packets. The outbound rate limitation works better with TCP flow control due to device-internal buffering of the data packets.
- ▶ Increase the aging time for learned Unicast addresses.

Perform the following steps:

- □ Open the *Switching* > *Rate Limiter* dialog.
- Activate the rate limiter and set limits for the data rate. The settings apply on a per port basis and are separated according to the type of the data packets:
 - Received Broadcast data packets
 - Received Multicast data packets
 - Received Unicast data packets with an unknown destination address

To activate the rate limiter on a port, mark the checkbox for at least one category. In the *Unit* column, you specify if the device interpretes the threshold values as percent of the port bandwidth or as packets per second. The threshold value 0 deactivates the rate limiter.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

10.4 **QoS/Priority**

QoS (Quality of Service) is a procedure defined in IEEE 802.1D which is used to distribute resources in the network. QoS lets you prioritize the data of necessary applications.

When there is a heavy network load, prioritizing helps prevent data packets with lower priority from interfering with delay-sensitive data packets. Delay-sensitive data packets include, for example, voice, video, and real-time data.

10.4.1 Description of prioritization

For data packet prioritization, *traffic classes* are defined in the device. The device prioritizes higher *traffic classes* over lower *traffic classes*. The number of *traffic classes* depends on the device type.

To provide for optimal data flow for delay-sensitive data, you assign higher *traffic classes* to this data. You assign lower *traffic classes* to data that is less sensitive to delay.

Assigning traffic classes to the data

The device automatically assigns *traffic classes* to inbound data (traffic classification). The device takes the following classification criteria into account:

- Methods according to which the device carries out assignment of received data packets to traffic classes:
 - trustDot1p
 - The device uses the priority of the data packet contained in the VLAN tag.
 - trustIpDscp
 - The device uses the QoS information contained in the IP header (ToS/DiffServ).
 - untrusted
 - The device ignores possible priority information within the data packets and uses the priority of the receiving port directly.
- The priority assigned to the receiving port.

Both classification criteria are configurable.

During traffic classification, the device uses the following rules:

- When the receiving port is set to trustDot1p (default setting), the device uses the data packet priority contained in the VLAN tag. When the data packets do not contain a VLAN tag, the device is guided by the priority of the receiving port.
- When the receiving port is set to *trustIpDscp*, the device uses the QoS information (ToS/ DiffServ) in the IP header. When the data packets do not contain IP packets, the device is guided by the priority of the receiving port.
- When the receiving port is set to *untrusted*, the device is guided by the priority of the receiving port.

Prioritizing traffic classes

For prioritization of *traffic classes*, the device uses the following methods:

Strict Priority

When transmission of data of a higher *traffic class* is no longer taking place or the relevant data is still in the queue, the device sends data of the corresponding *traffic class*. If every *traffic class* is prioritized according to the *Strict Priority* method, then under high network load the device can permanently block the data of lower *traffic classes*.

Weighted Fair Queuing

The *traffic class* is assigned a specific bandwidth. This helps ensure that the device sends the data packets of this *traffic class*, although there is a great deal of data packets in higher *traffic classes*.

10.4.2 Handling of received priority information

Applications label data packets with the following prioritization information:

- VLAN priority according to IEEE 802.1Q (Layer 2)
- ▶ Type-of-Service (ToS) or DiffServ (DSCP) for VLAN Management IP packets (Layer 3)

The device lets you evaluate this priority information using the following options:

trustDot1p

The device assigns VLAN-tagged data packets to the different *traffic classes* according to their VLAN priorities. The corresponding allocation is configurable. The device assigns the priority of the receiving port to data packets it receives without a VLAN tag.

trustIpDscp

The device assigns the IP packets to the different *traffic classes* according to the DSCP value in the IP header, although the packet was also VLAN-tagged. The corresponding allocation is configurable. The device prioritizes non-IP packets according to the priority of the receiving port.

untrusted

The device ignores the priority information in the data packets and assigns the priority of the receiving port to them.

10.4.3 VLAN tagging

For the VLAN and prioritizing functions, IEEE 802.1Q provides for integrating a MAC frame in the VLAN tag. The VLAN tag consists of 4 bytes and is between the source address field ("Source Address Field") and type field ("Length / Type Field").




Figure 23: Ethernet data packet with tag

For data packets with VLAN tags, the device evaluates the following information:

- Priority information
- When VLANs are set up, VLAN tagging




Figure 24: Structure of the VLAN tagging

A data packets with VLAN tag containing priority information but no VLAN information (VLAN ID = 0), is known as a *Priority Tagged* frame.

Note: Network protocols and redundancy mechanisms use the highest *traffic class* 7. Therefore, select other *traffic classes* for application data.

When using VLAN prioritizing, consider the following special features:

- End-to-end prioritizing requires the VLAN tags to be transmitted to the entire network. The prerequisite is that every network component is VLAN-capable.
- Routers are not able to send and receive packets with VLAN tags through port-based router interfaces.

10.4.4 IP ToS (Type of Service)

The Type-of-Service field (ToS) in the IP header was already part of the IP protocol from the start, and is used to differentiate different services in IP networks. Even back then, there were ideas about differentiated treatment of IP packets, due to the limited bandwidth available and the unreliable connection paths. Because of the continuous increase in the available bandwidth, there was no need to use the ToS field.

Only with the real-time requirements of today's networks has the ToS field become significant again. Selecting the ToS byte of the IP header lets you differentiate between different services. However, this field is not widely used in practice.



Table 21: ToS field in the IP header

Bits (0-2): IP Precedence Define	d Bits (3-6): Type of Service Defined	Bit (7)
111 - Network Control	0000 - [all normal]	0 - Zero
110 - Internetwork Control	1000 - [minimize delay]	
101 - CRITIC / ECP	0100 - [maximize throughput	

Table 21:	ToS field in the IP header (cont.)
-----------	------------------------------------

Bits (0-2): IP Precedence Define	d Bits (3-6): Type of Service Bit (7) Defined	
100 - Flash Override	0010 - [maximize reliability]	
011 - Flash	0001 - [minimize monetary cost]	
010 - Immediate		
001 - Priority		
000 - Routine		

10.4.5 Handling of traffic classes

The device provides the following options for handling *traffic classes*:

- Strict Priority
- Weighted Fair Queuing
- Strict Priority combined with Weighted Fair Queuing
- Queue management

Strict Priority description

With the *Strict Priority* setting, the device first transmits data packets that have a higher *traffic class* (higher priority) before transmitting a data packet with the next highest *traffic class*. When there are no other data packets remaining in the queue, the device transmits a data packet with the lowest *traffic class* (lowest priority). In unfortunate cases, if there is a high volume of high-priority data packets waiting to be sent on this port, then the device does not send data packets with a low priority.

In delay-sensitive applications, such as VoIP or video, *Strict Priority* lets data to be sent immediately.

Weighted Fair Queuing description

With *Weighted Fair Queuing*, also called *Weighted Round Robin (WRR)*, you assign a minimum or reserved bandwidth to each *traffic class*. This helps ensure that data packets with a lower priority are also sent although the network is very busy.

The reserved values range from 0% through 100% of the available bandwidth, in steps of 1%.

- A reservation of 0 is equivalent to a "no bandwidth" setting.
- ▶ The sum of the individual bandwidths can be up to 100%.

When you assign *Weighted Fair Queuing* to every *traffic class*, the entire bandwidth of the corresponding port is available to you.

Combining Strict Priority and Weighted Fair Queuing

When combining *Weighted Fair Queuing* with *Strict Priority*, verify that the highest *traffic class* of *Weighted Fair Queuing* is lower than the lowest *traffic class* of *Strict Priority*.

If you combine *Weighted Fair Queuing* with *Strict Priority*, then a high *Strict Priority* network load can significantly reduce the bandwidth available for *Weighted Fair Queuing*.

10.4.6 Queue management

Queue Shaping

Queue Shaping throttles the rate at which queues transmit packets. For example, using Queue Shaping, you rate-limit a higher strict-priority queue so that it lets a lower strict-priority queue to send packets even though higher priority packets are still available for transmission. The device lets you setup Queue Shaping for any queue. You specify Queue Shaping as the maximum rate at which the data packets pass through a queue by assigning a percentage of the available bandwidth.

Defining settings for queue management

Perform the following steps:

□ Open the Switching > QoS/Priority > Queue Management dialog.

The total assigned bandwidth in the *Min. bandwidth* [%] column is 100%.

- □ To activate *Weighted Fair Queuing* for *Traffic class* = 0, proceed as follows:
 - ▶ Unmark the checkbox in the *Strict priority* column.
 - In the *Min. bandwidth* [%] column, specify the value 5.
- □ To activate *Weighted Fair Queuing* for *Traffic class* = 1, proceed as follows:
 - Unmark the checkbox in the Strict priority column.
 - In the *Min. bandwidth* [%] column, specify the value 20.
- □ To activate *Weighted Fair Queuing* for *Traffic class* = 2, proceed as follows:
 - Unmark the checkbox in the *Strict priority* column.
 - ▶ In the *Min. bandwidth* [%] column, specify the value 30.
- □ To activate *Weighted Fair Queuing* for *Traffic class* = 3, proceed as follows:
 - Unmark the checkbox in the *Strict priority* column.
 - In the *Min. bandwidth* [%] column, specify the value 20.
- □ To activate *Weighted Fair Queuing* and Queue Shaping for *Traffic class* = 4, proceed as follows:
 - Unmark the checkbox in the Strict priority column.
 - In the *Min. bandwidth* [%] column, specify the value 10.
 - ▶ In the Max. bandwidth [%] column, specify the value 10.

When using a *Weighted Fair Queuing* and Queue Shaping combination for a specific *traffic class*, specify a higher value in the *Max. bandwidth* [%] column than the value specified in the *Min. bandwidth* [%] column.

- □ To activate *Weighted Fair Queuing* for *Traffic class* = 5, proceed as follows:
 - ▶ Unmark the checkbox in the *Strict priority* column.
 - ▶ In the *Min. bandwidth [%]* column, specify the value 5.

To activate Weighted Fair Queuing for Traffic class = 6, proceed as follows:

- Unmark the checkbox in the *Strict priority* column.
- ▶ In the Min. bandwidth [%] column, specify the value 10.
- □ To activate *Strict Priority* and Queue Shaping for *Traffic class* = 7, proceed as follows:
 - Mark the checkbox in the *Strict priority* column.
 - ▶ In the Max. bandwidth [%] column, specify the value 10.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable			To change to the Privileged EXEC mode.
configure			To change to the Configuration mode.
cos-queue	weighted 0		To enable <i>Weighted Fair Queuing</i> for <i>traffic</i> class 0.
cos-queue	min-bandwidth:	05	To assign a weight of 5 % to <i>traffic class</i> 0.
cos-queue	weighted 1		To enable <i>Weighted Fair Queuing</i> for <i>traffic</i> class 1.
cos-queue	min-bandwidth:	1 20	To assign a weight of 20 % to <i>traffic class</i> 1.
cos-queue	weighted 2		To enable <i>Weighted Fair Queuing</i> for <i>traffic</i> class 2.
cos-queue	min-bandwidth:	2 30	To assign a weight of 30 % to <i>traffic class</i> 2.
cos-queue	weighted 3		To enable <i>Weighted Fair Queuing</i> for <i>traffic class</i> 3.
cos-queue	min-bandwidth:	3 20	To assign a weight of 20 % to <i>traffic class</i> 3.
show cos-	queue		
Queue Id	Min. bandwidth	Max. bandwidth	Scheduler type
0	5	0	weighted
1	20	0	weighted
2	30	0	weighted
3	20	0	weighted
4	0	0	strict
5	0	0	strict
6	0	0	strict
7	0	0	strict

Combining Weighted Fair Queuing and Queue Shaping

Perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
cos-queue weighted 4	To enable <i>Weighted Fair Queuing</i> for <i>traffic</i> class 4.
cos-queue min-bandwidth: 4 10	To assign a weight of 10 % to <i>traffic class</i> 4.
cos-queue max-bandwidth: 4 10	To assign a weight of 10 % to <i>traffic class</i> 4.
cos-queue weighted 5	To enable <i>Weighted Fair Queuing</i> for <i>traffic</i> class 5.
cos-queue min-bandwidth: 5 5	To assign a weight of 5 % to <i>traffic class</i> 5.

cos-queue	weighted 6		To enable <i>Weighted Fair Queuing</i> for <i>traffic</i> class 6.
cos-queue	min-bandwidth:	6 10	To assign a weight of 10 % to <i>traffic class</i> 6.
show cos-	queue		
Queue Id	Min. bandwidth	Scheduler type	
0	5	0	weighted
1	20	0	weighted
2	30	0	weighted
3	20	0	weighted
4	10	10	weighted
5	5	0	weighted
6	10	0	weighted
7	0	0	strict

Setting up Queue Shaping

Perform the following steps:

enable			To change to the Privileged EXEC mode.
configure	!		To change to the Configuration mode.
cos-queue	<pre>max-bandwidth:</pre>	7 10	To assign a weight of 10 % to <i>traffic class</i> 7.
show cos-	queue		
Queue Id	Min. bandwidth	Scheduler type	
0	5	0	weighted
1	20	0	weighted
2	30	0	weighted
3	20	0	weighted
4	10	10	weighted
5	5	0	weighted
6	10	0	weighted
7	0	10	strict

10.4.7 Management prioritization

The device lets you prioritize the management packets so that you can access the device management at any time in situations with high network load.

When prioritizing management packets, the device sends the management packets with priority information.

- On Layer 2, the device modifies the VLAN priority in the VLAN tag. The prerequisite for this function is that the corresponding ports are set to allow sending packets with a VLAN tag.
- ▶ On Layer 3, the device modifies the IP-DSCP value.

10.4.8 Setting prioritization

Assigning the Port priority

Perform the following steps:

- □ Open the Switching > QoS/Priority > Port Configuration dialog.
- □ In the *Port priority* column, you specify the priority with which the device forwards the data packets received on this port without a VLAN tag.
- □ In the *Trust mode* column, you specify the criteria the device uses to assign a *traffic class* to data packets received.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
vlan priority 3	To assign interface 1/1 the Port priority3.
exit	To change to the Configuration mode.

Assigning VLAN priority to a traffic class

Perform the following steps:

- □ Open the Switching > QoS/Priority > 802.1D/p Mapping dialog.
- □ To assign a *traffic class* to a VLAN priority, insert the associated value in the *Traffic class* column.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
classofservice dot1p-mapping 0 2	To assign a VLAN priority of 0 to <i>traffic class</i> 2.
classofservice dot1p-mapping 1 2	To assign a VLAN priority of 1 to <i>traffic class</i> 2.
exit	To change to the Privileged EXEC mode.
show classofservice dot1p-mapping	To display the assignment.

Assigning Port priority to received data packets

Perform the following steps:

enable
configure
interface 1/1
classofservice trust untrusted
classofservice dot1p-mapping 0 2
classofservice dot1p-mapping 1 2
vlan priority 1
exit
exit
show classofservice trust
Interface Trust Mode
1/1 untrusted
1/2 dot1p
1/3 dot1p
1/4 dot1p
1/5 dot1p
1/6 dot1p
1/7 dot1p

To change to the Privileged EXEC mode. To change to the Configuration mode. To change to the interface configuration mode of interface 1/1. To assign the *untrusted* mode to the interface. To assign a VLAN priority of 0 to *traffic class* 2. To assign a VLAN priority of 1 to *traffic class* 2. To specify the value 1 for the *Port priority*. To change to the Configuration mode. To change to the Privileged EXEC mode. To display the Trust mode of the ports/interfaces.

Assigning DSCP to a traffic class

Perform the following steps:

(cs1)

1

□ Open the *Switching* > *QoS/Priority* > *IP DSCP Mapping* dialog. Specify the desired value in the *Traffic class* column. \Box Apply the settings temporarily. To do this, click the \checkmark button. enable To change to the Privileged EXEC mode. configure To change to the Configuration mode. classofservice ip-dscp-mapping cs1 1 To assign the DSCP value CS1 to traffic class 1. show classofservice ip-dscp-mapping To display the IP DSCP assignments IP DSCP Traffic Class ---------be 2 2 1 .

Assigning the DSCP priority to received IP data packets

Perform the following steps:

enable	
configure	
interface 1/1	
classofservice	trust ip-dscp
exit	
show classofser	rvice trust
Interface	Trust Mode
1/1	ip-dscp
1/2	dot1p
1/3	dot1p
•	•
1/5	dot1p
•	•

To change to the Privileged EXEC mode.

To change to the Configuration mode.

To change to the interface configuration mode of interface 1/1.

To assign the trust ip-dscp mode globally.

To change to the Configuration mode.

To display the Trust mode of the ports/interfaces.

Configuring traffic shaping on a port

Perform the following steps:

1/1

1/2 1/3

1/4

0 % 50 %

0 %

0 %

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/2	To change to the interface configuration mode of interface $1/2$.
traffic-shape bw 50	To limit the maximum bandwidth of the port $1/2$ to 50%.
exit	To change to the Configuration mode.
exit	To change to the Privileged EXEC mode.
show traffic-shape	To display the Traffic Shaping configuration.
Interface Shaping rate	

Configuring Layer 2 management priority

Perform the following steps:

 Open the Switching > QoS/Priority > Global dialog. In the VLAN priority for management packets field, specify the VLAN priority with which the device sends management data packets. 			
\Box Apply the settings temporarily. To do this, click the \checkmark button.			
enable	To change to the Privileged EXEC mode.		
network management priority dot1p 7	To assign the VLAN priority of 7 to management packets. The device sends management packets with the highest priority.		
show network parms	To display the priority of the VLAN in which the device management is located.		
IPv4 Network			
 Management VLAN priority7 			

Configuring Layer 3 management priority

Perform the following steps:

□ Open the Switching > QoS/Priority > Global dialog. □ In the *IP DSCP value for management packets* field, specify the DSCP value with which the device sends management data packets. \Box Apply the settings temporarily. To do this, click the \checkmark button. enable To change to the Privileged EXEC mode. network management priority ip-dscp 56 To assign the DSCP value of 56 to management packets. The device sends management packets with the highest priority. show network parms To display the priority of the VLAN in which the device management is located. IPv4 Network -----. . . Management IP-DSCP value.....56

10.5 Differentiated services

RFC 2474 defines the "Differentiated Services" field in the IP header. This field is also called "DiffServ Codepoint" or DSCP. The DSCP field is used for classification of packets into different quality classes.

The DSCP field replaces the ToS field. The first 3 bits of the DSCP field are used to divide the packets into classes. The next 3 bits are used to further subdivide the classes on the basis of different criteria. This results in up to 64 different service classes.

Bits	0	1	2	3	4	5	6	7
	Clas		SCP) F ctor	rvices RFC 24	Codep 174	oint	Cong Notifi	olicit estion cation CN)

Figure 25: Differentiated Services field in the IP header

The different DSCP values get the device to employ a different forwarding behavior, what is known as *Per Hop Behavior (PHB)*. The following PHB classes are defined:

- Class Selector (CS0–CS7) For backward compatibility, the *Class Selector* PHB assigns the 7 possible *IP Precedence* values from the previous ToS field to specific DSCP values.
 Expedited Forwarding (EF)
- For applications with high priority. The *Expedited Forwarding* PHB reduces delays (latency), jitter, and packet loss (RFC 2598).
- Assured Forwarding (AF) The Assured Forwarding PHB provides a differentiated schema for handling different data packets (RFC 2597).
- Default Forwarding/Best Effort This DUD the default is a set of the set of

This PHB stands for the dispensation with a specific prioritization.

Table 22: Assigning the IP precedence values to the DSCP value

ToS Meaning	Precedence Value	Assigned DSCP
Network Control	111	CS7 (111000)
Internetwork Control	110	CS6 (110000)
Critical	101	CS5 (101000)
Flash Override	100	CS4 (100000)
Flash	011	CS3 (011000)
Immediate	010	CS2 (010000)
Priority	001	CS1 (001000)
Routine	000	CS0 (00000)

10.5.1 Application example for the DiffServ function

Set up the device to drop packets received on port 1/1 with the source IP address 10.20.10.11, the TCP protocol and the source port 80 using the following steps.

Perform the following steps: Step 1: Add a class.

□ Open the Switching > QoS/Priority > DiffServ > Class dialog. Create a class: Click the # button. The dialog displays the Create window. In the *Class name* field, enter the name class1. From the *Type* drop-down list, select the item *protocol*. In the Protocol number field, enter the value 6. Specify a value according to the Assigned Internet Protocol Numbers defined by the IANA. Use this link to find a list of the protocol numbers: https://www.iana.org/assignments/protocol-numbers/protocol-numbers.xhtml Click the Ok button. Add the source IP address and mask to the class: \blacktriangleright Click the $\overset{\blacksquare}{+}$ button. The dialog displays the Create window. In the Class name field, enter the name class1 or select it from the list. From the *Type* drop-down list, select the item *srcip*. In the Source IP address field, enter the value 10.20.10.11. Click the Ok button. □ Add the source port to the class. Click the # button. The dialog displays the Create window. In the Class name field, enter the name class1 or select it from the list. From the *Type* drop-down list, select the item *srcl4port*. ▶ In the Source IP address field, enter the value 80. Click the Ok button. \Box Apply the settings temporarily. To do this, click the \checkmark button. Step 2: Add a policy. □ Open the Switching > QoS/Priority > DiffServ > Policy dialog. Create a policy: \blacktriangleright Click the $\overset{\textbf{III}}{\twoheadrightarrow}$ button.

The dialog displays the Create window.

- In the Policy name field, enter the policy1 item.
- From the *Direction* drop-down list, select the item *in*.
- In the Class name field, select the class1 item.
- In the *Type* field, select the *drop* item.
- Click the Ok button.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

 \Box Step 3: Assign the policy to a port.

□ Open the Switching > QoS/Priority > DiffServ > Assignment dialog.

- \Box Assign the policy to a port:
 - \blacktriangleright Click the $\overset{\tt HH}{+}$ button.
 - The dialog displays the Create window.
 - From the *Port* drop-down list, select the port 1/1.
 - From the *Direction* drop-down list, select the item *In*.
 - From the *Policy* drop-down list, select the item policy1.
 - Click the Ok button.

Note: You cannot apply IP ACL rules and DiffServ rules together in the same direction on a port.

 $\hfill\square$ Apply the settings temporarily. To do this, click the \checkmark button.

□ Step 4: Enable the function globally.

□ Open the Switching > QoS/Priority > DiffServ > Global dialog.

□ To enable the function, select the *0n* radio button in the *Operation* frame.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

When the link on the port is up, the value is up, in the Status column.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
class-map match-all class1	To add a class named class1.
class-map name class1 match protocol tcp	To add the tcp protocol as a match condition to the class.
class-map name class1 match srcip 10.20.10.11 255.255.255.0	To add the source IP address 10.20.10.11 as a match condition to the class.
class-map name class1 match srcl4port http	To add the value http (TCP Port 80) as a match condition to the class.
policy-map create policy1 in	To add a policy named policy1 for incoming data packets (in).
policy-map name policy1 class add class1	To assign the class with the name class1 to the policy with the name policy1.
policy-map name policy1 class name class1 drop	To drop data packets.
interface 1/1	To change to the interface configuration mode of interface 1/1.
service-policy in policy1	To assign the policy with the name policy1 to the interface 1/1.
exit	To change to the Configuration mode.
diffserv enable	To enable the <i>DiffServ</i> function globally.

10.6 Flow control

If a large number of data packets are received in the priority queue of a port at the same time, then this can cause the port memory to overflow. This happens, for example, when the device receives data on a Gigabit port and forwards it to a port with a lower bandwidth. The device discards superfluous data packets.

The flow control mechanism defined in IEEE 802.3 helps ensure that no data packets are lost due to buffer overflow on a port. Shortly before the buffer memory of a port is completely full, the device signals to the connected devices that it is not accepting any more data packets from them.

In full-duplex mode, the device sends a pause data packet.

In half-duplex mode, the device simulates a collision.

The following figure displays how flow control works. Workstations 1, 2, and 3 want to simultaneously transmit a large amount of data to Workstation 4. The combined bandwidth of Workstations 1, 2, and 3 is greater than the bandwidth of Workstation 4. This causes an overflow on the receive queue of port 4. The left funnel symbolizes this status.

When the flow control function on ports 1, 2 and 3 of the device is enabled, the device reacts before the funnel overflows. The funnel on the right illustrates ports 1, 2 and 3 sending a message to the transmitting devices to control the transmittion speed. This results in the receiving port no longer being overwhelmed and is able to process the incoming data packets.




Figure 26: Example of flow control

10.6.1 Flow Control with a half-duplex link

In the example, there is a half-duplex link between Workstation 2 and the device.

Before the send queue of port 2 overflows, the device sends data back to Workstation 2. Workstation 2 detects a collision and stops transmitting.

10.6.2 Flow Control with a full-duplex link

In the example, there is a full-duplex link between Workstation 2 and the device.

Before the send queue of port 2 overflows, the device sends a request to Workstation 2 to include a small break in the sending transmission.

10.6.3 Setting up the Flow Control

Perform the following steps:

- \Box Open the *Switching* > *Global* dialog.
- ☐ Mark the *Flow control* checkbox.
- With this setting you enable flow control in the device.
- □ Open the *Basic Settings > Port* dialog, *Configuration* tab.
- □ To enable the Flow Control on a port, mark the checkbox in the *Flow control* column.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

Note: When you are using a redundancy function, you deactivate the flow control on the participating ports. If the flow control and the redundancy function are active at the same time, it is possible that the redundancy function operates differently than intended.

11 VLANs

In the simplest case, a virtual LAN (VLAN) consists of a group of network participants in one network segment who can communicate with each other as though they belonged to a separate LAN.

More complex VLANs span out over multiple network segments and are also based on logical (instead of only physical) connections between network participants. VLANs are an element of flexible network design. It is easier to reconfiguring logical connections centrally than cable connections.

The device supports independent VLAN learning according to IEEE 802.1Q which defines the *VLAN* function.

Using VLANs has many benefits. The following list displays the top benefits:

Network load limiting

VLANs reduce the network load considerably as the devices transmit Broadcast, Multicast, and Unicast packets with unknown (unlearned) destination addresses only inside the virtual LAN. The rest of the data network forwards the data packets as normal.

Flexibility

You have the option of forming user groups based on the function of the participants apart from their physical location or medium.

Clarity

VLANs give networks a clear structure and make maintenance easier.

11.1 Examples of VLANs

The following practical examples provide a quick introduction to the structure of a VLAN.

Note: When configuring VLANs you use an interface for accessing the device management that will remain unchanged. For this example, you use either interface 1/6 or the serial connection to set up the VLANs.

11.1.1 Application example of a simple port-based VLAN

The example displays a minimal VLAN configuration (port-based VLAN). An administrator has connected multiple end devices to a transmission device and assigned them to 2 VLANs. This effectively prohibits any data transmission between the VLANs, whose members communicate only within their own VLANs.




Figure 27: Example of a simple port-based VLAN

When setting up the VLANs, you add communication rules for every port, which you set up in ingress (incoming) and egress (outgoing) tables.

The ingress table specifies which VLAN ID a port assigns to the incoming data packets. Hereby, you use the port address of the end device to assign it to a VLAN.

The egress table specifies on which ports the device sends the packets from this VLAN.

- \blacktriangleright T = Tagged (with a tag field, marked)
- ▶ U = Untagged (without a tag field, unmarked)

For this example, the status of the TAG field of the data packets has no relevance, so you use the setting U.

Table 23: Ingress table

Terminal	Port	Port VLAN identifier (PVID)
A	1	2
В	2	3
С	3	3
D	4	2
	5	1

Table 24:	Egress table
-----------	--------------

VLAN ID	Port				
	1	2	3	4	5
1					U
2	U			U	
3		U	U		

Perform the following steps: Setting up the VLAN

- □ Open the *Switching* > *VLAN* > *Configuration* dialog.
- □ Click the ₩ button. The dialog displays the *Create* window.
- □ In the VLAN ID field, specify the value 2.
- Click the Ok button.
- For the VLAN, specify the name VLAN2:
 Double-click in the *Name* column and specify the name.
 For VLAN 1, in the *Name* column, change the value Default to VLAN1.
- □ Repeat the previous steps to add VLAN 3 with the name VLAN3.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
vlan add 2	To add VLAN 2.
name 2 VLAN2	To assign the name 2 to the VLAN VLAN2.
vlan add 3	To add VLAN 3.
name 3 VLAN3	To assign the name 3 to the VLAN VLAN3.
name 1 VLAN1	To assign the name 1 to the VLAN VLAN1.
exit	To change to the Privileged EXEC mode.
show vlan brief	To display the current VLAN configuration.
Max. VLAN ID	4042
Max. supported VLANs	256
Number of currently configured VLANs	
vlan unaware mode	disabled
VLAN ID VLAN Name VI	AN Type VLAN Creation Time
1 VLAN1 de	efault 0 days, 00:00:05
2 VLAN2 s1	tatic 0 days, 02:44:29
3 VLAN3 st	tatic 0 days, 02:52:26

- Setting up the ports
 - □ Open the *Switching* > *VLAN* > *Configuration* dialog.
 - To assign the port to a VLAN, specify the desired value in the corresponding column. Possible values:
 - T = The port is a member of the VLAN. The port transmits tagged data packets.
 - ▶ U = The port is a member of the VLAN. The port transmits untagged data packets.
 - F = The port is not a member of the VLAN. Changes using the GVRP function are disabled.
 - = The port is not a member of this VLAN.
 - Changes using the *GVRP* function are allowed.

Because end devices usually interpret untagged data packets, you specify the value U.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

□ Open the *Switching* > *VLAN* > *Port* dialog.

In the *Port-VLAN ID* column, specify the related VLAN:
 2 or 3

□ Because end devices usually interpret untagged data packets, in the *Acceptable packet types* column, you specify the value *admitALL* for end device ports.

 $\hfill\square$ Apply the settings temporarily. To do this, click the \checkmark button.

The value in the Ingress filtering column has no affect on how this example functions.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
vlan participation include 2	The port 1/1 becomes a member of the VLAN 2 and transmits the data packets without a VLAN tag.
vlan pvid 2	To assign the Port VLAN ID 1/1 to port 2.
exit	To change to the Configuration mode.
interface 1/2	To change to the interface configuration mode of interface $1/2$.
vlan participation include 3	The port 1/2 becomes a member of the VLAN 3 and transmits the data packets without a VLAN tag.
vlan pvid 3	To assign the Port VLAN ID $1/2$ to port 3.
exit	To change to the Configuration mode.
interface 1/3	To change to the interface configuration mode of interface 1/3.
vlan participation include 3	The port 1/3 becomes a member of the VLAN 3 and transmits the data packets without a VLAN tag.
vlan pvid 3	To assign the Port VLAN ID 1/3 to port 3.
exit	To change to the Configuration mode.
interface 1/4	To change to the interface configuration mode of interface 1/4.
vlan participation include 2	The port 1/4 becomes a member of the VLAN 2 and transmits the data packets without a VLAN tag.
vlan pvid 2	To assign the Port VLAN ID 1/4 to port 2.
exit	To change to the Configuration mode.
exit	To change to the Privileged EXEC mode.
show vlan id 3	To display details for VLAN 3.
VLAN ID : 3	
VLAN Name : VLAN3	
VLAN Type : Static	
Interface Current Configured T	Tagging
1/1 - Autodetect T	Fagged
	Intagged
	Intagged
	Fagged

1/5

Autodetect

Tagged

11.1.2 Application example of a complex VLAN setup

The second example displays a more complex configuration with 3 VLANs (1 to 3). Along with the Switch from example 1, you use a second Switch (on the right in the example).




Figure 28: Example of a more complex VLAN configuration

The terminal devices (A to H) of the individual VLANs are spread over 2 transmission devices (Switches). Such VLANs are therefore known as distributed VLANs. An optional network management station is also shown, which has access to the device management of each network component if the associated VLAN is set up correctly.

Note: In this case, VLAN 1 has no significance for the end device communication, but it is required for the administration of the transmission devices through what is known as the Management VLAN.

As in the previous example, uniquely assign the ports with their connected terminal devices to a VLAN. With the direct connection between both transmission devices (uplink), the ports transport packets for both VLANs. To differentiate these uplinks you use "VLAN tagging", which handles the data packets accordingly. Thus, you maintain the assignment to the respective VLANs.

Perform the following steps:

- Add Uplink Port 5 to the ingress and egress tables from example 1.
- □ Create new ingress and egress tables for the right switch, as described in the first example.

The egress table specifies on which ports the device sends the packets from this VLAN.

- ▶ T = Tagged (with a tag field, marked)
- U = Untagged (without a tag field, unmarked)

In this example, tagged packets are used in the communication between the transmission devices (Uplink), as packets for different VLANs are differentiated at these ports.

Table 25:	Ingress table for device on left
-----------	----------------------------------

Terminal	Port	Port VLAN identifier (PVID)
A	1	2
В	2	3
С	3	3
D	4	2
Uplink	5	1

Terminal	Port	Port VLAN identifier (PVID)
Uplink	1	1
E	2	2
F	3	3
G	4	2
Н	5	3

Table 26: Ingress table for device on right

Table 27: Egress table for device on left

VLAN ID	Port					
	1	2	3	4	5	
1					U	
2	U			U	Т	
3		U	U		Т	

Table 28: Egress table for device on right

VLAN ID	Port					
	1	2	3	4	5	
1	U					
2	Т	U		U		
3	Т		U		U	

The communication relationships here are as follows: end devices on ports 1 and 4 of the left device and end devices on ports 2 and 4 of the right device are members of VLAN 2 and can thus communicate with each other. The behavior is the same for the end devices on ports 2 and 3 of the left device and the end devices on ports 3 and 5 of the right device. These belong to VLAN 3.

The end devices "see" their respective part of the network. Participants outside this VLAN cannot be reached. The device also sends Broadcast, Multicast, and Unicast packets with unknown (unlearned) destination addresses only inside a VLAN.

Here, the devices use VLAN tagging (IEEE 801.1Q) within the VLAN with the ID 1 (Uplink). The letter T in the egress table of the ports indicates VLAN tagging.

The configuration of the example is the same for the device on the right. Proceed in the same way, using the ingress and egress tables specified above to adapt the previously set up left device to the new environment.

Perform the following steps: Setting up the VLAN

□ Open the *Switching* > *VLAN* > *Configuration* dialog.

- □ Click the [₩] button. The dialog displays the *Create* window.
- □ In the VLAN ID field, specify the VLAN, for example 2.

Click the Ok button. □ For the VLAN, specify the name VLAN2: Double-click in the Name column and specify the name. For VLAN 1, in the Name column, change the value Default to VLAN1. □ Repeat the previous steps to add VLAN 3 with the name VLAN3. enable To change to the Privileged EXEC mode. vlan database To change to the VLAN configuration mode. To add VLAN 2. vlan add 2 name 2 VLAN2 To assign the name 2 to the VLAN VLAN2. vlan add 3 To add VLAN 3. name 3 VLAN3 To assign the name 3 to the VLAN VLAN3. name 1 VLAN1 To assign the name 1 to the VLAN VLAN1. exit To change to the Privileged EXEC mode. show vlan brief To display the current VLAN configuration. 1017

Max. VLA	AN ID		4042
Max. sup	pported VLANs		256
Number o	of currently configured VLANs.		3
vlan una	aware mode		disabled
VLAN ID	VLAN Name	VLAN Type	VLAN Creation Time
1	VLAN1	default	0 days, 00:00:05
2	VLAN2	static	0 days, 02:44:29
3	VLAN3	static	0 days, 02:52:26

□ Setting up the ports

- □ Open the Switching > VLAN > Configuration dialog.
- To assign the port to a VLAN, specify the desired value in the corresponding column. Possible values:
 - T = The port is a member of the VLAN. The port transmits tagged data packets.
 - ▶ U = The port is a member of the VLAN. The port transmits untagged data packets.
 - F = The port is not a member of the VLAN.

Changes using the GVRP function are disabled.

- = The port is not a member of this VLAN. Changes using the GVRP function are disabled.

Because end devices usually interpret untagged data packets, you specify the value U.

You specify the ⊺ setting on the uplink port on which the VLANs communicate with each other.

- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Switching* > *VLAN* > *Port* dialog.
- In the *Port-VLAN ID* column, specify the related VLAN:
 1, 2 or 3
- □ Because end devices usually interpret untagged data packets, in the *Acceptable packet types* column, you specify the value admitAll for end device ports.

- □ For the uplink port, in the *Acceptable packet types* column, specify the value *admitOnLyVLanTagged*.
- □ Mark the checkbox in the *Ingress filtering* column for the uplink ports to evaluate VLAN tags on this port.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
vlan participation include 1	The port 1/1 becomes a member of the VLAN 1 and transmits the data packets without a VLAN tag.
vlan participation include 2	The port 1/1 becomes a member of the VLAN 2 and transmits the data packets without a VLAN tag.
vlan tagging 2 enable	The port 1/1 becomes a member of the VLAN 2 and transmits the data packets with a VLAN tag.
vlan participation include 3	The port 1/1 becomes a member of the VLAN 3 and transmits the data packets without a VLAN tag.
vlan tagging 3 enable	The port 1/1 becomes a member of the VLAN 3 and transmits the data packets with a VLAN tag.
vlan pvid 1	To assign the Port VLAN ID 1 to port 1/1.
vlan ingressfilter	To activate ingress filtering on port 1/1.
vlan acceptframe vlanonly	Port 1/1 only forwards packets with a VLAN tag.
exit	To change to the Configuration mode.
interface 1/2	To change to the interface configuration mode of interface 1/2.
vlan participation include 2	The port 1/2 becomes a member of the VLAN 2 and transmits the data packets without a VLAN tag.
vlan pvid 2	To assign the Port VLAN ID 2 to port $1/2$.
exit	To change to the Configuration mode.
interface 1/3	To change to the interface configuration mode of interface 1/3.
vlan participation include 3	The port 1/3 becomes a member of the VLAN 3 and transmits the data packets without a VLAN tag.
vlan pvid 3	To assign the Port VLAN ID 3 to port 1/3.
exit	To change to the Configuration mode.
interface 1/4	To change to the interface configuration mode of interface 1/4.
vlan participation include 2	The port 1/4 becomes a member of the VLAN 2 and transmits the data packets without a VLAN tag.
vlan pvid 2	To assign the Port VLAN ID 2 to port 1/4.
exit	To change to the Configuration mode.
interface 1/5	To change to the interface configuration mode of interface 1/5.
vlan participation include 3	The port 1/5 becomes a member of the VLAN 3 and transmits the data packets without a VLAN tag.
vlan pvid 3	To assign the Port VLAN ID 3 to port 1/5.

```
exit
                                 To change to the Configuration mode.
exit
                                 To change to the Privileged EXEC mode.
show vlan id 3
                                 To display details for VLAN 3.
VLAN Name.....VLAN3
VLAN Type.....Static
VLAN Creation Time.....0 days, 00:07:47 (System Uptime)
VLAN Routing.....disabled
Interface Current Configured Tagging
----- -----
1/1
        Include Include
                         Tagged
1/2
        -
               Autodetect Untagged
        Include Include
                         Untagged
1/3
               Autodetect Untagged
1/4
        -
1/5
        Include Include
                         Untagged
```

11.2 Guest VLAN / Unauthenticated VLAN

A Guest VLAN lets a device provide port-based Network Access Control (IEEE 802.1x) to non-802.1x capable supplicants. This feature provides a mechanism to allow guests to access external networks only. If you connect non-802.1x capable supplicants to an active unauthorized 802.1x port, then the supplicants send no responds to 802.1x requests. Since the supplicants send no responses, the port remains in the unauthorized state. The supplicants have no access to external networks.

The Guest VLAN supplicant is a per-port basis configuration. When you set up a Guest VLAN on a port and connect non-802.1x capable supplicants to this port, the device assigns the supplicants to the Guest VLAN. Adding supplicants to a Guest VLAN causes the port to change to the authorized state allowing the supplicants to access to external networks.

An Unauthenticated VLAN lets the device provide service to 802.1x capable supplicants which authenticate incorrectly. This function lets the unauthorized supplicants have access to limited services. If you set up an Unauthenticated VLAN on a port with 802.1x port authentication and the global operation enabled, then the device places the port in an Unauthenticated VLAN. When a 802.1x capable supplicant incorrectly authenticates on the port, the device adds the supplicant to the Unauthenticated VLAN. If you also set up a Guest VLAN on the port, then non-802.1x capable supplicants use the Guest VLAN.

If the port has an Unauthenticated VLAN assigned, then the reauthentication timer counts down. When the time specified in the *Reauthentication period* [s] column expires and supplicants are present on the port, the Unauthenticated VLAN reauthenticates. When no supplicants are present, the device places the port in the set-up Guest VLAN.

The following example explains how to add a Guest VLAN. Add an Unauthorized VLAN in the same manner.

Perform the following steps:

- □ Open the Switching > VLAN > Configuration dialog.
- □ Click the ₩ button. The dialog displays the *Create* window.
- \Box In the VLAN ID field, specify the value 10.
- Click the Ok button.
- For the VLAN, specify the name Guest:
 Double-click in the Name column and specify the name.
- \Box Click the $\overset{\blacksquare}{+}$ button.

The dialog displays the Create window.

- $\hfill\square$ In the VLAN ID field, specify the value 20.
- Click the Ok button.
- For the VLAN, specify the name Not authorized:
 Double-click in the Name column and specify the name.
- □ Open the *Network Security* > 802.1X > Global dialog.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

- □ Open the *Network Security* > 802.1X > Port Configuration dialog.
- \Box Specify the following settings for port 1/4:
 - The value *auto* in the *Port control* column
 - The value 10 in the *Guest VLAN ID* column
 - The value 20 in the Unauthenticated VLAN ID column
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
vlan add 10	To add VLAN 10.
vlan add 20	To add VLAN 20.
name 10 Guest	To rename VLAN 10 to Guest.
name 20 Unauth	To rename VLAN 20 to Unauth.
exit	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>dot1x system-auth-control enable</pre>	To enable the 802.1X function globally.
dot1x port-control auto	To enable port control on port 1/4.
interface 1/4	To change to the interface configuration mode of interface 1/4.
dot1x guest-vlan 10	To assign the guest vlan to port 1/4.
dot1x unauthenticated-vlan 20	To assign the unauthorized vlan to port 1/4.
exit	To change to the Configuration mode.

11.3 RADIUS VLAN assignment

The RADIUS VLAN assignment feature makes it possible for a RADIUS VLAN ID attribute to be associated with an authenticated client. When a client authenticates successfully, and the RADIUS server sends a VLAN attribute, the device associates the client with the RADIUS assigned VLAN. As a result, the device adds the physical port as an member to the appropriate VLAN and sets the port VLAN ID (PVID) with the given value. The port transmits the data packets without a VLAN tag.

11.4 Creating a Voice VLAN

Use the Voice VLAN feature to separate voice and data packets on a port, by VLAN and/or priority. A significant benefit of the voice VLAN is that a high volume of data on the port does not affect the sound quality of an IP phone.

The device uses the source MAC address to identify and prioritize the voice data flow. Identifying by MAC address reduces the potential for a "rogue client" to connect to the port and manipulate voice data packets.

Another benefit of the Voice VLAN feature is that a VoIP phone obtains a VLAN ID or priority information using LLDP-MED. As a result, the VoIP phone sends voice data packets with VLAN tag, priority tag or untagged. This depends on the Voice VLAN Interface configuration.

The following Voice VLAN interface modes are possible. The first 3 methods segregate and prioritize voice and data packets. The segregation of the data packets improves the quality of the voice data stream in case of high data volumes.

- Configuring the port to using the vLan mode lets the device tag the voice data coming from a VoIP phone with the user-defined voice VLAN ID. The device assigns regular data to the default port VLAN ID.
- Configuring the port to use the *dot1p-priority* mode lets the device tag the data coming from a VoIP phone with VLAN 0 and the user-defined priority. The device assigns the default priority of the port to regular data.
- Specify both the voice VLAN ID and the priority using the vLan/dot1p-priority mode. In this mode the VoIP phone sends voice data with the user-defined voice VLAN ID and priority information. The device assigns the default PVID and priority of the port to regular data.
- When set up as *untagged*, the phone sends untagged packets.
- When set up as *none*, the phone uses its own configuration to send voice data packets.

11.5 MAC based VLANs

Use the MAC-based VLAN to forward the data packets based on the source MAC address associated with the VLAN. A MAC-based VLAN defines the filtering criteria for untagged or priority tagged packets.

You specify a MAC-based VLAN filter by assigning a specific source address to a MAC-based VLAN. The device forwards untagged packets received with the source MAC address on the MAC-based VLAN. The other untagged packets are subject to normal VLAN classification rules.

11.6 IP subnet-based VLANs

In an IP subnet-based VLAN, the device forwards the data packets based on the source IP address and subnet mask associated with the VLAN. User-defined filters determine if a packet belongs to a particular VLAN.

Use the IP subnet-based VLAN to specify the filtering criteria for untagged or priority tagged packets. For example, assign a specific subnet address to an IP subnet-based VLAN. When the device receives untagged packets from the subnet address, it forwards them to the IP subnet-based VLAN. Other untagged packets are subject to normal VLAN classification rules.

To set up an IP subnet-based VLAN, specify an IP address, a subnet mask and the associated VLAN ID. In case of multiple matching entries, the device associates the VLAN ID to the entry with the longer prefix first.

11.7 Protocol-based VLAN

In a protocol-based VLAN, the device bridges the data packets through specified ports based on the protocol associated with the VLAN. User-defined packet filters determine if a packet belongs to a particular VLAN.

Set up protocol-based VLANs using the value in the *Ethertype* column as the filtering criteria for untagged packets. For example, assign a specific protocol to a protocol-based VLAN. When the device receives untagged packets with the protocol, it forwards them to the protocol-based VLAN. The device assigns the other untagged packets to the port VLAN ID.

11.8 VLAN unaware mode

The *VLAN-unaware mode* defines the operation of the device in a LAN segmented by VLANs. The device accepts packets and processes them according to its inbound rules. According to IEEE 802.1Q, the function governs how the device processes VLAN tagged packets.

Use the VLAN aware mode to apply the user-defined VLAN topology set up by the network administrator. When the device forwards packets, it uses VLAN tagging and the IP or Ethernet address. The device processes inbound and outbound packets according to the defined rules. VLAN configuration is a manual process.


Use the VLAN unaware mode to forward the data packets as received, without any modification. When the device receives packets as tagged, it transmits tagged packets. When the device receives packets as untagged, it transmits untagged packets. Regardless of VLAN assignment mechanisms, the device assigns packets to VLAN 1 and to a Multicast group, indicating that the packet flood domain is according to the VLAN.

12 Redundancy

12.1 Network Topology vs. Redundancy Protocols

When using Ethernet, a significant prerequisite is that data packets follow a single (unique) path from the sender to the receiver. The following network topologies support this prerequisite:

- Line topology
- Star topology
- Tree topology



To maintain communication in case a connection failure is detected, install additional physical connections between the network nodes. Redundancy protocols help ensure that the additional connections remain switched off while the original connection is still working. When a connection failure is detected, the redundancy protocol generates a new path from the sender to the receiver through the alternative connection.

To introduce redundancy onto Layer 2 of a network, you first define which network topology you require. Depending on the network topology selected, you then choose from the redundancy protocols that can be used with this network topology.

12.1.1 Network topologies

Meshed topology

For networks with star or tree topologies, redundancy procedures are only possible in connection with physical looping. The result is a meshed topology.




Figure 30: Meshed topology: Tree topology with physical loops

For operating in this network topology, the device provides you with the following redundancy protocols:

Rapid Spanning Tree Protocol (RSTP)

Ring topology

In networks with a line topology, you can use redundancy procedures by connecting the ends of the line. This results in a ring topology.




Figure 31: Ring topology: Line topology with connected ends

For operating in this network topology, the device provides you with the following redundancy protocols:

- Media Redundancy Protocol (MRP)
- ► High-availability Seamless Redundancy (HSR) (depends on hardware)
- Rapid Spanning Tree Protocol (RSTP)

12.1.2 Redundancy Protocols

For operating in different network topologies, the device provides you with the following redundancy protocols:

Table 29: Overview of redundancy protocols	Table 29:	Overview of redundancy protocols
--------------------------------------------	-----------	----------------------------------

Redundancy protocol	Network topology	Comments	
MRP	Ring	The switching time can be selected and is practically independent of the number of devices. An MRP Ring consists of up to 50 devices that support the Media Redundancy Protocol (MRP) according to IEC 62439. When you only use Hirschmann devices, up to 100 devices a possible in the MRP Ring.	
Fast MRP	Ring	The devices with hardware for enhanced redundancy functions offer the short failover times $30ms$ and $10ms$.	
Sub Ring	Ring	The <i>Sub Ring</i> function lets you easily couple network segments to existing redundancy rings.	
Ring/Network coupling	Ring		
RCP	Ring		
DLR	Ring	Implementation in EtherNet/IP end-devices that have 2 Ethernet ports and embedded Layer 2 switch technology. The DLR protocol provides network fault detection and reconfiguration to support demanding control applications.	
PRP	Random structure of the PRP LANs	Uninterrupted availability. On the path from the sender to the receiver, PRP transports a data packet in parallel through 2 mutually independent LANs.	
HSR	Ring	Uninterrupted availability. On the path from the sender to the receiver, HSR transports the data packets in both directions through a ring.	

Redundancy protocol	Network topology	Comments	
RSTP	Random structure	 The switching time depends on the network topology and the number of devices. ▶ typ. < 1 s with RSTP ▶ typ. < 30 s with STP 	
Link Aggregation	Random structure	A Link Aggregation Group (LAG) is a combination of 2 or more links between 2 switches to increase bandwidth. Each involved link operates in full-duplex mode and with the same data rate.	
Link Backup	Random structure	When the device detects an error on the primary link, the device transfers the data packets to the backup link. You typically use Link Backup in service-provider or enterprise networks.	
HIPER Ring Client	Ring	Extend an existing HIPER Ring or replace a device already participating as a client in a HIPER Ring.	
HIPER Ring over LAG	Ring	Link devices together over a Link Aggregation Group (LAG). The <i>Ring Manager</i> and <i>Ring Client</i> devices behave in the same manner as a ring without a LAG instance.	

Table 29:	Overview of redundancy protocols (cont.)
-----------	------------------------------------------

Note: If you are using a redundancy function, then you deactivate the flow control on the participating device ports. If the flow control and the redundancy function are active at the same time, it is possible that the redundancy function operates differently than intended.

12.1.3 Combinations of redundancy protocols

	MRP	RSTP/ MSTP	Link Aggreg.	Link Backup	Sub Rin g	HIPER Ring	Fast MR P	DLR	HSR	PRP
MRP		_	_	_	_	_	_	_	_	—
RSTP/ MSTP ³⁾	▲ ¹⁾		—	—	_	—	—	—	_	—
Link Aggreg.	▲2)	▲ ²⁾		_	_	_		_	_	_
Link Backup	A			A	—	—	—	—	—	—
Sub Rin g	A	A	▲ ²⁾			—	—	—	—	—
HIPER Ring		▲ ¹⁾	▲ ²⁾				—	—	—	_
Fast MR P ⁴⁾	-	▲ ¹⁾		A	A	0	A	—	—	—
DLR ⁴⁾	▲ ¹⁾	▲ 1)				0	0		_	_
HSR ⁴⁾		▲ ¹⁾					0	0	▲ ⁴⁾	—
PRP ⁴⁾		▲ ¹⁾		A		A	0	0	А	▲ ⁴⁾

- ▲ Combination applicable
- Combination not applicable
- A redundant coupling between these network topologies will possibly lead to loops. To redundantly couple these topologies, refer to chapter "FuseNet function" on page 262.
- 2) Combination applicable on the same port
- 3) In combination with MSTP, the failover times of other redundancy protocols can slightly increase.
- 4) Available only on port 1 and port 2.
- A HSR/PRP coupling: Same PRP ID on every non-HSR port.

12.2 Media Redundancy Protocol (MRP)

Since May 2008, the Media Redundancy Protocol (MRP) has been a standardized solution for ring redundancy in the industrial environment.

MRP is compatible with redundant ring coupling, supports VLANs, and is distinguished by very short reconfiguration times.

An MRP Ring consists of up to 50 devices that support the Media Redundancy Protocol (MRP) according to IEC 62439. When you only use Hirschmann devices, up to 100 devices are possible in the MRP Ring.

When you use the fixed MRP redundant port (Fixed Backup) and the *Ring Manager* device detects a primary ring link failure, it forwards data to the secondary ring link. When the primary link is restored, the secondary link continues to be in use.

12.2.1 Network structure

The concept of ring redundancy lets you construct high-availability ring-shaped network structures.

Using the *Ring manager* function, the two ends of a backbone in a line structure can be closed to a redundant ring. The *Ring Manager* device keeps the redundant line open as long as the line structure is intact. When a segment becomes inoperable, the *Ring Manager* device immediately closes the redundant line, and line structure is intact again.




Figure 32: Line structure




Figure 33: Redundant ring structure RM = Ring Manager — main line --- redundant line

12.2.2 Reconfiguration time

When a line section failure is detected, the *Ring Manager* device changes the MRP Ring back into a line structure. You define the maximum time for the reconfiguration of the line in the *Ring Manager* device.

Possible values for the maximum delay time:

- 500ms
- 30ms
- *30ms* (depends on hardware)
- 10ms (depends on hardware)

The delay times *30ms* and *10ms* are available for devices with an FPGA (hardware for extended functions).

To use these fast delay times, load the device software supporting Fast MRP.

You can set the delay time to *10ms*, only in rings containing up to 20 devices that support this delay time. If you use more than 20 of these devices in the ring, then set the delay time to at least *30ms*.

Note: If every device in the ring supports the shorter delay time, then you can set up the reconfiguration time with a value less than *500ms*.

Otherwise the devices that only support longer delay times might not be reachable due to overloading. Loops can occur as a result.

12.2.3 Advanced mode

For times even shorter than the specified reconfiguration time, the device provides the *Advanced mode*. When the ring participants inform the *Ring Manager* device about interruptions in the ring through *Link Down* notifications, the *Advanced mode* speeds up the link failure detection.

Hirschmann devices support *Link Down* notifications. Therefore, you generally activate the *Advanced mode* in the *Ring Manager* device.

When you are using devices that do not support *Link Down* notifications, the *Ring Manager* device reconfigures the line in the selected maximum reconfiguration time.

12.2.4 Prerequisites for MRP

Before setting up an MRP Ring, verify that the following conditions are fulfilled:

- All ring participants support MRP.
- The ring participants are connected to each other through the ring ports. Apart from its neighbors, no other ring participants are connected to the respective device.
- All ring participants support the configuration time specified in the *Ring Manager* device.
- There is exactly one Ring Manager device in the ring.

If you are using VLANs, then set up every ring port with the following settings:

- □ Deactivate ingress filtering see the *Switching* > *VLAN* > *Port* dialog.
- □ Define the port VLAN ID (PVID) see the *Switching* > *VLAN* > *Port* dialog.
 - PVID = 1 in cases where the device transmits the MRP data packets untagged (VLAN ID = 0 in *Switching > L2-Redundancy > MRP* dialog)
 By setting the PVID = 1, the device automatically assigns the received untagged packets to
 - by setting the PVID = 1, the device automatically assigns the received untagged packets to VLAN 1.
 - PVID = any in cases where the device transmits the MRP data packets in a VLAN (VLAN ID ≥1 in the *Switching* > *L2-Redundancy* > *MRP* dialog)
- Define egress rules see *Switching > VLAN > Configuration* dialog.
 - U (untagged) for the ring ports of VLAN 1 in cases where the device transmits the MRP data packets untagged (VLAN ID = 0 in the *Switching* > *L2-Redundancy* > *MRP* dialog, the MRP Ring is not assigned to a VLAN).
 - T (tagged) for the ring ports of the VLAN which you assign to the MRP Ring. Select T, in cases where the device transmits the MRP data packets in a VLAN (VLAN ID ≥1 in the Switching > L2-Redundancy > MRP dialog).

12.2.5 Advanced Information

MRP Packets

The Media Redundancy Protocol (MRP) uses *Test*, *Link Change*, and *Topology Change* (*FDB Flush*) packets.

The *Ring Manager* device is connected to the ring with 2 ring ports. As long as all connections in the ring are operational, the *Ring Manager* device sets one of its ports, the redundant port, into the *blocking* state. In this state, the redundant port neither receives nor sends normal (payload) data packets. This way, the *Ring Manager* device prevents a network loop.

The *Ring Manager* device periodically sends test packets into the ring from both ring ports. The test packets are special packets. The *Ring Manager* device sends and receives test packets even at the redundant port although the redundant port blocks normal packets. The *Ring Manager* device expects to receive the test packets on its respective other ring port. If the *Ring Manager* device does not receive any expected test packets for a specified amount of time, it detects a ring failure.

If the *Advanced mode* function is active, the *Ring Manager* device also reacts to *Link Down* packets. The prerequisite is that each device in the ring can send a *Link Change* packet when the link to the next device in the ring changes. These packets help the *Ring Manager* device react more quickly to a link failure or recovery. The *Ring Manager* device receives the *Link Change* packets even on its redundant port.

On reconfiguration of the ring, the *Ring Manager* device flushes its MAC address table (forwarding database) and sends *Topology Change* packets to the devices participating in the ring. The *Topology Change* packets prompt the other devices participating in the ring to flush their MAC address table (forwarding database), too. This procedure helps forward the payload packets over the new path more quickly. This procedure applies regardless of whether the ring reconfiguration was caused by a *Link Down* or a *Link Up* notification.

Table 31: MRP Packets

Packet Type	Send Mode	Time Parameter	Value
Test packet ¹	Periodically	Send interval	50 ms (for ring recovery time 500 ms) 20 ms (for ring recovery time 200 ms) 3 ms (for ring recovery time 30 ms) ² 1 ms (for ring recovery time 10 ms) ²
		Reception timeout	400 ms (for ring recovery time 500 ms) 160 ms (for ring recovery time 200 ms)
			24 ms (for ring recovery time 30 ms) ²
			8 ms (for ring recovery time 10 ms) ²
Link Down packet ³	Event-driven	On link-down of a ring port	-
Tanalassi Ohanasa	E	On an entited	

Topology Change Event-driven On reconfiguration packet⁴

1. Sent by the *Ring Manager* device only.

2. Available for devices with an FPGA. See the note following the table.

- 3. Sent by supporting ring participants.
- 4. The reception of a *Topology Change* packet prompts the supporting devices participating in the ring to flush their MAC address table (forwarding database).

Note: The ring recovery times *30ms* and *10ms* are available for devices with an FPGA (hardware for extended functions). To use these fast ring recovery times, load the Fast MRP device software.

MRP Packet Prioritization

The devices participating in the ring send *Test*, *Link Change*, and *Topology Change* packets with a user-configurable VLAN ID. The default VLAN ID is 0. The devices send the test packets untagged and thus without priority (Class of Service) information.

To help minimize the reconfiguration time under high network load, you can add a VLAN tag and thus priority information to these packets. The devices then forward and send these packets with the IEEE 802.1Q Class of Service priority 7 (Network control).

To prioritize the test packets, perform the following steps on the *Ring Manager* and *Ring Client* devices:


- □ Specify the MRP VLAN ID to a value \geq 1.
- \Box Specify the ring ports as T (tagged) members of this MRP VLAN.


Note: When you set the MRP VLAN ID to a value ≥ 1 in the *Switching* > *L2-Redundancy* > *MRP* dialog, the device adds its ring ports as \top (tagged) members of this MRP VLAN. If the MRP VLAN does not yet exist, the device automatically sets up this VLAN. After setting a new MRP VLAN ID, check the *Switching* > *VLAN* > *Configuration* dialog for the VLAN and the port settings.

12.2.6 Application example of an MRP Ring

A backbone network contains 3 devices in a line structure. To increase the availability of the network, you convert the line structure to a redundant ring structure. Devices from different manufacturers are used. All devices support MRP. On every device you define ports 1/1 and 1/2 as ring ports.

When a primary ring link failure is detected, the *Ring Manager* device sends data on the secondary ring link. When the primary link is restored, the secondary link reverts back to the backup mode.





The following example configuration describes the configuration of the *Ring Manager* device (1). You set up the 2 other devices (2 to 3) in the same way, but without enabling the *Ring manager* function. This example does not use a VLAN. You specify the value *30ms* as the ring recovery time. Every device supports the *Advanced mode* function.

- □ Set up the network to meet your demands.
- □ To minimize the ring recovery time in case of a link-up after a failure, set up the speed and duplex mode of the ring ports as follows:
 - For 100 Mbit/s TX ports, disable Automatic Negotiation and manually set up 100M FDX.
 - For the other port types, keep the port-specific default settings.

Note: Set up each device of the MRP Ring individually. Before you connect the redundant line, verify that you have completed the configuration of every device of the MRP Ring. You thus help avoid loops during the configuration phase.

You deactivate the flow control on the participating ports.

If the flow control and the redundancy function are active at the same time, it is possible that the redundancy function operates differently than intended. (Default setting: flow control deactivated globally and activated on every port.)

Disable the *Spanning Tree* function in every device in the network. To do this, perform the following steps:

□ Open the Switching > L2-Redundancy > Spanning Tree > Global dialog.

Disable the function. In the state on delivery, Spanning Tree is enabled in the device.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
no spanning-tree operation	To switch Spanning Tree off.
show spanning-tree global	To display the parameters for checking.

Enable MRP on every device in the network. To do this, perform the following steps:

□ Open the *Switching* > *L*2-*Redundancy* > *MRP* dialog.

□ Specify the desired ring ports.

Note: If the device uses the software supporting Fast MRP, then you cannot select a *Link Aggregation* port as a ring port.

In the Command Line Interface you first define an additional parameter, the MRP domain ID. Set up every ring participant with the same MRP domain ID. The MRP domain ID is a sequence of 16 number blocks (8-bit values).

mrp domain add default-domain	To add an MRP domain with the ID default- domain.
mrp domain modify port primary 1/1	To specify port 1/1 as ring port 1.
mrp domain modify port secondary 1/2	To specify port $1/2$ as ring port 2.

Enable the *Fixed backup* port. To do this, perform the following steps:

 Enable the *Ring manager* function. For the other devices in the ring, leave the setting as *Off*.
 To allow the device to continue sending data on the secondary port after the ring is restored, mark the *Fixed backup* checkbox.
 Note: When the device reverts back to the *Primary port*, the maximum ring recovery time can be exceeded.
 When you unmark the *Fixed backup* checkbox, and the ring is restored, the *Ring Manager* device blocks the secondary port and unblocks the *Primary port*.
 mrp domain modify port secondary 1/2 fixed-backup enable
 To activate the *Fixed backup* function on the secondary port. The secondary port continues forwarding data after the ring is restored.

Enable the *Ring manager* function. For the other devices in the ring, leave the setting as *Off.*

	mrp domain modify mode manager	To designate the device as the <i>Ring Manager</i> device. For the other devices in the ring, leave the default setting.				
	Select the checkbox in the <i>Advanced</i> r	<i>node</i> field.				
	mrp domain modify advanced-mode enabled	To activate the Advanced mode.				
	\Box In the <i>Ring recovery</i> field, select the value <i>30ms</i> .					
	mrp domain modify recovery-delay 200ms	To specify the value <i>30ms</i> as the max. delay time for the reconfiguration of the ring.				
Note: If selecting the value <i>30ms</i> for the ring recovery does not provide the ring stability necessary to meet the requirements of the network, then select the value <i>500ms</i> .						

Switch the operation of the MRP Ring on.
Apply the settings temporarily. To do this, click the ✓ button.

mrp domain modify operation enable To activate the MRP Ring.

When every ring participant is set up, close the line to create the ring. To do this, you connect the devices at the ends of the line through their ring ports.

Check the messages from the device. To do this, perform the following steps:

show mrp

To display the parameters for checking.

The *Operation* field displays the operating state of the ring port.

Possible values:

- forwarding
 - The port is enabled, connection exists.
- blocked
 - The port is blocked, connection exists.
- disabled
 - The port is disabled.
- not-connected No connection exists.

The *Information* field displays messages for the redundancy configuration and the possible causes of detected errors.

When the device operates in the *Ring Client* or *Ring Manager* mode, the following messages are possible:

- Redundancy available The redundancy is set up. When a component of the ring is inoperable, the redundant line takes over its function.
- Configuration error: Error on ringport link. An error is detected in the cabling of the ring ports.

When the device operates in the *Ring Manager* mode, the following messages are possible: *Configuration error: Packets from another ring manager received.*

- Another device exists in the ring that operates in the *Ring Manager* mode. Enable the *Ring manager* function on exactly one device in the ring.
- Configuration error: Ring link is connected to wrong port. A line in the ring is connected with a different port instead of with a ring port. The device only receives test data packets on one ring port.

When applicable, integrate the MRP Ring into a VLAN. To do this, perform the following steps:

□ In the VLAN ID field, define the MRP VLAN ID. The MRP VLAN ID determines in which of the set-up VLANs the device transmits the MRP packets.

To set the MRP VLAN ID, first set up the VLANs and the corresponding egress rules in the *Switching > VLAN > Configuration* dialog.

If the MRP Ring is not assigned to a VLAN (like in this example), then leave the VLAN ID as 0.

In the *Switching > VLAN > Configuration* dialog, specify the VLAN membership as U (untagged) for the ring ports in VLAN 1.

If the MRP Ring is assigned to a VLAN, then enter a VLAN ID >0.
 In the Switching > VLAN > Configuration dialog, specify the VLAN membership as T (tagged) for the ring ports in the selected VLAN.

mrp domain modify vlan <0..4042>

To assign the VLAN ID.

12.2.7 MRP over LAG

Hirschmann devices let you combine *Link Aggregation Groups (LAG)* to increase bandwidth with the Media Redundancy Protocol (MRP) providing redundancy. The function lets you increase the bandwidth on individual segments or on the entire network.

The *Link Aggregation* function helps you overcome bandwidth limitations of individual ports. LAG lets you combine 2 or more connections into one logical connection between 2 devices. The parallel links increase the bandwidth between the 2 devices.

An MRP Ring consists of up to 50 devices that support the Media Redundancy Protocol (MRP) according to IEC 62439. When you use only Hirschmann devices, the protocol lets you set up MRP Rings with up to 100 devices.

You use MRP over LAG in the following cases:

- ▶ to increase bandwidth only on specific segments of an MRP Ring
- to increase bandwidth on the entire MRP Ring

Network structure

When configuring an MRP Ring with LAGs, the *Ring Manager* device monitors both ends of the backbone for continuity. The *Ring Manager* device blocks data on the secondary (redundant) port as long as the backbone is intact. When the *Ring Manager* device detects an interruption of the data stream on the ring, it begins forwarding data on the secondary port, which restores backbone continuity.

You use LAG instances in MRP Rings to increase bandwidth only, in this case MRP provides the redundancy.

For the *Ring Manager* device to detect an interruption on the ring, MRP requires a device to block every port in the LAG instance in cases where a port in the instance is down.

LAG on a single segment of an MRP Ring

The device lets you set up a LAG instance on individual segments of an MRP Ring.

You use the LAG Single Switch method for devices in the MRP Ring. The Single Switch method provides you an inexpensive way to grow the network by using only one device on each side of a segment to provide the physical ports. You group the ports of the device into a LAG instance to provide increased bandwidth on specific segments where needed.




Figure 35: Link Aggregation over a single link of an MRP Ring.

LAG on an entire MRP Ring

Besides being able to set up a LAG instance on specific segments of an MRP Ring, Hirschmann devices also allow you to set up LAG instances on every segment, which increases bandwidth on the entire MRP Ring.




Figure 36: Link Aggregation over the entire MRP Ring.

Detecting interruptions on the ring

When configuring the LAG instance, specify the *Active ports (min.)* value to equal the total number of ports used in the LAG instance. When a device detects an interruption on a port in the LAG instance, it blocks data on the other ports of the instance. With every port of an instance blocked, the *Ring Manager* device detects that the ring is open and begins forwarding data on the secondary port. This way the *Ring Manager* device is able to restore continuity to the devices on the other side of the interrupted segment.




Figure 37: Interruption of a link in an MRP Ring

Application example for MRP over LAG

In the following example, switch A and switch B link two departments. The data volume of the departments exceeds the individual bandwidth capacity of the ports. You set up an LAG instance for the single segment of the MRP Ring, increasing the bandwidth of the segment.

The prerequisite for the example configuration is that you begin with an operational MRP Ring.




Figure 38: Application example of an MRP over LAG setup

Set up switch A first. To do this, perform the following steps. Then set up switch B using the same steps, substituting the appropriate port and ring port numbers.

□ Open the Switching > L2-Redundancy > Link Aggregation dialog.

- □ Click the ₩ button. The dialog displays the *Create* window.
- □ From the *Trunk port* drop-down list, select the instance number of the link aggregation group.
- \Box From the *Port* drop-down list, select port 1/1.
- Click the Ok button.
- \Box Repeat the preceding steps and select the port 1/2.
- Click the Ok button.
- □ In the *Active ports (min.)* column enter 2, which in this case is the total number of ports in the instance. When combining MRP and LAG you specify the total number of ports as the *Active ports (min.)*. When the device detects an interruption on a port, it blocks the other ports in the instance causing the ring to open. The *Ring Manager* device detects that the ring is open, then begins forwarding data on its secondary ring port which restores the connectivity to the other devices in the network.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Switching* > *L2-Redundancy* > *MRP* dialog.
- □ In the *Ring port 2* frame, select port lag/1 from the *Port* drop-down list.

Note: If the device uses the software supporting Fast MRP, then you cannot select a *Link Aggregation* port as a ring port.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

hable	To change to the Privileged EXEC mode.
onfigure	To change to the Configuration mode.
nk-aggregation add lag/1	To add a Link Aggregation Group lag/1.

ena cor lir link-aggregation modify lag/1 addport 1/1
link-aggregation modify lag/1 addport 1/2
mrp domain modify port secondary lag/1
copy config running-config nvm

To add port 1/1 to the Link Aggregation Group. To add port 1/2 to the Link Aggregation Group. To specify port lag/1 as ring port 2.

To save the current settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

12.3 HIPER Ring Client

The concept of HIPER Ring Redundancy enables the construction of high-availability, ring-shaped network structures. The *HIPER Ring* Client function lets the network administrator extend an existing HIPER Ring or replace a client device already participating in a HIPER Ring.

When the device senses that the link on a ring port becomes inoperable, the device sends a *Link Down* packet to the *Ring Manager* device and flushes the MAC address table (forwarding database). As soon as the *Ring Manager* device receives the *Link Down* packet, it immediately forwards the data stream over both the primary and secondary ring ports. Thus, the *Ring Manager* device is able to maintain the integrity of the HIPER Ring.

The device only supports Fast Ethernet and Gigabit Ethernet ports as ring ports. Furthermore, you can include the ring ports in a LAG instance.

In the default state, the *HIPER Ring Client* mode is inactive, and the primary and secondary ports are not set up.

To minimize the ring recovery time in case of a link-up after a failure, set up the speed and duplex mode of the ring ports as follows:

- For 100 Mbit/s TX ports, disable Automatic Negotiation and manually specify 100M FDX.
- For the other port types, keep the port-specific default settings.

Note: Deactivate in the *Switching* > *L2-Redundancy* > *Spanning Tree* > *Port* dialog the *Spanning Tree* function for the ring ports. STP and HIPER Ring have different reaction times.

12.3.1 VLANS on the HIPER Ring

The device lets you forward VLAN data over the HIPER Ring. Thus, the device provides redundancy for your VLAN data. The device forwards management data around the ring, for example, on VLAN 1. For the data to reach the management station, the devices participating in the ring forward the untagged management data to their ring ports. Also, specify the ring ports as members of VLAN 1.

When you have other VLANs traversing your ring, the devices participating in the ring forward the other VLAN data as tagged.

Specify the VLAN settings. To do this, perform the following steps on the *Ring Manager* and *Ring Client* devices:

- □ Open the *Switching* > *VLAN* > *Configuration* dialog.
- Forward untagged VLAN management data on the ring ports.
 For VLAN 1, select in the columns related to the ring ports the U item from the drop-down list.
- Block redundancy protocol packets from being forwarded to the non-ring ports:
 For VLAN 1, select in the columns **not** related to the ring ports the item from the drop-down list.
- □ Allow a device participating in the ring to forward VLAN data to and from ports with VLAN membership.

For the other VLANs, select in the columns related to the ring ports the ⊺ item from the drop-down list.

- □ Open the *Switching* > *VLAN* > *Port* dialog.
- Assign VLAN 1 membership to the ring ports.
 Enter the value 1 in the *Port-VLAN ID* column of the ring port rows.
- Assign VLAN membership to the non-ring ports. Enter the appropriate VLAN ID in the *Port-VLAN ID* column of the non-ring port rows.

12.3.2 Advanced Information

The HIPER Ring is the proprietary predecessor of MRP. The HIPER Ring works similar to MRP but uses different packets. For setting up a new redundant ring, Hirschmann recommends using MRP.

HIPER Ring Packets

The HIPER Ring protocol uses Test, Link Down, and Topology Change packets.

Note: HiOS devices offer *HIPER Ring Client* functions. The *HIPER Ring Manager* functions are offered by devices with Classic Software. The *HIPER Ring Manager* functions are mentioned here only for completeness. For details, refer to the documentation of your HIPER Ring Manager device.

The *Ring Manager (RM)* device is connected to the ring with 2 ring ports. As long as all connections in the ring are operational, the *Ring Manager* device sets one of its ports, the redundant port, into the *blocking* state. In this state, the redundant port neither receives nor sends normal (payload) data packets. This way, the *Ring Manager* device prevents a network loop.

The *Ring Manager* device periodically sends test packets into the ring from both ring ports. The test packets are special packets. The *Ring Manager* device sends and receives test packets even at the redundant port although the redundant port blocks normal packets. The *Ring Manager* device expects to receive the test packets on its respective other ring port. If the *Ring Manager* device does not receive any expected test packets for a specified amount of time, it detects a ring failure.

When a link between 2 devices participating in the ring becomes inoperable, the affected devices send a *Link Down* packet to the *Ring Manager* device. This helps the *Ring Manager* device react more quickly to a link failure. The *Ring Manager* device receives the *Link Down* packets even on its redundant port.

On reconfiguration of the ring, the *Ring Manager* device flushes its MAC address table (forwarding database) and sends *Topology Change* packets to the devices participating in the ring. The *Topology Change* packets prompt the other devices participating in the ring to flush their MAC address table (forwarding database), too. This procedure helps forward the payload packets over the new path more quickly. This procedure applies regardless of whether the ring reconfiguration was caused by a *Link Down* or a *Link Up* notification.

Table 32: HIPER Ring Packets

Packet Type	Send Mode	Time Parameter	Value		
Test packet ¹ Periodically		Send interval ²	20 ms (Ring recovery time accelerated) 60 ms (Ring recovery time standard)		
		Reception timeout	280 ms (Ring recovery time accelerated) 480 ms (Ring recovery time standard)		
Link Down packet ³	Event-driven	On link-down of a ring port	-		
<i>Topology Change</i> packet ⁴	Event-driven	On reconfiguration	-		
1. Sent by the HIPER Ring Manager device (Classic Software) only.					

2. Specified in the HIPER Ring Manager device (Classic Software) only.

3. Sent by supporting ring participants.

4. The reception of a *Topology Change* packet prompts the supporting devices participating in the ring to flush their MAC address table (forwarding database).

HIPER Ring Packet Prioritization

The devices participating in the ring send *Test*, *Link Change*, and *Topology Change* packets with the fixed VLAN ID 1. In the default setting, these packets are untagged and thus without priority (Class of Service) information. To help minimize the reconfiguration time under high network load, you can add a VLAN tag and thus priority information to these packets. The *Ring Manager* and *Ring Client* devices then forward and send these packets with the IEEE 802.1Q Class of Service priority 7 (Network control).

To do that, specify on the *Ring Manager* device (Classic software) and *Ring Client* devices the ring ports as T (tagged) members of VLAN 1.

Note: These settings for VLAN 1 are different from the VLAN settings described in chapter "VLANS on the HIPER Ring" on page 215.

12.3.3 HIPER Ring over LAG

The *HIPER Ring* function lets you link the devices together over a Link Aggregation Group (LAG). The *Ring Manager* and *Ring Client* devices behave in the same manner as a ring without a LAG instance.

If an LAG link goes down, then the other link in the instance also goes down making a break in the ring. After detecting a break in the ring, the affected ports send a *Link Down* packet to the *Ring Manager* device. The *Ring Manager* device unblocks its redundant port, sends data in both directions in the ring, and replies with a *Topology Change* packet. Upon receiving a *Topology Change* packet, the ring participants flush their MAC address table (forwarding database).

12.4 Parallel Redundancy Protocol (PRP) (dd

(depends on hardware)

Unlike ring redundancy protocols, PRP uses 2 separate LANs for uninterrupted availability. On the path from the sender to the receiver, PRP sends 2 data packets in parallel through the 2 mutually independent LANs. The receiver processes the first data packet received and discards the second data packet of the pair. The international standard IEC 62439-3 defines the Parallel Redundancy Protocol (PRP).

Note: When PRP is active, it uses the interfaces 1/1 and 1/2. As seen in the *Switching* > *VLAN*, *Switching* > *Rate Limiter* and *Switching* > *Filter for MAC Addresses* dialogs, the *PRP* function replaces the interfaces 1/1 and 1/2 with the interface *prp/1*. Set up the VLAN membership, the rate limiting, and the MAC filtering for the interface *prp/1*.

12.4.1 Implementation

When the upper protocol layers send a data packet, the PRP interface generates a "twin packet" from the original packet. The PRP interface then transmits one data packet of the pair to each participating LAN simultaneously. The devices in the 2 separate LANs forward the packets to the receiving PRP interface. Therefore, the packets have different run times.


The receiving PRP interface forwards the first packet of a pair towards the upper protocol layers and discards the second packet. When viewed from the application, a PRP interface functions like a standard Ethernet interface.

The PRP interface or a Redundancy Box (RedBox) injects a Redundancy Control Trailer (RCT) into each packet. The RCT is a 48-bit identification field that is responsible for the identification of duplicates. This field contains LAN identification (LAN A or B), information about the length of the payload, and a 16-bit sequence number. The twin packets therefore differ only in the LAN identification and, as a result, in the FCS checksum. The PRP interface increments the sequence number for each packet sent. Using the unique attributes included in each packet, such as physical MAC source address and sequence number, the receiving RedBox or Double Attached Node (DAN) interface identifies and discards duplicates.

Depending on the packet size, with PRP it attains a reduced throughput of the available bandwidth, due to the addition of the RCT trailer.

12.4.2 LRE functionality

Each Double Attached Node implementing PRP (DANP) has 2 LAN ports that operate in parallel. The Link Redundancy Entity (LRE) connects the upper protocol layers with every individual port.



The LRE has the following tasks:

- Handling of duplicates
- Management of redundancy

When transmitting packets from the upper protocol layers, the LRE sends them from both ports at nearly the same time. The 2 data packets pass through the LANs with different delays. When the device receives the first data packet, the LRE forwards it to the upper protocol layers and discards the second data packet received.

For the upper protocol layers, the LRE behaves like a normal port.

To identify the twin packets, the LRE attaches an RCT with a sequential number to the packets. The LRE also periodically sends multicast PRP supervision packets and evaluates the multicast PRP supervision packets of the other RedBoxes and DANPs.

The device lets you view the received supervision packet entries. The entries in the *Switching* > *L*2-*Redundancy* > *PRP* > *DAN/VDAN Table* dialog help detect redundancy in the network and potential connection issues. For example, in an index the *Last seen B* timestamp resets and the *Last seen A* timestamp remains the same. The *Last seen A* and *Last seen B* timestamps steadily resetting indicate a normal condition.

Note: According to IEC 62439, the Entry Forget Time is 400 ms. The Entry Forget Time is the time after which the device removes an entry from the duplicate table. When the device receives the second packet of a pair after 400 ms or later, the device processes the second packet instead of discarding it. To help prevent this, Hirschmann recommends that you use a maximum bandwidth of 90%.

Note: If the inter-frame gap is shorter than the latency between the 2 LANs, then a frame-ordering mismatch can occur. Frame-ordering mismatch is a phenomenon of the Parallel Redundancy Protocol (PRP). The only solution to help avoid a frame-ordering mismatch is to verify that the interframe gap is greater than the latency between the LANs.

12.4.3 PRP Network structure

PRP uses 2 independent LANs. The topology of each of these LANs is arbitrary, and ring, star, bus and meshed topologies are possible.

The main advantage of PRP is zero recovery time with an active (transit) LAN. When the end device receives no packets from one of the LANs, the second (transit) LAN maintains the connection. As long as one (transit) LAN is available, repairs and maintenance on the other (transit) LAN have no impact on the data packet transmission.

The elementary devices of a PRP network are the RedBox (Redundancy Box) and the DANP (Double Attached Node implementing PRP). Both devices have one connection each to the (transit) LANs.

The devices in the (transit) LAN are conventional switches. The devices transmit PRP data packets transparently, without evaluating the RCT information.

Note: The RCT trailer increases the packet size by 6 bytes. Specify an MTU size \geq 1524 bytes for the LAN A and B devices.

Terminal devices that connect directly to a device in the (transit) LAN are SANs (Single Attached Nodes). SANs connected to a LAN have no redundancy. To use the PRP redundant network, connect the SAN to the PRP network through a RedBox.




Figure 40: Parallel Redundancy Protocol Network

12.4.4 Connecting RedBoxes and DANPs to a PRP network

DANPs have 2 interfaces for the connection to the PRP network. A RedBox is a DANP that contains additional switch ports. Use the switch ports to integrate one or more SANs into the PRP network redundantly.

When sending a data packet to the PRP network, the Link Redundancy Entity (LRE) in the RedBox generates a twin packet. When the LRE receives the first data packet of the twin pair, the LRE forwards the data packet, and discards the second data packet of the twin pair.

Note: The RedBox supports up to 128 hosts. If you attempt to support more than 128 hosts with the RedBox, then the device drops packets.




Figure 41: RedBox Transition from double to single LAN

12.4.5 Application example of a PRP Network

The following example uses a PRP network with 4 devices. Verify that the LAN A and LAN B ports contain 100 Mbit/s optical SFP interfaces. Connect Port A to LAN A and Port B to LAN B.




Figure 42: Example PRP Network

Note: *PRP* is available for devices with an FPGA (hardware for extended functions). The product code indicates if your device supports *PRP*. To use the functions, load the device software supporting *PRP*.

The *PRP* function reserves ports 1/1 and 1/2. This removes the possibility of using other redundancy protocols such as Spanning Tree or MRP in parallel on ports 1/1 and 1/2.

If you use Spanning Tree in parallel to PRP, then deactivate Spanning Tree on ports 1/1 and 1/2.
 Also deactivate the *Root guard*, *TCN guard*, and *Loop guard* functions on ports 1/1 and 1/2.

□ If you use MRP in parallel to PRP, then specify the other free device ports as MRP Ring ports.

Set up both the RedBox 1 and DANP 1 devices. To do this, perform the following steps:

Open the Switching > L2-Redundancy > PRP > Configuration dialog.
 In the Supervision packet receiver frame, perform the following step: To analyze received PRP supervision packets, activate the Evaluate supervision packets checkbox.
 In the Supervision packet sender frame, perform the following steps: To transmit PRP supervision packets from this device, activate Active. The device sends either only its own PRP supervision packets, or sends both its own supervision packets and packets of connected devices. To transmit packets for VDANs listed in the Switching > L2-Redundancy > PRP > DAN/VDAN Table dialog, mark the Send VDAN packets checkbox. When deactivated, the device forwards only its own supervision packets. After installing new PRP devices, deactivate this function to maintain a clear overview of the PRP supervision packets on remote devices.
\Box To enable the ports, in the <i>Port A</i> and <i>Port B</i> frames, select the value <i>On</i> .
□ To enable the function, select the <i>On</i> radio button in the <i>Operation</i> frame.
\Box Apply the settings temporarily. To do this, click the \checkmark button.
 Apply the settings temporarily. To do this, click the ✓ button. To load the configuration saved in the volatile memory, click the C button.
 To load the configuration saved in the volatile memory, click the C button. Open the <i>Switching > L2-Redundancy > PRP > Proxy Node Table</i> dialog to view the terminating VDAN devices for which this device provides PRP conversion.
 To load the configuration saved in the volatile memory, click the C button. Open the <i>Switching > L2-Redundancy > PRP > Proxy Node Table</i> dialog to view the terminating VDAN devices for which this device provides PRP conversion. To remove this list, click <i>Reset</i>.
 To load the configuration saved in the volatile memory, click the C button. Open the <i>Switching > L2-Redundancy > PRP > Proxy Node Table</i> dialog to view the terminating VDAN devices for which this device provides PRP conversion. To remove this list, click <i>Reset</i>. To load the list of currently connected devices, click the C button. Open the <i>Switching > L2-Redundancy > PRP > Statistics</i> dialog to view the quality of the data stream that the device receives, forwards, and sends. The device detects errors and displays them according to MIB Managed Objects and the respective link.

The device lets you view the received supervision packet entries. The entries in the *Switching* > *L*2-*Redundancy* > *PRP* > *DAN/VDAN Table* dialog help detect redundancy in the network and potential connection issues. For example, in an index the *Last seen B* timestamp resets and the *Last seen A* timestamp remains the same. The *Last seen A* and *Last seen A* timestamps steadily resetting indicate a normal condition.

Note: If you deactivate the *PRP* function, then deactivate either Port "A" or "B" to help prevent network loops.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
no mrp operation	To disable the option.
no spanning-tree operation	To disable the option.
interface 1/1	To change to the interface configuration mode of interface 1/1.
no shutdown	To enable the interface.
exit	To change to the Configuration mode.
interface 1/2	To change to the interface configuration mode of interface $1/2$.
no shutdown	To enable the interface.

exit	To change to the Configuration mode.
prp instance 1 supervision evaluate	To enable evaluation of received supervision packets.
prp instance 1 supervision send	To enable supervision packet transmission.
prp instance 1 supervision redbox-exclusively	To send supervision packets only for this RedBox. Use the no form of the command to send supervision packets for each connected VDAN and this RedBox. The prerequisite is that you enable the supervision packet send function.
prp operation	To enable the PRP function.
show prp counters	To display the PRP counters.
show prp node-table	To display the node table.
show prp proxy-node-table	To display the Proxy Node Table.

12.5 High-availability Seamless Redundancy (HSR) (depends on

hardware)

As with PRP, an HSR ring also offers zero recovery time. HSR is suited for applications that demand high availability and short reaction times. For example, protection applications for electrical station automation and controllers for synchronized drives which require constant connection.

Note: When HSR is active, it uses the interfaces 1/1 and 1/2. As seen in the *Switching* > *Rate Limiter* and *Switching* > *Filter for MAC Addresses* dialogs, the *HSR* function replaces the interfaces 1/1 and 1/2 with the interface *hsr/1*. Set up the VLAN membership and the rate limiting for the interface *hsr/1*.

12.5.1 Implementation

HSR Redundancy Boxes (RedBox) use 2 Ethernet ports operating in parallel to connect to a ring. An HSR RedBox operating in this configuration is a Doubly Attached Node implementing the HSR protocol (DANH). A standard Ethernet device connected to the HSR ring through an HSR RedBox is a Virtual DANH (VDANH).

As with PRP, the transmitting HSR Node or HSR RedBox sends twin packets, one in each direction, on the ring. For identification, the HSR node injects the twin packets with an HSR tag. The HSR tag consists of a *Port Identifier*, the length of the payload and a sequence number. In a normal operating ring, the destination HSR node or RedBox receives both packets within a certain time skew. When the HSR node receives the first packet, the HSR node forwards the packet, and discards the second packet. A RedBox on the other hand forwards the first packet to the VDANHs and discards the second packet.

The HSR Nodes and HSR RedBoxes insert an HSR tag after the source MAC address in the packet. The advantage of the HSR tag placement is that the device can forward the packet immediately after receiving the HSR header and performing duplicate recognition. This effectively decreases the delay time within the device in contrast to PRP where the RCT contains a PRP suffix near the end of the packet. Meaning that a PRP device receives the entire packet before forwarding the packet out of the correct port.

HSR Nodes and HSR RedBoxes also use the LRE function as described in the chapter "Parallel Redundancy Protocol (PRP) (depends on hardware)" on page 218. As with PRP, the LRE in the HSR RedBoxes are responsible for tagging and duplicate recognition.

The number of HSR nodes in the ring should not exceed 50. If the HSR interface speed is *1Gbps*, then the number should not exceed 300.

It is useful to limit the amount of data packets injected into the HSR ring. If there are any third-party devices with a higher latency in the ring, then you reduce the number of ring participants. Verify that the sum of bandwidths applied to the HSR nodes is less than 84%.

Note: *HSR* is available for devices with an FPGA (hardware for extended functions). The product code indicates if your device supports *HSR*. To use the functions, load the device software supporting *HSR*.

12.5.2 HSR Network structure

An HSR Network consists of a ring, where each HSR device performs a specific role in the network. An HSR device, for example, connects standard Ethernet devices to an HSR ring, or PRP LANs to an HSR ring.

Connecting SANs to an HSR Network

Standard Ethernet devices, such as laptops or printers, have one network interface. Therefore, standard Ethernet devices transmit the data packets across an HSR ring through an HSR RedBox, which acts as a proxy for the Ethernet devices attached to it. The HSR RedBox interfaces transmit one twin packet in each direction around the network.

The host HSR RedBox forwards only the first unicast packet to the destination VDANH and discards the second unicast packet.

The HSR Nodes and RedBoxes forward multicast and broadcast data packets around the ring and also to the connected VDANH devices. To help prevent the data packets from endlessly looping around the ring, the node originally transmitting the data packets on the network discards the data packets it transmitted.




Figure 43: Connecting a VDANH to an HSR network

Application example of an SAN Device Connection

An HSR network consists of 3 HSR devices, as seen in the previous figure. The following example demonstrates setting up a host HSR RedBox for standard Ethernet devices.

Deactivate the *Spanning Tree* function on the HSR ports or globally. Also, deactivate MRP on the HSR ports or set up MRP on ports other than the HSR ports.

Perform the following steps:

- □ Open the *Switching* > *L2-Redundancy* > *MRP* dialog.
- □ To disable the function, select the *Off* radio button in the *Operation* frame.
- □ Verify that the ports in *Ring port 1* and *Ring port 2* frames are different from the ports used by the *HSR* function.
- □ Open the Switching > L2-Redundancy > Spanning Tree > Global dialog.
- □ To disable the function, select the *Off* radio button in the *Operation* frame.
- □ Open the Switching > L2-Redundancy > Spanning Tree > Port dialog.
- □ In the *CIST* tab, deactivate the ports used for HSR in the *STP active* column.
- □ In the *Guards* tab, deactivate the ports used for HSR in the *Root guard*, *TCN guard* and *Loop guard* columns.

Note: If you deactivate the *HSR* function, then deactivate either Port "A" or "B" to help prevent network loops.

The device sends either only its own HSR supervision packets, or sends both its own supervision packets and packets of connected devices. After installing new HSR devices, deactivate this function to maintain a clear overview of the HSR supervision packets on remote devices.

Perform the following steps:

- □ Open the Switching > L2-Redundancy > HSR > Configuration dialog.
- □ To analyze received HSR supervision packets, activate the *Evaluate supervision packets*checkbox in the *Supervision packet receiver* frame.
- □ To transmit HSR supervision packets from this device, activate *Active*in the *Supervision packet sender* frame.
- □ To transmit packets for VDANs listed in the *Switching* > *L2-Redundancy* > *HSR* > *DAN/VDAN Table* dialog, mark the *Send VDAN packets* checkbox.

Set up HSR RedBox 1. To do this, perform the following steps:

- □ To set up the device to forward unicast data packets around the ring and to the destination device, set the *HSR mode* to the value modeu.
- □ To set up the device as an HSR host, set the *Switching node type* to the value hsrredboxsan.

Note: Setting Switching node type to hsrredboxsan disables the Redbox identity function.

- □ To enable the ports, select the *On* radio button in the *Port A* and *Port B* frames.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- \Box To load the configuration saved in the volatile memory, click the f C button.
- □ Open the *Switching* > *L2-Redundancy* > *HSR* > *DAN/VDAN Table* dialog to view the data packets received from the LAN. This information helps you in detecting how the LANs are functioning.
- □ To remove this list, click *Reset*.
- \Box To update the table rows, click the f C button.
- □ Open the *Switching* > *L2-Redundancy* > *HSR* > *Proxy Node Table* dialog to view the terminating VDAN devices for which this device provides HSR conversion.
- □ To remove the entries in the proxy table, click *Reset*.
- \Box To update the table rows, click the \mathbf{C} button.

The device detects errors and displays them according to MIB Managed Objects and the respective link.

- □ Open the *Switching* > *L2-Redundancy* > *HSR* > *Statistics* dialog to view the quality of the data stream that the device receives, forwards, and sends.
- □ To remove the entry in the statistics table, click *Reset*.

 \Box To load the current statistics, click the old C button.

Another possibility is to set up the host HSR RedBox 1 using the following commands:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
no mrp operation	To disable the option.
no spanning-tree operation	To disable the option.
interface 1/1	To change to the interface configuration mode of interface 1/1.
no shutdown	To enable the interface.
exit	To change to the Configuration mode.
interface 1/2	To change to the interface configuration mode of interface 1/2.
no shutdown	To enable the interface.
exit	To change to the Configuration mode.
hsr instance 1 mode modeu	The HSR host forwards unicast data packets to the connected VDANs and around the ring.
hsr instance 1 port-a	To activate the HSR Port A.
hsr instance 1 port-b	To activate the HSR Port B.
hsr instance 1 switching-node-type hsrredboxsan	To enable the device to process the data packets destined for LAN B of the PRP network.
hsr instance 1 supervision evaluate	To enable evaluation of received supervision packets.
hsr instance 1 supervision send	To enable supervision packet transmission.
hsr instance 1 supervision redbox-exclusively	To send supervision packets only for this RedBox. Use the no form of the command to send supervision packets for each connected VDAN and this RedBox. The prerequisite is that you enable the supervision packet send function.
hsr operation	To enable the <i>HSR</i> function.

View data stream statistics on a device using the show commands.

show hsr counters	To display the HSR counters.
show hsr node-table	To display the node table.
show hsr proxy-node-table	To display the Proxy Node Table.

HSR and PRP network connections

When connecting PRP networks to an HSR network, the HSR device uses 2 interfaces to connect to the HSR ring. The HSR device uses a third interface to connect to either LAN A or LAN B of the PRP network as seen in the following figure. The HSR device transmitting the data packets across the HSR ring identifies the data packets destined for PRP networks with the appropriate tag. The HSR devices then forward the PRP data packets through LAN A or LAN B. The PRP device receives the data packets and processes it as described in the PRP chapter.

The HSR devices identify and tag the data packets for up to 7 PRP networks connected to one HSR ring.




Figure 44: Connecting a PRP network to an HSR network

HSR RedBoxes use 2 interfaces for the HSR ring. When set up to manage PRP data packets, a third interface connects to a LAN of the PRP network. The other interfaces make HSR network access available to VDANs. The HSR RedBox lists the connected VDANs in the *Switching* > *L2-Redundancy* > *HSR* > *Proxy Node Table*.

Application example of a PRP Network Connection

In the following example, you set up an HSR network with 3 HSR devices, as shown in the previous figure. Use the HSR RedBox set up in the previous example to connect the standard Ethernet devices to the HSR ring. HSR RedBox 1 sends one twin packet toward DANH 1 and one twin packet toward DANH 2. When the first packet of a pair arrives, DANH 1 sends the packet to PRP network 1 LAN A and DANH 2 sends the packet to PRP network 1 LAN B.

Deactivate the *Spanning Tree* function on the PRP ports or globally. Also, deactivate MRP on the PRP ports or set up MRP on ports other than the PRP ports.

Use the HSR RedBox set up in the previous example for HSR RedBox 1.

For the DANH 1 and 2, perform the following steps:

- □ Open the *Switching* > *L2-Redundancy* > *MRP* dialog.
- □ To disable the function, select the *Off* radio button in the *Operation* frame.
- □ Verify that the ports in *Ring port 1* and *Ring port 2* frames are different from the ports used by the *HSR* function.
- □ Open the Switching > L2-Redundancy > Spanning Tree > Global dialog.
- □ To disable the function, select the *Off* radio button in the *Operation* frame.
- □ Open the Switching > L2-Redundancy > Spanning Tree > Port dialog.
- □ In the CIST tab, deactivate the ports used for HSR in the STP active column.
- □ In the *Guards* tab, deactivate the ports used for HSR in the *Root guard*, *TCN guard* and *Loop guard* columns.

Note: If you deactivate the *HSR* function, then deactivate either Port "A" or "B" to help prevent network loops.

The device sends either only its own HSR supervision packets, or sends both its own supervision packets and packets of connected devices. After installing new HSR devices, deactivate this function to maintain a clear overview of the HSR supervision packets on remote devices.

Perform the following steps:

- □ Open the Switching > L2-Redundancy > HSR > Configuration dialog.
- □ To analyze received HSR supervision packets, activate the *Evaluate supervision packets*checkbox in the *Supervision packet receiver* frame.
- □ To transmit HSR supervision packets from this device, activate *Active*in the *Supervision packet sender* frame.
- □ To transmit packets for VDANs listed in the *Switching* > *L*2-*Redundancy* > *HSR* > *DAN/VDAN Table* dialog, mark the *Send VDAN packets* checkbox.

Set up DANH 1. To do this, perform the following steps:

- □ Open the Switching > L2-Redundancy > HSR > Configuration dialog.
- □ To set up the device to forward unicast data packets around the ring and to the destination device, set the *HSR mode* to modeu.
- □ To set up the device to forward the data packets to PRP LAN A, set the *Switching node type* to the value hsrredboxprpa.
- To set up the device to forward the data packets to PRP network 1 LAN A, set the value in the *Redbox identity* column to id1a.
- □ To enable the ports, select the *On* radio button in the *Port A* and *Port B* frames.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- \Box To load the configuration saved in the volatile memory, click the $m{C}$ button.

Set up DANH 2. To do this, perform the following steps:

□ Open the Switching > L2-Redundancy > HSR > Configuration dialog.

- □ To set up the device to forward unicast data packets around the ring and to the destination device, set the *HSR mode* to modeu.
- To set up the device to forward the data packets to PRP LAN A, set the Switching node type to the value hsrredboxprpb.
- □ To set up the device to forward the data packets to PRP network 1 LAN B, set the value in the *Redbox identity* column to id1b.
- □ To enable the ports, select the *On* radio button in the *Port A* and *Port B* frames.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- \Box To load the configuration saved in the volatile memory, click the C button.

Another possibility is to use the following commands to set up the HSR devices 1 and 2. To do this, perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
no mrp operation	To disable the option.
no spanning-tree operation	To disable the option.
interface 1/1	To change to the interface configuration mode of interface 1/1.
no shutdown	To enable the interface.
exit	To change to the Configuration mode.
interface 1/2	To change to the interface configuration mode of interface 1/2.
no shutdown	To enable the interface.
exit	To change to the Configuration mode.

Set up DANH 1 to process the data packets for PRP network 1 LAN A. To do this, perform the following steps:

hsr instance 1 mode modeu	The HSR host forwards unicast data packets to the connected VDANs and around the ring.
hsr instance 1 port-a	To activate the HSR Port A.
hsr instance 1 port-b	To activate the HSR Port B.
hsr instance 1 switching-node-type hsrredboxprpa	To enable the device to process the data packets destined for LAN A of the PRP network.
hsr instance 1 redbox-id id1a	To enable the device to process the data packets destined for LAN A of the PRP network 1.
hsr instance 1 supervision evaluate	To enable evaluation of received supervision packets.

hsr instance 1 supervision send	To enable supervision packet transmission.
hsr instance 1 supervision redbox-exclusively	To send supervision packets only for this RedBox. Use the no form of the command to send supervision packets for each connected VDAN and this RedBox. The prerequisite is that you enable the supervision packet send function.
hsr operation	To enable the <i>HSR</i> function.

Set up DANH 2 to process the data packets for PRP network 1 LAN B. To do this, perform the following steps:

hsr instance 1 mode modeu	The HSR host forwards unicast data packets to the connected VDANs and around the ring.
hsr instance 1 port-a	To activate the HSR Port A.
hsr instance 1 port-b	To activate the HSR Port B.
hsr instance 1 switching-node-type hsrredboxprpb	To enable the device to process the data packets destined for LAN B of the PRP network.
hsr instance 1 redbox-id id1b	To enable the device to process the data packets destined for LAN B of the PRP network 1.
hsr instance 1 supervision evaluate	To enable evaluation of received supervision packets.
hsr instance 1 supervision send	To enable supervision packet transmission.
hsr instance 1 supervision redbox-exclusively	To send supervision packets only for this RedBox. Use the no form of the command to send supervision packets for each connected VDAN and this RedBox. The prerequisite is that you enable the supervision packet send function.
hsr operation	To enable the <i>HSR</i> function.

View data stream statistics on a device using the show commands.

Perform the following steps:

show hsr counters	To display the HSR counters.
show hsr node-table	To display the node table.
show hsr proxy-node-table	To display the Proxy Node Table.

12.6 Device Level Ring (DLR)

The Device Level Ring (DLR) protocol is a Layer 2 protocol that provides redundancy for Ethernet data using a ring topology. The primary implementation for the DLR protocol is to control and monitor EtherNet/IP devices.

The DLR protocol operates at Layer 2 in the OSI model. The presence of the ring topology and the operation of the DLR protocol are transparent to higher layer protocols such as TCP/IP and EtherNet/IP. The DLR protocol is transparent except for a DLR Object. The DLR Object provides a configuration and diagnostic interface for the EtherNet/IP protocol.

The DLR protocol also lets you install non-DLR multi-port Layer 2 switches in the ring. Non-DLR Layer 2 switches are subject to certain restrictions. For example, the Layer 2 switch has the MAC table filtering disabled. Non-DLR devices have an impact on the ring recovery time.

In the delivery setting, the function is disabled.




Figure 45: DLR Network with ring participants

12.6.1 Device Roles

A DLR network includes at least one ring supervisor and one DLR capable ring participant. Every participant in the ring has at least 2 Ethernet ports and implements Layer 2 switching technology. After a ring participant receives a packet on a ring port, it determines whether to process or forward the packet, depending on the MAC address contained in the packet.

Active Ring Supervisor

The active ring supervisor is responsible for monitoring and controlling the network. To monitor the network, the active ring supervisor uses *Beacon* and *Announce* packets. The *Beacon* packets contain configuration information that the active ring supervisor sends to the ring participants. The ring participants set up their DLR parameters with the information contained in the *Beacon* packets.

The following list contains the configuration information sent in the Beacon packet:

- Beacon interval
- Beacon timeout
- Supervisor Precedence, entered in the Beacon based participant configuration only
- DLR VLAN ID

Note: The default VLAN ID used for DLR is 0. Verify that the VLAN-unaware mode in the Switching > Global dialog is active.




Figure 46: Beacon and Announce packets

An active ring supervisor boots in the *FAULT_STATE* and forwards *Beacon* and *Announce* packets on both Ethernet ports. During the system startup, the *Beacon* and *Announce* packets contain the value *RING_FAULT_STATE* as the ring state.

As soon as the active ring supervisor receives *Beacon* packets on both ports, it transitions the ring state to the *NORMAL_STATE*, sets a port to the *blocking* state, and flushes its unicast MAC address table (forwarding database).

The active ring supervisor continues to send the following packets:

- Beacon packets on both ports
- Announce packets only on the unblocked port

By blocking a ring port, the active ring supervisor provides only one path for the ring participants to send and receive data. The active ring supervisor sends an *Announce* packet on the unblocked port, with the ring state set to *RING_NORMAL_STATE*.

Since the active ring supervisor is responsible for controlling and monitoring the ring, it needs to know which participants are on the ring. The active ring supervisor does this by initiating the *Sign_On* process.

Backup Supervisors

When the ring contains multiple supervisors, each supervisor sends *Beacon* packets during the system startup. Besides ring state messages, and configuration information, the *Beacon* packets also contain a supervisor precedence value. When an active ring supervisor receives a *Beacon* packet, it checks the precedence value. If the precedence value in the *Beacon* packet is higher than its own, then the active ring supervisor transitions to the *FAULT_STATE* state and assumes the backup supervisor role. When the precedence values are the same, the ring supervisor with the numerically higher MAC address assumes the role of the active ring supervisor.

The backup supervisors set up their DLR parameters, except for the supervisor precedence value, and the DLR VLAN ID with the information contained in the *Beacon* packets. The backup supervisors continue to monitor both ports for a timeout of the *Beacon* packets. When the backup supervisor times out the *Beacon* packets on both ports, it waits an additional *Beacon* Timeout period before sending its *Beacon* packets.

Beacon based Nodes (depends on hardware)

When the supervisor function on a ring participant is inactive, it assumes the role of a *Beacon* based participant. *Beacon* based participants process both *Beacon* packets and *Announce* packets. This speeds up the response to a detected ring interruption.

A *Beacon* based ring participant boots up in the *IDLE_STATE*, and presumes the network has a linear topology. Upon receiving a *Beacon* packet on the primary or secondary ring port, the ring participant transitions to the *FAULT_STATE*, and presumes the network has a ring topology. The ring participant flushes its unicast MAC address table (forwarding database) and saves the DLR parameters received in the *Beacon* packets.

The ring participants save the following DLR parameters in their configuration:

- Supervisor addresses, MAC and IP address
- Supervisor precedence
- Beacon interval
- Beacon timeout
- DLR VLAN ID

Upon receiving the *Beacon* packets on both ports, the ring participant transitions to the *NORMAL_STATE*. Then the ring participant flushes its unicast MAC address table (forwarding database).

Non-DLR Nodes

The DLR protocol does not require that every ring participant implement the protocol. The network administrator can install non-DLR participants in the ring. This assumes that the devices support certain required configurations.

Note: Using non-DLR participants in the ring lengthens the recovery time. When possible, connect the non-DLR participants to the ring through a DLR capable device.

If you install non-DLR participants directly in the ring, then the participants require certain configurations. The following list describes the configurations required:

Disable unicast MAC address learning.

Beacon packets arrive on both ports with the MAC address of the active ring supervisor. Address learning causes the MAC address of the active ring supervisor to bounce from port to port.

- Disable multicast filtering on DLR ring ports. The *Beacon* and *Announce* packets used in the DLR protocol are multicast messages. When unsupported, the participant filters out the DLR messages.
- Support the reception of 802.1Q packets and preservation of the VLAN ID and tag priority.
- If unsupported, then the device can drop or incorrectly queue the DLR messages.
 Implement priority queues with strict priority scheduling.
 - Assign the DLR messages the highest priority queue. If unsupported, then the device delays DLR messages. This affects ring recovery performance.

Note: Using non-DLR participants can result in loss of unicast packets for some time following a detected error or ring restoration. If the non-DLR participant maintains the MAC address table (forwarding database) after a detected error, then the participant can send unicast packets on the wrong port. For this reason, DLR capable participants flush their MAC address table (forwarding database).

12.6.2 Error Detection

The active ring supervisor is responsible for ring integrity. To control and monitor the ring, the active ring supervisor sends Beacon and *Announce* packets. The *Beacon* and *Announce* packets contain various status messages. The status messages inform the ring participants about the health of the ring.

The ring participants also monitor connections to their neighbors. When a ring participant detects that the link to a neighbor is interrupted, it sends a *Link_Status* message to the active ring supervisor.

After receipt of the *Link_Status* message, the ring supervisor unblocks its previously blocked port. Unblocking the port transitions the network from a ring to a linear topology. The active ring supervisor then flushes its unicast MAC table, and immediately sends *Beacon* and *Announce* packets. The ring state set to *RING_FAULT_STATE*.

Active Ring Supervisor

The following list contains events in which the active ring supervisor transitions to the *FAULT_STATE*:

- Receiving *Beacon* packets from another supervisor with a higher precedence value.
- Loss of *Beacon* packets on either port for the specified *Beacon* Timeout period, indicating a break in the ring.
- Interruption of link with the neighboring participant detected on either port.
- Receiving a Link_Status message from a ring participant, indicating that a ring participant has detected an error.

In the cases listed above, the active ring supervisor responds with the following actions:

- Transition to FAULT_STATE
- Flush the unicast MAC address table (forwarding database)
- Unblock the blocked port
- Send *Beacon* packets on both ports, with ring state set to the *RING_FAULT_STATE*
- Send Announce packets on both ports, with ring state set to the RING_FAULT_STATE

When the active ring supervisor times out a *Beacon* packet, it initiates the Neighbor Check process by sending a Locate Fault packet. The supervisor also sends Neighbor Check packets to the neighbor connected to the ports on which it timed out the *Beacon* packet.

When in the *FAULT_STATE*, the active ring supervisor continues to send *Beacon* packets. Sending *Beacon* packets lets the active ring supervisor detect ring restoration.

Ring Participants

The following list contains events in which the ring participant transitions from the *NORMAL_STATE* to another state:

- Receipt of a *Beacon* packet with the ring state set to *RING_FAULT_STATE*.
- Receipt of a *Beacon* packet with a different MAC address and higher precedence than the current active ring supervisor.
- Loss of *Beacon* packets on both ports for the specified *Beacon* Timeout period. Losing the *Beacon* packets on both ports causes the participant to transition to *IDLE_STATE*. The ring participant assumes that the topology has transitioned from a ring to a linear network.
- Loss of *Beacon* packets on a single port for the specified *Beacon* Timeout period.

In the cases listed above, the ring participant responds with the following actions:


- Flush the unicast MAC address table (forwarding database)
- A loss of *Beacon* packets on both ports or the loss of *Announce* packets causes the ring participant to transition to the *IDLE_STATE*.
- A loss of *Beacon* packets on a single port causes the ring participant to transition to the FAULT_STATE.

12.6.3 Neighbor Check process

When the active ring supervisor detects the loss of *Beacon* packets, it sends a *Locate_Fault* packet to the ring participants through both ports.

Upon receipt of the *Locate_Fault* packet, each ring participant sends a *Neighbor_Check_Request* packet to its immediate neighbors. The supervisor also sends its own *Neighbor_Check_Request* to its immediate neighbors.

When the ring participant receives a *Neighbor_Check_Request* packet, it responds with a *Neighbor_Check_Response* packet on the port from which it received the request. When the participant sending the *Neighbor_Check_Request* packet does not receive a response, it sends another request. When the participant receives no responses after 3 attempts, it sends a *Neighbor_Status* packet to the ring supervisor.



12.6.4 Sign On Process

To identify ring participants, the active ring supervisor sends *Sign_On* packets after transiting to the *NORMAL_STATE*. The active supervisor sends a *Sign_On* packet once every minute while in the *NORMAL_STATE*. When the active supervisor receives a *Sign_On* packet that it previously sent, it discontinues sending *Sign_On* packets. The device displays the ring participant list in the *Switching* > *L2-Redundancy* > *DLR* > *Statistics* dialog.

The active ring supervisor sends the multicast *Sign_On* packets from the unblocked port. When a ring participant receives the *Sign_On* packet, it forwards the packet to the CPU of the device only. The CPU adds the addresses of the participant and sends the *Sign_On* packet out of the port opposite to the receiving port.

The ring participants send the *Sign_On* packet around the ring. Each participant processes the *Sign_On* packet similarly. Eventually, the *Sign_On* packet returns to the active ring supervisor. The active supervisor verifies that it sent the *Sign_On* packet. For this purpose, the active supervisor checks the first entry in the ring participant list.




Figure 48: Sign On Process

If adding an address of a participant to the *Sign_On* packet exceeds the maximum packet size, then the participant does not add its address to the received packet. The participant saves the port on which it received the packet. Then the participant sends the *Sign_On* packet directly to the unicast MAC address of the active ring supervisor.

When the ring supervisor receives the *Sign_On* packet sent to its unicast MAC address, it assumes this is due to the *Sign_On* packet size reaching its maximum capacity. The supervisor restarts the process by sending a new *Sign_On* packet directly to the unicast MAC address of the participant from which it received the unicast *Sign_On* packet.

Upon receiving the new *Sign_On* packet from the active ring supervisor, the ring participant adds its address to the *Sign_On* packet. The participant then sends the multicast *Sign_On* packet on the ring port opposite to the port saved in memory.

12.6.5 Application example for DLR

The Device Level Ring (DLR) protocol provides redundancy for Ethernet data in a ring topology. Using the DLR protocol, you control and monitor Ethernet and IP devices.

EtherNet/IP Environments

If you use the *DLR* function in Ethernet environments, then verify that the parameters are specified as follows:

► DLR:

- The *DLR* function is enabled.
- The ports 1/1 and 1/2 are specified as the DLR ring ports.
- The Supervisor active function is active.
- EtherNet/IP:
 - The *EtherNet/IP* function is enabled.
 - The Write access function is active.
- Spanning Tree:
 - The Spanning Tree function is disabled.

VLANs:

- The VLAN-unaware mode function is active.

- ► IGMP Snooping:
 - The IGMP Snooping function is enabled, and active on every port.
 - The Querier function is enabled.
 - The Snooping Enhancements on DLR ring ports are specified as Static (S) and Forward all (F).

When you order the device using the hardware code D, the values of parameters listed above are specified as the default settings.

Set up the *DLR* operation within an *EtherNet/IP* environment for example, with Rockwell or Allen-Bradley devices. To do this, perform the following steps:

- □ Open the *Switching* > *Global* dialog.
- □ In the *Configuration* frame, mark the *VLAN-unaware mode* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the Switching > L2-Redundancy > DLR > Configuration dialog.
- \Box To add a table row, click the $\overset{\blacksquare}{+}$ button.
- □ In the *Name* column, specify the value DLR_Ring_1.
- \Box In the VLAN ID column, specify the value 0.
- □ To activate the configuration, mark the checkbox in the *Active* column.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
vlan-unaware-mode	To activate the VLAN-unaware mode function.
exit	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dlr ring add 1	To add the <i>DLR</i> ring 1.
dlr ring modify 1 name DLR_Ring_1	To specify the value DLR_Ring_1 as the name of the DLR ring.
dlr ring modify 1 port-1 1/1	To specify port 1/1 as the DLR ring port 1.
dlr ring modify 1 port-2 1/2	To specify port $1/2$ as the <i>DLR</i> ring port 2.
dlr ring modify 1 precedence 250	To specify the value 250 as the supervisor precedence.
dlr ring modify 1 supervisor enable	To enable the ring supervisor function.
dlr ring modify 1 vlan 0	To specify the value 0 as the VLAN identifier. The device uses the VLAN to forward the <i>DLR</i> protocol messages.
dlr ring modify 1 operation enable	To enable the <i>DLR</i> function for ring 1.
dlr operation	To enable the global <i>DLR</i> function.

12.7 Spanning Tree

Note: The Spanning Tree Protocol (STP) is a protocol for MAC bridges. For this reason, the following description uses the term bridge for the device.

Local networks are getting bigger and bigger. This applies to both the geographical expansion and the number of network participants. Therefore, it is advantageous to use multiple bridges, for example:

- to reduce the network load in sub-areas,
- to set up redundant connections and
- ▶ to overcome distance limitations.

However, using multiple bridges with multiple redundant connections between the subnets can lead to loops and thus interruption of communication across the network. To help avoid this, you can use Spanning Tree. Spanning Tree helps avoid loops through the systematic deactivation of redundant connections. Redundancy enables the systematic reactivation of individual connections as needed.

RSTP is a further development of the Spanning Tree Protocol (STP) and is compatible with it. When a connection or a bridge becomes inoperable, the STP requires a maximum of 30 seconds to reconfigure. This is no longer acceptable in time-sensitive applications. RSTP achieves average reconfiguration times of less than a second. When you use RSTP in a ring topology with 10 to 20 devices, you can even achieve reconfiguration times in the order of milliseconds.

Note: RSTP reduces a layer 2 network topology with redundant paths into a tree structure (Spanning Tree) that does not contain any more redundant paths. One of the devices takes over the role of the *Root bridge* here. The maximum number of devices permitted in an active branch from the *Root bridge* to the tip of the branch is specified by the variable *Max age* for the current *Root bridge*. The preset value for *Max age* is 20, which can be increased up to 40.

If the device working as the root is inoperable and another device takes over its function, then the *Max age* setting of the new *Root bridge* determines the maximum number of devices allowed in a branch.

Note: The RSTP standard requires that every device within a network operates with the (Rapid) Spanning Tree Algorithm. When STP and RSTP are used at the same time, the advantages of faster reconfiguration with RSTP are lost in the network segments that are operated in combination.

A device that only supports RSTP works together with MSTP devices by not assigning an MST region to itself, but rather the Common Spanning Tree (CST).

12.7.1 Basics

Because RSTP is a further development of the STP, every of the following descriptions of the STP also apply to RSTP.

The tasks of the STP

The Spanning Tree Algorithm reduces network topologies built with bridges and containing ring structures due to redundant links to a tree structure. In doing so, STP opens ring structures according to preset rules by deactivating redundant paths. When a path is interrupted because a network component becomes inoperable, STP reactivates the previously deactivated path again. This lets redundant links increase the availability of communication.

STP determines a bridge that represents the STP tree structure's base. This bridge is called *Root bridge*.

Features of the STP algorithm:

- Automatic reconfiguration of the tree structure in the case of a bridge becoming inoperable or the interruption of a data path.
- The tree structure is stabilized up to the maximum network size.
- The topology stabilizes within a predictable time period.
- ▶ The administrator can specify and reproduce the topology.
- Transparency for the end devices.
- The network load is low relative to the available transmission capacity due to the tree structure set-up.

Bridge parameters

In the context of Spanning Tree, each bridge and its connections are uniquely described by the following parameters:

- Bridge Identifier
- Root path cost of the bridge ports
- Port Identifier

Bridge Identifier

The *Bridge Identifier* consists of 8 bytes. The bridge with the numerically lowest *Bridge Identifier* value has the highest priority.

According to the original standard IEEE 802.1D-1998, the 2 highest-value bytes are the *Bridge priority*. When configuring the bridge, the bridge administrator can change the default setting for the *Bridge priority* which is 32768 (8000H).

In the newer standard IEEE 802.1Q-2014, the *Bridge priority* is interpreted differently. The highest 4 bits represent the *Bridge priority*. The lower 12 bits are reserved for the VLAN ID and are all zero. As a result, the bridge administrator can set the *Bridge priority* in steps of 4096. The default value is 32768 (8000H), and the max. value is 61440 (F000H).

The 6 lowest-value bytes of the *Bridge Identifier* are the MAC address of the bridge. The MAC address lets each bridge have a unique *Bridge Identifier*.




Figure 49: Bridge Identifier, Example (interpretation according to IEEE 802.1D-1998, values in hexadecimal notation)

Root path cost

Each path that connects 2 bridges is assigned a cost for the transmission (path cost). The device determines this value based on the transmission speed (see table 33 on page 241). The device assigns a higher path cost to paths with lower transmission speeds.

As an alternative, the administrator can set the path cost. Like the device, the administrator assigns a higher path cost to paths with lower transmission speeds. However, since the administrator can choose this value freely, he has a tool with which he can give a certain path an advantage among redundant paths.

The *Root path cost* is the sum of the individual path costs from the port of the connected bridge to the *Root bridge*.




Figure 50: Path costs

Data rate	Recommended value	Recommended range	Possible range
≤100 kbit/s	200 000000 ¹	20000000-200000000	1-200000000
1 Mbit/s	20 000 000 ^a	2000000-200000000	1-200000000
10 Mbit/s	2000000 ^a	200000-20000000	1-200000000
100 Mbit/s	200000 ^a	20000-2000000	1-200000000
1 Gbit/s	20000	2000-200000	1-200000000
10 Gbit/s	2000	200-20000	1-200 000000
100 Gbit/s	200	20-2000	1-200000000
1 Tbit/s	20	2-200	1-200000000
10 Tbit/s	2	1-20	1-200000000

1. Verify that bridges, which conform to IEEE 802.1D-1998 and only support 16-bit values for the past costs, use the value 65535 (FFFFH) for path costs in cases where they are used in conjunction with bridges that support 32-bit values for the path costs.

Port Identifier

According to the original standard IEEE 802.1D-1998, the *Port Identifier* consists of 2 bytes. The lower-value byte contains the physical port number. This provides a unique identifier for the port of this bridge. The higher-value byte is the *Port priority*, which is specified by the administrator (default value: 128 or 80H).

In the newer standard IEEE 802.1Q-2014, the *Port priority* is interpreted differently. The highest 4 bits represent the *Port priority*. The lower 12 bits are the port number. This allows for bridges with up to 4095 ports. As a result, the bridge administrator can set the *Port priority* in steps of 4096, when viewed as a 16-bit number. The default value is 32768 (8000H), and the max. value is 61440 (F000H). When viewed as 4-bit number, the default value is 8 (8H), the min. value is 0 (0H), and the max. value is 15 (FH).



Priority Port number

Figure 51: Port Identifier (interpretation according to IEEE 802.1D-1998)

Max Age and Diameter

The "Max Age" and "Diameter" values largely determine the maximum expansion of a Spanning Tree network.

Diameter

The number of connections between the devices in the network that are furthest removed from each other is known as the network diameter.




Figure 52: Definition of diameter

The network diameter that can be achieved in the network is MaxAge-1.

In the state on delivery, MaxAge = 20 and the maximum diameter that can be achieved is 19. When you set the maximum value of 40 for MaxAge, the maximum diameter that can be achieved is 39.

MaxAge

Every STP-BPDU contains a "MessageAge" counter. When a bridge is passed through, the counter increases by 1.

Before forwarding a STP-BPDU, the bridge compares the "MessageAge" counter with the "MaxAge" value specified in the device:

- □ When MessageAge < MaxAge, the bridge forwards the STP-BPDU to the next bridge.
- □ When MessageAge = MaxAge, the bridge discards the STP-BPDU.

Root-Bridge




Figure 53: Transmission of an STP-BPDU depending on MaxAge

12.7.2 Rules for Creating the Tree Structure

Bridge information

To determine the tree structure, the bridges need more detailed information about the other bridges located in the network.

To obtain this information, each bridge sends a BPDU (Bridge Protocol Data Unit) to the other bridges.

The contents of a BPDU include:

- Bridge Identifier
- Root path cost
- Port Identifier

(see IEEE 802.1D)

Setting up the tree structure

The bridge with the numerically lowest *Bridge Identifier* value is called the *Root bridge*. This bridge is (or will become) the root of the tree structure.

The structure of the tree depends on the *Root path costs*. Spanning Tree selects the structure so that the path costs between each individual bridge and the *Root bridge* become as small as possible.

- When there are multiple paths with the same *Root path costs*, the bridge further away from the root decides which port it blocks. For this purpose, the bridge further from the root uses the *Bridge Identifiers* of the bridge closer to the root. The the bridge further from the root blocks the port that leads to the bridge with the numerically higher ID (a numerically higher ID is the logically worse one). When 2 bridges have the same priority, the bridge with the numerically larger MAC address has the numerically higher ID, which is logically the worse one.
- When multiple paths with the same Root path costs lead from one bridge to the same bridge, the bridge further away from the root uses the Port Identifier of the other bridge as the last criterion (see figure 51 on page 242). In the process, the bridge blocks the port that leads to the port with the numerically higher ID. A numerically higher ID is the logically worse one. When 2 ports have the same priority, the port with the higher port number has the numerically higher ID, which is logically the worse one.




Figure 54: Flow diagram for specifying the root path

12.7.3 Examples

Example of determining the root path

You can use the network plan to follow the flow chart (see figure 54 on page 244) for determining the root path. The administrator has specified a priority in the *Bridge Identifier* for each bridge. The bridge with the numerically lowest value for the *Bridge Identifier* takes on the role of the *Root bridge*, in this case, bridge 1. In the example every sub-path has the same path costs. The protocol blocks the path between bridge 2 and bridge 3 because a connection from bridge 3 through bridge 2 to the *Root bridge* would result in higher path costs.

The path from bridge 6 to the *Root bridge* is interesting:

- The path through bridge 5 and bridge 3 has the same Root path costs as the path through bridge 4 and bridge 2.
- STP selects the path using the bridge that has the lowest MAC address in the Bridge Identifier (bridge 4 in the illustration).
- There are also 2 paths between bridge 6 and bridge 4. The Port Identifier is decisive here (Port 1 < Port 3).</p>




Figure 55: Example of a network plan for determining the root path

Note: When the current *Root bridge* goes down, the MAC address in the *Bridge Identifier* alone determines which bridge becomes the new *Root bridge*, because the administrator does not change the default values for the priorities of the bridges in the *Bridge Identifier*, apart from the value for the *Root bridge*.

Example of manipulating the root path

You can use the network plan to follow the flow chart (see figure 54 on page 244) for determining the root path. The administrator has performed the following:

- Left the default value of 32768 (8000H) for every bridge apart from bridge 1 and bridge 5, and
- assigned to bridge 1 the value 16384 (4000H), thus making it the Root bridge.
- To bridge 5 he assigned the value 28672 (7000H).

The protocol blocks the path between bridge 2 and bridge 3 because a connection from bridge 3 through bridge 2 to the *Root bridge* would result in higher path costs.

The path from bridge 6 to the *Root bridge* is interesting:

The bridges select the path through bridge 5 because the value 28672 for the priority in the Bridge Identifier is lower than the value 32768.





Figure 56: Example of a network plan for manipulating the root path

Example of manipulating the tree structure

The administrator soon discovers that this configuration with bridge 1 as the *Root bridge* is invalid. On the paths from bridge 1 to bridge 2 and bridge 1 to bridge 3, the control packets which the *Root bridge* sends to every other bridge add up.

When the administrator sets up bridge 2 as the *Root bridge*, the burden of the control packets on the subnets is distributed much more evenly. The result is the configuration shown in the following figure. The path costs for most of the bridges to the *Root bridge* have decreased.



---- Interrupted path

Figure 57: Example of manipulating the tree structure

12.8 Rapid Spanning Tree Protocol

The Rapid Spanning Tree Protocol (RSTP) uses the same algorithm for determining the tree structure as Spanning Tree Protocol (STP). When a link or bridge becomes inoperable, the Rapid Spanning Tree Protocol (RSTP) adds mechanisms that speed up the reconfiguration.

The ports play a significant role in this context.

12.8.1 Port roles

The Rapid Spanning Tree Protocol (RSTP) assigns each bridge port one of the following roles: *Root port*:

This is the port at which a bridge receives data packets with the lowest path costs from the *Root* bridge.

When there are multiple ports with equally low path costs, the *Bridge Identifier* of the bridge that leads to the root (*Designated bridge*) decides which of its ports is given the role of the *Root port* by the bridge further away from the root.

When a bridge has multiple ports with equally low path costs to the same bridge, the bridge uses the port ID of the bridge leading to the root (*Designated bridge*) to decide which port it selects locally as the *Root port*. See figure 54 on page 244.

The Root bridge itself does not have a Root port, only Designated ports.

Designated port:

The bridge in a network segment that has the numerically lowest *Root path costs* value is the *Designated bridge*.

When more than one bridge has the same *Root path costs*, the bridge with the numerically lowest *Bridge Identifier* value becomes the *Designated bridge*. The *Designated port* on this bridge is the port that connects a network segment leading away from the *Root bridge*. When a bridge is connected to a network segment through more than one port (through a hub, for example), the bridge gives the role of the *Designated port* to the port with the better port ID.

Edge port

Every network segment with no additional RSTP bridges is connected with exactly one *Designated port*. In this case, this *Designated port* is also an *Edge port*. The distinction of an *Edge port* is the fact that it does not receive any *RST BPDUs (Rapid Spanning Tree Bridge Protocol Data Units)*.

Alternate port

When the connection to the *Root bridge* is lost, this blocked port takes over the task of the *Root port*. The *Alternate port* provides a backup for the connection to the *Root bridge*.

Backup port

This is a blocked port that serves as a backup in case the connection to the *Designated port* of this network segment (without any RSTP bridges) is lost

Disabled port

This is a port that does not participate in the Spanning Tree Operation, that means, the port is switched off or does not have any connection.




Figure 58: Port role assignment

12.8.2 Port states

Depending on the tree structure and the state of the selected connection paths, RSTP assigns the ports their states.

STP port state	Administrative bridge port state	MAC Operational	RSTP Port state	Active topology (port role)
Disabled	Disabled	FALSE	Discarding ¹	Excluded (disabled)
Disabled	Enabled	FALSE	Discarding ^a	Excluded (disabled)
Blocking	Enabled	TRUE	Discarding ²	Excluded (alternate, backup)
Listening	Enabled	TRUE	Discarding ^b	Included (root, designated)
Learning	Enabled	TRUE	Learning	Included (root, designated)
Forwarding	Enabled	TRUE	Forwarding	Included (root, designated)

1. The dot1d-MIB displays Disabled.

2. The dot1d-MIB displays *Blocked*.

Meaning of the RSTP port states:

- Disabled: Port does not belong to the active topology
- Discarding: No address learning in the MAC address table (forwarding database), no data packets except for STP-BPDUs

- Learning: Address learning active in the MAC address table (forwarding database), no data packets apart from STP-BPDUs
- Forwarding: Address learning in the MAC address table (forwarding database) active, sending and receiving of every packet type (not only STP-BPDUs)

12.8.3 Spanning Tree Priority Vector

To assign roles to the ports, the RSTP bridges exchange configuration information with each other. This information is known as the Spanning Tree Priority Vector. It is part of the *RST BPDUs* and contains the following information:

- *Bridge Identifier* of the *Root bridge*
- Root path costs of the sending bridge
- Bridge Identifier of the sending bridge
- > Port Identifier of the port through which the message was sent
- > Port Identifier of the port through which the message was received

Based on this information, the bridges participating in RSTP are able to determine port roles themselves and define the port states of their own ports.

12.8.4 Fast reconfiguration

Why can RSTP react faster than STP to an interruption of the root path?

Introduction of edge-ports:

During a reconfiguration, RSTP sets an *Edge port* into the transmission mode after 3 seconds (default setting). To ascertain that no bridge sending BPDUs is connected, RSTP waits for the "Hello Time" to elapse.

When you verify that an end device is and remains connected to this port, there are no waiting times at this port in the case of a reconfiguration.

- Introduction of Alternate ports: As the port roles are already distributed in normal operation, a bridge can immediately switch from the Root port to the Alternate port after the connection to the Root bridge is lost.
- Communication with neighboring bridges (point-to-point connections): Decentralized, direct communication between neighboring bridges enables reaction without wait periods to status changes in the spanning tree topology.
- Address table:

With Spanning Tree Protocol (STP), the age of the entries in the MAC address table (forwarding database) determines the updating of communication. The Rapid Spanning Tree Protocol (RSTP) immediately deletes the entries in those ports affected by a reconfiguration.

Reaction to events:

Without having to match any time specifications, Rapid Spanning Tree Protocol (RSTP) immediately reacts to events, for example, connection interruption and connection reinstatement.

Note: Data packages could be duplicated and/or arrive at the recipient in the wrong order during the reconfiguration phase of the RSTP topology. You may also use the Spanning Tree Protocol (STP) or select another redundancy procedure described in this manual.

12.8.5 Configuring the device

RSTP sets up the network topology completely autonomously. The device with the numerically lowest *Bridge priority* value automatically becomes the *Root bridge*. However, to define a specific network structure, you specify a device as the *Root bridge*. In general, a device in the backbone takes on this role.

Perform the following steps:

- □ Set up the network to meet your requirements, initially without redundant lines.
- You deactivate the flow control on the participating ports. If the flow control and the redundancy function are active at the same time, it is possible that the redundancy function operates differently than intended. (Default setting: flow control deactivated globally and activated on every port.)
- Disable MRP on every device.
- Enable Spanning Tree on every device in the network.
 In the state on delivery, Spanning Tree is switched on in the device.

Perform the following steps:

Open the Switching > L2-Redundancy > Spanning Tree > Global dialog.
 Enable the function.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
spanning-tree operation	To enable Spanning Tree.
show spanning-tree global	To display the parameters for checking.

Now connect the redundant lines.

Define the settings for the device that takes over the role of the Root bridge.

Perform the following steps:

In the *Priority* field you specify a numerically lower value. The bridge with the numerically lowest *Bridge Identifier* value has the highest priority and becomes the *Root bridge* of the network.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

spanning-tree mst priority 0 <0..61440> To specify the Bridge priority of the device.

Note: Specify the *Bridge priority* in the range 0..61440 in steps of 4096.

After saving, the dialog shows the following information:

- The *Bridge is root* checkbox is marked.
- The *Root port* field shows the value 0.0.
- The Root path cost field shows the value 0.

 show spanning-tree global
 To display the parameters for checking.

 If applicable, then change the values in the Forward delay [s] and Max age fields.

 The Root bridge transmits the changed values to the other devices.

 Apply the settings temporarily. To do this, click the ✓ button.

 spanning-tree forward-time <4..30>

 spanning-tree max-age <6..40>

 To specify the delay time for the status change in seconds.

 spanning-tree max-age <6..40>

 To specify the maximum permissible branch length, for example the number of devices to the Root bridge.

 show spanning-tree global
 To display the parameters for checking.

Note: The parameters Forward delay [s] and Max age have the following relationship:

Forward delay $[s] \ge (Max age/2) + 1$

If you enter values in the fields that contradict this relationship, then the device replaces these values with the last valid values or with the default value.

Note: When possible, do not change the value in the "Hello Time" field.

Check the following values in the other devices:

- Bridge Identifier (Bridge priority and MAC address) of the corresponding device and the Root bridge.
- Number of the device port that leads to the Root bridge.
- Path cost from the Root port of the device to the Root bridge.

Perform the following steps:

show spanning-tree global


To display the parameters for checking.

12.8.6 Guards

The device lets you activate various protection functions (guards) in the device ports.

The following protection functions help protect the network from incorrect configurations, loops and attacks with STP-BPDUs:


BPDU guard – for manually specified Edge ports (end device ports) You activate this protection function globally in the device.



Terminal device ports do not normally receive any STP-BPDUs. If an attacker still attempts to feed in STP-BPDUs on this port, then the device deactivates the device port.

Root guard – for Designated ports

You activate this protection function separately for every device port.



When a *Designated port* receives an STP-BPDU with better path information to the *Root bridge*, the device discards the STP-BPDU and sets the transmission state of the port to *discarding* instead of root.


When there are no STP-BPDUs with better path information to the *Root bridge*, after 2 × *Hello time* [s] the device resets the state of the port to a value according to the port role.

TCN guard – for ports that receive STP-BPDUs with a Topology Change flag You activate this protection function separately for every device port.



If the protection function is activated, then the device ignores Topology Change flags in received STP-BPDUs. This does not change the content of the MAC address table (forwarding database) of the device port. However, additional information in the BPDU that changes the topology is processed by the device.

Loop guard – for Root ports, Alternate ports and Backup ports You activate this protection function separately for every device port.



If the port does not receive any more STP-BPDUs, then this protection function helps prevent the transmission status of a port from unintentionally being changed to *forwarding*. If this situation occurs, then the device designates the loop status of the port as inconsistent, but does not forward any data packets.

Activating the BPDU guard function

Perform the following steps:

□ Open the Switching > L2-Redundancy > Spanning Tree > Global dialog. □ Mark the *BPDU guard* checkbox. \Box Apply the settings temporarily. To do this, click the \checkmark button. enable

To change to the Privileged EXEC mode.

configure spanning-tree bpdu-guard show spanning-tree global To change to the Configuration mode. To activate the *BPDU guard* function. To display the parameters for checking.

 Open the Switching > L2-Redundancy > Spanning Tree > Port dialog. Switch to the CIST tab. For end device ports, mark the checkbox in the Admin edge portcolumn. 		
\square Apply the settings temporarily. To do this, click the \checkmark button.		
interface <x y=""></x>	To change to the interface configuration mode of interface <x y="">.</x>	
spanning-tree edge-port	To designate the port as a <i>Edge port</i> (end device port).	
show spanning-tree port x/y	To display the parameters for checking.	

exit

When an *Edge port* receives an STP-BPDU, the device behaves as follows:

The device deactivates this port. In the Basic Settings > Port dialog, Configuration tab, the checkbox for this port in the Port on column is unmarked.

To leave the interface mode.

The device designates the port.

You can determine if a port has disabled itself because of a received a BPDU. To do this, perform the following steps:

In the *Switching* > *L2-Redundancy* > *Spanning Tree* > *Port* dialog, *Guards* tab, the checkbox in the *BPDU guard effect* column is marked.

show spanning-tree port x/y

To display the parameters of the port for checking. The value of the *BPDU guard effect* parameter is enabled.

Reset the status of the device port to the value forwarding. To do this, perform the following steps: When the port still receives BPDUs:

- Remove the manual definition as an *Edge port* (end device port).
 or
- Deactivate the BPDU guard function.
- □ Activate the device port again.

Activating the Root guard / TCN guard / Loop guard function

Perform the following steps:

 Open the Switching > L2-Redundancy > Spanning Tree > Port dialog. Switch to the Guards tab. For Designated ports, select the checkbox in the Root guard column. For ports that receive STP-BPDUs with a Topology Change flag, select the checkbox in the TCN guard column. For Root ports, Alternate ports or Backup ports, mark the checkbox in the Loop guard column. 				
Note: The <i>Root guard</i> and <i>Loop guard</i> functions are mutually exclusive. If you try to activate the <i>Root guard</i> function while the <i>Loop guard</i> function is active, then the device deactivates the <i>Loop guard</i> function.				
\Box Apply the settings temporarily. To do this, click the \checkmark button.				
enable	To change to the Privileged EXEC mode.			
configure	To change to the Configuration mode.			
interface <x y=""></x>	To change to the interface configuration mode of interface <x y="">.</x>			
spanning-tree guard-root	To activate the <i>Root guard</i> function on the <i>Designated port</i> .			
spanning-tree guard-tcn	To activate the <i>TCN guard</i> function on the port that receives STP-BPDUs with a <i>Topology Change</i> flag.			
spanning-tree guard-loop	To activate the <i>Loop guard</i> function on a <i>Root port</i> , <i>Alternate port</i> , or <i>Backup port</i> .			
exit	To leave the interface mode.			
show spanning-tree port x/y	To display the parameters of the port for checking.			

12.8.7 Ring only mode function

You use the *Ring only mode* function to recognize full-duplex connectivity and to set up the ports that are connected to the end stations. The *Ring only mode* function lets the device transition to the *forwarding* state, and suppress the *Topology Change Notification* PDUs.

Configuring the Ring only mode

When you activate the *Ring only mode* function on the ports, and the device ignores the message age of normal BDPUs, the device sends *Topology Change* messages with the message age of 1.

Setting up the Ring only mode function

The given example describes the configuration of the Ring only mode function.

Perform the following steps:

- □ Open the Switching > L2-Redundancy > Spanning Tree > Global dialog.
- \Box In the *Ring only mode* frame, select the port 1/1 in the *First port* field.
- □ In the *Ring only mode* frame, select the port 1/2 in the Second port field.
- □ To activate the function, in the *Ring only mode* frame, mark the *Active* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
spanning-tree ring-only-mode operation	To enable the <i>Ring only mode</i> function.
<pre>spanning-tree ring-only-mode first-port 1/ 1</pre>	To specify port $1/1$ as the first interface.
spanning-tree ring-only-mode second- port 1/2	To specify port $1/2$ as the second interface.

12.8.8 RSTP over HSR

The RSTP over HSR function lets you redundantly couple an RSTP network to an HSR ring.

By doing this:

- The device uses the logical port hsr/1.
- When the logical port hsr/1 changes from the RSTP state to *forwarding*, the device flushes the *Proxy Node Table*.

Setting up RSTP over HSR

HSR limits the bandwidth. In the case of redundancy, RSTP is set up in such a way that the device forwards the data packets over the HSR ring only.

Application example for the RSTP over HSR function

You use the RSTP over HSR function to redundantly couple an RSTP network to an HSR ring.

Perform the following steps:

- □ Open the *Switching* > *L*2-*Redundancy* > *Spanning Tree* > *Port* dialog.
- \Box In the *Port priority* column, specify the value 240 for port hsr/1.
- □ In the Port path cost column, specify the value 200000000 for port hsr/1.
- □ Enable the *Spanning Tree* function on port hsr/1.
 - In the STP active column, mark the checkbox for port hsr/1.

12.9 Link Aggregation

The *Link Aggregation* function using the single switch method helps you overcome 2 limitations with Ethernet links, namely bandwidth, and redundancy.

The *Link Aggregation* function helps you overcome bandwidth limitations of individual ports. The *Link Aggregation* function lets you combine 2 or more connections into one logical connection between 2 devices. The parallel links increase the bandwidth between the 2 devices.

You typically use the *Link Aggregation* function on the network backbone. The function provides you an inexpensive way to incrementally increase bandwidth.

Furthermore, the *Link Aggregation* function provides for redundancy with a seamless failover. When a link goes down, with 2 or more links set up in parallel, the other links in the group continue to forward the data packets.

The device uses a hash option to determine load balancing across the port group. Tagging the egress data packets lets the device transmit associated packets across the same link.

The default settings for a new Link Aggregation instance are as follows:

- ▶ In the *Configuration* frame, the value in the *Hashing option* field is sourceDestMacVlan.
- In the *Active* column, the checkbox is marked.
- ▶ In the Send trap (Link up/down) column, the checkbox is marked.
- In the *Static link aggregation* column, the checkbox is unmarked.
- ▶ In the *Hashing option* column, the value is sourceDestMacVlan.
- In the Active ports (min.) column, the value is 1.

12.9.1 Methods of Operation

The device operates on the Single Switch method. The Single Switch method provides you an inexpensive way to grow the network. The single switch method states that you need one device on each side of a link to provide the physical ports. The device balances the network load across the group member ports.

The device also uses the Same Link Speed method in which the group member ports operate in full-duplex, point-to-point links having the same transmission rate. The first port that you add to the group is the master port and determines the bandwidth for the other member ports of the Link Aggregation Group.

The device lets you set a maximum of 4 Link Aggregation groups. The number of useable ports per Link Aggregation group depends on the device.

Hash Algorithm

The frame distributor is responsible for receiving frames from the end devices and transmitting them over the Link Aggregation Group. The frame distributor implements a distribution algorithm responsible for choosing the link used for transmitting any given packet. The hash option helps you achieve load balancing across the group.

The following list contains options which you set for link selection.

- Source MAC address, VLAN ID, EtherType, and receiving port
- Destination MAC address, VLAN ID, EtherType, and receiving port

- Source/Destination MAC address, VLAN ID, EtherType, and receiving port
- Source IP address and Source TCP/UDP port
- Destination IP address and destination TCP/UDP port
- Source/destination IP address and source/destination TCP/UDP port

Static and Dynamic Links

The device lets you set up static and dynamic links.

- Static Links The administrator sets up and maintains the links manually. For example, when a link fails and there is a media converter between the devices, the media converter continues forwarding the data packets on the link, causing the link to fail. Another possibility is that cabling or an undetected configuration mistake causes undesirable network behavior. In this case, the network administrator manually changes the link setup to restore the data stream.
- Dynamic Links The device confirms that the setup on the remote device is able to handle link aggregation and failover occurs automatically.

12.9.2 Link Aggregation Example

Connect multiple workstations using one aggregated link group between Switch 1 and 2. By aggregating multiple links, higher speeds are achievable without a hardware upgrade.




Figure 59: Link Aggregation Switch to Switch Network

Set up Switch 1 and 2 in the Graphical User Interface. To do this, perform the following steps:

- □ Open the Switching > L2-Redundancy > Link Aggregation dialog.
- \Box Click the $\overset{\blacksquare}{+}$ button.

The dialog displays the Create window.

- □ From the *Trunk port* drop-down list, select the instance number of the link aggregation group.
- \Box From the *Port* drop-down list, select port 1/1.
- Click the Ok button.
- \Box Repeat the preceding steps and select the port 1/2.
- Click the Ok button.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
link-aggregation add lag/1	To add a Link Aggregation Group lag/1.
link-aggregation modify lag/1 addport 1/1	To add port 1/1 to the Link Aggregation Group.
link-aggregation modify lag/1 addport 1/2	To add port 1/2 to the Link Aggregation Group.

12.10 Link Backup

Link Backup provides a redundant link for the data packets on Layer 2 devices. When the device detects an error on the primary link, the device transfers the data packets to the backup link. You typically use Link Backup in service-provider or enterprise networks.

You set up the backup links in pairs, one as a primary and one as a backup. When providing redundancy for enterprise networks for example, the device lets you set up more than one pair. The maximum number of link backup pairs is: total number of physical ports / 2. Furthermore, when the state of a port participating in a link backup pair changes, the device sends an SNMP trap.

When configuring link backup pairs, remember the following rules:

- A link pair consists of any combination of physical ports. For example, one port is a 100 Mbit port and the other is a 1000 Mbit SFP port.
- A specific port is a member of one link backup pair at any given time.
- Verify that the ports of a link backup pair are members of the same VLAN with the same VLAN ID. When the *Primary port* or *Backup port* is a member of a VLAN, assign the second port of the pair to the same VLAN.

The default setting for this function is inactive without any link backup pairs.

Note: Verify that the Spanning Tree Protocol (STP) is disabled on the Link Backup ports.

12.10.1 Fail Back Description

Link Backup also lets you set up a Fail Back option. When you activate the *Fail back* function and the *Primary port* returns to normal operation, the device first blocks the data packets on the *Backup port* and then forwards the data packets to the *Primary port*. This process helps protect the device from causing loops in the network.

When the *Primary port* returns to the link up and active state, the device supports 2 modes of operation:

- When you inactivate Fail back, the Primary port remains in the blocking state until the backup link fails.
- When you activate Fail back, and after the Fail back delay [s] timer expires, the Primary port returns to the forwarding state and the Backup port changes to down.

In the cases listed above, the port forcing its link to forward the data packets, first sends a *Topology Change* packet to the remote device. The *Topology Change* packet helps the remote device quickly relearn the MAC addresses.

12.10.2 Application example for the Link Backup function

In the example network below, you connect ports 2/3 and 2/4 on Switch A to the uplink Switches B and C. When you set up the ports as a Link Backup pair, one of the ports forwards the data packets and the other port is in the *blocking* state.

The *Primary port 2/3* on Switch A, is the active port and is forwarding the data packets to port 1 on Switch B. Port 2/4 on Switch A is the *Backup port* and blocks the data packets.

When Switch A disables port 2/3 because of a detected error, port 2/4 on Switch A starts forwarding data packets to port 2 on Switch C.

When port 2/3 returns to the active state, "no shutdown", with *Fail back* activated, and *Fail back delay* [s] set to 30 seconds. After the timer expires, port 2/4 first blocks the data packets and then port 2/3 starts forwarding data packets.




Figure 60: Link Backup example network

The following tables contain examples of parameters to set up Switch A.

Perform the following steps:

Open the Switching > L2-Redundancy > Link Backu	<i>p</i> dialog.
-------------------------------------------------	------------------

- □ Enter a new Link Backup pair in the table:
 - \Box Click the $\overset{\blacksquare}{+}$ button.

The dialog displays the Create window.

- □ From the *Primary port* drop-down list, select port 2/3.
- From the *Backup port* drop-down list, select port 2/4.
- Click the Ok button.
- □ In the *Description* textbox, enter Link_Backup_1 as the name for the backup pair.
- □ To activate the *Fail back* function for the link backup pair, mark the *Fail back* checkbox.
- Set the fail back timer for the link backup pair, enter 30 s in Fail back delay [s].
- □ To activate the link backup pair, mark the Active checkbox.
- □ To enable the function, select the *On* radio button in the *Operation* frame.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 2/3	To change to the interface configuration mode of interface 2/3.
link-backup add 2/4	To add a Link Backup instance where port 2/3 is the <i>Primary port</i> and port 2/4 is the <i>Backup port</i> .
link-backup modify 2/4 description Link_Backup_1	To specify the string Link_Backup_1 as the name of the backup pair.
link-backup modify 2/4 failback-status enable	To enable the fail back timer.
link-backup modify 2/4 failback-time 30	To specify the fail back delay time as 30 s.
link-backup modify 2/4 status enable	To enable the Link Backup instance.
exit	To change to the Configuration mode.
link-backup operation	To enable the <i>Link Backup</i> function globally in the device.

12.11 FuseNet function

The *FuseNet* protocols let you couple rings that are operating with one of the following redundancy protocols:

- . MRP
- Fast MRP (depends on hardware)
- ► HIPER Ring
- DLR (depends on hardware)
- RSTP

Note: The prerequisite for coupling a network to the main ring using the *Ring/Network Coupling* function is that the connected network contains only network devices that support the *Ring/Network Coupling* function.

Use the following table to select the *FuseNet* coupling protocol to be used in the network:

Main Ring	Connected Network				
	MRP	Fast MRP ²⁾	HIPER Ring	DLR ²⁾	RSTP
MRP	Sub Ring ¹⁾	Ring/Network Coupling	 – RCP – Ring/Network Coupling 	– RCP – Ring/Network Coupling	– RCP – Ring/Network Coupling
Fast MRP ²⁾	Sub Ring ¹⁾	Ring/Network Coupling	– RCP – Ring/Network Coupling	Ring/Network Coupling	– RCP – Ring/Network Coupling
HIPER Ring	Sub Ring	– RCP – Ring/Network Coupling	Ring/Network Coupling	– RCP – Ring/Network Coupling	– RCP – Ring/Network Coupling
DLR ²⁾	– Sub Ring – RCP	_	RCP	_	RCP
RSTP	RCP	RCP	RCP	RCP	_

no suitable coupling protocol

1) with the *MRP* function set-up on different VLANs

2) depending on the device configuration

12.12 Sub Ring

The *Sub Ring* function lets you couple a Sub Ring to a main ring that can use various protocols. The Sub Ring protocol provides redundancy for devices by coupling both ends of an otherwise flat network to a main ring.

The prerequisite is that main ring operates with the one of the following redundancy protocols:

- MRP
- Fast MRP (depends on hardware)
- DLR (depends on hardware)
- ► RSTP
- HIPER Ring

Setting up Sub Rings has the following advantages:

- Through the coupling process, you include the new network segment in the redundancy concept.
- Sub Rings allow easy integration of new areas into existing networks.
- Sub Rings allow you easy mapping of the organizational structure of an area in a network topology.
- In a Sub Ring coupled to an MRP Ring, the failover times of the Sub Ring in redundancy cases are typically <100 ms.</p>

12.12.1 Sub Ring description

The Sub Ring concept lets you couple new network segments to suitable devices in an existing ring (main ring). The devices with which you couple the Sub Ring to the main ring are Sub Ring Managers (SRM).





Figure 61: Example of a Sub Ring structure blue ring = Main ring orange ring = Sub Ring SRM = Sub Ring Manager RM = Ring Manager

The *Sub Ring Manager* capable devices support up to 8 instances and thus manage up to 8 Sub Rings at the same time.

The *Sub Ring* function lets you integrate devices that support MRP as participants. The devices with which you couple the Sub Ring to the main ring require the *Sub Ring* Manager function.

Each Sub Ring can consist of up to 200 participants, in addition to the *Sub Ring Manager* devices themselves and the devices between the *Sub Ring Manager* devices in the main ring.



The following figures display examples of possible Sub Ring topologies:

Figure 62: Example of an overlapping Sub Ring structure




Figure 63: Special case: A Sub Ring Manager device manages 2 Sub Rings (2 instances). The Sub Ring Manager device is capable of managing up to 8 instances.




Figure 64: Special case: A Sub Ring Manager device manages both ends of a Sub Ring on different ports (Single Sub Ring Manger).

If you use MRP for the main ring, then specify the VLAN settings as follows:

- VLAN X for the main ring
 - on the ring ports of the main ring participants
 - on the main ring ports of the Sub Ring Manager device
- VLAN Y for the Sub Ring (another VLAN ID than VLAN X)
 - on the ring ports of the devices participating in the Sub Ring
 - on the Sub Ring ports of the Sub Ring Manager device
 - You can use the same VLAN for multiple Sub Rings.

12.12.2 Advanced Information

Sub Ring Packets

The Sub Ring protocol uses Test, Link Change, and Topology Change (FDB Flush) packets.

The 2 SRMs connect the Sub Ring with one Sub Ring port each. The SRMs have different roles, manager and redundantManager. In case of only one SRM, this SRM has 2 Sub Ring ports. The SRM has the role singleManager and takes on the functions of both SRMs in the normal configuration.

As long as the connections in the Sub Ring are operational, the SRM with the role redundantManager sets its Sub Ring port into the *blocking* state. In this state, this Sub Ring port receives and sends only Sub Ring packets, it neither receives nor sends normal (payload) data packets. This way, this SRM prevents a network loop in the Sub Ring.

Both SRMs periodically send test packets into the Sub Ring. The test packets are special packets. The SRMs expect to receive the test packets of their partner SRM. The SRM with the role redundantManager sends and receives test packets even at its redundant Sub Ring port although the redundant Sub Ring port blocks normal (payload) packets.

If the SRM with the role redundantManager does not receive test packets for a specified time, the SRM detects a Sub Ring failure. The SRM then unblocks its redundant Sub Ring port. Conversely, if the SRM again receives test packets from its partner SRM, the SRM sets its redundant port into *blocking*.

On reconfiguration of the Sub Ring, the SRM also flushes its MAC address table (forwarding database) and sends *Topology Change* packets to the Sub Ring participants. The *Topology Change* packets prompt the devices participating in the Sub Ring to flush their MAC address table (forwarding database), too. This procedure helps forward the payload packets over the new path more quickly. This procedure applies regardless of whether the Sub Ring reconfiguration was caused by a *Link Down* or a *Link Up* notification.

Packet Type	Send Mode	Time Parameter	Value
Test packet	Periodically	Send interval	40 ms ¹
		Reception timeout	280 ms ²
Link Down packet ³	Event-driven	On link-down of a Sub Ring port	-
Topology Change packet ⁴	Event-driven	On Sub Ring reconfiguration	-

Table 35: Sub Ring Packets

1. For Sub Ring recovery time 100 ms.

2. The maximum Sub Ring recovery time is 300 ms.

3. Sent by supporting Sub Ring participants.

4. The reception of a *Topology Change* packet prompts the supporting devices participating in the Sub Ring to flush their MAC address table (forwarding database).

Sub Ring Packet Prioritization

The devices participating in the Sub Ring send the test packets, the *Link Change* packets, and the *Topology Change* packets with a user-configurable VLAN ID. The default VLAN ID is 0. The devices send the test packets untagged and thus without priority (Class of Service) information.

To help minimize the reconfiguration time under high network load, you can add a VLAN tag and thus priority information to these packets. The devices then forward and send these packets with the IEEE 802.1Q Class of Service priority 7 (Network control).

To prioritize the test packets, perform the following steps on every device in the Sub Ring:

- □ Specify the VLAN ID for the Sub Ring test packets to a value ≥1.
- □ Specify the Sub Ring ports as T (tagged) members of this VLAN.

Note: When you set the VLAN ID for the Sub Ring packets to a value ≥ 1 in the *Switching* > *L2*-*Redundancy* > *FuseNet* > *Sub Ring* dialog, the device adds its Sub Ring ports as T (tagged) members of this VLAN. If the VLAN does not yet exist, the device automatically sets up this VLAN. After setting a new VLAN ID for the Sub Ring packets, check the *Switching* > *VLAN* > *Configuration* dialog for the VLAN and the Sub Ring port membership settings.

12.12.3 Sub Ring example

In the following example, you couple a new network segment with 3 devices to an existing main ring which uses the Media Redundancy Protocol (MRP). When you couple the network at both ends instead of one end, the Sub Ring provides increased availability with the corresponding configuration.

You couple the new network segment as a Sub Ring. You couple the Sub Ring to the existing devices of the main ring using the following configuration types.




Figure 65: Example of a Sub Ring structure with VLANs orange line= Main ring members in VLAN 1 black line= Sub Ring members in VLAN 2 orange dashed line= Main ring loop open black dashed line= Sub Ring loop open SRM = Sub Ring Manager RM = Ring Manager

To set up the Sub Ring, perform the following steps:

- Set up the 3 devices of the new network segment as participants in an MRP Ring:
- □ To minimize the ring recovery time in case of a link-up after a failure, set up the speed and duplex mode of the ring ports as follows:
 - For 100 Mbit/s TX ports, disable Automatic Negotiation and manually set up 100M FDX.
 - For the other port types, keep the port-specific default settings.

The following steps contain additional settings for Sub Ring configuration:

- □ To help prevent loops during configuration, deactivate the *Sub Ring* function on the devices participating in the main ring and Sub Ring. After you completely set up every device participating in the main ring and Sub Rings, activate the global *Sub Ring* function in the *Sub Ring Manager* devices.
- Disable the RSTP function on the MRP Ring ports used in the Sub Ring.
- □ Verify that the *Link Aggregation* function is inactive on ports participating in the main ring and Sub Ring.
- □ To minimize the ring recovery time in case of a link-up after a failure, set up the speed and duplex mode of the Sub Ring ports as follows:
 - For 100 Mbit/s TX ports, disable Automatic Negotiation and manually set up 100M FDX.
 - For the other port types, keep the port-specific default settings.
- Specify a different VLAN membership for the main ring ports and Sub Ring ports although the main ring is using the Media Redundancy Protocol (MRP). For example, use VLAN ID 1 for the main ring and the redundant link, then use VLAN ID 2 for the Sub Ring.
 - For the devices participating in the main ring for example, open the Switching > VLAN > Configuration dialog. Add VLAN 1 in the static VLAN table. To tag the main ring ports for membership in VLAN 1, select the T item from the drop-down list of the appropriate port columns.
 - For the devices participating in the Sub Ring use the step above and add the ports to VLAN 2 in the static VLAN table.
- Activate the *MRP* function for the devices participating in the main ring and Sub Ring.
 - In the Switching > L2-Redundancy > MRP dialog, select the 2 ports participating in the main ring on the devices participating in the main ring.
 - For the devices participating in the Sub Ring use the steps above and set up the 2 ports participating in the Sub Ring.
 - Assign the same MRP domain ID to the devices participating in the main ring and Sub Ring.
 When you only use Hirschmann devices, the default values suffice for the MRP domain ID.

Note: The *MRP domain* is a sequence of 16 numbers in the range from 0 to 255. The default value is 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 . 255 .

The *Switching* > *L*2-*Redundancy* > *FuseNet* > *Sub Ring* dialog lets you change the MRP domain ID. As an alternative, you can use the Command Line Interface. To do this, perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
mrp domain delete	To delete the current MRP domain.
<pre>mrp domain add domain-id 0.0.1.1.2.2.3.4.4.111. 222.123.0.0.66.99</pre>	To add an MRP domain with the specified MRP domain ID. Any subsequent MRP domain changes apply to this domain ID.

12.12.4 Application example for the Sub Ring function

Note: Help avoid loops during configuration. Set up every device of the Sub Ring individually. Before you activate the redundant link, completely set up every device participating in the Sub Ring.

Set up the 2 Sub Ring Manager devices in the example. To do this, perform the following steps:

□ Open the Switching > L2-Redundancy > FuseNet > Sub Ring dialog. □ To add a table row, click the ₩ button. □ In the Port column, select the port that couples the device to the Sub Ring. Use port 1/3 for this example. For coupling, use one of the available ports with the exception of the ports which are already connected to the main ring. □ In the Name column, assign a name to the Sub Ring. For this example enter Test. □ In the Administrative mode column, select the Sub Ring Manager mode. You thus specify which port for coupling the Sub Ring to the main ring becomes the redundant port of the Sub Ring Manager device. The options for the coupling are: > manager When you specify both Sub Ring Manager devices with the same value, the device with the higher MAC address manages the redundant link. > redundant manager This device manages the redundant link, as long as the other Sub Ring Manager device operates in the manager mode. Otherwise the device with the higher MAC address manages the redundant link. > redundant manager This device manages the redundant link, as long as the other Sub Ring Manager device operates in the manager mode. Otherwise the device with the higher MAC address manages the redundant link. > predivide for Sub Ring Manager device 1 the value manager, in accordance with the figure depicting this example. □ Leave the values in the VLAN column and MRP domain column unchanged. The default values are correct for the example configuration. □ apply the settings temporarily. To do this, click the ✓ butto			
 In the <i>Port</i> column, select the port that couples the device to the Sub Ring. Use port 1/3 for this example. For coupling, use one of the available ports with the exception of the ports which are already connected to the main ring. In the <i>Name</i> column, assign a name to the Sub Ring. For this example enter Test. In the <i>Administrative mode</i> column, select the <i>Sub Ring Manager</i> mode. You thus specify which port for coupling the Sub Ring to the main ring becomes the redundant port of the <i>Sub Ring Manager</i> device. The options for the coupling are: manager When you specify both <i>Sub Ring Manager</i> devices with the same value, the device with the higher MAC address manages the redundant link. redundant manager This device manages the redundant link, as long as the other <i>Sub Ring Manager</i> device operates in the <i>manager</i> mode. Otherwise the device with the higher MAC address manages the redundant link. Specify for <i>Sub Ring Manager</i> device 1 the value manager, in accordance with the figure depicting this example. Leave the values in the <i>VLAN</i> column and <i>MRP domain</i> column unchanged. The default values are correct for the example configuration. Apply the settings temporarily. To do this, click the ✓ button. enable To change to the Privileged EXEC mode. sub-ring modify 1 port 1/3 To specify port 1/3 as the Sub Ring port. sub-ring modify 1 name Test To assign the name Test to the Sub Ring 1. sub-ring modify 1 mode manager To display the Sub Rings state on this device. 	□ Open the <i>Switching</i> > <i>L</i> 2- <i>Redundancy</i> >	FuseNet > Sub Ring dialog.	
Use port 1/3 for this example. For coupling, use one of the available ports with the exception of the ports which are already connected to the main ring. In the Name column, assign a name to the Sub Ring. For this example enter Test. In the Administrative mode column, select the Sub Ring Manager mode. You thus specify which port for coupling the Sub Ring Manager mode. You thus specify which port for coupling the Sub Ring Manager mode. You thus specify which port for coupling the Sub Ring Manager mode. The options for the coupling are: manager When you specify both Sub Ring Manager devices with the same value, the device with the higher MAC address manages the redundant link. Fedundant manager This device manages the redundant link, as long as the other Sub Ring Manager device operates in the manager mode. Otherwise the device with the higher MAC address manages the redundant link. Specify for Sub Ring Manager device 1 the value manager, in accordance with the figure depicting this example. Leave the values in the VLAN column and MRP domain column unchanged. The default values are correct for the example configuration. Apply the settings temporarily. To do this, click the ✓ button. enable To change to the Privileged EXEC mode. configure To add a Sub Ring with the Sub Ring 10. sub-ring modify 1 port 1/3 To specify port 1/3 as the Sub Rin	\Box To add a table row, click the $\overset{\blacksquare}{+}$ button.		
For this example enter Test. □ In the Administrative mode column, select the Sub Ring Manager mode. You thus specify which port for coupling the Sub Ring to the main ring becomes the redundant port of the Sub Ring Manager device. The options for the coupling are: ▶ manager When you specify both Sub Ring Manager devices with the same value, the device with the higher MAC address manages the redundant link. ▶ redundant manager This device manages the redundant link, as long as the other Sub Ring Manager device operates in the manager mode. Otherwise the device with the higher MAC address manages the redundant link. Specify for Sub Ring Manager device 1 the value manager, in accordance with the figure depicting this example. □ Leave the values in the VLAN column and MRP domain column unchanged. The default values are correct for the example configuration. enable To change to the Privileged EXEC mode. configure To change to the Configuration mode. sub-ring modify 1 port 1/3 To specify port 1/3 as the Sub Ring ID 1. sub-ring modify 1 name Test To assign the name Test to the Sub Ring 1. sub-ring modify 1 mode manager To assign the manager mode to the Sub Ring 1. show sub-ring ring To display the Sub Rings state on this device.	Use port <i>1/3</i> for this example. For coupling, use one of the available	· · ·	
You thus specify which port for coupling the Sub Ring to the main ring becomes the redundant port of the Sub Ring Manager device. The options for the coupling are: > manager When you specify both Sub Ring Manager devices with the same value, the device with the higher MAC address manages the redundant link. > redundant manager This device manages the redundant link, as long as the other Sub Ring Manager device operates in the manager mode. Otherwise the device with the higher MAC address manages the redundant link. Specify for Sub Ring Manager device 1 the value manager, in accordance with the figure depicting this example. Leave the values in the VLAN column and MRP domain column unchanged. The default values are correct for the example configuration. Apply the settings temporarily. To do this, click the ✓ button. enable To change to the Privileged EXEC mode. configure To change to the Configuration mode. sub-ring modify 1 port 1/3 To specify port 1/3 as the Sub Ring port. sub-ring modify 1 name Test To assign the name Test to the Sub Ring 1. sub-ring modify 1 mode manager To assign the manager mode to the Sub Ring 1. show sub-ring ring To display the Sub Rings state on this device.		o the Sub Ring.	
When you specify both Sub Ring Manager devices with the same value, the device with the higher MAC address manages the redundant link. ▶ redundant manager This device manages the redundant link, as long as the other Sub Ring Manager device operates in the manager mode. Otherwise the device with the higher MAC address manages the redundant link. Specify for Sub Ring Manager device 1 the value manager, in accordance with the figure depicting this example. Leave the values in the VLAN column and MRP domain column unchanged. The default values are correct for the example configuration. Apply the settings temporarily. To do this, click the ✓ button. enable To change to the Privileged EXEC mode. configure To change to the Configuration mode. sub-ring modify 1 port 1/3 To specify port 1/3 as the Sub Ring ID 1. sub-ring modify 1 name Test To assign the name Test to the Sub Ring 1. sub-ring ring To assign the manager mode to the Sub Ring 1.	You thus specify which port for coupling the Sub Ring to the main ring becomes the redundant port of the <i>Sub Ring Manager</i> device. The options for the coupling are:		
manages the redundant link. Specify for Sub Ring Manager device 1 the value manager, in accordance with the figure depicting this example. Leave the values in the VLAN column and MRP domain column unchanged. The default values are correct for the example configuration. Apply the settings temporarily. To do this, click the ✓ button. enable To change to the Privileged EXEC mode. configure To change to the Configuration mode. sub-ring add 1 To add a Sub Ring with the Sub Ring ID 1. sub-ring modify 1 port 1/3 To assign the name Test to the Sub Ring port. sub-ring modify 1 mode manager To assign the manager mode to the Sub Ring 1. show sub-ring ring To display the Sub Rings state on this device.	 When you specify both Sub Ring Manager devices with the same value, the device with the higher MAC address manages the redundant link. redundant manager This device manages the redundant link, as long as the other Sub Ring Manager device 		
The default values are correct for the example configuration. □ Apply the settings temporarily. To do this, click the ✓ button. enable To change to the Privileged EXEC mode. configure To change to the Configuration mode. sub-ring add 1 To add a Sub Ring with the Sub Ring ID 1. sub-ring modify 1 port 1/3 To specify port 1/3 as the Sub Ring port. sub-ring modify 1 name Test To assign the name Test to the Sub Ring 1. sub-ring modify 1 mode manager To assign the sub Rings state on this device.	manages the redundant link. Specify for <i>Sub Ring Manager</i> device 1 the value manager, in accordance with the figure		
enableTo change to the Privileged EXEC mode.configureTo change to the Configuration mode.sub-ring add 1To add a Sub Ring with the Sub Ring ID 1.sub-ring modify 1 port 1/3To specify port 1/3 as the Sub Ring port.sub-ring modify 1 name TestTo assign the name Test to the Sub Ring 1.sub-ring modify 1 mode managerTo assign the manager mode to the Sub Ring 1.show sub-ring ringTo display the Sub Rings state on this device.			
configureTo change to the Configuration mode.sub-ring add 1To add a Sub Ring with the Sub Ring ID 1.sub-ring modify 1 port 1/3To specify port 1/3 as the Sub Ring port.sub-ring modify 1 name TestTo assign the name Test to the Sub Ring 1.sub-ring modify 1 mode managerTo assign the manager mode to the Sub Ring 1.show sub-ring ringTo display the Sub Rings state on this device.	□ Apply the settings temporarily. To do	this, click the 🗸 button.	
sub-ring add 1To add a Sub Ring with the Sub Ring ID 1.sub-ring modify 1 port 1/3To specify port 1/3 as the Sub Ring port.sub-ring modify 1 name TestTo assign the name Test to the Sub Ring 1.sub-ring modify 1 mode managerTo assign the manager mode to the Sub Ring 1.show sub-ring ringTo display the Sub Rings state on this device.	enable	To change to the Privileged EXEC mode.	
sub-ring modify 1 port 1/3To specify port 1/3 as the Sub Ring port.sub-ring modify 1 name TestTo assign the name Test to the Sub Ring 1.sub-ring modify 1 mode managerTo assign the manager mode to the Sub Ring 1.show sub-ring ringTo display the Sub Rings state on this device.	configure	To change to the Configuration mode.	
sub-ring modify 1 name TestTo assign the name Test to the Sub Ring 1.sub-ring modify 1 mode managerTo assign the manager mode to the Sub Ring 1.show sub-ring ringTo display the Sub Rings state on this device.	sub-ring add 1	To add a Sub Ring with the Sub Ring ID 1.	
sub-ring modify 1 mode managerTo assign the manager mode to the Sub Ring 1.show sub-ring ringTo display the Sub Rings state on this device.	sub-ring modify 1 port 1/3	To specify port 1/3 as the Sub Ring port.	
show sub-ring ring To display the Sub Rings state on this device.	sub-ring modify 1 name Test	To assign the name Test to the Sub Ring 1.	
	sub-ring modify 1 mode manager	To assign the manager mode to the Sub Ring 1.	
show sub-ring global To display the Sub Ring global state on this device.	show sub-ring ring	To display the Sub Rings state on this device.	
	show sub-ring global	To display the Sub Ring global state on this device.	


Set up the second Sub Ring Manager device in the same way. Specify for Sub Ring Manager device 2 the value redundant manager, in accordance with the figure depicting this example.

- □ To activate the *Sub Ring Manager* mode, mark the *Active* checkbox in the corresponding table row.
- □ After you have set up both *Sub Ring Manager* devices and the devices participating in the Sub Ring, enable the function and close the redundant link.
- $\hfill\square$ Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
sub-ring enable 1	To activate Sub Ring 1.
sub-ring enable 2	To activate Sub Ring 2.
exit	To change to the Privileged EXEC mode.
show sub-ring ring <domain id=""></domain>	To display the settings of the selected Sub Rings.
show sub-ring global	To display global Sub Ring settings.
copy config running-config nvm profile Test	To save the current settings in the configuration profile named Test in the non-volatile memory (nvm).

12.12.5 Cascaded Sub Rings example

The following example displays a cascaded Sub Ring network topology which uses the MRP and the SRM protocol. You couple the new network segments as Sub Rings to the existing devices of the main ring.



The configuration for this example is split into the following parts:

- Setting up the *Ring Manager mode*
- Setting up the devices participating in the Sub Ring

Setting up the Ring Manager mode

This example guides you through the configuration of the *Ring Manager* mode as shown above. To do this, perform the following steps:

- □ Open the *Switching* > *L2-Redundancy* > *MRP* dialog.
- □ Select port 1/1 in the *Ring port* 1 frame and port 1/2 in the *Ring port* 2 frame.
- □ To enable the *Ring manager* function, select the *0n* radio button in the *Configuration* frame.
- □ Assign the value 100 in the VLAN ID field.
- □ To enable the *MRP* function, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the Switching > L2-Redundancy > Spanning Tree > Port dialog, CIST tab.
- □ To disable the *Spanning Tree* function on the ring ports, in the *STP active* column, unmark the checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
mrp domain delete	To delete the current MRP domain.
mrp domain add default-domain	To add a default MRP domain. Any subsequent MRP domain changes apply to this domain ID.
mrp domain modify port primary 1/1	To set up the primary ring port.
mrp domain modify port secondary 1/2	To set up the secondary ring port.
mrp domain modify mode manager	To enable the <i>Ring manager</i> function.
mrp domain modify operation enable	To enable the <i>MRP</i> function.
mrp domain modify vlan 100	To assign the VLAN ID to the ring ports.
interface 1/1 spanning-tree mode disable	To disable Spanning Tree on interface 1/1.
interface 1/2 spanning-tree mode disable	To disable Spanning Tree on interface 1/2.

Specify a different VLAN membership for the main ring and the Sub Rings. For example, use VLAN ID 100 for the main ring, VLAN ID 200 for the first Sub Ring and VLAN ID 300 for the second Sub Ring.

Setting up the devices participating in the Sub Ring

Set up each device participating in the Sub Ring in the same way. To do this, perform the following steps:

- \Box Open the *Switching* > *L2-Redundancy* > *MRP* dialog.
- □ From the *Port* drop-down list, select port 1/1 in the *Ring port* 1 frame and port 1/2 in the *Ring port* 2 frame.
- □ To disable the *Ring manager* function, select the *Off* radio button in the *Operation* frame (if this has not already been done).
- □ Assign the value 100 in the VLAN ID field.

□ To enable the <i>MRP</i> function, select the <i>0n</i> radio button in the <i>Operation</i> frame.			
\Box Apply the settings temporarily. To do this, click the \checkmark button.			
□ Open the <i>Switching</i> > <i>L</i> 2- <i>Redundancy</i>	□ Open the Switching > L2-Redundancy > FuseNet > Sub Ring dialog.		
\Box To add a table row, click the $oldsymbol{\Psi}$ but	tton.		
□ In the <i>Name</i> column, assign a name	to the Sub Ring.		
 In the <i>Port</i> column, select the approp <i>Sub Ring Manager</i> mode. In the given example you use port 1/ 	vriate port for which the device operates in the		
□ Assign the value 200 in the VLAN col	umn.		
 In the Administrative mode column, select the value manager. You thus specify which port for coupling the Sub Ring to the main ring becomes the redundant manager. The options for the coupling are: manager When you specify both Sub Ring Manager devices with the same value, the device with the higher MAC address manages the redundant link. redundant manager This device manages the redundant link, as long as the other Sub Ring Manager device operates in the manager mode. Otherwise the device with the higher MAC address 			
manages the redundant link. □ To activate the Sub Ring, mark the c	checkbox in the <i>Active</i> column.		
Apply the settings temporarily. To do	o this, click the 🗸 button.		
□ Open the Switching > L2-Redundancy > Spanning Tree > Port dialog, CIST tab.			
To disable the Spanning Tree function on the Sub Ring ports, in the STP active column, unmark the checkbox.			
\Box Apply the settings temporarily. To do this, click the \checkmark button.			
enable	To change to the Privileged EXEC mode.		
configure	To change to the Configuration mode.		
sub-ring modify 1 port 1/3	To specify port $1/3$ as the Sub Ring port.		
sub-ring modify 1 name Test	To assign the name Test to the Sub Ring.		
sub-ring add 1 mode manager vlan 200 port 1/3 name SRM1	To assign the manager mode to the Sub Ring 1.		
sub-ring enable 1	To activate the Sub Ring.		
auh uina ananatian anahla	To enable the Sub Direction		

Sub-Iting enable 1	To activate the Sub Ring.
sub-ring operation enable	To enable the Sub Ring function.
interface 1/3 spanning-tree mode disable	To disable Spanning Tree on interface 1/3.
show sub-ring ring	To display the Sub Ring state on this device.
show sub-ring global	To display the Sub Ring global state on this device.

12.12.6 Sub Ring with LAG

When at least two parallel redundant connecting lines exist (known as a trunk) between two devices, and these lines are combined into one logical connection, this is a Link Aggregation (LAG) connection.

The device lets you use the LAG ports as ring ports with the Sub Ring function.

Application example for Sub Ring with LAG

The following example is a simple setup between an MRP Ring and a Sub Ring.




Figure 67: Sub Ring with Link Aggregation

The following table describes the device roles as seen in the figure above. The table provides information of how you use the ring ports and Sub Ring ports as LAG ports.

Device Name	Ring Port	Main Ring Role	Sub Ring Role	Sub Ring Port
MRC1	1/3, 1/4	MRP client	-	-
SRM1	1/3, 1/4	MRP client	Redundant Manager	lag/1
SRM2	2/4, 2/5	MRP manager	Manager	lag/1
MRC2	lag/1, 1/3	-	MRP client	-
MRC3	lag/1, 1/3	-	MRP client	-

Table 36: Devices, Ports and Roles

MRP Ring configuration

The devices participating in the Main ring are members of VLAN 300.

Perform the following steps:

SRM2

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
mrp domain add default-domain	To add an MRP domain with the ID default- domain.
mrp domain modify port primary 2/4	To specify port 2/4 as ring port 1.
mrp domain modify port secondary 2/5	To specify port 2/5 as ring port 2.

mrp domain modify mode manager	To designate the device as the <i>Ring Manager</i> device. Do not activate the <i>Ring manager</i> function on any other device.
mrp domain modify operation enable	To activate the MRP Ring.
mrp domain modify vlan 300	To specify the VLAN ID as 300.
mrp operation	To enable the <i>MRP</i> function in the device.

MRC1, SRM1

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
mrp domain add default-domain	To add an MRP domain with the ID default- domain.
mrp domain modify port primary 1/3	To specify port 1/3 as ring port 1.
mrp domain modify port secondary 1/4	To specify port 1/4 as ring port 2.
mrp domain modify mode client	To set up the device as a <i>Ring Client</i> device.
mrp domain modify operation enable	To activate the MRP Ring.
mrp domain modify vlan 300	To specify the VLAN ID as 300.
mrp operation	To enable the <i>MRP</i> function in the device.

Sub Ring configuration

The devices participating in the attached Sub Ring are members of VLAN 200.

Perform the following steps:

SRM1

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
link-aggregation add lag/1	To add a Link Aggregation Group lag/1.
link-aggregation modify lag/1 addport 1/1	To add port 1/1 to the Link Aggregation Group.
link-aggregation modify lag/1 addport 1/2	To add port $1/2$ to the Link Aggregation Group.
link-aggregation modify lag/1 adminmode	To activate the Link Aggregation Group.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
sub-ring add 1	To add a Sub Ring with the Sub Ring ID 1.
sub-ring modify 1 name SRM1	To assign the name SRM1 to the Sub Ring 1.
sub-ring modify 1 mode redundant-manager vlan 200 port lag/1	To assign the device the role of Sub Ring redundant managerin Sub Ring 1. If the Sub Ring is closed, then the device blocks the ring port. VLAN 200 is the set for the VLAN ID of the domain. The lag/1 port is set as a member in VLAN 200.
sub-ring enable 1	To activate Sub Ring 1.
sub-ring operation	To enable the global <i>Sub Ring Manager</i> function on this device.

SRM2

MRC

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
link-aggregation add lag/1	To add a Link Aggregation Group lag/1.
<pre>link-aggregation modify lag/1 addport 2/7</pre>	To add port 2/7 to the Link Aggregation Group.
<pre>link-aggregation modify lag/1 addport 2/8</pre>	To add port 2/8 to the Link Aggregation Group.
<pre>link-aggregation modify lag/1 adminmode</pre>	To activate the Link Aggregation Group.
•	

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
sub-ring add 1	To add a Sub Ring with the Sub Ring ID 1.
sub-ring modify 1 mode manager vlan 200 port lag/1	To assign the device the role of Sub Ring manager in Sub Ring 1. VLAN 200 is the set for the VLAN ID of the domain. The $lag/1$ port is set as a member in VLAN 200.
sub-ring modify 1 name SRM2	To assign the name SRM2 to the Sub Ring 1.
sub-ring enable 1	To activate Sub Ring 1.
sub-ring operation	To enable the global <i>Sub Ring Manager</i> function on this device.
2, 3	

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
mrp domain add default-domain	To add an MRP domain with the ID default- domain.
mrp domain modify port primary lag/1	To specify port $lag/1$ as ring port 1.
mrp domain modify port secondary 1/3	To specify port 1/3 as ring port 2.
mrp domain modify mode client	To set up the device as a <i>Ring Client</i> device.
mrp domain modify operation enable	To activate the MRP Ring.
mrp domain modify vlan 200	To specify the VLAN ID as 200.
mrp operation	To enable the <i>MRP</i> function in the device.

Disabling STP

Disable the *Spanning Tree* function on every port that you specified as an MRP or Sub Ring port. The following example uses port 1/3.

Perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/3	To change to the interface configuration mode of interface <i>1/3</i> .
no spanning-tree operation	To disable the Spanning Tree function on the port.

12.13 Ring/Network Coupling function

Based on a ring, the *Ring/Network Coupling* function couples rings or network segments redundantly. *Ring/Network Coupling* connects 2 rings/network segments through 2 separate paths.

When the devices in the coupled network are Hirschmann devices, the *Ring/Network Coupling* function supports the coupling following ring protocols in the primary and secondary rings:

HIPER Ring

Fast HIPER Ring

MRP

The *Ring/Network Coupling* function can also couple network segments of a bus and mesh structures.

12.13.1 Methods of Ring/Network Coupling

1-Switch coupling

Two ports of **one** device in the first ring/network connect to one port each of two devices in the second ring/network. See figure 75 on page 283.

In the 1-Switch coupling method, the main line forwards data and the device blocks the redundant line.

When the main line no longer functions, the device immediately unblocks the redundant line. When the main line is restored, the device blocks data on the redundant line. The main line forwards data again.

The ring coupling detects and handles an error within 500 ms (typically 150 ms).

2-Switch coupling

One port each from **two** devices in the first ring/network connects to one port each of two devices in the second ring/network segment. See figure 77 on page 286.

The device with the redundant line connected and the device with the main line connected use control packets to inform each other about their operating states, using the existing network or a dedicated control line.

When the main line goes down, the redundant device (Stand-by) unblocks the redundant line. When the main line comes up again, the device connected to the main line informs the redundant device of this. The Stand-by device then again blocks data on the redundant line. The device connected to the main line then again forwards data on the main line.

The ring coupling detects and handles a fault within 500 ms (typically 150 ms).


Selection of a coupling method

The type of coupling configuration is primarily determined by the network topological and the desired level of availability.

Table 37: Selection criteria for the configuration types for redundant coupling

	1-Switch coupling	2-Switch coupling	2-Switch coupling with Control line
Application	The 2 devices are in impractical topological positions. Therefore, putting a link between the devices would involve a lot of effort for 2-Switch coupling.	The 2 devices are in practical topological positions. Installing a control line would involve a lot of effort.	The 2 devices are in practical topological positions. Installing a control line would not involve much effort.
Disadvantage	If the Switch set up for the redundant coupling becomes inoperable, then no connection remains between the networks.	connect both devices to	More effort is needed to connect both devices to the network (compared with 1-Switch and 2- Switch coupling).
Advantage	Less effort involved in connecting the 2 devices to the network (compared with 2-Switch coupling).	When one of the devices set up for the redundant coupling becomes inoperable, the coupled networks are still connected.	When one of the devices set up for the redundant coupling becomes inoperable, the coupled networks are still connected. The partner determination between the coupling devices occurs more reliable and faster than without the control line.

12.13.2 Advanced Information



Link Topology of 1-Switch coupling

- 5: Main line
- 6: Redundant line


In a 1-Switch coupling (see figure 68), one device manages both coupling lines:


- The partner coupling port (3) connects the main line (5).
- ▶ The coupling port (4) connects the redundant line (6).

The single coupling device sends the following test packets:

- ▶ The partner coupling port (3) sends *Ring/Network Coupling* unicast test packets A.
- ▶ The coupling port (4) sends *Ring/Network Coupling* unicast test packets B.

Note: The 2 ring ports (unnumbered) connect the local redundant ring (red lines in graphic) and do not send any *Ring/Network Coupling* test packets.





In a 2-Switch coupling (see figure 69), the 2 devices have specific roles:

- ▶ The coupling port (1) of the primary device connects the main line (see figure 70).
- The partner coupling port (1) of the secondary device connects the stand-by line (4) (see figure 71).

The primary device (see figure 70) sends no test packets.

The secondary device (see figure 71) sends the following test packets:

- ▶ The 2 ring ports (unnumbered) send *Ring/Network Coupling* unicast test packets A.
- The coupling port (4) sends Ring/Network Coupling unicast test packets B.






Figure 70: 2-Switch coupling, Primary device 1: Coupling port 2: Partner coupling port



Link Topology of 2-Switch coupling with Control Line

This topology differs from the previous one by the additional control line. The control line helps speed up reconfiguration.



- 1: Ring
- 2: Backbone
- 3: Main line
- 4: Redundant line
- 5: Control line


In a 2-Switch coupling with Control Line (see figure 72), both devices are connected as follows:

- The primary device and the secondary device connect the control line (5) through their control ports (unnumbered).
- ▶ The coupling port (1) of the primary device connects the main line (see figure 73).
- The partner coupling port (1) of the secondary device connects the stand-by line (4) (see figure 74).

The primary device (see figure 73) sends control packets on its control port.

The secondary device (see figure 74) sends the following packets:

- > The control port (unnumbered) sends control packets.
- ▶ The 2 ring ports (unnumbered) send *Ring/Network Coupling* unicast test packets A.
- ▶ The coupling port (4) sends *Ring/Network Coupling* unicast test packets B.



Packets

The Ring/Network Coupling function uses Test, Control, Link Change, and Topology Change packets.

Table 38: Ring/Network Coupling packets

Packet Type	Send Mode	Time Parameter	Value
Unicast test packet A ¹	Cyclical	Send interval	80 ms (50 ms during config. phase)
		Reception timeout	1500 ms
Unicast test packet B ²	Cyclical	Send interval	80 ms (50 ms during config. phase)
		Reception timeout	1500 ms
Control packet ³	Event-driven	On reconfiguration	-
<i>Link Change</i> packet ⁴	Event-driven	On link-down or link-up of a ring port or coupling port	-
<i>Topology Change</i> packet	Event-driven	On reconfiguration	-

1. 2-Switch coupling: Sent by the secondary (stand-by) device only. Destination address: Device MAC address+1, source address: Device MAC address+2.

2. 2-Switch coupling: Sent by the secondary (stand-by) device only. Destination address: Device MAC address+2, source address: Device MAC address+1 (addresses swapped with respect to unicast test packet A).

3. Destination address (multicast): 01:80:63:07:00:02, source address: 00:80:63:07:10:01.

4. Sent by supporting ring participants.

1-Switch coupling: The local device periodically sends test packets A into the ring from both ring ports. The local device expects to receive the test packets A back on its respective other ring port. If the local device receives no test packets A for a specified amount of time, the local device detects a network failure.

The local device also sends test packets B from its partner coupling port. The test packets B are special packets that the local device receives at the coupling port although the coupling port blocks the reception of normal packets. The local device expects to receive the test packets B back on its coupling port. If the local device receives no test packets B for a specified amount of time, the local device detects a coupling network failure.

2-Switch coupling: The secondary (stand-by) device periodically sends test packets A into the ring from both ring ports. The secondary device expects to receive the test packets A back on its respective other ring port. If the secondary device receives no test packets A for a specified amount of time, the secondary device detects a network failure.

The secondary (stand-by) device also sends test packets B from its coupling port. The test packets B are special packets that the secondary device sends from its coupling port although the coupling port blocks the sending of normal packets. The primary device forwards received test packets B to the secondary device. The secondary device expects to receive the test packets B back on its ring port connected to the primary device. If the secondary device receives no test packets B for a specified amount of time, the secondary device detects a coupling network failure.

In extended redundancy mode, the same packets are used, only the reaction to a detected network failure differs.

On reconfiguration of the Ring/Network coupling, the secondary (stand-by) device flushes its MAC address table (forwarding database) and sends Ring/Network coupling *Topology Change* packets to its partner device. It also sends Ring/Network coupling *Topology Change* packets to the connected rings.

If a device participating in a connected ring receives a Ring/Network coupling *Topology Change* packet, it flushes its MAC address table (forwarding database). It also converts the Ring/Network coupling *Topology Change* packet to a ring *Topology Change* packet and sends the *Topology Change* packet on. The *Topology Change* packets prompt the other devices participating in the ring to flush their MAC address table (forwarding database), too. This applies to all rings that the Ring/Network coupling connects. This procedure helps forward the payload packets over the new path more quickly.

The Ring/Network coupling devices also act on ring *Topology Change* packets from a *Ring Manager* device because the Ring/Network coupling devices are members of that ring.

Packet Prioritization

The Ring/Network Coupling devices send their test packets, control packets, *Link Down* packets, and Ring/Network coupling *Topology Change* packets with the fixed VLAN ID 1. In the default setting, these packets are untagged and thus without priority (Class of Service) information. To help minimize the reconfiguration time under high network load, you can add a VLAN tag and thus priority information to these packets. The devices then send and forward the packets with the IEEE 802.1Q Class of Service priority 7 (Network control).

To prioritize these packets, set up each of the following ports as ⊺ (tagged) member of VLAN 1: In the local ring where the coupling device (or devices) are located:

- ☐ The coupling port of the respective coupling device (local or secondary)
- The partner coupling port of the respective coupling device (local or primary)
- □ The ring ports of all devices in the local ring, including the *Ring Manager* device
- In the remote ring:
 - The port of the device in the remote ring connected to the coupling port
 - The port of the device in the remote ring connected to the partner coupling port
 - □ The 2 ring ports connecting the 2 devices just mentioned to each other

Note: In a 2-Switch coupling with Control Line, the VLAN membership settings of both control ports must match. You can keep the default settings of the control ports (VLAN 1 membership untagged).

Link Topology Requirements

In the absence of packet prioritization, the following links must be direct, without any intervening devices:

- The 2 coupling links connecting the coupling device (or devices) in the local ring with the 2 coupled devices in the remote ring
- ▶ The link in the remote ring connecting the 2 coupled devices
- ▶ In a 2-Switch coupling: The link in the local ring connecting the 2 coupling devices
- In a 2-Switch coupling with Control Line, Hirschmann recommends to use a direct line but this is not strictly required.

This helps ensure that the packets are transmitted with minimal delay and high reliability. This again helps minimize the reconfiguration time under high network load.

Note: Hirschmann recommends the above link topology even with packet prioritization.

12.13.3 Prepare the Ring/Network Coupling

Using the images in the dialog you define the role of the devices within the *Ring/Network Coupling*.

In the following screen shots and diagrams, the following conventions are used:


- Blue boxes and lines indicate devices or connections of the items currently being described.
- Solid lines indicate a main connection.
- Dash lines indicate a stand-by connection.
- Dotted lines indicate the control line.

Perform the following steps:

Open the Switching > L2-Redundancy > FuseNet > Ring/Network Coupling dialog.
 In the Mode frame, Type option list, select the required radio button.
 one-switch coupling
 two-switch coupling, master
 two-switch coupling, slave
 two-switch coupling with control line, master
 two-switch coupling with control line, slave


Note: Refrain from operating the *Spanning Tree* and the *Ring/Network Coupling* functions on the same ports.

1-Switch coupling



The main line, indicated by the solid blue line, which is connected to the partner coupling port provides coupling between the two networks in the normal mode of operation. If the main line is inoperable, then the redundant line, indicated by the dashed blue line, which is connected to the coupling port takes over the ring/network coupling. **One** switch performs the coupling switch-over.

The following settings apply to the device displayed in blue in the selected graphic.



Perform the following steps:

- □ Open the Switching > L2-Redundancy > FuseNet > Ring/Network Coupling dialog.
- □ In the *Mode* frame, *Type* option list, select the *one-switch coupling* radio button.

Note: Set up the Partner coupling port and the ring ports on different ports.

- □ In the *Coupling port* frame, select the port on which you want to connect the redundant line from the *Port* drop-down list.
- □ In the *Partner coupling port* frame, select the port on which you connect the main line from the *Port* drop-down list.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- Connect the redundant line to the Partner coupling port.
 In the *Partner coupling port* frame, the *State* field displays the status of the Partner coupling port.
- Connect the main line to the Coupling port.
 In the *Coupling port* frame, the *State* field displays the status of the Coupling port.

In the *Information* frame, the *Redundancy* field displays if the redundancy is available. The *Configuration failure* field displays if the settings are complete and correct.

For the coupling ports, perform the following steps:

Note: The following settings are required for the coupling ports.

- □ Open the *Basic Settings > Port* dialog, *Configuration* tab.
- □ For the ports selected as the coupling ports, specify the settings according to the parameters in the following table.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

To minimize the ring recovery time in case of a link-up after a failure, set up the speed and duplex mode of the ring ports as follows:

- For 100 Mbit/s TX ports, disable Automatic Negotiation and manually specify 100M FDX.
- · For the other port types, keep the port-specific default settings.

If you have set up VLANs on the coupling ports, then you specify the VLAN settings on the coupling and partner coupling ports. To do this, perform the following steps:

- \Box Open the *Switching* > *VLAN* > *Port* dialog.
- Change the *Port-VLAN ID* setting to the value of the VLAN ID set up on the ports.
- Unmark the Ingress filtering checkbox for both coupling ports.
- □ Open the *Switching* > *VLAN* > *Configuration* dialog.
- □ To tag the redundant connections for VLAN 1 and VLAN Membership, enter the value T in the cells corresponding to both coupling ports on the VLAN 1 table row.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

The coupling device now sends the redundancy packets with the highest priority on VLAN 1.


 In the Configurationframe, Redundancy mode option list, specify the type of redundancy: With the redundant ring/network coupling setting, either the main line or the redundant line is active. The setting lets the devices toggle between both lines. When you activate the extended redundancy setting, the main line and the redundant line can become active simultaneously if required. The setting lets you add redundancy to the remote (coupled) network. When the connection between the coupling devices in the second network becomes inoperable, the coupling devices continue to transmit and receive data.
Note: During the reconfiguration period, packet duplications can occur. Therefore, select this setting only if your devices detect package duplications.
The Coupling mode describes the type of the backbone network to which you connect the ring

network. See figure 75 on page 283.


In the *Configuration* frame, *Coupling mode* option list, specify the type of the second network:

- □ If you connect to a ring network, then select the *ring coupling* radio button.
- □ If you connect to a bus or mesh structure, then select the *network coupling* radio button.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

You can reset the coupling settings to the default state. To do this, perform the following steps:



2-Switch coupling



The coupling between 2 networks is performed by the main line, indicated by the solid blue line. If the main line or one of the connected devices becomes inoperable, then the redundant line, indicated by the dashed black line, takes over the network coupling. The coupling is performed by 2 devices.


The devices send control packets to each other over the network.

The primary device connected to the main line, and the stand-by device connected to the redundant line are partners with regard to the coupling.

□ Connect the 2 partners using the ring ports.

2-Switch coupling, Primary device

The following settings apply to the device displayed in blue in the selected graphic.



Perform the following steps:

- □ Open the Switching > L2-Redundancy > FuseNet > Ring/Network Coupling dialog.
- □ In the *Mode* frame, *Type* option list, select the *two-switch coupling, master* radio button.
- □ In the *Coupling port* frame, select the port on which you connect the network segments from the *Port* drop-down list.

Set up the *Coupling port* and the ring ports on different ports.

- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- Connect the main line to the *Coupling port*.
 In the *Coupling port* frame, the *State* field displays the status of the Coupling port.
 When the partner is already operating in the network, the *IP address* field in the *Partner coupling port* frame displays the IP address of the partner port.

In the *Information* frame, the *Redundancy* field displays if the redundancy is available. The *Configuration failure* field displays if the settings are complete and correct.

To help prevent continuous loops while the connections are in operation on the ring coupling ports, perform one of the following actions. The device sets the port state of the coupling port to "off":

- disable the operation
- change the configuration

For the coupling ports, perform the following steps:

- □ Open the *Basic Settings > Port* dialog, *Configuration* tab.
- □ For the ports selected as the coupling ports, specify the settings according to the parameters in the following table.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

To minimize the ring recovery time in case of a link-up after a failure, set up the speed and duplex mode of the ring ports as follows:

- For 100 Mbit/s TX ports, disable Automatic Negotiation and manually specify 100M FDX.
- For the other port types, keep the port-specific default settings.

If you have set up VLANs on the coupling ports, then you specify the VLAN settings on the coupling and partner coupling ports. To do this, perform the following steps:


- □ Open the *Switching* > *VLAN* > *Port* dialog.
- □ Change the *Port-VLAN ID* setting to the value of the VLAN ID set up on the ports.
- Unmark the *Ingress filtering* checkbox for both coupling ports.
- □ Open the *Switching* > *VLAN* > *Configuration* dialog.
- □ To tag the redundant connections for VLAN 1 and to establish the VLAN membership, enter the value T in the cells corresponding to both coupling ports on the VLAN 1 table row.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

The coupling device now sends the redundancy packets with the highest priority on VLAN 1.

2-Switch coupling, Stand-by device

The following settings apply to the device displayed in blue in the selected graphic.



Perform the following steps:

- □ Open the Switching > L2-Redundancy > FuseNet > Ring/Network Coupling dialog.
- □ In the *Mode* frame, *Type* option list, select the *two-switch coupling*, *slave* radio button.
- □ In the *Coupling port* frame, select the port on which you connect the network segments from the *Port* drop-down list.
 - Set up the Coupling port and the ring ports on different ports.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- Connect the redundant line to the *Coupling port*.
 In the *Coupling port* frame, the *State* field displays the status of the Coupling port.
 When the partner is already operating in the network, the *IP address* field in the *Partner coupling port* frame displays the IP address of the partner port.

In the *Information* frame, the *Redundancy* field displays if the redundancy is available. The *Configuration failure* field displays if the settings are complete and correct.

To help prevent continuous loops while the connections are in operation on the ring coupling ports, perform one of the following actions. The device sets the port state of the coupling port to "off":

- disable the operation
- change the configuration

For the coupling ports, perform the following steps:

- □ Open the *Basic Settings > Port* dialog, *Configuration* tab.
- □ For the ports selected as the coupling ports, specify the settings according to the parameters in the following table.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

To minimize the ring recovery time in case of a link-up after a failure, set up the speed and duplex mode of the ring ports as follows:

- For 100 Mbit/s TX ports, disable Automatic Negotiation and manually specify 100M FDX.
- For the other port types, keep the port-specific default settings.

If you have set up VLANs on the coupling ports, then you specify the VLAN settings on the coupling and partner coupling ports. To do this, perform the following steps:


- □ Open the *Switching* > *VLAN* > *Port* dialog.
- Change the *Port-VLAN ID* setting to the value of the VLAN ID set up on the ports.
- Unmark the Ingress filtering checkbox for both coupling ports.
- □ Open the *Switching* > *VLAN* > *Configuration* dialog.
- □ To tag the redundant connections for VLAN 1 and VLAN Membership, enter the value T in the cells corresponding to both coupling ports on the VLAN 1 table row.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.


The coupling devices now send the redundancy packets with the highest priority on VLAN 1.

Specify the *Redundancy mode* and *Coupling mode* settings. To do this, perform the following steps:

□ Open the Switching > L2-Redundancy > FuseNet > Ring/Network Coupling dialog. □ In the *Configuration* frame, *Redundancy mode* option list, select one of the following radio buttons: redundant ring/network coupling With this setting, either the main line or the redundant line is active. The setting lets the devices toggle between both lines. extended redundancy With this setting, the main line and the redundant line are active simultaneously. The setting lets you add redundancy to the second network. When the connection between the coupling devices in the second network becomes inoperable, the coupling devices continue to transmit and receive data. During the reconfiguration period, packet duplications can occur. Therefore, select this setting only if your devices detect package duplications. □ In the *Configuration* frame, *Coupling mode* option list, select one of the following radio buttons: □ If you connect to a ring network, then select the *ring coupling* radio button. □ If you connect to a bus or mesh structure, then select the *network coupling* radio button. The Coupling mode describes the type of the backbone network to which you connect the ring network. See figure 77 on page 286. \Box Apply the settings temporarily. To do this, click the \checkmark button.

Reset the coupling settings to the default state. To do this, perform the following steps:





2-Switch coupling with Control Line

- 3: Main line
- 4: Redundant line
- 5: Control line

The coupling between 2 networks is performed by the main line, indicated by the solid blue line. If the main line or one of the adjacent devices become inoperable, then the redundant line, indicated by the dashed blue line, takes over coupling the 2 networks. The ring coupling is performed by 2 devices.


The devices send control packets over a control line indicated by the dotted blue line. See figure 81 on page 291.

The primary device connected to the main line, and the stand-by device connected to the redundant line are partners with regard to the coupling.

□ Connect the 2 partners using the ring ports.

2-Switch coupling with Control Line, Primary device

The following settings apply to the device displayed in blue in the selected graphic.



Perform the following steps:

- □ Open the Switching > L2-Redundancy > FuseNet > Ring/Network Coupling dialog.
- □ In the *Mode* frame, *Type* option list, select the *two-switch coupling with control line*, *master* radio button.
- □ In the *Coupling port* frame, select the port on which you connect the network segments from the *Port* drop-down list.

Set up the Coupling port and the ring ports on different ports.

□ In the *Control port* frame, select the port on which you connect the control line from the *Port* drop-down list.

Set up the Coupling port and the ring ports on different ports.

- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- Connect the redundant line to the Coupling port.
 In the *Coupling port* frame, the *State* field displays the status of the Coupling port.
 When the partner is already operating in the network, the *IP address* field in the *Partner coupling port* frame displays the IP address of the partner port.
- Connect the control line to the Control port.
 In the *Control port* frame, the *State* field displays the status of the Control port.
 When the partner is already operating in the network, the *IP address* field in the *Partner coupling port* frame displays the IP address of the partner port.

In the *Information* frame, the *Redundancy* field displays if the redundancy is available. The *Configuration failure* field displays if the settings are complete and correct.

To help prevent continuous loops while the connections are in operation on the ring coupling ports, perform one of the following actions. The device sets the port state of the coupling port to "off":

- disable the operation
- change the configuration

For the coupling ports, perform the following steps:

□ Open the *Basic Settings > Port* dialog, *Configuration* tab.

□ For the ports selected as the coupling ports, specify the settings according to the parameters in the following table.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

To minimize the ring recovery time in case of a link-up after a failure, set up the speed and duplex mode of the ring ports as follows:

- For 100 Mbit/s TX ports, disable Automatic Negotiation and manually specify 100M FDX.
- For the other port types, keep the port-specific default settings.

If you have set up VLANs on the coupling ports, then you specify the VLAN settings on the coupling and partner coupling ports. To do this, perform the following steps:

- □ Open the *Switching* > *VLAN* > *Port* dialog.
- Change the *Port-VLAN ID* setting to the value of the VLAN ID set up on the ports.
- Unmark the *Ingress filtering* checkbox for both coupling ports.
- □ Open the Switching > VLAN > Configuration dialog.
- □ To tag the redundant connections for VLAN 1 and VLAN Membership, enter the value T in the cells corresponding to both coupling ports on the VLAN 1 table row.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

The coupling device now sends the redundancy packets with the highest priority on VLAN 1.

2-Switch coupling with Control Line, Stand-by device

The following settings apply to the device displayed in blue in the selected graphic.




Figure 82: 2-Sw

- 2: 2-Switch coupling with Control Line, Stand-by device 1: Coupling port
 - 2: Partner coupling port

3: Control line

Perform the following steps:

□ Open the Switching > L2-Redundancy > FuseNet > Ring/Network Coupling dialog.

- □ In the *Mode* frame, *Type* option list, select the *two-switch coupling with control line*, *slave* radio button.
- In the Coupling port frame, select the port on which you connect the network segments from the Port drop-down list.

Set up the Coupling port and the ring ports on different ports.

- □ In the *Control port* frame, select the port on which you connect the control line from the *Port* drop-down list.
 - Set up the Coupling port and the ring ports on different ports.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- Connect the redundant line to the Coupling port.
 In the *Coupling port* frame, the *State* field displays the status of the Coupling port.
 When the partner is already operating in the network, the *IP address* field in the *Partner coupling port* frame displays the IP address of the partner port.
- Connect the control line to the Control port.
 In the *Control port* frame, the *State* field displays the status of the Control port.
 When the partner is already operating in the network, the *IP address* field in the *Partner coupling port* frame displays the IP address of the partner port.

In the *Information* frame, the *Redundancy* field displays if the redundancy is available. The *Configuration failure* field displays if the settings are complete and correct.

To help prevent continuous loops while the connections are in operation on the ring coupling ports, perform one of the following actions. The device sets the port state of the coupling port to "off":

- disable the operation
- change the configuration

For the coupling ports, perform the following steps:

- □ Open the *Switching* > *VLAN* > *Port* dialog.
- Change the *Port-VLAN ID* setting to the value of the VLAN ID set up on the ports.
- □ Unmark the *Ingress filtering* checkbox for both coupling ports.
- □ Open the Switching > VLAN > Configuration dialog.
- □ To tag the redundant connections for VLAN 1 and VLAN Membership, enter the value T in the cells corresponding to both coupling ports on the VLAN 1 table row.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.


The coupling devices now send the redundancy packets with the highest priority on VLAN 1.

Specify the *Redundancy mode* and *Coupling mode* settings. To do this, perform the following steps:

□ Open the Switching > L2-Redundancy > FuseNet > Ring/Network Coupling dialog.

- □ In the *Configuration* frame, *Redundancy mode* option list, select one of the following radio buttons:
 - redundant ring/network coupling
 - With this setting, either the main line or the redundant line is active. The setting lets the devices toggle between both lines.
 - extended redundancy

With this setting, the main line and the redundant line are active simultaneously. The setting lets you add redundancy to the second network. When the connection between the coupling devices in the second network becomes inoperable, the coupling devices continue to transmit and receive data.



During the reconfiguration period, packet duplications can occur. Therefore, select this setting only if your devices detect package duplications.

- □ In the *Configuration* frame, *Coupling mode* option list, select one of the following radio buttons:
 - □ If you connect to a ring network, then select the *ring coupling* radio button.

□ If you connect to a bus or mesh structure, then select the *network coupling* radio button. The *Coupling mode* describes the type of the backbone network to which you connect the ring network. See figure 80 on page 290.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

Reset the coupling settings to the default state. To do this, perform the following steps:

 \Box Click the **\boxed{}** button.

12.14 RCP function

Industrial applications require the networks to have high availability. This includes deterministic, short interruption times in cases where a network device or link becomes inoperable.

A ring topology provides short transition times with a minimal use of resources. However, ring topologies bring the challenge of coupling these rings redundantly.

The Redundant Coupling Protocol (RCP) lets you couple rings that are operating with one of the following redundancy protocols:

- MRP
- Fast MRP (depends on hardware)
- HIPER Ring
- DLR (depends on hardware)
- RSTP

The *RCP* function also lets you couple multiple secondary rings to a primary ring. See the following figure. Only the devices which couple the rings require the *RCP* function.

You can also use devices other than Hirschmann devices within the coupled networks.

The *RCP* function uses a master and a slave device to transport data between the networks. Only the master device forwards frames between the rings.

Using Hirschmann proprietary multicast messages, the *RCP* master and slave devices inform each other about their operating state. Set up the devices in the secondary ring which are not coupling devices to forward the following multicast addresses:


01:80:63:07:00:0A

Connect the master and slave devices as direct neighbors.

^{01:80:63:07:00:09}

You use 4 ports per device to establish the redundant coupling. Set up the coupling devices with 2 inner and 2 outer ports in each network.

- ▶ The inner ports connect the master and slave devices.
- > The outer ports connect the devices to the other, neighboring devices of the network.



4: Inner coupling port in the secondary ring

When you specify the role of a coupler device as *auto*, the coupler device automatically selects its role as *master* or *slave*. When you want a predetermined master or slave device, specify the roles explicitly.

If the master is no longer reachable using the inner coupling ports, then the slave device waits for a specified timeout period to expire before taking over the master role. During the timeout period, the slave attempts to reach the master using the outer coupling ports. When the master is still unreachable, the slave assumes the master role. To maintain stability in the network connected to the outer coupling ports, specify the timeout period for a longer duration than the recovery time in the coupled rings.

Note: Disable RSTP on the *RCP* inner and outer ports that are not connected to the RSTP ring. In the example configuration, you disable RSTP on ports 1 and 2 of every device.

12.14.1 Prerequisites for RCP

Prerequisite for setting up an RCP coupler pair is that every device in the network (besides the coupler pair) supports the forwarding of untagged multicast packets.

12.14.2 Advanced Information

Topology Overview

RCP supports the following topology:

Two-Switch Redundant Coupling

Note: For a topology example with 2 instances of a Two-Switch Redundant Coupling (see figure 83).

This topology has the following characteristics:

- Each RCP device has 2 internal network segments:
 - A primary segment
 - A secondary segment
- In the normal state of operation, the RCP devices treat packets traveling between these 2 network segments as follows:
 - The RCP master device forwards packets between the 2 network segments.
 - The RCP slave device does not forward packets between the 2 network segments.
- Port associations:
 - Only the ports explicitly set up as inner or outer RCP ports for the secondary segment belong to the RCP secondary segment of the device.
 - The inner and outer RCP ports for the primary segment belong to the RCP primary segment.
 - All other ports implicitly belong to the RCP primary segment.
- ▶ The management of an RCP device is located in the primary segment.

Note: If you want to access the management of an RCP slave device from the secondary segment, avoid the port-based routing function on the outer ports for the secondary segment. This helps you maintain the management access to the device from the secondary segment.

Topology of the Two-Switch Redundant Coupling

In a Two-Switch Redundant Coupling, one pair of devices couples the 2 rings. Each of the paired devices has a distinct coupling role master or slave, either automatically set up or explicitly specified.

The devices are connected as follows (see figure 83):

- The ring ports (1) of both devices connect to the primary ring/network. These ports are the outer ports for the primary network.
- The ring ports (2) of both devices connect to each other for the primary ring/network. These ports are the inner ports for the primary network.
- The ring ports (3) of both devices connect to the secondary ring/network. These ports are the outer ports for the secondary network.
- The ring ports (4) of both devices connect to each other for the secondary ring. These ports are the inner ports for the secondary network.

Packets

RCP uses multicast test packets, named after the RCP port role number (1..4) of the sending port. *Table 39: RCP Packets*

Packet Type	Operating State	Time Parameter	Value	
•	Normal operation of the inner ports	Send interval	45 ms	
and 4 (on the inner ports)		Reception timeout ¹	180 ms (4 send intervals, fixed)	
Test packets 1 and 3 (on the outer ports)	On link loss of the inner ports	Send interval	10 ms (during the first 90 ms of the reception timeout) 5 ms (after 90 ms of the reception timeout have elapsed)	
		<i>Topology Change</i> timeout ²	5 ms60000 ms (customizable, default setting: 250 ms)	

1. The slave treats the reception timeout as a link loss on the respective port even if the port still has a link.

2. After detecting a link loss, the slave device waits for the duration of the *Topology Change* timeout before forwarding packets between the 2 network segments.

Link Topology Requirements

The following links must be direct, without any other devices in between:

The 2 links connecting the inner ports (2, 4) of each coupler pair in the respective primary and secondary rings.

This helps ensure that a link loss is quickly detected by the RCP devices.


12.14.3 Application example for RCP coupling

The Hirschmann devices support the two-switch redundant coupling. You can use the *RCP* function to provide a network installed in a train for example. The network provides information for the passengers about the train location or the different stops on the line. The network can also help provide passenger safety, for example using video surveillance.

The primary rings in the figure represent an *MRP* ring within each car. Each primary ring consists of 4 devices. See the following figure.

The secondary rings in the figure represent RSTP rings that automatically form when 2 cars are being coupled. Each secondary ring consists of 2 coupler pairs that are joined through their respective outer ports. In the figure, these device quadruples are called Coupler A and B.

To simplify the port configuration, the *MRP* ring ports and the *RCP* inner and outer ports are assigned the same port numbers on each switch. For example, on the switches 2A..2D, specify the ports 2/1 and 2/2 as MRP Ring ports, the ports 2/4 as *RCP* inner ports, and the ports 2/3 as *RCP* outer ports.



The following steps describe how to specify the parameters for the railway car represented by the MRP2 ring.

Set up the switches 2A..2C as an MRP *Ring Client* device. Set up only switch 2D as the MRP *Ring Manager* device. Set up the switches 2A and 2B as one RCP coupler pair and the switches 2C and 2D as the second coupler pair.

Disabling the RSTP function on the MRP Ring ports

MRP and RSTP do not work together. Therefore, deactivate the RSTP function on the *RCP* ports used in the *MRP* ring. In the example configuration, ports x/1 and x/2 are used for the *MRP* ring. Activate the RSTP function only on the *RCP* inner and outer ports used in the secondary ring. For example, activate the RSTP function on the ports x/3 and x/4.

If you disable the *MRP* function, then the device re-enables the RSTP function on the *RCP* ports used in the primary ring. In the example configuration, the device re-enables RSTP on ports x/1 and x/2.

Note: Substitute the port designation examples like x/1 with the actual port numbers on your system. Depending on your device, the port designation may consist of only the port number.

Perform the following steps on the switches 2A..2D:

- □ Open the Switching > L2-Redundancy > Spanning Tree > Port dialog, CIST tab.
- □ In the default setting, the RSTP function is active on the ports. To deactivate the RSTP function on the *MRP* ring ports, unmark the *STP active* checkboxes for ports x/1 and x/2.
- □ Open the Switching > L2-Redundancy > Spanning Tree > Global dialog.
- □ To enable the *Spanning Tree* function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface x/1	To change to the interface configuration mode of interface x/1.
no spanning-tree mode	To disable the Spanning Tree function on the port.
exit	To change to the Configuration mode.
interface x/2	To change to the interface configuration mode of interface $x/2$.
no spanning-tree mode	To disable the Spanning Tree function on the port.
exit	To change to the Configuration mode.
spanning-tree operation	To enable the Spanning Tree function.

Setting up the MRP Ring Manager and Ring Client devices

Set up the switches 2A..2C as an MRP *Ring Client* device. Set up only switch 2D as the MRP *Ring Manager* device. See figure 84 on page 299.

Set up the other switches in the rings as *Ring Client* devices. To do this, perform the following steps:

- □ Open the *Switching* > *L2-Redundancy* > *MRP* dialog.
- □ Specify the first ring port in the *Ring port 1* frame. From the *Port* drop-down list, select port x/1.
- □ Specify the second ring port in the *Ring port* 2 frame. From the *Port* drop-down list, select port x/2.

- □ On switch 2D only: To designate the device as the MRP *Ring Manager* device, enable the *Ring manager* function. For switches 2A..2C, leave the default setting.
- □ To enable the *MRP* function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
mrp domain add default-domain	To add a MRP domain with the ID default-domain.
mrp domain modify port primary x/1	To specify port $x/1$ as ring port 1.
mrp domain modify port secondary x/2	To specify port $x/2$ as ring port 2.
mrp domain modify mode manager	On switch 2D only: To designate the device as the <i>Ring Manager</i> device. For switches 2A2C, leave the default setting.
mrp domain modify operation enable	To enable the <i>MRP</i> function.

Specifying the ports for the RCP coupler pairs

Note: The example leaves the roles of the coupler pair devices at the default value *auto*. The coupler pair devices then automatically select their roles as *master* or *slave*. When you want specific master or slave roles for a device pair, specify the roles explicitly.

Perform the following steps on the switches 2A..2D:

- □ Open the Switching > L2-Redundancy > FuseNet > RCP dialog.
- □ Specify the *Inner port* in the *Primary ring/network* frame. Select port x/2.
- □ Specify the *Outer port* in the *Primary ring/network* frame. Select port x/1.
- Specify the *Inner port* in the *Secondary ring/network* frame. Select port x/4.
- □ Specify the Outer port in the Secondary ring/network frame. Select port x/3.

□ To enable the *RCP* function, select the *On* radio button in the *Operation* frame.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable

configure

redundant-coupling port primary inner x/2 redundant-coupling port primary outer x/1 redundant-coupling port secondary inner x/4 redundant-coupling port secondary outer x/3 redundant-coupling operation

To change to the Privileged EXEC mode. To change to the Configuration mode. To specify port x/2 as the primary inner port. To specify port x/1 as the primary outer port. To specify port x/4 as the secondary inner port. To specify port x/3 as the secondary outer port. To enable the *RCP* function in the device.

13 Tracking

The tracking function lets you monitor certain objects, such as the availability of an interface or reachability of a network.

Tracking can monitor the following objects:

- Link status of an interface (interface tracking)
- Result of logical connections of tracking entries (logic tracking)

An object can have the following statuses:

- up (OK)
- down (not OK)
- notReady (not enabled)

The definition of "up" and "down" depends on the type of the tracking object (for example interface tracking).

Tracking can forward the state changes of an object to the following applications:

- Static routing
- Interface status

13.1 Interface tracking

With interface tracking the device monitors the link status of:

- Physical ports
- Link Aggregation interfaces
- VLAN router interfaces




Figure 85: Monitoring a line with interface tracking

Ports/interfaces can have the following link statuses:

- interrupted physical link (link down)
- existing physical link (link up)

If the link to the participating ports is interrupted, then a Link Aggregation interface has link status "down".

If the link is interrupted from the physical ports/Link Aggregation interfaces that are members of the corresponding VLAN, then the VLAN router interface has the link status "down".

Setting a delay time lets you insert a delay before informing the application about an object status change.

If the physical link interruption remains for longer than the "link down delay" delay time, then the interface tracking object has the status "down".

When the physical link holds for longer than the "link up delay" delay time, the interface tracking object has the status "up".

State on delivery: delay times = 0 seconds.

This means that in case where a status changes, the registered application is informed immediately.

You can set the "link down delay" and "link up delay" delay times independently of each other in the range from 0 to 255 seconds.

You can define an interface tracking object for each interface.

13.2 Logical tracking

Logical tracking lets you logically link multiple tracking objects with each other and thus perform relatively complex monitoring tasks.

You can use logical tracking, for example, to monitor the link status for a network node to which redundant paths lead.

The device provides the following options for a logical link:

and

▶ or

For a logical link, you can combine up to 2 operands with one operator.

Logical tracking objects can have the following statuses:

- The result of the logical link is incorrect (down).
- The result of the logical link is correct (*up*).
- The monitoring of the tracking object is inactive (notReady).

When a logical link delivers the result *down*, the device can choose to use an alternative path.

13.3 Configuring the tracking

You configure the tracking by setting up tracking objects. The following steps are required to set up a tracking object:

- Enter the tracking object ID number (track ID).
- Select a tracking type, for example interface.
- Depending on the track type, enter additional options such as "port" or "link up delay" in the interface tracking.

Note: The registration of applications (for example VRRP) to which the tracking function reports status changes is performed in the application itself.

13.3.1 Configuring interface tracking

- Set up interface tracking on port 1/1 with a link down delay of 0 seconds and a link up delay of 3 seconds. To do this, perform the following steps:
 - □ Open the *Advanced* > *Tracking* > *Configuration* dialog.
 - \Box Click the $\overset{\blacksquare}{+}$ button.

The dialog displays the Create window.

Select type:

- Enter the values you desire, for example:
 Type: *interface Track ID*: 11
- Click the Ok button.

Properties:

- Enter the values you desire, for example: *Port*: 1/1
 Link up delay [s]: 3
 Link down delay [s]: 0
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
track add interface 11	To add a tracking object to the table.
track modify interface 11 ifnumber 1/1 link-up-delay 3 link-down-delay 0	To specify the parameters for this tracking object.
track enable interface 11	To activate the tracking object.
Tracking ID interface-11 created Target Link Up Delay for target interface set Link Down Delay for target interface so Tracking ID 11 activated	to 3 sec
5	
exit	To change to the Privileged EXEC mode.
show track interface	To display the set-up tracking objects.
Name If-Number Link-Up-Delay Link-	Down-Delay State Active
if-11 1/1 0	3 up [x]

13.4 Interface status application

The interface status application lets you control the status of one or more interfaces based on the status changes of a tracking object.

For example:

- ▶ When the status of the tracking object changes to *down*, the status of the linked interfaces also changes to *down*.
- ▶ When the status of the tracking object changes to *up*, the status of the linked interfaces also changes to *up*.

The device lets you link the following interface types to a tracking object:

- Physical ports
- Link Aggregation interfaces

13.4.1 Special conditions during use

If you manually deactivate the linked interface, then its status remains *down* even if the tracking object status changes to *up*.

The interface status application checks the reason for disabling an interface. If the *Auto-Disable* function has disabled a linked interface, then the interface status application does not enable this port again.

13.4.2 Example for the Interface status application

In the following example, the administrator links the tracking object if-1 to interface 1/2. When the status of the tracking object if-1 changes, the interface status application changes the status of interface 1/2 accordingly. The prerequisite is that for interface 1/1, a tracking object with *Track name* = if-1 and *Type* = *interface* is set up. See section "Configuring the tracking" on page 306.

Perform the following steps:

Open the Basic Settings > Port dialog The dialog displays the settings for You link a Link Aggregation interface	
dialog.	
 In the table row for interface 1/2, <i>Tra</i> 1 tracking object item. 	ack name column, select from the drop-down list the if-
□ Apply the settings temporarily. To c	do this, click the 🗸 button.
Open the Advanced > Tracking > App to the tracking objects.	<i>lications</i> dialog to display which applications are linked
enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.

interface 1/2

To change to the interface configuration mode of interface 1/2.

track if-st	atus add if	-1	To link the tracking object if-1 to interface 1/2.
show track	application		To verify the status of the applications.
Туре	Track-Id	App-Name	App-Object-Name
interface	1	IntfState 1/1	if-1
save			To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

14 Operation diagnosis

The device provides you with the following diagnostic tools:

- Sending SNMP traps
- Monitoring the Device Status
- Out-of-Band signaling using the signal contact
- Event counter at port level
- Detecting non-matching duplex modes
- Auto-Disable
- Displaying the SFP status
- Topology discovery
- Detecting IP address conflicts
- Detecting loops
- Help protect against layer 2 network loops
- Reports
- Monitoring data stream on a port (port mirroring)
- Syslog
- Event log
- Cause and action management during selftest

14.1 Sending SNMP traps

The device immediately reports unusual events which occur during normal operation to the network management station. This is done by messages called SNMP traps that bypass the polling procedure ("polling" means querying the data stations at regular intervals). SNMP traps allow you to react quickly to unusual events.

Examples of such events are:

- Hardware reset
- Changes to the configuration
- Segmentation of a port

The device sends SNMP traps to various hosts to increase the transmission reliability for the messages. The unacknowledged SNMP trap message consists of a packet containing information about an unusual event.

The device sends SNMP traps to those hosts specified in the trap destination table. The device lets you set up the trap destination table with the network management station using SNMP.

14.1.1List of SNMP traps

The following table displays possible SNMP traps sent by the device.

Table 40: Possible SNMP traps

Name of the SNMP trap	Meaning
authenticationFailure	When a station attempts to access an agent without authorisation, the device sends this trap.
coldStart	Sent after the system startup.
hm2DevMonSenseExtNvmRemoval	When the external memory has been removed, the device sends this trap.
linkDown	When the connection on a port is interrupted, the device sends this trap.
linkUp	When connection is established to a port, the device sends this trap.
hm2DevMonSensePSState	When the status of a power supply unit changes, the device sends this trap.
hm2SigConStateChange	When the status of the signal contact changes in the operation monitoring, the device sends this trap.
newRoot	When the sending agent becomes the new root of the spanning tree, the device sends this trap.
topologyChange	When the port changes from blocking to forwarding or from forwarding to blocking, the device sends this trap.
alarmRisingThreshold	When the <i>RMON input</i> exceeds its upper threshold, the device sends this trap.
alarmFallingThreshold	When the <i>RMON input</i> goes below its lower threshold, the device sends this trap.
hm2AgentPortSecurityViolatio n	When a MAC address detected on this port does not match the current settings of the parameter hm2AgentPortSecurityEntry, the device sends this trap.
hm2DiagSelftestActionTrap	When a self test for the four categories <i>task</i> , <i>resource</i> , <i>software</i> , and <i>hardware</i> is performed according to the specified settings, the device sends this trap.
hm2MrpReconfig	When the configuration of the MRP Ring changes, the device sends this trap.
hm2DiagIfaceUtilizationTrap	When the actual value of the interface exceeds the specified upper threshold value or falls below the specified lower threshold value, the device sends this trap.
hm2LogAuditStartNextSector	When the audit trail after completing one sector starts a new one, the device sends this trap.
hm2PtpSynchronizationChance	When the status of the PTP synchronization has been changed, the device sends this trap.
hm2ConfigurationSavedTrap	After the device has successfully saved its settings locally, the device sends this trap.
hm2ConfigurationChangedTrap	When you change the settings of the device for the first time after it has been saved locally, the device sends this trap.
hm2PlatformStpInstanceLoopIn consistentStartTrap	When the port in this STP instance changes to the <i>Loop Inconsistent</i> status, the device sends this trap.
hm2PlatformStpInstanceLoopIn consistentEndTrap	When the port in this STP instance leaves the <i>Loop Inconsistent</i> status receiving a BPDU packet, the device sends this trap.

14.1.2 SNMP traps for configuration activity

After you save a configuration in the memory, the device sends a hm2ConfigurationSavedTrap. This SNMP trap contains both the state variables of non-volatile memory (*NVM*) and external memory (*ENVM*) indicating if the running configuration is in sync with the non-volatile memory, and with the external memory. You can also trigger this SNMP trap by transferring a configuration file onto the device, replacing the active saved configuration.

Furthermore, the device sends a hm2ConfigurationChangedTrap, whenever you change the local configuration, indicating a mismatch between the running and saved configuration.

14.1.3 SNMP trap setting

The device lets you send an SNMP trap as a reaction to specific events. Set up at least one trap destination that receives SNMP traps.

Perform the following steps:

- □ Open the *Diagnostics* > *Status Configuration* > *Alarms* (*Traps*) dialog.
- □ Click the ₩ button.
- The dialog displays the Create window.
- □ In the *Name* frame, specify the name that the device uses to identify itself as the source of the SNMP trap.
- □ In the *Address* frame, specify the IP address of the trap destination to which the device sends the SNMP traps.
- □ In the *Active* column, select the entries that the device takes into account when it sends SNMP traps.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

For example, in the following dialogs you specify when the device triggers an SNMP trap:

- Basic Settings > Port dialog
- Basic Settings > Power over Ethernet > Global dialog
- Network Security > Port Security dialog
- Switching > L2-Redundancy > Link Aggregation dialog
- Advanced > Tracking > Configuration dialog
- Diagnostics > Status Configuration > Device Status dialog
- Diagnostics > Status Configuration > Security Status dialog
- Diagnostics > Status Configuration > Signal Contact dialog
- Diagnostics > Status Configuration > MAC Notification dialog
- Diagnostics > System > IP Address Conflict Detection dialog
- Diagnostics > System > Selftest dialog
- Diagnostics > Ports > Port Monitor dialog

14.1.4 ICMP messaging

The device lets you use the Internet Control Message Protocol (ICMP) for diagnostic applications, for example ping and trace route. The device also uses ICMP for time-to-live and discarding messages in which the device forwards an ICMP message back to the packet source device.

Use the ping network tool to test the path to a particular host across an IP network. The traceroute diagnostic tool displays paths and transit delays of packets across a network.

14.2 Monitoring the Device Status

The device status provides an overview of the overall condition of the device. Many process visualization systems record the device status for a device to present its condition in graphic form.

The device displays its current status as *error* or *ok* in the *Device status* frame. The device determines this status from the individual monitoring results.

The device lets you:

- Out-of-Band signalling using a signal contact
- signal the changed device status by sending an SNMP trap
- detect the device status in the Basic Settings > System dialog of the Graphical User Interface
- query the device status in the Command Line Interface

The *Global* tab of the *Diagnostics* > *Status Configuration* > *Device Status* dialog lets you set up the device to send a trap to the management station for the following events:

- Incorrect supply voltage
 - at least one of the 2 supply voltages is not operating
 - the internal supply voltage is not operating
- When you operate the device outside of the user-specified temperature threshold values
- Loss of the redundancy (when the device operates in the *Ring Manager* mode)
- The interruption of link connection(s)
- Set up at least one port for this feature. In the table of the *Port* tab, *Propagate connection error* column, you specify for which ports the device will propagate a link interruption to the device status. In the default setting, link connection monitoring is inactive.
- The removal of the external memory
- The configuration profile in the external memory does not match the settings in the device.
- The removal of a module

Select the corresponding entries to decide which events the device status includes.

Note: With a non-redundant voltage supply, the device reports the absence of a supply voltage. To disable this message, feed the supply voltage over both inputs or ignore the monitoring.

14.2.1 Events which can be monitored

Table 41: Device Status events

Name	Meaning
Connection errors	Activate this function to monitor every port link event in which the <i>Propagate connection error</i> checkbox is marked.
Temperature	Activate this function to monitor if the temperature exceeds the specified upper threshold value or falls below the specified lower threshold value.
Ethernet module removal	Activate this function to monitor the removal of a module. Also activate the individual module to monitor.
External memory removal	Activate this function to monitor the presence of an external storage device.
External memory not in sync	The device monitors synchronization between the device settings and the configuration profile stored in the external memory (<i>ENVM</i>).
Ring redundancy	When ring redundancy is present, activate this function to monitor.
Power supply	Activate this function to monitor the power supply.

14.2.2 Configuring the Device Status

Perform the following steps:

- □ Open the *Diagnostics* > *Status Configuration* > *Device Status* dialog, *Global* tab.
- □ For the parameters to be monitored, mark the checkbox in the *Monitor* column.
- □ To send an SNMP trap to the management station, activate the *Send trap* function in the *Traps* frame.
- □ In the *Diagnostics* > *Status Configuration* > *Alarms (Traps)* dialog, add at least one trap destination that receives SNMP traps.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Basic Settings* > *System* dialog.
- □ To monitor the temperature, in the *System data* frame, you specify the temperature threshold values.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
device-status trap	To send an SNMP trap when the device status changes.
device-status monitor envm-not-in-sync	 To monitor the configuration profiles in the device and in the external memory. The <i>Device status</i> changes to <i>error</i> in the following situations: The configuration profile only exists in the device. The configuration profile in the device differs from the configuration profile in the external memory.
device-status monitor envm-removal	To monitor the active external memory. When you remove the active external memory from the device, the value in the <i>Device status</i> frame changes to <i>error</i> .
device-status monitor power-supply 1	To monitor the power supply unit 1. When the device has a detected power supply fault, the value in the <i>Device status</i> frame changes to <i>error</i> .
device-status monitor ring-redundancy	 To monitor the ring redundancy. The <i>Device status</i> changes to <i>error</i> in the following situations: The redundancy function becomes active (loss of redundancy reserve). The device is a normal ring participant and detects an error in its settings.

device	-status monitor temperature	To monitor the temperature in the device. When the temperature exceeds the specified upper threshold value or falls below the specified lower threshold value, the value in the <i>Device status</i> frame changes to <i>error</i> .
device	-status monitor module-removal	To monitor the modules. When you remove a module from the device, the value in the <i>Device status</i> frame changes to <i>error</i> .
device	-status module 1	To monitor module 1. When you remove the module 1 from the device, the value in the <i>Device status</i> frame changes to <i>error</i> .

To enable the device to monitor an active link without a connection, first enable the global function, then enable the individual ports.

Perform the following steps:

□ Open the <i>Diagnostics</i> > Status Configu	ration > Device Status dialog, Global tab.	
□ For the <i>Connection errors</i> parameter, mark the checkbox in the <i>Monitor</i> column.		
□ Open the <i>Diagnostics</i> > <i>Status Configuration</i> > <i>Device Status</i> dialog, <i>Port</i> tab.		
☐ For the <i>Propagate connection error</i> parameter, mark the checkbox in the column of the ports to be monitored.		
\Box Apply the settings temporarily. To do	o this, click the 🗸 button.	
enable	To change to the Privileged EXEC mode.	
configure	To change to the Configuration mode.	
device-status monitor link-failure	To monitor the ports/interfaces link. When the link interrupts on a monitored port/interface, the value in the <i>Device status</i> frame changes to <i>error</i> .	
interface 1/1	To change to the interface configuration mode of interface 1/1.	
device-status link-alarm	To monitor the port/interface link. When the link	

Note: The above commands activate monitoring and trapping for the supported components. When you want to activate or deactivate monitoring for individual components, you will find the corresponding syntax in the "Command Line Interface" reference manual or in the help of the Command Line Interface console. To display the help in Command Line Interface, insert a question mark ? and press the <Enter> key.

interrupts on a monitored port/interface, the value in the *Device status* frame changes to *error*.

14.2.3 Displaying the Device Status

Perform the following steps:

□ Open the *Basic Settings* > *System* dialog.

UM Config RSPE

enable

show device-status all

To change to the Privileged EXEC mode.

To display the device status and the setting for the device status determination.

14.3 Security Status

The Security Status provides an overview of the overall security of the device. Many processes aid in system visualization by recording the security status of the device and then presenting its condition in graphic form. The device displays the overall security status in the *Basic Settings* > System dialog, *Security status* frame.

In the *Global* tab of the *Diagnostics* > *Status Configuration* > *Security Status* dialog the device displays its current status as *error* or *ok* in the *Security status* frame. The device determines this status from the individual monitoring results.

The device lets you:

- Out-of-Band signalling using a signal contact
- ▶ signal the changed security status by sending an SNMP trap
- b detect the security status in the *Basic Settings > System* dialog of the Graphical User Interface
- query the security status in the Command Line Interface

14.3.1 Events which can be monitored

Perform the following steps:

- □ Specify the events that the device monitors.
- □ For the corresponding parameter, mark the checkbox in the *Monitor* column.

Table 42: Security Status events

Name	Meaning
Password default settings unchanged	After installation change the passwords to increase security. When active and the default passwords remain unchanged, the device displays an alarm.
Min. password length shorter than 8	Create passwords more than 8 characters long to maintain a high security posture. When active, the device monitors the <i>Min. password length</i> setting.
Password policy settings deactivated	The device monitors the settings located in the <i>Device Security</i> > User Management dialog for password policy requirements.
User account password policy check deactivated	The device monitors the settings of the <i>Policy check</i> checkbox. When <i>Policy check</i> is inactive, the device sends an SNMP trap.
Telnet server active	Activate this function to monitor when the <i>Telnet</i> function is active.
HTTP server active	Activate this function to monitor when the <i>HTTP</i> function is active.
SNMP unencrypted	Activate this function to monitor when the <i>SNMPv1</i> or <i>SNMPv2</i> function is active.
Access to system monitor with serial interface possible	The device monitors the System Monitor status.
Saving the configuration profile on the external memory possible	The device monitors the possibility to save settings to the external non-volatile memory.
Link interrupted on enabled device ports	The device monitors the link status of active ports.
Access with HiDiscovery possible	Activate this function to monitor when the HiDiscovery function has write access to the device.

Name	Meaning
Load unencrypted config from external memory	The device monitors the security settings for loading the configuration from the external NVM.
IEC61850-MMS active	The device monitors the IEC 61850-MMS protocol activation setting.
Self-signed HTTPS certificate present	The device monitors the HTTPS server for self-generated digital certificates.
Modbus TCP active	The device monitors the Modbus TCP/IP protocol activation setting.

Table 42: Security Status events (cont.)

14.3.2 Configuring the Security Status

Perform the following steps:

- □ Open the *Diagnostics* > *Status Configuration* > *Security Status* dialog, *Global* tab.
- □ For the parameters to be monitored, mark the checkbox in the *Monitor* column.
- □ To send an SNMP trap to the management station, activate the *Send trap* function in the *Traps* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ In the *Diagnostics* > *Status Configuration* > *Alarms (Traps)* dialog, add at least one trap destination that receives SNMP traps.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
security-status monitor pwd-change	To monitor the password for the locally set up user account admin. When the password for the admin user account is the default setting, the value in the <i>Security status</i> frame changes to <i>error</i> .
security-status monitor pwd-min-length	To monitor the value specified in the <i>Min. password length</i> policy. When the value for the <i>Min. password length</i> policy is less than 8, the value in the <i>Security status</i> frame changes to <i>error</i> .
security-status monitor pwd-policy-config	 To monitor the password policy settings. When the value for at least one of the following policies is specified as Ø, the value in the Security status frame changes to error. Upper-case characters (min.) Lower-case characters (min.) Digits (min.) Special characters (min.)
security-status monitor pwd-policy- inactive	To monitor the password policy settings. When the value for at least one of the following policies is specified as 0, the value in the <i>Security status</i> frame changes to <i>error</i> .
security-status monitor telnet-enabled	To monitor the Telnet server. When you enable the Telnet server, the value in the <i>Security status</i> frame changes to <i>error</i> .

security-status monitor http-enabled	To monitor the HTTP server. When you enable the HTTP server, the value in the <i>Security status</i> frame changes to <i>error</i> .
security-status monitor snmp-unsecure	 To monitor the SNMP server. When at least one of the following conditions applies, the value in the <i>Security status</i> frame changes to <i>error</i>: The <i>SNMPv1</i> function is enabled. The <i>SNMPv2</i> function is enabled. The encryption for SNMPv3 is disabled. You enable the encryption in the <i>Device Security > User Management</i> dialog, in the <i>SNMP encryption type</i> field.
security-status monitor sysmon-enabled	To monitor the activation of the <i>System Monitor 1</i> function in the device.
security-status monitor extnvm-upd-enabled	To monitor the activation of the external non volatile memory update.
security-status monitor iec61850-mms- enabled	To monitor the <i>IEC61850-MMS</i> function. When you enable the <i>IEC61850-MMS</i> function, the value in the <i>Security status</i> frame changes to <i>error</i> .
security-status trap	To send an SNMP trap when the device status changes.

To enable the device to monitor an active link without a connection, first enable the global function, then enable the individual ports.

Perform the following steps:

- □ Open the *Diagnostics* > *Status Configuration* > *Security Status* dialog, *Global* tab.
- □ For the *Link interrupted on enabled device ports* parameter, mark the checkbox in the *Monitor* column.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Diagnostics* > *Status Configuration* > *Device Status* dialog, *Port* tab.
- □ For the *Link interrupted on enabled device ports* parameter, mark the checkbox in the column of the ports to be monitored.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
security-status monitor no-link-enabled	To monitor the link on active ports. When the link interrupts on an active port, the value in the <i>Security status</i> frame changes to <i>error</i> .
interface 1/1	To change to the interface configuration mode of interface 1/1.
security-status monitor no-link	To monitor the link on interface/port 1.

14.3.3 Displaying the Security Status

Perform the following steps:

□ Open the *Basic Settings* > *System* dialog.

enable

show security-status all

To change to the Privileged EXEC mode.

To display the security status and the setting for the security status determination.

14.4 Out-of-Band signaling

The device uses the signal contact to control external devices and monitor device functions. Function monitoring lets you perform remote diagnostics.

The device reports the operating status using a break in the potential-free signal contact (relay contact, closed circuit) for the selected mode. The device monitors the following functions:

- Incorrect supply voltage
 - at least one of the 2 supply voltages is not operating
 - the internal supply voltage is not operating
- When you operate the device outside of the user-specified temperature threshold values
- Events for ring redundancy Loss of the redundancy (when the device operates in the *Ring Manager* mode) In the default setting, ring redundancy monitoring is inactive. The device is a normal ring participant and detects an error in the local configuration.
- The interruption of link connection(s) Set up at least one port for this feature. In the *Propagate connection error* frame, you specify which ports the device signals for a link interruption. In the default setting, link monitoring is inactive.
- The removal of the external memory The configuration profile in the external memory does not match the settings in the device.
- ▶ The removal of a module

Select the corresponding entries to decide which events the device status includes.

Note: With a non-redundant voltage supply, the device reports the absence of a supply voltage. To disable this message, feed the supply voltage over both inputs or ignore the monitoring.

14.4.1 Controlling the Signal contact

With the *Manual setting* mode you control this signal contact remotely.

Application options:

- Simulation of an error detected during SPS error monitoring
- Remote control of a device using SNMP, such as switching on a camera

Perform the following steps:

Open the *Diagnostics > Status Configuration > Signal Contact* dialog, *Global* tab.
 To control the signal contact manually, in the *Configuration* frame, select the *Manual setting* item from the *Mode* drop-down list.
 To open the signal contact, you select the *open* radio button in the *Configuration* frame.
 To close the signal contact, you select the *cLose* radio button in the *Configuration* frame.
 Apply the settings temporarily. To do this, click the ✓ button.

signal-contact 1 mode manual

signal-contact 1 state open
signal-contact 1 state closed

To select the manual setting mode for signal contact 1. To open signal contact 1.

To close signal contact 1.

14.4.2 Monitoring the Device and Security Statuses

In the *Configuration* field, you specify which events the signal contact indicates.

- Device status
 - Using this setting the signal contact indicates the status of the parameters monitored in the *Diagnostics > Status Configuration > Device Status* dialog.
- Security status Using this setting the signal contact indicates the status of the parameters monitored in the Diagnostics > Status Configuration > Security Status dialog.
- Device/Security status Using this setting the signal contact indicates the status of the parameters monitored in the Diagnostics > Status Configuration > Device Status and the Diagnostics > Status Configuration > Security Status dialog.

Configuring the operation monitoring

Perform the following steps:

- □ Open the *Diagnostics* > *Status Configuration* > *Signal Contact* dialog, *Global* tab.
- □ To monitor the device functions using the signal contact, in the *Configuration* frame, specify the value *Monitoring correct operation* in the *Mode* field.
- □ For the parameters to be monitored, mark the checkbox in the *Monitor* column.
- □ To send an SNMP trap to the management station, activate the *Send trap* function in the *Traps* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ In the *Diagnostics* > *Status Configuration* > *Alarms (Traps)* dialog, add at least one trap destination that receives SNMP traps.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- ☐ You specify the temperature threshold values for the temperature monitoring in the Basic Settings > System dialog.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
signal-contact 1 monitor temperature	To monitor the temperature in the device. When the temperature exceeds the specified upper threshold value or falls below the specified lower threshold value, the signal contact opens.

signal-contact 1 monitor ring-redundancy	 To monitor the ring redundancy. The signal contact opens in the following situations: The redundancy function becomes active (loss of redundancy reserve). The device is a normal ring participant and detects an error in its settings.
signal-contact 1 monitor link-failure	To monitor the ports/interfaces link. When the link interrupts on a monitored port/interface, the signal contact opens.
signal-contact 1 monitor envm-removal	To monitor the active external memory. When you remove the active external memory from the device, the signal contact opens.
signal-contact 1 monitor envm-not-in-sync	 To monitor the configuration profiles in the device and in the external memory. The signal contact opens in the following situations: The configuration profile only exists in the device. The configuration profile in the device differs from the configuration profile in the external memory.
signal-contact 1 monitor power-supply 1	To monitor the power supply unit 1. When the device has a detected power supply fault, the signal contact opens.
signal-contact 1 monitor module-removal 1	To monitor module 1. When you remove module 1 from the device, the signal contact opens.
signal-contact 1 trap	To send an SNMP trap when the status of the operation monitoring changes.
no signal-contact 1 trap	To disable the SNMP trap

To enable the device to monitor an active link without a connection, first enable the global function, then enable the individual ports.

Perform the following steps:

In the *Monitor* column, activate the *Link interrupted on enabled device ports* function.
 Open the *Diagnostics > Status Configuration > Device Status* dialog, *Port* tab.

enable		To change to the Privileged EXEC mode.
configur	e	To change to the Configuration mode.
signal-c	ontact 1 monitor link-failure	To monitor the ports/interfaces link. When the link interrupts on a monitored port/interface, the signal contact opens.
interfac	e 1/1	To change to the interface configuration mode of interface 1/1.
signal-c	ontact 1 link-alarm	To monitor the port/interface link. When the link interrupts on the port/interface, the signal contact opens.

Events which can be monitored

Table 43: Device Status events

Name	Meaning
Connection errors	Activate this function to monitor every port link event in which the <i>Propagate connection error</i> checkbox is marked.
Temperature	Activate this function to monitor if the temperature exceeds the specified upper threshold value or falls below the specified lower threshold value.
Ethernet module removal	Activate this function to monitor the removal of a module. Also activate the individual module to monitor.
External memory removed	Activate this function to monitor the presence of an external storage device.
External memory not in sync with NVM	The device monitors synchronization between the device settings and the configuration profile stored in the external memory (<i>ENVM</i>).
Ring redundancy	When ring redundancy is present, activate this function to monitor.
Power supply	Activate this function to monitor the power supply.

Displaying the signal contact status

The device gives you additional options for displaying the status of the signal contact:

- Display in the Graphical User Interface
- Query in the Command Line Interface

Perform the following steps:

Open the Basic Settings > System dialog.
 The Signal contact status frame displays the signal contact status and informs you about alarms that have occurred.

show signal-contact 1 all

To display the settings for the specified signal contact.

14.5 **Port event counter**

The port statistics table assists experienced network administrators in identifying potential network interruptions.

This table displays the contents of various event counters. The packet counters add up the events sent and the events received. In the *Basic Settings > Restart* dialog, you can reset the event counters.

Table 44: Examples indicating known weaknesses

Counter	Indication of known possible weakness
Received fragments	 Non-functioning controller of the connected device Electromagnetic interference in the transmission medium
CRC Error	 Non-functioning controller of the connected device Electromagnetic interference in the transmission medium Inoperable component in the network
Collisions	 Non-functioning controller of the connected device Network over extended/lines too long Collision or a detected fault with a data packet

Perform the following steps:

- □ To display the event counter, open the *Basic Settings > Port* dialog, *Statistics* tab.
- □ To reset the counters, in the *Basic Settings* > *Restart* dialog, click the *Clear port statistics* button.

14.5.1 Detecting non-matching duplex modes

Potential problems occur when 2 ports directly connected to each other have mismatched duplex modes. These potential problems are difficult to detect. The automatic detection and reporting of this situation has the benefit of recognizing mismatched duplex modes before potential problems occur.

This situation arises from an incorrect configuration, for example, deactivation of the automatic configuration on the remote port.

A typical effect of this non-matching is that at a low data rate, the connection seems to be functioning, but at a higher bi-directional data stream level the local device records a lot of detected CRC errors, and the connection falls significantly below its nominal capacity.

The device lets you detect this situation and report it to the network management station. In the process, the device evaluates the detected error counters of the port in the context of the port settings.

Possible causes of port error events

The following table lists the duplex operating modes for TX ports, with the possible fault events. The meanings of terms used in the table are as follows:

Duplex problem detected

Mismatched duplex modes.

► EMI

Electromagnetic interference.

Network extension

The network extension is too great, or too many cascading hubs.

Collisions, *Late Collisions*

In half-duplex mode, collisions mean normal operation.

In full-duplex mode, no incrementation of the port counters for collisions or *Late Collisions*. CRC Error

The device evaluates these detected errors as non-matching duplex modes in the manual fullduplex mode.

Table 45: Evaluation of non-matching of the duplex mode

No.	Automatic configuration	Current duplex mode	Detected error events (≥ 10 after link up)	Duplex modes	Possible causes
1	marked	Half-duplex	None	OK	
2	marked	Half-duplex	Collisions	OK	
3	marked	Half-duplex	Late Collisions	Duplex problem detected	Potential duplex problem, EMI, network extension
4	marked	Half-duplex	CRC Error	ОК	EMI
5	marked	Full-duplex	None	ОК	
6	marked	Full-duplex	Collisions	ОК	EMI
7	marked	Full-duplex	Late Collisions	ОК	EMI
8	marked	Full-duplex	CRC Error	ОК	EMI
9	unmarked	Half-duplex	None	ОК	
10	unmarked	Half-duplex	Collisions	ОК	
11	unmarked	Half-duplex	Late Collisions	Duplex problem detected	Potential duplex problem, EMI, network extension
12	unmarked	Half-duplex	CRC Error	OK	EMI
13	unmarked	Full-duplex	None	ОК	
14	unmarked	Full-duplex	Collisions	ОК	EMI
15	unmarked	Full-duplex	Late Collisions	ОК	EMI
16	unmarked	Full-duplex	CRC Error	Duplex problem detected	Potential duplex problem, EMI

14.6 Auto-Disable

The device can disable a port on various user-selectable events, such as a detected error or change of condition. Each of these events leads to the shutdown of the port. To recover the port, either clear the condition that caused the port shutdown or specify a timer to automatically re-enable the port.

If the device disables the port, then the device no longer forwards data packets to and from that port. The port LED blinks green 3 times per period and indicates the reason for disabling. In addition, the device generates a log file entry which lists the causes of the deactivation. When you re-enable the port after a timeout using the *Auto-Disable* function, the device generates a log entry.

The *Auto-Disable* function provides a recovery function which automatically enables an autodisabled port after a user-defined time. When this function enables a port, the device sends an SNMP trap with the port number, but without a value for the *Reason* parameter.

The Auto-Disable function serves the following purposes:

- It assists the network administrator in port analysis.
- It reduces the possibility that this port causes the network to be instable.

The Auto-Disable function is available for the following functions:

- Link flap (Port Monitor function)
- CRC/Fragments (Port Monitor function)
- Duplex Mismatch detection (*Port Monitor* function)
- DHCP Snooping
- Dynamic ARP Inspection
- Spanning Tree
- ► Port Security
- Overload detection (Port Monitor function)
- Link speed/Duplex mode detection (Port Monitor function)

If the interface status application disables the port due to the status of the linked tracking object changes to down, then the *Auto-Disable* function does not automatically enable the port.

In the following example, you set up the device to disable a port due to detected violations to the threshold values specified the *Diagnostics* > *Ports* > *Port Monitor* dialog, *CRC/Fragments* tab, and then automatically re-enable a port.

Perform the following steps:

- □ Open the *Diagnostics* > *Ports* > *Port Monitor* dialog, *CRC/Fragments* tab.
- Verify that the threshold values specified in the table concur to your preferences for port 1/
 1.
- □ Open the *Diagnostics* > *Ports* > *Port Monitor* dialog, *Global* tab.
- □ To enable the function, select the *0n* radio button in the *Operation* frame.
- To allow the device to disable the port due to detected errors, mark the checkbox in the *CRC/Fragments on* column for port 1/1.

- □ In the *Action* column you can choose how the device reacts to detected errors. In this example, the device disables port 1/1 for threshold value violations and then automatically re-enables the port.
 - To allow the device to disable and automatically re-enable the port, select the value auto-disable and set up the Auto-Disable function. The value auto-disable only works in conjunction with the Auto-Disable function.

The device can also disable a port without auto re-enabling.

To allow the device to disable the port only, select the value disable port.

To manually re-enable a disabled port, select the table row of the port and click the **b**utton.

- When you set up the Auto-Disable function, the value disable port also automatically re-enables the port.
- □ Open the *Diagnostics* > *Ports* > *Port Monitor* dialog, *Auto-disable* tab.
- □ To allow the device to auto re-enable the port after it was disabled due to detected threshold value violations, mark the checkbox in the *CRC error* column.
- □ Open the *Diagnostics* > *Ports* > *Port Monitor* dialog, *Port* tab.
- □ Specify the delay time as 120 s in the *Reset timer* [s] column for the ports you want to enable.

Note: The *Reset* item lets you enable the port before the time specified in the *Reset timer* [s] column has expired.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
port-monitor condition crc-fragments count 2000	To specify the CRC-Fragment counter to 2000 parts per million.
port-monitor condition crc-fragments interval 15	To set the measure interval to 15 seconds for CRC-Fragment detection.
auto-disable timer 120	To specify the waiting period of 120 seconds, after which the <i>Auto-disable</i> function re-enables the port.
exit	To change to the Configuration mode.
auto-disable reason crc-error	To activate the auto-disable CRC function.
port-monitor condition crc-fragments mode	To activate the CRC-Fragments condition to trigger an action.
port-monitor operation	To activate the Port Monitor function.

When the device disables a port due to threshold value violations, the device lets you use the following commands to manually reset the disabled port.

Perform the following steps:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
auto-disable reset	To let you enable the port before the time has expired.

14.7 Displaying the SFP status

The SFP status display lets you look at the current SFP module connections and their properties. The properties include:

- module type
- serial number of media module
- ▶ temperature in ° C
- transmission power in mW
- receive power in mW

Perform the following step:

□ Open the *Diagnostics* > *Ports* > *SFP* dialog.

14.8 Topology discovery

IEEE 802.1AB defines the Link Layer Discovery Protocol (LLDP). LLDP lets you automatically detect the LAN network topology.

Devices with LLDP active:

- ▶ broadcast their connection and management information to neighboring devices on the shared LAN. When the receiving device has its *LLDP* function active, evaluation of the devices occur.
- receive connection and management information from neighbor devices on the shared LAN, provided these adjacent devices also have LLDP active.
- build a management information database and object definitions for storing information about adjacent devices with LLDP active.

As the main element, the connection information contains an exact, unique identifier for the connection end point: MAC (Service Access Point). This is made up of a device identifier which is unique on the entire network and a unique port identifier for this device.

- Chassis identifier (its MAC address)
- Port identifier (its port-MAC address)
- Description of port
- System name
- System description
- Supported system capabilities
- System capabilities currently active
- Interface ID of the management address
- VLAN-ID of the port
- Auto-negotiation status on the port
- Medium, half/full-duplex setting and port speed setting
- Information about the VLANs installed in the device (VLAN-ID and VLAN name, irrespective of whether the port is a VLAN participant).

A network management station can call up this information from devices with activated LLDP. This information lets the network management station map the topology of the network.

Non-LLDP-capable devices normally block the special Multicast LLDP IEEE MAC address used for information exchange. Non-LLDP-capable devices therefore discard LLDP packets. If you position a non-LLDP-capable device between 2 LLDP-capable devices, then the non-LLDP-capable device prohibits information exchanges between the 2 LLDP-capable devices.

The Management Information Base (MIB) for a device with LLDP capability holds the LLDP information in the IIdp MIB and in the private HM2-LLDP-EXT-HM-MIB and HM2-LLDP-MIB.

14.8.1 Displaying the Topology discovery results

Display the topology of the network. To do this, perform the following step:

□ Open the *Diagnostics* > *LLDP* > *Topology Discovery* dialog, *LLDP* tab.

When you use a port to connect several devices, for example through a hub, the table contains a line for each connected device.

If you connect the port to devices with the topology discovery function active, then the devices exchange LLDP Data Units (LLDPDU) and the topology table displays these neighboring devices.

When a port connects only devices without an active topology discovery, the table contains a line for this port to represent the connected devices. This line contains the number of connected devices.

The MAC address table (forwarding database) contains MAC addresses of devices that the topology table hides for the sake of clarity.

14.8.2 LLDP-Med

LLDP for Media Endpoint Devices (LLDP-MED) is an extension to LLDP that operates between endpoint devices. Endpoints include devices such as IP phones, or other Voice over IP (VoIP) devices or servers and network devices such as switches. It specifically provides support for VoIP applications. LLDP-MED provides this support using an additional set of common type-length-value (TLV) advertisement messages, for capabilities discovery, network policy, Power over Ethernet, inventory management and location information.

The device supports the following TLV messages:

capabilities TLV

Lets the LLDP-MED endpoints determine the capabilities that the connected device supports and what capabilities the device has enabled.

Network policy TLV

Lets both network connectivity devices and endpoints advertise VLAN configurations and associated attributes for the specific application on that port. For example, the device notifies a phone of the VLAN number. The phone connects to a switch, obtain its VLAN number, and then starts communicating with the call control.

LLDP-MED provides the following functions:

- Network policy discovery, including VLAN ID, 802.1p priority and DSCP (Differentiated Services Code Point)
- Device location and topology discovery based on LAN-level MAC/port information
- Endpoint move detection notification, from network connectivity device to the associated VoIP management application
- Extended device identification for inventory management
- Identification of endpoint network connectivity capabilities, for example, multi-port IP Phone with embedded switch or bridge capability
- Application level interactions with the Link Layer Discovery Protocol (LLDP) elements to provide timely startup of LLDP to support rapid availability of an Emergency Call Service
- ▶ Applicability of LLDP-MED to Wireless LAN environments, support for Voice over Wireless LAN

14.9 Detecting loops

Loops in the network cause connection interruptions or data loss. This also applies to temporary loops. The automatic detection and reporting of this situation lets you detect it faster and diagnose it more easily.

An incorrect configuration causes loops, for example, deactivating Spanning Tree.

The device lets you detect the effects typically caused by loops and report this situation automatically to the network management station. You have the option here to specify the magnitude of the loop effects that trigger the device to send a report.

BPDU frames sent from the *Designated port* and received on either a different port of the same device or the same port within a short time, is a typical effect of a loop.

To check if the device has detected a loop, perform the following steps:

- □ Open the Switching > L2-Redundancy > Spanning Tree > Port dialog, CIST tab.
- Check the value in the Port state and Port role fields. If the Port state field displays the value discarding and the Port role field displays the value backup, then the port is in a loop status.
 or
- □ Open the Switching > L2-Redundancy > Spanning Tree > Port dialog, Guards tab.
- □ Check the value in the *Loop state* column. If the field displays the value true, then the port is in a loop status.

14.10 Helping avoid layer 2 network loops

The device helps protect against layer 2 network loops.

A network loop can lead to a standstill of the network due to overload. A possible reason is the continuous duplication of data packets due to a misconfiguration. The cause could be, for example, a poorly connected cable or an incorrect setting in the device.

For example, a layer 2 network loop can occur in the following cases, if no redundancy protocols are active:

- Two ports of the same device are directly connected to each other.
- More than one active connection is established between two devices.

14.10.1 Helping avoid layer 2 network loops

The figure displays examples for possible layer 2 loops in a network. The *Loop Protection* function is enabled in every device.

- A: Active mode Ports that are intended to connect end devices operate in the active mode. The device evaluates and sends loop detection packets on these ports.
- P: Passive mode Ports which belong to the redundant rings operate in the passive mode. The device only evaluates loop detection packets on these ports.
- Loop 1..Loop 4 Unintentionally set-up layer 2 network loops.




Figure 86: Examples for unintended layer 2 network loops

Assigning the Loop Protection settings to the ports

For each active and each passive port, assign the settings of the Loop Protection function.

Perform the following steps:

- □ Open the *Diagnostics* > *Loop Protection* dialog.
- □ In the *Global* frame, *Transmit interval* field, adjust the value, if necessary.
- □ In the *Global* frame, *Receive threshold* field, adjust the value, if necessary.
- □ In the *Mode* column, specify the behavior of the *Loop Protection* function on the port: - *active* for ports that are intended to connect end devices
 - passive for ports which belong to the redundant rings
- In the Action column, specify the value all.
 When the device detects a layer 2 loop on this port, then it sends a trap and disables the port using the Auto-Disable function. If necessary, adjust the value.
- □ In the *Active* column, mark the checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
loop-protection tx-interval 5	To specify the transmit interval, if necessary.
loop-protection rx-threshold 1	To specify the receive threshold value, if necessary.
interface 1/1	To change to the Interface mode. Example: port 1/1.
loop-protection mode active	To specify the mode active for ports that are intended to connect end devices.
loop-protection mode passive	To specify the mode passive for ports which belong to the redundant rings.
loop-protection action all	To specify the action that the device performs when it detects a layer 2 network loop on this port.
loop-protection operation	To activate the Loop Protection function on the port.
exit	To change to the Configuration mode.

Activating the Auto-Disable function

After you assigned the Loop Protection settings to the ports, activate the Auto-Disable function.

Perform the following steps:

□ In the *Configuration* frame, mark the *Auto-disable* checkbox.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

loop-protection auto-disable

To activate the Auto-Disable function.

Enabling the Loop Protection function in the device

When finished, enable the *Loop Protection* function in the device.

Perform the following steps:

□ In the *Operation* frame, select the *On* radio button.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

loop-protection operation

To enable the *Loop Protection* function in the device.

14.10.2 Recommendations for redundant ports

Depending on the *Loop Protection* settings, the device disables ports using the *Auto-Disable* function when the device detects a layer 2 network loop.

If any redundancy function is active on a port, then do not activate the *active* mode on this port. Otherwise, port shutdowns on redundant network paths can be the result. In the example above these are the ports which belong to the redundant rings.

Verify that a redundant network path is available as backup media. The device changes to the redundant path in case of the outage of the primary path.

The following settings help avoid port shutdowns on redundant network paths:

- Disable the *Loop Protection* function on redundant ports.
- or
- Enable the *passive* mode on redundant ports.

The *Loop Protection* function and the *Spanning Tree* function have an effect on each other. The following steps help avoid unexpected behavior of the device:

- □ Disable the *Spanning Tree* function on the port on which you want to enable the *Loop Protection* function. See the *Switching* > *L2-Redundancy* > *Spanning Tree* > *Port* dialog, *STP active* column.
- □ Disable the *Spanning Tree* function on the connected port of each connected device. See the *Switching* > *L2-Redundancy* > *Spanning Tree* dialog.

14.11 Using the Email Notification function

The device lets you inform users by email about events that have occurred. Prerequisite is that a mail server is available through the network on which the device transfers the emails.

To set up the device to send emails, perform the steps in the following chapters:

- □ Specifying the sender address
- □ Specifying the triggering events
- □ Specifying the recipients
- □ Specifying the mail server
- □ Enabling/Disabling the Email Notification function
- □ Sending a test email

14.11.1 Specifying the sender address

The sender address is the email address that indicates the device which sent the email. In the device, the default setting is switch@hirschmann.com.

Change the preset value. To do this, perform the following steps:

- Open the *Diagnostics* > *Email Notification* > *Global* dialog.
- □ In the *Sender* frame, change the value in the *Email address* field. Add a valid email address.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable		To change to the Privileged EXEC mode.
configure		To change to the Configuration mode.
logging email from-addr	<user@doma.in></user@doma.in>	To change the sender address.

14.11.2 Specifying the triggering events

The device differentiates between the following severities: *Table 46: Meaning of the severities for events*

Severity	Meaning	
emergency	Device not ready for operation	
alert	Immediate user intervention required	
critical	Critical status	
error	Error status	
warning	Warning	
notice	Significant, normal status	
informational	Informal message	
debug	Debug message	

You have the option of specifying the events of which the device informs you. For this, assign the desired minimum severity to the notification levels of the device.

The device informs the recipients as follows:

- Notification urgent
 - When an event of the severity assigned or more severe occurs, the device sends an email immediately.
- Notification non-urgent
 - When an event of the severity assigned or more severe occurs, the device logs the event in a buffer.
 - The device sends an email with the log file periodically or if the buffer is full.
 - When an event of a lower severity occurs, the device does not log this event.

Perform the following steps:

□ Open the *Diagnostics* > *Email Notification* > *Global* dialog.

In the *Notification urgent* frame, you specify the settings for emails which the device sends immediately.

□ In the *Severity* field, you specify the minimum severity.

□ In the *Subject* field, you specify the subject of the email.

In the *Notification non-urgent* frame, you specify the settings for emails which the device sends periodically.

□ In the *Severity* field, you specify the minimum severity.

□ In the *Subject* field, you specify the subject of the email.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>logging email severity immediate <level></level></pre>	To specify the minimum severity for events for which the device sends an email immediately.
logging email severity periodic <level></level>	To specify the minimum severity for events for which the device sends an email periodically.
logging email subject add <immediate <br="">periodic> TEXT</immediate>	To add a subject line with the content TEXT.

14.11.3 Changing the sending interval

The device lets you specify in which interval it sends emails with the log file. The default setting is 30 minutes.

Perform the following steps:

□ Open the *Diagnostics* > *Email Notification* > *Global* dialog.

In the *Notification non-urgent* frame, you specify the settings for emails which the device sends periodically.

□ Change the value in the Sending interval [min] field to change the interval.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
logging email duration <301440>	To specify the interval at which the device sends emails with log file.

14.11.4 Specifying the recipients

The device lets you specify up to 10 recipients.

Perform the following steps:

□ Open the *Diagnostics* > *Email Notification* > *Recipients* dialog.

- \Box To add a table row, click the $\overset{\blacksquare}{T}$ button.
- □ In the *Notification type* column, specify if the device sends the emails to this recipient immediately or periodically.
- □ In the *Email address* column, specify the email address of the recipient.
- □ In the *Active* column, mark the checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
logging email to-addr add <110> addr <user@doma.in> msgtype <immediately <br="">periodically></immediately></user@doma.in>	To specify the recipient with the email address user@doma.in. The device manages the settings in memory 110.

14.11.5 Specifying the mail server

The device supports encrypted and unencrypted connections to the mail server.

Perform the following steps:

- □ Open the *Diagnostics* > *Email Notification* > *Mail Server* dialog.
- \Box To add a table row, click the $\overset{\blacksquare}{+}$ button.
- □ In the *IP* address column, specify the IP address or the DNS name of the server.
- □ In the *Encryption* column, specify the protocol which encrypts the connection between the device and the mail server.
- □ When the mail server uses a port other than the well-known port, specify the TCP port in the *Destination TCP port* column.

When the mail server requests an authentication:

□ In the *User name* and *Password* columns, specify the account credentials which the device uses to authenticate on the mail server.

In the *Description* column, enter a meaningful name for the mail server.
 In the *Active* column, mark the checkbox.
 Apply the settings temporarily. To do this, click the ✓ button.
 enable
 configure
 To change to the Privileged EXEC mode.
 To change to the Configuration mode.
 To specify the mail server with the IP address
 IP ADDRESS> [security <none|tlsv1>]
 [username <USER NAME>]
 [password <PASSWORD>] [port <1..65535>]

14.11.6 Enabling/Disabling the Email Notification function

Perform the following steps:

Open the Diagnostics > Email Notification > Global dialog.

□ To enable the function, select the *0n* radio button in the *Operation* frame.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
logging email operation	To enable the sending of emails.
no logging email operation	To disable the sending of emails.

14.11.7 Sending a test email

The device lets you check the settings by sending a test email.

Prerequisite:

- The email settings are completely specified.
- The *Email Notification* function is enabled.

- □ Open the *Diagnostics* > *Email Notification* > *Mail Server* dialog.
- Click the k button.
 The dialog displays the *Connection test* window.
- □ From the *Recipient* drop-down list, select to which recipients the device sends the test email.
- □ In the *Message text* field, specify the text of the test email.
- \Box Click the Ok button to send the test email.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
logging email test msgtype <urgent non- urgent> TEXT</urgent non- 	To send an email with the content TEXT to the recipients.

When you do not see any message for detected errors and the recipients obtain the email, the device settings are correct.

14.12 Reports

The following lists reports and buttons available for diagnostics:

- System Log file
 - The device logs device-internal events in the System Log file.
- Audit Trail
 - Logs successful commands and user comments. The file also includes SNMP logging.
- Persistent Logging

When the external memory is present, the device saves log entries in a file in the external memory. These files remain available even after powering off the device. The maximum size, maximum number of retainable files, and the severity of logged events are configurable. After obtaining the user-defined maximum size or maximum number of retainable files, the device archives the entries and starts a new file. The device deletes the oldest file and renames the other files to maintain the number of files set up. To review these files, use the Command Line Interface or copy them to an external server for future reference.

Download support information

This button lets you download system information as a ZIP archive.

In service situations, these reports provide the technician with the necessary information.

14.12.1 Global settings

Using this dialog you enable or disable where the device sends reports, for example, to a Console, a syslog server, or a connection to the Command Line Interface. You also set at which severity level the device writes events into the reports.

Perform the following steps:

- □ Open the *Diagnostics* > *Report* > *Global* dialog.
- □ To send a report to the console, specify the desired level in the *Console logging* frame, *Severity* field.
- □ To enable the function, select the *0n* radio button in the *Console logging* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

The device buffers logged events in 2 separate storage areas so that the device keeps log entries for urgent events. Specify the minimum severity for events that the device logs to the buffered storage area with a higher priority.

Perform the following steps:

- □ To send events to the buffer, specify the desired level in the *Buffered logging* frame, *Severity* field.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

When you activate the logging of SNMP requests, the device logs the requests as events in the syslog. The *Log SNMP get request* function logs user requests for device configuration information. The *Log SNMP set request* function logs device setup events. Specify the minimum level for events that the device logs in the syslog.

Perform the following steps:

- □ Enable the *Log SNMP get request* function for the device to send SNMP Read requests as events to the syslog server.
 - To enable the function, select the On radio button in the SNMP logging frame.
- □ Enable the *Log SNMP set request* function for the device to send SNMP Write requests as events to the syslog server.
- To enable the function, select the *0n* radio button in the *SNMP logging* frame.
- □ Choose the desired severity level for the get and set requests.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

When active, the device logs configuration changes made using the Command Line Interface, to the audit trail. This feature is based on IEEE 1686 for Substation Intelligent Electronic Devices.

Perform the following steps:

- \Box Open the *Diagnostics* > *Report* > *Global* dialog.
- □ To enable the function, select the *On* radio button in the *CLI logging* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

The device lets you save the following system information data in one ZIP file on your PC:

- audittrail.html
- config.xml
- defaultconfig.xml
- script
- runningconfig.xml
- supportinfo.html
- systeminfo.html
- systemlog.html

The device names the ZIP archive automatically in the format <IP_address>_<system_name>.zip.

Perform the following steps:

Click the	Ð	button.
-----------	---	---------

After a while, you can download the ZIP archive.

- □ Select the directory in which you want to save the support information.
- Click the Ok button.

14.12.2 Syslog

The device lets you send messages about device internal events to one or more syslog servers (up to 8). Additionally, you also include SNMP requests to the device as events in the syslog.

Note: To display the logged events, open the *Diagnostics* > *Report* > *Audit Trail* dialog or the *Diagnostics* > *Report* > *System Log* dialog.

Perform the following steps:

- □ Open the *Diagnostics* > *Syslog* dialog.
- \Box To add a table row, click the $\overset{\blacksquare}{+}$ button.
- □ In the *IP address* column, enter the IP address or *Hostname* of the syslog server. You can specify a valid IPv4 or IPv6 address for the syslog server.
- □ In the *Destination UDP port* column, specify the TCP or UDP port on which the syslog server expects the log entries.
- □ In the *Min. severity* column, specify the minimum severity level that an event requires for the device to send a log entry to this syslog server.
- □ Mark the checkbox in the *Active* column.
- □ To enable the function, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

In the SNMP logging frame, set up the following settings for SNMP read and write requests:

- □ Open the *Diagnostics* > *Report* > *Global* dialog.
- □ Enable the *Log SNMP get request* function for the device to send SNMP Read requests as events to the syslog server.
- To enable the function, select the *On* radio button in the *SNMP logging* frame.
- □ Enable the *Log SNMP set request* function for the device to send SNMP Write requests as events to the syslog server.
 - To enable the function, select the On radio button in the SNMP logging frame.
- $\hfill\square$ Choose the desired severity level for the get and set requests.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
logging host add 1 addr 10.0.1.159 severity 3	To add a recipient in the syslog servers list. The value 3 specifies the severity level of the event that the device logs. The value 3 means error.
logging host add 2 addr 2001::1 severity 4	To add an IPv6 recipient in the syslog servers list. The value 4 means warning.
logging syslog operation	To enable the Syslog function.
exit	To change to the Privileged EXEC mode.
show logging host	To display the syslog host settings.
No. Server IP Port Max. Severity	Type Status
1 10.0.1.159 514 error 2 2001::1 514 warning	systemlog active
configure	To change to the Configuration mode.
logging snmp-requests get operation	To log the reception of SNMP Get requests.
logging snmp-requests get severity 5	The value 5 specifies the severity level of the event that the device logs when it receives an <i>SNMP Get request</i> . The value 5 means notice.

logging snmp-requests set operation	To log the reception of SNMP Set requests.
logging snmp-requests set severity	The value 5 specifies the severity level of the event that the device logs when it receives an <i>SNMP Set</i> <i>request</i> . The value 5 means notice.
exit	To change to the Privileged EXEC mode.
show logging snmp	To display the SNMP logging settings.
Log SNMP GET requests	: enabled
Log SNMP GET severity	: notice
Log SNMP SET requests	: enabled
Log SNMP SET severity	: notice

14.12.3 System Log

The device lets you call up a System Log file of the system events. The table in the *Diagnostics* > Report > *System Log* dialog lists the logged events.

You have the following options:

- View and refresh the System Log file
- Searching for content
- Downloading a copy of the System Log file
- Clearing the System Log file on the device

You have the option to also send the logged events to one or more syslog servers.

View and refresh the System Log file

The device continuously logs events in the System Log file. The display of events in the Graphical User Interface does not update automatically. If the dialog is already open for a while, refresh the display to also display the recently logged events.

Perform the following steps:



Refresh the display of the System Log file in the Graphical User Interface. To do this, click the C button.

enable show logging buffered To change to the Privileged EXEC mode. To display the buffered log entries.

Searching for content

The device continuously logs events in the System Log file. After a while, the file may contain a large number of events.

Perform the following steps:

Look for a keyword in the System Log file. To do this, use the search function of your web browser.

enable	To change to the Privileged EXEC mode.
show logging buffered <filter></filter>	To display the buffered log entries. You can enter keywords for the severity level, digits, or ranges, separated by a comma. Example: emergency,alert-error,4,5-6

Downloading a copy of the System Log file

The device continuously logs events in the System Log file. After a while, the file may contain many events. In the Graphical User Interface, you can download a copy of the System Log file to analyze the logged events on your computer. Using the Command Line Interface, you can save a copy of the System Log file in the external memory or on a remote server.

Perform the following steps:

- Download a copy of the System Log file onto your computer. To do this, click the button.
- The web browser saves the file on the computer according to its download settings. If necessary, select the file location.

enable	To change to the Privileged EXEC mode.
copy eventlog buffered envm EXAMPLE	To save a copy of the System Log file with filename EXAMPLE in the external memory.
<pre>copy eventlog buffered remote ftp:// 1.2.3.4/EXAMPLE</pre>	To save a copy of the System Log file with filename EXAMPLE on a remote server.

Clearing the System Log file on the device

The device continuously logs events in the System Log file. After a while, the file may contain many events. If you are no longer interested in the logged events, you can clear the System Log file in the device.

Perform the following steps:

Delete the content of the System Log file. To do this, click the button.

enable

clear logging buffered

To change to the Privileged EXEC mode. To clear the log file.

14.12.4 Syslog over TLS

The Transport Layer Security (TLS) is a cryptographic protocol designed to provide communications security over a computer network. The primary goal of the TLS protocol is to provide privacy and data integrity between two communicating computer applications.

When initiating a connection with a syslog server, using a TLS handshake, the device validates the digital certificate received from the server. For this purpose, you transfer the digital certificate from a remote server or from the external memory onto the device. Verify that the specified IP address or DNS name of the server matches the Common Name or Subject Alternative Name information in the digital certificate.

The device sends the TLS encrypted syslog messages over the TCP port specified in the *Destination UDP port* column.

Note: To establish an encrypted connection using a digital certificate, verify that the Common Name or Subject Alternative Name information in the digital certificate that you have transferred onto the device matches the IP address or DNS name of the server.

Application example for the Syslog function

The given example describes the configuration of the *Syslog* function. By following these steps, the device lets you send the TLS encrypted syslog messages over the TCP port specified in the *Destination UDP port* column.

The syslog messages that are sent from a device to a syslog server can pass through untrusted networks. To set up a syslog-over-TLS server, transfer the digital certificate onto the device. For security reasons, Hirschmann recommends using only digital certificates signed by a Certification Authority (CA).

Note: For the changes to take effect after transferring a digital certificate or a CRL into the device, disable and re-enable the *Syslog* function. See the *Operation* frame.

Perform the following steps:

- □ Open the *Diagnostics* > *Syslog* dialog.
- □ To initiate a data connection with the syslog servers, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

The device validates the digital certificate received. The device also authenticates the server and starts sending syslog messages.

□ Transfer the digital certificate from the remote server or from the external memory onto the device.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
logging host add 1 addr 192.168.3.215	To add index 1 to the syslog server with IPv4 address 192.168.3.215.
logging host add 2 addr 2001::1	To add index 2 to the syslog server with IPv6 address 2001::1.
logging host modify 1 port 6512 type systemlog	To specify the port number 6512 and logging the events in the system log.
logging host modify 1 transport tls	To specify the type of transmission as tls .
logging host modify 1 severity informational	To specify the type of event to log into the system log as <i>informational</i> .
exit	To change to the Privileged EXEC mode.
copy syslogcacert evmm	To transfer the digital certificates from the external memory onto the device.
show logging host	To display the syslog host settings.

14.12.5 Audit Trail

The *Diagnostics > Report > Audit Trail* dialog contains system information and changes to the device settings performed through the Command Line Interface and SNMP. In the case of a change in the device settings, the dialog displays Who changed What and When.

The *Diagnostics* > *Syslog* dialog lets you specify up to 8 syslog servers to which the device sends Audit Trails.

The following list contains log events:

- changes to configuration parameters
- Commands (except show commands) using the Command Line Interface
- Command logging audit-trail <string> using the Command Line Interface which logs the comment
- Automatic changes to the System Time
- watchdog events
- locking a user after several unsuccessful login attempts
- ▶ User login, either locally or remote, using the Command Line Interface
- Manual, user-initiated, logout
- > Timed logout after a user-defined period of inactivity in the Command Line Interface
- File transfer operation including a device software update
- Configuration changes using HiDiscovery
- > Automatic configuration or device software updates using the external memory
- Blocked access to the device management due to invalid login
- Rebooting
- Opening and closing SNMP over HTTPS tunnels
- Detected power failures

14.13 Network analysis with TCPdump

Tcpdump is a packet-sniffing UNIX utility used by network administrators to sniff and analyze the data stream on a network. A couple of reasons for sniffing data streams on a network are to verify connectivity between hosts or to analyze the data stream traversing the network.

TCPDump in the device provides the possibility to decode or capture packets received and transmitted by the Management CPU. This function is available using the debug command. For further information on the TCPDump function, see the "Command Line Interface" reference manual.

14.14 Monitoring the data stream with Port Mirroring

The *Port Mirroring* function lets you copy data packets from physical source ports to a physical destination port. Port Mirroring is also known as Switched Port Analyzer (SPAN).

You monitor the data packets on the source ports in the sending and receiving directions with a management tool connected on the destination port, for example an *RMON probe*. The function has no effect on the data stream running on the source ports.




Figure 87: Application example of a port-mirroring setup

On the destination port, the device only forwards the data packets copied from the source ports.

Before you switch on the *Port Mirroring* function, mark the checkbox *Allow management* to access the device management through the destination port. The device lets users access the device management through the destination port without interrupting the active *Port Mirroring* session.

Note: The device duplicates multicasts, broadcasts and unknown unicasts on the destination port.

The VLAN settings on the destination port remain unchanged. Prerequisite for access to the device management on the destination port is that the destination port is a member of the device management VLAN.

14.14.1 Peculiarities in connection with redundancy protocols (depends on hardware)

Fast MRP

 If you select a Fast MRP ring port as a Port Mirroring source port, the source port will not mirror sent MRP test packets.

HSR

- To monitor the data stream on HSR ports, specify the *source port* 1/1. On the *source port* 1/1, the *Port Mirroring* function records:
 - Data packets entering the HSR network from the outside through the device
 - Data packets after duplicate recognition that leave the HSR network through the device
- The *Port Mirroring* function does not record *link-local frames* that protocols such as LLDP work with.

PRP

- To monitor the data stream on PRP ports, specify the *source port* 1/1. On the *source port* 1/1, the *Port Mirroring* function records:
 - Data packets entering the PRP network from the outside through the device
 - Data packets after duplicate recognition that leave the PRP network through the device
- The *Port Mirroring* function does not record *link-local frames* that protocols such as LLDP work with.

14.14.2 Enabling the Port Mirroring function

Perform the following steps:

- □ Open the *Diagnostics* > *Ports* > *Port Mirroring* dialog.
- Specify the source ports.
 Mark the checkbox in the *Enabled* column for the relevant ports.
- Specify the destination port.
 In the *Destination port* frame, select the desired port from the *Primary port* drop-down list.
 The drop-down list only displays available ports. Ports that are already specified as source ports are unavailable.
- □ To access the device management through the destination port: In the *Destination port* frame, mark the *Allow management* checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

To deactivate the *Port Mirroring* function and restore the default settings, click the **b**utton.

14.15 Monitoring the data stream with VLAN mirroring

The VLAN mirroring function lets you mirror the received data stream that matches a specific VLAN to a selected destination port. The device only copies the data on the VLAN, and sends the original data to the intended recipients. For example, the device can mirror data to a network analyzer connected to the destination port.

Only one of the functions, either the *VLAN mirroring* function or the *Port Mirroring* function, can be active at the same time. When you select VLAN 0 as the source VLAN, the *VLAN mirroring* function is inactive. To disable the *VLAN mirroring* function, unmark the checkbox in the *Enabled* column for the source port.

If the data stream received on the mirrored VLAN exceeds the maximum bandwidth of the destination port, then the device drops some packets to accommodate the maximum bandwidth of the destination port. Even though the device drops some packets, the device continues to mirror packets that match the specified VLAN.

When you specify the PVID on a port as the source VLAN ID, the device mirrors the untagged packets received, but without a VLAN tag. In this case, the device mirrors the packet exactly as it received the packet.

14.15.1 Application example for the VLAN mirroring function

In this application example, Sw 4 mirrors data received on VLAN 20 to a network analyzer on the destination port.

To set up VLAN mirroring on Sw 4, use the following steps:

- □ Add the VLAN you want to mirror.
- Set up VLAN mirroring




Figure 88: Application example of a VLAN mirroring setup

Perform the following steps:

 Open the Switching > VLAN > Configuration dialog.
 Add the VLAN:
 Click the \u03c4 the button. The dialog displays the Create window.
 In the VLAN ID field, specify the value 20.
 Click the Ok button.
 In the Name column, specify the value VLAN mirroring port.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

- □ Open the *Diagnostics* > *Ports* > *Port Mirroring* dialog.
- Deactivating the *Port Mirroring* function:
 Unmark every checkbox in the *Enabled* column.
- Specifying the destination port: In the *Destination port* frame, specify the value 3/4.
- Specifying the data source: In the VLAN mirroring frame, Source VLAN ID field, specify the value 20.
- \Box To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
vlan add 20	To add VLAN 20.
name 20 VLAN mirroring port	To assign the name 20 to the VLAN VLAN mirroring port.
exit	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
monitor session 1 source vlan 20	To add VLAN mirroring session 1, the source is VLAN 20.
monitor session 1 destination interface 3/4	To specify port $3/4$ as the destination port.
monitor session 1 mode	To activate VLAN mirroring session 1.

14.16 Monitoring data streams with RSPAN

RSPAN (Remote Switched Port Analyzer) extends the concept of Switched Port Analyzer (SPAN), which is also called Port Mirroring.

In contrast to SPAN, which operates on a single switch device, RSPAN uses a topology of 2 or more RSPAN-enabled devices. This lets you analyze the data stream at a location other than directly at the source.

14.16.1 Purpose

RSPAN lets a network administrator collect data packets from selected locations in a network and monitor the mirrored data packets at a convenient location.

The data packets are collected by one or more devices acting in the *source role*. These so-called *source devices* collect data packets from selectable *source ports* or from a selectable *source VLAN*. A *source device* can have several *source ports* but only one *source VLAN*.

Each RSPAN-enabled device receives and forwards the mirrored data packets on a specified RSPAN VLAN to the final destination. This includes optional devices in an *intermediate role*, so-called *intermediate devices*.

Finally, a device in the *destination role*, a so-called *destination device*, sends the mirrored data packets to its local *destination port*. An analyzer tool, usually a dedicated computer, can then monitor or analyze the mirrored data packets at a convenient, for example, central location.

RSPAN key aspects are:

- Topology
- An RSPAN topology consists of 2 or more RSPAN-enabled devices.
- See "RSPAN topologies" on page 353.
- VLAN

The RSPAN VLAN transfers the mirrored data packets between RSPAN-enabled devices. See "RSPAN VLAN properties" on page 356.

Roles

RSPAN roles are specific roles for the devices in an RSPAN topology. See "RSPAN device roles" on page 357.

Uplinks
 DODANL un links

RSPAN uplinks can be separate uplinks or shared with normal uplinks. See "RSPAN uplinks" on page 359.

14.16.2 **RSPAN** topologies

RSPAN topologies and the consequential locations of the devices in RSPAN roles can be:

- Line topology
- Tree topology
- Ring topology

Line topology

An RSPAN line topology is a simple line structure, superimposed on the existing network. The underlying network may have a more generalized topology, for example, a tree topology.




Figure 89: Example of a line topology, using a reflector port (with separate uplinks)




Figure 90: Example of a line topology, without a reflector port (with separate uplinks)

A line topology is a simple topology, where only one *source* and one *destination* device are required, and *intermediate devices* are optional:

- One source device
- The source device is located at one end of the line, at the data sources to be mirrored.
- One destination device
- The *destination device* is located at the other end of the line, near the analyzer tool. Optional *intermediate devices*
- The *intermediate devices* are located in the middle of the line, between the *source device* and the *destination device*. You can connect the *source device* directly to the *destination device*, if your situation allows.

The graphics show separate uplinks for RSPAN and non-RSPAN data packets.

You can also create shared uplinks. For this, you use the normal (non-RSPAN) uplinks also for RSPAN. To create shared uplinks, select the existing, non-RSPAN uplink ports as RSPAN ports.

Tree topology

An RSPAN tree topology is a tree structure, superimposed on the existing network. The underlying network may have a more generalized topology, for example, a mesh topology.




Figure 91: Example of a complex tree topology, using reflector ports (with separate uplinks)




Figure 92: Example of a complex tree topology, without reflector ports (with separate uplinks)

A tree topology consists of:

- 2 or more source devices
- The *source devices* are located at the leaves of the tree, at the data sources to be mirrored. • One *destination device*
- The *destination device* is located at the root of the tree, near the analyzer tool. • Optional *intermediate devices*

The *intermediate devices are* located as nodes in the middle of the tree, between the *source device* and the *destination device*. You can connect the *source devices* directly to the *destination device*, if your situation allows.

Tree topology subtypes:


- Simple tree topology:
- A simple tree topology requires only one *destination* and several *source devices*. *Intermediate* devices are optional, and the topology requires no *combined source/intermediate devices*.
- Complex tree topology: A complex tree topology requires additionally one or more *combined source/intermediate devices*. See "Combined source/intermediate role" on page 358.


The graphics show separate uplinks for RSPAN and non-RSPAN data packets.

You can also create shared uplinks. For this, you use the normal (non-RSPAN) uplinks also for RSPAN. To create shared uplinks, select the existing, non-RSPAN uplink ports as RSPAN ports.

Ring topology

An RSPAN ring topology is a ring structure, superimposed on the existing network. The underlying network may have a more generalized topology, for example, coupled rings.





A ring topology consists of:

- In the ring:
 - One source device
 The source device is located in the ring, at the data sources to be mirrored.
 The source device has 2 destination ports and needs a reflector port.
 - One or more *intermediate devices*
 - One of the *intermediate devices* forwards the RSPAN data packets out of the ring. In the following, this device is called the ring exit device.
 - The other *intermediate devices* are located in the ring, between the *source device* and the ring exit device.
 - The intermediate devices have one RSPAN VLAN membership port each.
- Outside the ring:
 - One destination device
 - The *destination device is* located outside the ring, near the analyzer tool.
 - You can connect the ring exit device directly to the *destination device*, if your situation allows. Optional *intermediate devices*
 - These optional *intermediate devices* connect the ring exit device to the *destination device*.

When setting up the RSPAN VLAN membership ports of the *intermediate devices* in the ring, consider the following data packet stream scenarios to the ring exit device:

- The regular RSPAN data packet stream, with the ring intact and the redundancy port blocked
- The alternate RSPAN data packet stream, with the ring interrupted and the redundancy port active

Note: The special case where the *source device* is also the ring exit device, is considered a line topology.

Ring topology subtypes:

- Simple ring topology
- A simple ring topology requires only *source, intermediate*, and *destination* devices, but no *combined source/intermediate devices*.
- Complex ring topology
- A complex ring topology additionally requires one or more *combined source/intermediate devices*. See "Combined source/intermediate role" on page 358.

14.16.3 RSPAN VLAN properties

The flow of mirrored data packets within the RSPAN VLAN is unidirectional towards the *destination port* of the *destination device*. Consequently, the devices disable source MAC address learning in the RSPAN VLAN and flood the mirrored data packets within the RSPAN VLAN. Because of this, only the RSPAN *destination ports* have to be set up as a members of the RSPAN VLAN.

In contrast, ports receiving RSPAN data packets are not members of the RSPAN VLAN.

The destination ports of a source device send RSPAN data packets in the following way:

- The device adds a single RSPAN VLAN tag to untagged source data packets.
- The device inserts an additional RSPAN VLAN tag into tagged source data packets. This results in double VLAN tagged data packets. The device inserts the RSPAN VLAN tag as the first VLAN tag (outer tag, EtherType 0x8100).

14.16.4 **RSPAN** device roles

The possible RSPAN roles in a topology have the following names, instances, functions, and specific settings:

- Destination role
- Source role
- Intermediate role
- Combined source/intermediate role

Destination role

The *destination role* is mandatory and requires exactly one instance in an RSPAN topology.

- A destination device has its destination port connected to an analyzer tool.
- In a tree topology, the destination device is the root of the tree.
- In a redundant ring, place the *destination device* outside the ring. This makes the setup of the *destination device* easier. See "Use of underlying redundancy protocols" on page 360.

The *destination device* receives the mirrored data packets on the RSPAN VLAN, either directly from the *source devices*, or indirectly through *intermediate devices*.

The destination port has the following properties:

- On a destination device, you can set up exactly one destination port.
- The *destination port* usually keeps the RSPAN VLAN tag when sending a data packet to the analyzer tool.
- If desired, the *destination port* can also strip the RSPAN VLAN tag.
 - For a tagged source data packet, this restores the original VLAN tag.
 - For an untagged source data packet, this restores the original untagged data packet.

Source role

The *source role* is mandatory and needs one or more instances in an RSPAN topology. A *source device* only collects data packets from *source ports* or a *source VLAN*. A pure *source device* has no ports that receive RSPAN data packets from other devices. For a *combined source/intermediate device*, see "Combined source/intermediate role" on page 358.

The *source device* collects the data packets it receives or sends on its selected local *source ports* or its selected *source VLAN*. The device forwards the mirrored data packets on the RSPAN VLAN, either directly to the *destination device*, or to an *intermediate device*.

- The source device supports one destination port without the need for a reflector port.
- To set up a source device with 2 destination ports, set up a reflector port. A possible use case is a source device in a ring redundancy topology. See "Use of underlying redundancy protocols" on page 360.
- The *destination port* adds the RSPAN VLAN tag when sending the data packet.

Note: If you do not use a *reflector port*, the device automatically adds an RSPAN VLAN tag to the source data packets regardless of the *destination port's* tag setting T (tagged) or U (untagged). Therefore, you do not need to set up this *destination port* as a RSPAN VLAN member.

Intermediate role

Depending on the RSPAN topology, the *intermediate role* has the following number of instances: *Table 47: Intermediate role instances, by topology*

Topology	Subtype	Intermediate role instances
Line	-	optional
Tree	simple	optional
	complex	optional
Ring	simple	one or more
	complex	one or more

For an *intermediate device*, you only need to set up the RSPAN VLAN. The device does not need any specific RSPAN settings.

An *intermediate device* has one or more ports that receive RSPAN data packets but neither *source ports* nor a *source VLAN*.

An *intermediate device* receives the mirrored data packets on the RSPAN VLAN and forwards the mirrored data packets. When sending the data packets, the *destination port* keeps the RSPAN VLAN tag.

Note: Verify that the ports receiving the mirrored data packets are not members of the RSPAN VLAN.

Combined source/intermediate role

Depending on the RSPAN topology, the *combined source/intermediate device* has the following number of instances:

Table 48:	Combined source/intermediate role instances, by topology
-----------	----------------------------------------------------------

Topology	Subtype	Combined source/intermediate role instances	
Line	-	-	
Tree	simple	none	
	complex	one or more	
Ring	simple	none	
	complex	one or more	

A combined source/intermediate device integrates the functions of a source device with that of an intermediate device:

- The combined source/intermediate device is located at the nodes of the topology tree, like intermediate devices.
- The device collects the data packets it receives or sends on its selected local source ports or a selected source VLAN.
- The device forwards the mirrored data packets, either directly to the *destination device*, or to another *intermediate device* towards the *destination device*. When sending the data packets, the *destination port* adds the RSPAN VLAN tag to the source data packets.
- The device additionally receives mirrored data packets on one or more additional ports, either directly from one or more source devices, or from one or more other *intermediate devices*.
- The device forwards the mirrored data packets, either directly to the *destination device*, or to another *intermediate device* towards the *destination device*. When sending the data packets, the *destination port* keeps the RSPAN VLAN tag in the received mirrored data packets.

- The device requires specific source device settings in addition to the RSPAN VLAN settings of an intermediate device.
- The device supports one *destination port* without the need for a *reflector port*.
- To set up the device with 2 destination ports, use a reflector port. A possible use case is a source device in a ring redundancy topology. See "Use of underlying redundancy protocols" on page 360.

Note: Due to the nature of a *combined source/intermediate device*, you need to set up the RSPAN VLAN membership of the *destination port* even if you do not use a *reflector port*.

14.16.5 **RSPAN** uplinks

For a shared RSPAN uplink, the *source device* or *intermediate device* send the mirrored data packets over an existing, normal uplink.

- You do not need to connect an additional cable.
- A shared uplink is necessary if you want to use the device as a *source device* or *intermediate device* in a ring redundancy topology.
- If the combined data rate of the RSPAN and non-RSPAN data packets exceeds the bandwidth of the shared uplink, RSPAN data packets and non-RSPAN data packets may affect each other. See "Packet prioritization" on page 362.

For a separate RSPAN uplink, the *source device* or *intermediate device* send the mirrored data packets over a separate connection different from the existing uplink.

- This requires an extra cable connection.
- A separate RSPAN uplink provides an exclusive path for RSPAN data packets. Consequently, the non-RSPAN data packets on their uplink are unaffected by the RSPAN data packets on the separate uplink.

For both uplink types, the RSPAN ports may require individual *Spanning Tree* settings. See "Use of underlying redundancy protocols" on page 360.

14.16.6 Reflector port on a source device

The *reflector port* in a *source device* has a special function without a physical connection. The *reflector port* internally receives the mirrored data packets and reflects (mirrors) them into the RSPAN VLAN instead of sending them. This way, the *reflector port* transforms the function of local Switched Port Analyzer (SPAN), or *Port Mirroring*, into the remote function, RSPAN.

A source device supports a reflector port for one or more destination ports as well as one destination port without the need for a reflector port.

You use a *reflector port* to set up a *source device* with 2 *destination ports*. A possible use case is a *source device* in a ring redundancy topology. See "Use of underlying redundancy protocols" on page 360.

Note: A setup, where the reflector port has a link, is unsupported.

14.16.7 Use of underlying redundancy protocols

You can use RSPAN in combination with the following redundancy protocols:

- Ring redundancy
- Link Aggregation
- Spanning Tree

Ring redundancy

RSPAN-enabled devices can forward RSPAN data packets over an underlying ring redundancy topology. Each ring connection serves as an RSPAN uplink between the *source device* and the directly connected *intermediate devices*, as well as between the other *intermediate devices*. This creates a redundant, shared RSPAN uplink.

A ring topology requires shared uplinks. The participating devices transmit the RSPAN data packets together with the other packets over their ring ports.

Note: The RSPAN roles are independent of the ring redundancy roles like *ring switch* and *ring manager*. However, there are recommendations which of the ring redundancy participants are best used as an *RSPAN source device*.

Planning RSPAN device roles and their setup in a redundant ring:

- □ Place the *destination device* outside the ring.
 - This makes the setup of the *destination device* easier.
- □ If possible, use the one of the following *ring redundancy devices* as the RSPAN *source device*:
 - The ring manager
 - The ring switch connected to the blocked port of the ring manager

This minimizes the flooding of mirrored data packets into paths not leading to the ring exit device, because the *ring manager* blocks one of these paths in the regular case.

- If you cannot use one of the above mentioned ring redundancy devices as the *source device*, flooding of mirrored data packets into paths not leading to the ring exit device is inevitable. Weigh up the advantages and disadvantages for your specific use case.
- □ If you plan a complex ring topology, you will need at least one *combined source/intermediate device* in addition to the *source device*. The same recommendations apply as for the simple ring topology which ring participants are best used as *source devices* or *combined source/intermediate devices*.
- On the source device, set up both ring ports as destination ports.
 Use a reflector port.
- □ On the *intermediate devices* in the ring:
 - Determine the device that sends the mirrored data packets out of the ring.
 In the following, this device is called the ring exit device.
 - For the ring exit device, set up the port leading out of the ring as an RSPAN VLAN member.
 - For the other *intermediate devices* on the path to the ring exit device, set up the ring ports connected to the next *intermediate device* or the ring exit device as an RSPAN VLAN member. Consider both data packet stream scenarios: with the ring intact and with the ring interrupted.

Link Aggregation

On the source device:

- If you set up a *reflector port*, the device can forward RSPAN data packets over a *Link Aggregation Group* (*LAG*).
- On a source device without a reflector port, the destination port needs to be a physical port.

The destination port of the destination device needs to be a physical port.

Spanning Tree

For shared RSPAN uplinks based on a mesh topology with *Spanning Tree* (*STP*, *RSTP*, or *MSTP*), RSPAN requires no further *Spanning Tree* settings.

If you use separate RSPAN uplinks, deactivate the *Spanning Tree* function on the ports for the separate RSPAN uplinks.

For shared RSPAN uplinks based on a mesh topology with *MSTP*: Verify that the RSPAN topology matches the underlying *MSTP* topology for the RSPAN VLAN ID.

If you want RSPAN to use the redundant paths provided by *Spanning Tree*, consider setting up a RSPAN topology similar to a ring topology. This means:

- The source device may require 2 or more destination ports and then require a reflector port.
- The intermediate devices may require 2 or more RSPAN VLAN membership ports.

In the above case, the use of redundant RSPAN paths will result in the mirrored data packets being flooded into paths that lead to the *destination device*, but these paths are blocked by the redundancy protocol in the regular case. Weigh up the advantages and disadvantages for your specific use case.

14.16.8 Peculiarities in connection with redundancy protocols (depends on hardware)

Fast MRP

 If you select a Fast MRP ring port as an RSPAN source port, the source port will not mirror sent MRP test packets.

HSR

- To monitor the data stream on HSR ports, specify the *source port* 1/1. On the *source port* 1/1, the *RSPAN* function records:
 - Data packets entering the HSR network from the outside through the device
 - Data packets after duplicate recognition that leave the HSR network through the device
- The RSPAN function does not record link-local frames that protocols such as LLDP work with.

PRP

- To monitor the data stream on PRP ports, specify the *source port* 1/1. On the *source port* 1/1, the *RSPAN* function records:
 - Data packets entering the PRP network from the outside through the device
 - Data packets after duplicate recognition that leave the PRP network through the device
- The RSPAN function does not record link-local frames that protocols such as LLDP work with.

14.16.9 Packet prioritization

The *source device* sends the mirrored data packets with the fixed *CoS priority* of 0 (best effort) in the VLAN tag.

If the combined data rate of the RSPAN and non-RSPAN data packets exceeds the bandwidth of the shared uplink, RSPAN data packets and non-RSPAN data packets may affect each other.

If you cannot tolerate a loss of non-RSPAN data packets and cannot solve this situation by other means, consider VLAN-tagging your non-RSPAN data packets and assign a *CoS priority* of 2 (excellent effort) or higher to minimize the impact of RSPAN data packets on non-RSPAN data packets.

14.16.10 Starting point for the examples

The network administrator wants to monitor specific data packets using a network analyzer tool located at a central location in the network. The options for setting up RSPAN devices in an existing network are illustrated below.

Boundary conditions:

- Device 1 collects the data packets from PC 1 on port 1/2.
- The analyzer tool, which data accepts packets with a single or a double VLAN tag, is connected to device 3, port 3/3.
- The devices 1 and 3 are connected by device 2. The RSPAN topology therefore is a simple line.
- For a possible separate uplink, the devices 1, 2 and 3 have unused ports available and a physical network connection is available between the devices 1 and 2, as well between the devices 2 and 3.
- The devices in the RSPAN topology are RSPAN-capable.

Setup options chosen by the network administrator:

- Separate or shared RSPAN uplinks are both possible and will be decided later.
- The RSPAN VLAN ID for the examples is 30.
- Use PC 2 to set up RSPAN in the devices.

RSPAN data rate and connection bandwidth:

- For separate RSPAN uplinks:
 - Depending on the data rate of the RSPAN data packets and the bandwidth of the RSPAN connections, the device may drop some RSPAN data packets.
- For shared RSPAN uplinks:
 - Depending on the combined data rate of RSPAN and non-RSPAN data packets and the bandwidth of the shared connections, RSPAN and non-RSPAN data packets may affect one another.
- To address this, use connections with sufficient bandwidth, for example, Gigabit ports, LAG interfaces, or a combination thereof.

Note: If you set up a *source device* without a *reflector port*, the *destination port* of the *source device* needs to be a physical port.

14.16.11 Example: RSPAN with a reflector port

In the following example, you set up a simple RSPAN line topology, using a *reflector port* on the *source device*. There are 2 options, either with separate or with shared uplinks.




Figure 94: RSPAN in a line topology, using a reflector port (with separate uplinks)





Figure 95: RSPAN in a line topology, using a reflector port (with shared uplinks)

The work steps are the same for both options. The only difference is which ports make up the existing uplink for non-RSPAN packets.

- For a separate uplink, the existing uplink for non-RSPAN packets connects ports 1/3 and 2/2 and ports 2/4 and 3/2 respectively. The work steps will create a separate uplink for RSPAN packets after you physically connect the respective RSPAN ports.
- For a shared uplink, the existing uplink for non-RSPAN packets connects ports 1/1 and 2/1 and ports 2/3 and 3/1 respectively. The work steps will then create a shared uplink for RSPAN packets and non-RSPAN packets.

Setting up device 1 as the source device

- \Box Open the *Switching* > *VLAN* > *Configuration* dialog.
- □ Add the RSPAN VLAN:
 - Click the $\overset{\blacksquare}{+}$ button.
 - The dialog displays the Create window.
 - In the VLAN ID field, specify the value 30.
 - Click the Ok button.
 - In the VLAN 30 table row, *RSPAN VLAN* column, mark the checkbox.
- □ Specify the port connected to the *intermediate device*.
 In the VLAN 30 table row, column of port 1/1, select the T item from the drop-down list.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Diagnostics* > *Ports* > *RSPAN* dialog.



monitor session 1 remote-vlan 30
reflector-port 1/4

monitor session 1 mode enable
exit

To activate the remote port mirroring session 1.

To change to the Privileged EXEC mode.

port 1/4 as the reflector port to session 1.

Setting up device 2 as the intermediate device

Perform the following steps:


- □ Open the Switching > VLAN > Configuration dialog.
- Add the RSPAN VLAN:
 - Click the $\overset{\blacksquare}{+}$ button.
 - The dialog displays the Create window.
 - In the VLAN ID field, specify the value 30.
 - Click the Ok button.
 - In the VLAN 30 table row, RSPAN VLAN column, mark the checkbox.
- □ Specify the port connected to the *destination device*. In the VLAN 30 table row, column of port 2/3, select the T item from the drop-down list.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
vlan add 30	To add VLAN 30.
remote-vlan 30	To specify VLAN 30 as the RSPAN VLAN ID.
exit	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 2/3	To change to the Interface Configuration mode of the <i>destination port</i> , interface 2/3.
vlan participation include 30	To make port 2/3 a member in the RSPAN VLAN 30.
vlan tagging 30	To send tagged data packets for the RSPAN VLAN 30.
exit	To change to the Configuration mode.

Setting up device 3 as the destination device


- □ Open the Switching > VLAN > Configuration dialog.
- Add the RSPAN VLAN:


 - Click the # button.
 The dialog displays the *Create* window.
 - In the VLAN ID field, specify the value 30.
 - Click the Ok button.
 - In the VLAN 30 table row, RSPAN VLAN column, mark the checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Diagnostics* > *Ports* > *RSPAN* dialog.
- □ Specify the *destination role*. In the Role frame, select the Destination switch item from the drop-down list.



14.16.12 Example: RSPAN without a reflector port

In the following example, you set up a simple RSPAN line topology, without a *reflector port* on the *source device*. There are 2 options, either with separate or with shared uplinks.








Figure 97: RSPAN in a line topology, without a reflector port (with shared uplinks)

The work steps are the same for both options. The only difference is which ports make up the existing uplink for non-RSPAN packets.

- For a separate uplink, the existing uplink for non-RSPAN packets connects ports 1/3 and 2/2 and ports 2/4 and 3/2 respectively. The work steps will create a separate uplink for RSPAN packets after you physically connect the respective RSPAN ports.
- For a shared uplink, the existing uplink for non-RSPAN packets connects ports 1/1 and 2/1 and ports 2/3 and 3/1 respectively. The work steps will then create a shared uplink for RSPAN packets and non-RSPAN packets.

Setting up device 1 as the source device

- □ Open the Switching > VLAN > Configuration dialog.
- Add the RSPAN VLAN:
- Click the $\stackrel{\textbf{IIII}}{\rightarrow}$ button. The dialog displays the *Create* window.
 - In the VLAN ID field, specify the value 30.
 - Click the Ok button.
 - In the VLAN 30 table row, RSPAN VLAN column, mark the checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Diagnostics* > *Ports* > *RSPAN* dialog.
- Specify the source role. In the Role frame, select the Source switch item from the drop-down list.
- Specify the RSPAN VLAN ID. In the RSPAN frame, RSPAN Destination VLAN ID field, specify the value 30.
- Specify the Source port. In the row of port 1/2, Active column, mark the checkbox.
- □ Specify the type of the data packets to be mirrored. In the row of port 1/2, Type column, select the txrx item from the drop-down list.
- □ Specify the *destination port*. In the *Destination port* frame, select port 1/1 from the *Destination port* drop-down list.
- Enable the function. In the Operation frame, select the On radio button.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
vlan add 30	To add VLAN 30.
remote-vlan 30	To specify VLAN 30 as the RSPAN VLAN ID.
exit	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
monitor session 1 source interface 1/2 operation enable	To add port 1/2 as a <i>source port</i> to session 1.
<pre>monitor session 1 source interface 1/2 direction txrx</pre>	To specify the type of the data packets to be mirrored on port $1/2$ as txrx in session 1.

monitor session 1 remote-vlan 30
monitor session 1 remote-vlan 30
destination port 1/1

monitor session 1 mode enable

To use VLAN 30 as the RSPAN VLAN in session 1. To add VLAN 30 as the RSPAN VLAN, and to add port 1/1 as the *destination port* to session 1. To activate the remote port mirroring session 1.

Setting up device 2 as the intermediate device

- \Box Open the *Switching* > *VLAN* > *Configuration* dialog.
- □ Add the RSPAN VLAN:
 - Click the $\overset{\blacksquare}{+}$ button.
 - The dialog displays the Create window.
 - In the VLAN ID field, specify the value 30.
 - Click the Ok button.
 - In the VLAN 30 table row, RSPAN VLAN column, mark the checkbox.
- Specify the port connected to the *destination device*.
 In the VLAN 30 table row, column of port 2/3, select the T item from the drop-down list.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
vlan add 30	To add VLAN 30.
remote-vlan 30	To specify VLAN 30 as the RSPAN VLAN ID.
exit	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 2/3	To change to the Interface Configuration mode of the <i>destination port</i> , interface 2/3.
vlan participation include 30	To make port 2/3 a member in the RSPAN VLAN 30.
vlan tagging 30	To send tagged data packets for the RSPAN VLAN 30.
exit	To change to the Configuration mode.

Setting up device 3 as the destination device

- □ Open the *Switching* > *VLAN* > *Configuration* dialog.
- Add the RSPAN VLAN:
 - Click the $\overset{\blacksquare}{+}$ button.
 - The dialog displays the *Create* window.
 - In the VLAN ID field, specify the value 30.
 - Click the Ok button.
 - In the VLAN 30 table row, *RSPAN VLAN* column, mark the checkbox.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Diagnostics* > *Ports* > *RSPAN* dialog.
- Specify the *destination role*.
 In the *Role* frame, select the *Destination switch* item from the drop-down list.
- Specify the RSPAN VLAN.
 In the RSPAN frame, RSPAN Source VLAN ID field, specify the value 30.
- Specify the destination port.
 In the Destination port frame, select port 3/3 from the Destination port drop-down list.
- Enable the function.
 In the *Operation* frame, select the *On* radio button.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
vlan add 30	To add VLAN 30.
remote-vlan 30	To specify VLAN 30 as the RSPAN VLAN ID.
exit	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
<pre>monitor session 1 destination interface 3/ 3</pre>	To add port 3/3 as the <i>destination port</i> to session 1.
monitor session 1 source remote-vlan 30	To add VLAN 30 as the RSPAN VLAN to session 1.
monitor session 1 mode enable	To activate the remote port mirroring session 1.

14.17 Self-test

The device checks its assets during the system startup and occasionally thereafter. The device checks system task availability or termination and the available amount of memory. Furthermore, the device checks for application functionality and any hardware degradation in the chip set.

If the device detects a loss in integrity, then the device responds to the degradation with a userdefined action. The following categories are available for configuration.

- task
 - Action to be taken in case a task is unsuccessful.
- resource

Action to be taken due to the lack of resources.

software

Action taken for loss of software integrity; for example, code segment checksum or access violations.

hardware

Action taken due to hardware degradation

Set up each category to produce an action in case the device detects a loss in integrity. The following actions are available for configuration.

log only

This action writes a message to the logging file.

send trap

Sends an SNMP trap to the trap destination.

reboot

If activated, then a detected error in the category will cause the device to reboot.

Perform the following steps:

- □ Open the *Diagnostics* > *System* > *Selftest* dialog.
- □ In the *Action* column, specify the action to perform for a cause.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
selftest action task log-only	To send a message to the event log when a task is unsuccessful.
selftest action resource send-trap	To send an SNMP trap when there are insufficient resources.
selftest action software send-trap	To send an SNMP trap when the software integrity has been lost.
selftest action hardware reboot	To reboot the device when hardware degradation occurs.

Disabling these functions lets you decrease the time required to restart the device after a cold start. You find these options in the *Diagnostics* > *System* > *Selftest* dialog, *Configuration* frame.

```
RAM test checkbox
```

Activates/deactivates RAM selftest during a cold start.

- SysMon1 is available checkbox Activates/deactivates System Monitor 1 during a cold start.
- Load default config on error checkbox Activates/deactivates the loading of the default device configuration in case no readable configuration is available during the system startup.

The following settings <u>block your access to the device permanently</u> in case the device does not detect any readable configuration profile at system startup.

- ▶ The SysMon1 is available checkbox is unmarked.
- ▶ The Load default config on error checkbox is unmarked.

This is the case, for example, when the password of the configuration profile that you are loading differs from the password set in the device. To have the device unlocked again, contact your sales partner.

selftest ramtest	To activate RAM selftest on cold start.
no selftest ramtest	To deactivate RAM selftest.
selftest system-monitor	To activate System Monitor 1.
no selftest system-monitor	To deactivate System Monitor 1.
show selftest action	To display the actions to be taken in the event of device degradation.
Cause Action	
task reboot	
resource reboot	
software reboot	
hardware reboot	
show selftest settings	To display the selftest settings.
Selftest settings	
Test RAM on cold startenabled	
System Monitor 1	
Boot default configuration on error	

14.18 Copper cable test

Use this function to check a copper cable attached to a port for a short or open circuit. The test interrupts the data stream, when in progress, on this port.

The table displays the state and lengths of each individual pair. The device returns a result with the following meaning:

- normal indicates that the cable is operating properly
- open indicates an interruption in the cable
- short circuit indicates a short circuit in the cable
- untested indicates an untested cable
- Unknown cable unplugged

14.19 Network monitoring with sFlow

SFlow is a standard protocol for monitoring networks. The device provides this function for visibility into network activity, enabling effective management and control of network resources.

The *SFlow* monitoring system consists of an *SFlow* agent, embedded in the device and a central *SFlow* collector. The agent uses sampling technology to capture the data packet statistics. *SFlow* instances associated with individual data sources within the agent perform packet flow and counter sampling. Using *SFlow* datagrams the agent forwards the sampled data packet statistics to an *SFlow* collector for analysis.

The agent uses 2 forms of sampling, a statistical packet based sampling of packet flows and a timed based sampling of counters. An *SFlow* datagram contains both types of samples. Packet flow sampling, based on a sampling rate, sends a steady, but random stream of datagrams to the collector. For time-based sampling, the agent polls the counters at set intervals to fill the datagrams.

The device implements datagram version 5 for the SFlow agent.

The user-defined *SFlow* functions are:

- Sampler configuration, packet flow sampling:
 - data source port number, to sample physical ports
 - receiver index associated with the sampler
 - Sampling rate
 - The device counts the packets of received data. When the count reaches the user-defined number, the agent samples the packet.
 - Range: 256..65535
 - Ø = function inactive
 - Header size in bytes to sample Range: 20..256
- Poller configuration, counter sampling:
 - data source port number, available for physical ports
 - receiver index associated with the poller
 - Interval, in seconds, between samples Range: 0..86400 (1 d)
- Receiver configuration, up to 8 entries:
 - Owner name, to claim an *SFlow* entry
 - timeout, in seconds, until sampling is stopped and the device releases the receiver along with the sampler and the poller
 - datagram size
 - IP address
 - port number

To set up the *SFlow* agent for a monitoring session, first set up an available receiver. Then, set up a sampling rate to perform packet flow sampling. Additionally, set up a polling interval for counter sampling.

For example, Company XYZ wishes to monitor data flow on a device. The IP address for the remote server containing the sFlow collector, is 10.10.10.10. XYZ requires a sample of the first 256 bytes of every 300th packet. Furthermore, XYZ requires counter polling every 400 s.

Perform the following steps:

- □ Open the *Diagnostics* > *SFlow* > *Receiver* dialog.
- □ For the name of the person or organization controlling the receiver, enter the value XYZ in the *Name* column.
- □ For the remote server IP address, on which the *SFlow* collector software runs, specify the value 10.10.10.10 in the *IP address* column.
- □ Open the *Diagnostics* > *SFlow* > *Configuration* dialog, *Sampler* tab.
- □ In the *Receiver* column, select the index number of the receiver specified in the previous steps.
- □ In the *Sampling rate* column, specify the value 300.
- □ In the *Max. header size [byte]* column, specify the value 256.
- □ Open the *Diagnostics* > *SFlow* > *Configuration* dialog, *Poller* tab.
- □ In the *Receiver* column, select the index number of the receiver specified in the previous steps.
- □ In the *Interval* [s] column, specify the value 400.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
sflow receiver 1 owner XYZ ip 10.10.10.10	To set up an SFlow receiver
interface 1/1	To change to the interface configuration mode of interface 1/1.
sflow sampler receiver 1 rate 300	To assign the <i>SFlow</i> sampler on the port to the previously specified receiver with a sampling rate of 300.
sflow sampler maxheadersize 256	To set up the maximum header size of the <i>SFlow</i> sampler to the value 256.
sflow poller receiver 1interval 400	To assign the <i>SFlow</i> poller to the previously specified receiver and to sample data for 400 s.

15 Advanced functions of the device

15.1 DHCP server

The Dynamic Host Configuration Protocol (DHCP) lets a server assign the IP settings to the devices on the network (clients). This reduces the effort required for manual setup. The DHCP server stores and assigns the available IP addresses and further settings, if specified.

The procedure for assigning the IP settings consists of 4 phases:

- DISCOVER sent by the DHCP client
- OFFER sent by the DHCP server
- *REQUEST* sent by the DHCP client
- ACKNOWLEDGE sent by the DHCP server

The DHCP server in the device listens for requests on UDP port 67 and responds to the client devices on UDP port 68. When the device receives a DHCP request, it validates the IP address to be assigned before leasing the IP address and other IP settings to the requesting client device.

The device lets you activate the DHCP Server function globally or on single physical ports.

15.1.1 Settings that the server assigns to the clients

When operating as a DHCP server, the device assigns the IP settings to the client devices based on the following parameters:

- MAC address of the client device
- Physical port to which the client device is connected
- VLAN of which the client device is a member

The device assigns the following IP settings to the client devices:

- IP address
- Subnet mask
- Default gateway, if specified
- Further network settings, if specified

15.1.2 **Pools**

The device stores the IP settings in two types of pools.

- Static pools
- To assign the same IP address to a specific device each time, the device stores the relevant IP settings in a pool whose address range is exactly one IP address.
- Static pools are useful, for example, to assign a fixed IP address to a server, NAS, or printer. Dynamic pools
- To assign IP addresses from a certain address range, the device stores the relevant IP settings in a pool whose address range includes multiple IP addresses.
- Dynamic pools are useful, for example, to assign a certain IP address to client devices that belong to a certain VLAN.

Setting up a static pool

In the following example, you set up the device to assign IP settings from a certain static pool to a certain client device connected to a certain port.

The static pool is to be set up based on the following parameters:

- MAC address of the client device: ec:e5:55:d6:50:01
- Physical port to which the client device is connected on the server device: 1/1
- ▶ IP address that the device should assign to the client device: 192.168.23.42
- The assigned IP settings are valid for 2 days: 172800

Perform the following steps:

- □ Open the *Advanced* > *DHCP* > *DHCP* Server > Pool dialog.
- \Box Add a table row. To do this, click the $\overset{\blacksquare}{\Box}$ button.
- □ Specify the following settings for the table row:
 - IP range start column = 192.168.23.42
 - Port column = 1/1
 - MAC address column = ec:e5:55:d6:50:01
 - Lease time [s] column = 172800
 - Active column = marked
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Advanced* > *DHCP* > *DHCP* Server > *Global* dialog.
- Verify that the DHCP function is active on port 1/1.
 If not already done, mark the checkbox in the DHCP server active column for port 1/1.
- □ Enable the DHCP server globally. To do this, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dhcp-server pool add 1 static 192.168.23.42	To add a static pool with index 1 with the IP address 192.168.23.42.
dhcp-server pool modify 1 mode interface 1/ 1	To assign the static pool with index 1 to physical port 1/1.
dhcp-server pool modify 1 mode mac EC:E5:55:D6:50:01	To assign the static pool with index 1 to a client device with MAC address EC:E5:55:D6:50:01.
dhcp-server pool modify 1 leasetime 172800	To specify the lease time of the static pool with index 1.
dhcp-server pool mode 1 enable	To enable the static pool with index 1.
dhcp-server operation	To enable the DHCP server globally.
interface 1/1	To change to the interface configuration mode of port 1/1.
dhcp-server operation	To activate the DHCP server function on this port.

Setting up a dynamic pool

In the following example, you set up the device to assign an IP address from a certain address range to client devices connected to a certain port.

The dynamic pool is to be set up based on the following parameters:

- MAC address of the client device or further information in the DHCP request is not to be evaluated.
- Physical port to which the client devices are connected on the server device: 1/2
- Address range from which the device assigns an IP address to the client devices: 192.168.23.92..192.168.23.142
- The assigned IP settings are valid for 2 days: 172800

Perform the following steps:

- □ Open the Advanced > DHCP > DHCP Server > Pool dialog.
- \Box Add a table row. To do this, click the $\overset{\blacksquare}{+}$ button.
- □ Specify the following settings for the table row:
 - *IP range start* column = 192.168.23.92
 - *IP range end* column = 192.168.23.142
 - Port column = 1/2
 - Lease time [s] column = 172800
 - Active column = Marked
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Advanced* > *DHCP* > *DHCP* Server > *Global* dialog.
- Verify that the DHCP function is active on port 1/2.
 If not already done, mark the checkbox in the DHCP server active column for port 1/2.
- □ Enable the DHCP server globally. To do this, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dhcp-server pool add 2 dynamic 192.168.23.92 192.168.23.142	To add a dynamic pool with index 2 with a range from 192.168.23.92 to 192.168.23.142.
dhcp-server pool modify 2 mode interface 1/2	To assign the static pool with index 2 to physical port 1/2.
dhcp-server pool modify 2 leasetime 172800	To specify the lease time of the dynamic pool with index 2.
dhcp-server pool mode 2 enable	To enable the dynamic pool with index 2.
dhcp-server operation	To enable the DHCP server globally.
interface 1/2	To change to the interface configuration mode of port $1/2$.
dhcp-server operation	To activate the DHCP server function on this port.

15.2 DHCP L2 Relay

A network administrator uses the DHCP Layer 2 *Relay Agent* to add DHCP client information. This information is required by Layer 3 *Relay Agents* and DHCP servers to assign an address and configuration to a client.

When a DHCP client and server are in the same IP subnet, they exchange IP address requests and replies directly. However, having a DHCP server on each subnet is expensive and often impractical. An alternative to having a DHCP server in every subnet is to use the network devices to relay packets between a DHCP client and a DHCP server located in a different subnet.

A Layer 3 *Relay Agent* is generally a router that has IP interfaces in both the client and server subnets and routes the data packets between them. However, in Layer 2 switched networks, there are one or more network devices, switches for example, between the client and the Layer 3 *Relay Agent* or DHCP server. In this case, this device provides a Layer 2 *Relay Agent* to add the information that the Layer 3 *Relay Agent* and DHCP server require to perform their roles in address and configuration assignment.

For the DHCPv6 protocol, a *Relay Agent* is used to add *Relay Agent* options to DHCPv6 packets exchanged between a client and a DHCPv6 server. The Lightweight DHCPv6 Relay Agent (LDRA) is described in RFC 6221.

The LDRA processes 2 types of messages:

- The first type of message is the *Relay-Forward* message which contains unique information about the client.
- The second type of message is the *Relay-Reply* message which the DHCPv6 server sends to the *Relay Agent*. The *Relay Agent* then validates the message to include the information encapsulated in the initial *Relay-Forward* message and if valid, sends the packet to the client.

The *Relay-Forward* message contains *Interface-ID* information, also known as *Option 18*. This option provides information that identifies the interface on which the client request was sent. The device discards DHCPv6 packets that do not contain *Option 18* information.

15.2.1 Circuit and Remote IDs

In an IPv4 environment, before forwarding the request of a client to the DHCP server, the device adds the *Circuit ID* and the *Remote ID* to the *Option 82* field of the DHCP request packet.

- The *Circuit ID* stores on which port the device received the request of the client.
- The Remote ID contains the MAC address, the IP address, the system name, or a user-defined character string. Using it, the participating devices identify the Relay Agent that received the request of the client.

The device and other *Relay Agents* use this information to re-direct the answer from the DHCP *Relay Agent* to the original client. The DHCP server is able to analyze this data for example to assign the client an IP address from a specific address pool.

Also, the replay packet of the DHCP server contains the *Circuit ID* and the *Remote ID*. Before forwarding the answer to the client, the device removes the information from the *Option 82* field.


15.2.2 DHCP L2 Relay configuration

The Advanced > DHCP L2 Relay > Configuration dialog lets you activate the function on the active ports and on the VLANs. In the Operation frame, select the On radio button. Then click the \checkmark button.

The device forwards DHCPv4 packets with *Option 82* information and DHCPv6 packets with *Option 18* information on those ports for which the checkbox in the *Active* column and in the *Trusted port* column is marked. Typically, these are ports in the network of the DHCP server.

The ports to which the DHCP clients are connected, you activate the *DHCP L2 Relay* function, but leave the *Trusted port* checkbox unmarked. On these ports, the device discards DHCPv4 packets with *Option 82* information and DHCPv6 packets with *Option 18* information.

An example configuration for the DHCPv4 L2 Relay function is shown below. The configuration steps for DHCPv6 L2 Relay function are similar, except for the *Circuit ID* and *Remote ID* entries that can only be specified for *Option 82*.



Perform the following steps on Switch 1:

- □ Open the Advanced > DHCP L2 Relay > Configuration dialog, Interface tab.
- \Box For port 1/1, specify the settings as follows:
 - Mark the checkbox in the Active column.
- \Box For port 1/2, specify the settings as follows:
 - Mark the checkbox in the Active column.
 - Mark the checkbox in the *Trusted port* column.
- □ Open the Advanced > DHCP L2 Relay > Configuration dialog, VLAN ID tab.
- □ Specify the settings for VLAN 2 as follows:
 - Mark the checkbox in the Active column.
 - Mark the checkbox in the Circuit ID column.
 - To use the IP address of the device as the *Remote ID*, in the *Remote ID type* column, specify the value ip.
- □ To enable the function, select the *On* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

Perform the following steps on Switch 2:

□ Open the Advanced > DHCP L2 Relay > Configuration dialog, Interface tab.

 \Box For port 1/1 and 1/2, specify the settings as follows:

- Mark the checkbox in the *Active* column.
- Mark the checkbox in the *Trusted port* column.
- □ To enable the function, select the *0n* radio button in the *Operation* frame.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

Verify that VLAN 2 is present. Then perform the following steps on Switch 1: \Box Set up VLAN 2, and specify port 1/1 as a member of VLAN 2.

enable	To change to the Privileged EXEC mode.
vlan database	To change to the VLAN configuration mode.
dhcp-l2relay circuit-id 2	To activate the Circuit ID and the DHCP Option 82 on VLAN 2.
dhcp-l2relay remote-id ip 2	To specify the IP address of the device as the Remote ID on VLAN 2.
dhcp-l2relay mode 2	To activate the DHCP L2 Relay function on VLAN 2.
exit	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
dhcp-l2relay mode	To activate the DHCP L2 Relay function on the port.
exit	To change to the Configuration mode.
interface 1/2	To change to the interface configuration mode of interface 1/2.
dhcp-l2relay trust	To specify the port as <i>Trusted port</i> .
dhcp-l2relay mode	To activate the DHCP L2 Relay function on the port.
exit	To change to the Configuration mode.
dhcp-l2relay mode	To enable the DHCP L2 Relay function in the device.

Perform the following steps on Switch 2:

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
dhcp-l2relay trust	To specify the port as <i>Trusted port</i> .
dhcp-l2relay mode	To activate the DHCP L2 Relay function on the port.
exit	To change to the Configuration mode.
interface 1/2	To change to the interface configuration mode of interface 1/2.
dhcp-l2relay trust	To specify the port as <i>Trusted port</i> .
dhcp-l2relay mode	To activate the DHCP L2 Relay function on the port.
exit	To change to the Configuration mode.
dhcp-l2relay mode	To enable the DHCP L2 Relay function in the device.

15.3 Using the device as a DNS client

As a DNS client, the device queries a DNS server to resolve the hostname of a device in the network to the related IP address.

The device lets you specify up to 4 DNS servers to which it forwards a request to resolve a hostname (*DNS request*).

As an alternative, the device can obtain the DNS server addresses from a DHCP server. For this, the DHCP server needs to be reachable in the same VLAN as the management of the device.

The device lets you manually enter into the device the hostname and IP address of known devices in the network. You can enter up to 64 so-called static hosts.

When the device receives a request to resolve a hostname (*DNS request*), it first tries to find the related IP address internally. If the device cannot resolve the hostname by itself, it forwards the request to a DNS server. The DNS server returns the associated IP address to the device.

Optionally, the device caches this response for future queries. The device caches up to 128 DNS server responses consisting of hostname and related IP address.

15.3.1 Setting up the DNS client function

The device has the option to contact a DNS server assigned by the DHCP server. This example describes how to set up the device to contact a user-defined DNS server instead. To do this, perform the following steps:

- □ Open the *Advanced* > *DNS* > *Client* > *Static* dialog.
- □ In the *Configuration* frame, select the user item from the *Source* drop-down list.
- □ In the *Configuration* frame, *Domain name* field, specify the value example.com.
- □ In the table, click the $\stackrel{\blacksquare}{+}$ button. The dialog displays the *Create* window.
- □ In the *Index* column, specify the value 1 as the sequential number. You can only assign unique values.
- □ In the *IP address* column, specify the IPv4 address of the DNS server, for example 192.168.3.5. You can also specify a valid IPv6 address.
- Click the Ok button.
 The device adds a table row.
- □ Open the *Advanced* > *DNS* > *Client* > *Global* dialog.
- □ To enable the function, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dns client source user	To specify that the device contacts a user-defined DNS server.

dns client domain-name example.com	To specify the string example.com as a domain name. The device adds this domain name to hostnames without a domain suffix.
dns client servers add 1 ip 192.168.3.5	To add a DNS server with the IPv4 address 192.168.3.5 as index 1.
dns client servers add 2 ip 2001::1	To add a DNS server with the IPv6 address 2001::1 as index 2.
dns client adminstate	To enable the <i>Client</i> function globally.

15.3.2 Setting up a static host

This example shows how to manually map an IP address to a hostname. To do this, perform the following steps:

Open the	Advanced >	> DNS >	Client >	Static Hosts dialog.
	/ luvullocu ·		Onone -	olulio moolo alulog.

- □ In the table, click the ♥♥ button. The dialog displays the *Create* window.
- □ In the *Index* column, specify the value 1.
- □ In the *Name* column, enter the hostname, for example device1.
- □ In the *IP address* column, specify the IPv4 address to be mapped to the hostname, for example 192.168.3.9. You can also specify a valid IPv6 address.
- Click the Ok button.
 The device adds a table row. The device sends data packets directed to device1 to the recipient with the IP address 192.168.3.9.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
dns client host add 1 name device1 ip 192.168.3.9	To map the hostname device1 with the IP address 192.168.3.9.
dns client adminstate	To enable the <i>Client</i> function globally.

15.4 GARP function

The Generic Attribute Registration Protocol (GARP) is defined by the IEEE standards association to provide a generic framework so switches can register and deregister attribute values, such as VLAN identifiers and Multicast group membership.

If an attribute for a participant is registered or deregistered according to the *GARP* function, then the participant is modified according to specific rules. The participants are a set of reachable end stations and network devices. The defined set of participants at any given time, along with their attributes, is the reachability tree for the subset of the network topology. The device forwards the data frames only to the registered end stations. The station registration helps prevent attempts to send data to the end stations that are unreachable.

15.4.1 Configuring GMRP

The GARP Multicast Registration Protocol (GMRP) is a Generic Attribute Registration Protocol (GARP) that provides a mechanism allowing network devices and end stations to dynamically register group membership. The devices register group membership information with the devices attached to the same LAN segment. The *GARP* function also lets the devices disseminate the information across the network devices that support extended filtering services.

Note: Before you enable the *GMRP* function, verify that the *MMRP* function is disabled.

The following example describes the configuration of the *GMRP* function. The device provides a constrained multicast flooding facility on a selected port. To do this, perform the following steps:

- □ Open the *Switching* > *GARP* > *GMRP* dialog.
- □ To provide constrained *Multicast Flooding* on a port, mark the checkbox in the *GMRP active* column.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
garp gmrp operation	To enable the GMRP function on the port.
exit	To change to the Configuration mode.
garp gmrp operation	To enable the <i>GMRP</i> function globally.

15.4.2 Configuring GVRP

You use the *GVRP* function to allow the device to exchange VLAN configuration information with other *GVRP*-capable devices. Thus reducing unnecessary traffic of Broadcast and unknown Unicast data packets. Besides, the *GVRP* function dynamically sets up VLANs on devices connected through 802.1Q trunk ports.

The following example describes the configuration of the *GVRP* function. The device lets you exchange VLAN configuration information with other *GVRP*-capable devices. To do this, perform the following steps:

- □ Open the *Switching* > *GARP* > *GVRP* dialog.
- □ To exchange VLAN configuration information with other *GVRP*-capable devices, mark checkbox in the *GVRP* active column for the port.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 3/1	To change to the interface configuration mode of interface 3/1.
garp gvrp operation	To enable the GVRP function on the port.
exit	To change to the Configuration mode.
garp gvrp operation	To enable the GVRP function globally.

15.5 MRP-IEEE

The IEEE 802.1ak amendment to the IEEE 802.1Q standard introduced the Multiple Registration Protocol (MRP) to replace the Generic Attribute Registration Protocol (GARP). The IEEE standards association also modified and replaced the *GARP* applications, GARP Multicast Registration Protocol (GMRP) and GARP VLAN Registration Protocol (GVRP), with the Multiple MAC Registration Protocol (MMRP) and the Multiple VLAN Registration Protocol (MVRP).

To confine forwarding the data packets to the required areas of a network, the MRP applications distribute attribute values to MRP enabled devices across a LAN. The MRP applications register and de-register Multicast group memberships and VLAN identifiers.

Note: The Multiple Registration Protocol (MRP) requires a loop free network. To help prevent loops in the network, use a network protocol such as the Media Redundancy Protocol, Spanning Tree Protocol, or Rapid Spanning Tree Protocol with MRP.

15.5.1 MRP operation

Each participant contains an applicant component and an MRP Attribute Declaration (MAD) component. The applicant component is responsible for forming the attribute values and their registration and de-registration. The MAD component generates MRP messages for transmission and processes messages received from other participants. The MAD component encodes and transmits the attributes to other participants in MRP Data Units (MRPDU). In the switch, an MRP Attribute Propagation (MAP) component distributes the attributes to participating ports.

A participant exists for each MRP application and each LAN port. For example, a participant application exists on an end device and another application exists on a switch port. The Applicant state machine records the attribute and port for each MRP participant declaration on an end device or switch. Applicant state machine variable changes trigger the transmission of MRPDUs to communicate the declaration or withdrawal.

To establish an *MMRP* instance, an end device first sends a Join empty (JoinMt) message with the appropriate attributes. The switch then floods the JoinMt to the participating ports and to the neighboring switches. The neighboring switches flood the message to their participating port, and so on, establishing a path for the group data packets.

15.5.2 MRP timers

The default timer settings help prevent unnecessary attribute declarations and withdraws. The timer settings allow the participants to receive and process MRP messages before the Leave or LeaveAll timers expire.

When you reconfigure the timers, maintain the following relationships:

- ► To allow for re-registration after a Leave or LeaveAll event, although there is a lost message, set the value of the LeaveTime as follows: ≥ (2x JoinTime) + 60 in 1/100 s
- ► To minimize the volume of rejoining data packets generated following a LeaveAll event, specify the value for the LeaveAll timer larger than the LeaveTime value.

The following list contains various MRP events that the device transmits:

- ▶ Join Controls the interval for the next Join message transmission
- Leave Controls the length of time that a switch waits in the Leave state before changing to the withdraw state
- LeaveAll Controls the frequency with which the switch generates LeaveAll messages

When expired, the Periodic timer initiates a Join request MRP message that the switch sends to participants on the LAN. The switches use this message to help prevent unnecessary withdraws.

15.5.3 MMRP

When a device receives Broadcast, Multicast or unknown data packets on a port, the device floods the data packets to the other ports. This process causes unnecessary use of bandwidth on the LAN.

The Multiple MAC Registration Protocol (MMRP) lets you control the data packets flooding by distributing an attribute declaration to participants on a LAN. The attribute values that the MAD component encodes and transmits on the LAN in MRP messages are Group service requirement information and 48-bit MAC addresses.

The switch stores the attributes in a filtering database as MAC address registration entries. The forwarding process uses the filtering database entries only to transmit data through those ports necessary to reach Group member LANs.

Switches facilitate the group distribution mechanisms based on the Open Host Group concept, receiving packets on the active ports and forwarding only to ports with group members. This way, any *MMRP* participants requiring packets transmitted to a particular group or groups, requests membership in the group. MAC service users send packets to a particular group from anywhere on the LAN. A group receives these packets on the LANs attached to registered *MMRP* participants. *MMRP* and the MAC Address Registration Entries thus restrict the packets to required segments of a loop-free LAN.

To maintain the registration and deregistration state and to receive data packets, a port declares interest periodically. Every device on a LAN with the *MMRP* function enabled maintains a filtering database and forwards the data packets with the group MAC addresses to the listed participants.

Setting up MMRP

In this example, Host A intends to listen to the data packets destined for group G1. Switch A processes the *MMRP* Join request received from host A and sends the request to both of the neighboring switches. The devices on the LAN now recognize that there is a host interested in receiving the data packets destined for group G1. When Host B starts transmitting data destined for group G1, the data flows on the path of registrations and Host A receives it.




Figure 99: MMRP Network for MAC address Registration

Enable the *MMRP* function on the switches. To do this, perform the following steps:

- □ Open the Switching > MRP-IEEE > MMRP dialog, Configuration tab.
- □ To activate port 1 and port 2 as *MMRP* participants, mark the checkbox in the *MMRP* column for port 1 and port 2 on switch 1.
- □ To activate port 3 and port 4 as *MMRP* participants, mark the checkbox in the *MMRP* column for port 3 and port 4 on switch 2.
- □ To activate port 5 and port 6 as *MMRP* participants, mark the checkbox in the *MMRP* column for port 5 and port 6 on switch 3.
- □ To send periodic events allowing the device to maintain the registration of the MAC address group, enable the *Periodic state machine*. Select the *On* radio button in the *Configuration* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

To enable the *MMRP* ports on switch 1, use the following commands. Substituting the appropriate interfaces in the commands, enable the *MMRP* functions and ports on switches 2 and 3.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the interface configuration mode of interface 1/1.
mrp-ieee mmrp operation	To enable the <i>MMRP</i> function on the port.
interface 1/2	To change to the interface configuration mode of interface 1/2.
mrp-ieee mmrp operation	To enable the <i>MMRP</i> function on the port.
exit	To change to the Configuration mode.
<pre>mrp-ieee mrp periodic-state-machine</pre>	To enable the <i>Periodic state machine</i> function globally.
mrp-ieee mmrp operation	To enable the <i>MMRP</i> function globally.

15.5.4 MVRP

The Multiple VLAN Registration Protocol (MVRP) is an MRP application that provides dynamic VLAN registration and withdraw services on a LAN.

The *MVRP* function provides a maintenance mechanism for the Dynamic VLAN Registration Entries, and for transmitting the information to other devices. This information lets *MVRP*-aware devices establish and update their VLAN membership information. When members are present on a VLAN, the information indicates through which ports the switch forwards the data packets to reach those members.

The main purpose of the *MVRP* function is to allow switches to discover some of the VLAN information that you otherwise manually set up. Discovering this information lets switches overcome the limitations of bandwidth consumption and convergence time in large VLAN networks.

MVRP example

Set up a network comprised of MVRP aware switches (1-4) connected in a ring topology with end device groups, A1, A2, B1, and B2 in 2 different VLANs, A and B. With STP enabled on the switches, the ports connecting switch 1 to switch 4 are in the *discarding* state, helping prevent a loop condition.




Figure 100: MVRP Example Network for VLAN Registration

In the MVRP example network, the LANs first send a Join request to the switches. The switch enters the VLAN registration in the MAC address table (forwarding database) for the port receiving the frames.

The switch then propagates the request to the other ports, and sends the request to the neighboring LANs and switches. This process continues until the switches have registered the VLANs in the MAC address table (forwarding database) of the receive port.

Enable MVRP on the switches. To do this, perform the following steps:

- □ Open the Switching > MRP-IEEE > MVRP dialog, Configuration tab.
- \Box To activate the ports 1 through 3 as *MVRP* participants, mark the checkbox in the *MVRP* column for the ports 1 through 3 on switch 1.
- □ To activate the ports 2 through 4 as MVRP participants, mark the checkbox in the MVRP column for the ports 2 through 4 on switch 2.
- \Box To activate the ports 3 through 6 as *MVRP* participants, mark the checkbox in the *MVRP* column for the ports 3 through 6 on switch 3.
- □ To activate port 7 and port 8 as *MVRP* participants, mark the checkbox in the *MVRP* column for port 7 and port 8 on switch 4.
- □ To maintain the registration of the VLANs, enable the *Periodic state machine*. Select the *On* radio button in the *Configuration* frame.
- □ To enable the function, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

To enable the MVRP ports on switch 1, use the following commands. Substituting the appropriate interfaces in the commands, enable the MVRP functions and ports on switches 2, 3 and 4.

nge to the Privileged EXEC mode.
nge to the Configuration mode.
nge to the interface configuration mode of $ce 1/1$.
ble the <i>MVRP</i> function on the port.
nge to the interface configuration mode of $ce 1/2$.
ble the <i>MVRP</i> function on the port.
nge to the Configuration mode.
ble the <i>Periodic state machine</i> function y.
ble the <i>MVRP</i> function globally.

16 Industry Protocols

For a long time, automation communication and office communication were on different paths. The requirements and the communication properties were too different.

Office communication moves large quantities of data with low demands with respect to the transfer time. Automation communication moves small quantities of data with high demands with respect to the transfer time and availability.

While the transmission devices in the office are usually kept in temperature-controlled, relatively clean rooms, the transmission devices used in automation are exposed to wider temperature ranges. Dirty, dusty and damp ambient conditions make additional demands on the quality of the transmission devices.

With the continued development of communication technology, the demands and the communication properties have moved closer together. The high bandwidths now available in Ethernet technology and the protocols they support enable large quantities to be transferred and exact transfer times to be specified.

With the first active optical LAN worldwide at the University of Stuttgart in 1984, Hirschmann laid the foundation for industry-compatible office communication devices. Thanks to Hirschmann's initiative with the world's first rail hub in the 1990s, Ethernet transmission devices such as switches, routers and firewalls are now available for the toughest automation conditions.

The desire for uniform, continuous communication structures encouraged many manufacturers of automation devices to come together and use standards to aid the progress of communication technology in the automation sector. This is why we now have protocols that let us communicate through Ethernet from the office right down to the field level.




Figure 101: Example of communication.

16.1 IEC 61850/MMS

IEC 61850/MMS is an industrial communication protocol standardized by the International Electrotechnical Commission (IEC). The protocol is to be found in substation automation, for example in the control technology of energy suppliers.

This protocol, which works in a packet-oriented way, is based on the TCP/IP transport protocol and uses the Manufacturing Messaging Specification (MMS) for the client-server communication. The protocol is object-oriented and defines a standardized configuration language that comprises, among other things, functions for SCADA, Intelligent Electronic Devices (IED) and for the network control technology.

Part 6 of the IEC 61850 standard defines the configuration language SCL (Substation Configuration Language). SCL describes the properties of the device and the system structure in an automatically processable form. The properties of the device described with SCL are stored in the ICD file in the device.

16.1.1 Switch model for IEC 61850

The Technical Report, IEC 61850 90-4, specifies a bridge model. The bridge model represents the functions of a switch as objects of an Intelligent Electronic Device (IED). An MMS client (for example the control room software) uses these objects to monitor and set up the device.

Phys	ical Device			
Log	gical Device	LN LPHD		
	LN LBRI			
	LN LCCH	LN LCCH	LN LCCH	
	LN LCCF	LN LCCF	LN LCCF	
	LN LBSP	LN LBSP	LN LBSP	LN LBSP
	LN LPLD	LN LPLD	LN LPLD	LN LPLD
	LN LPCP	LN LPCP	LN LPCP	LN LPCP
			A paired red	undant ports B
Port	Number 1	2	3	4

Figure 102: Bridge model based on Technical Report IEC 61850 90-4

Table 49: Classes of the bridge model based on TR IEC61850 90-4

Class	Description
LN LLN0	Zero logical node of the Bridge IED: Defines the logical properties of the device.
LN LPHD	Physical Device logical node of the Bridge IED: Defines the physical properties of the device.
LN LBRI	Bridge logical node: Represents general settings of the bridge functions of the device.
LN LCCH	Communication Channel logical node: Defines the logical Communication Channel that consists of one or more physical device ports.

Class	Description
LN LCCF	Channel Communication Filtering logical node: Defines the VLAN and Multicast settings for the higher-level Communication Channel.
LN LBSP	Port Spanning Tree Protocol logical node: Defines the Spanning Tree statuses and settings for the respective physical device port.
LN LPLD	Port Layer Discovery logical node: Defines the LLDP statuses and settings for the respective physical device port.
LN LPCP	Physical Communication Port logical node: Represents the respective physical device port.

Table 49: Classes of the bridge model based on TR IEC61850 90-4 (cont.)

16.1.2 Integration into a Control System

-

Preparation of the device

Perform the following steps:

- $\hfill\square$ Check that the device has an IP address assigned.
- □ Open the Advanced > Industrial Protocols > IEC61850-MMS dialog.
- □ To start the MMS server, select in the *Operation* frame the *On* radio button, and click ✓ button. Afterwards, an MMS client is able to connect to the device and to read and monitor the objects defined in the bridge model.

IEC61850/MMS does not provide any authentication mechanisms. If the write access for IEC61850/MMS is activated, then every client that can access the device using TCP/IP is capable of changing the settings of the device. As a result, incorrect device settings and potential network interruptions may occur.

NOTICE

RISK OF UNAUTHORIZED ACCESS TO THE DEVICE

Only activate the write access if you have taken additional measures (for example Firewall, VPN, etc.) to reduce possible unauthorized access.

Failure to follow these instructions can result in equipment damage.

- □ To allow the MMS client to change the settings, mark the *Write access* checkbox, and click the
 - ✓ button.

Offline configuration

The device lets you download the ICD file using the Graphical User Interface. This file contains the properties of the device described with SCL and lets you set up the substation without directly connecting to the device.

- □ Open the Advanced > Industrial Protocols > IEC61850-MMS dialog.
- □ To load the ICD file to your PC, click the 👱 button.

Monitoring the device

The IEC61850/MMS server integrated into the device lets you monitor multiple statuses of the device by means of the Report Control Block (RCB). Up to 5 MMS clients can register for a Report Control Block at the same time.

The device lets you monitor the following statuses:

Table 50: St	tatuses of the	device that can	be monitored wit	h IEC 61850/MMS
--------------	----------------	-----------------	------------------	-----------------

Class	RCB object	Description
LN LPHD	TmpAlm	When the temperature measured in the device exceeds or falls below the specified temperature threshold values, the status changes.
	PhyHealth	When the status of the LPHD.TmpAlm RCB object changes, the status changes.
LN LPHD	TmpAlm	When the temperature measured in the device exceeds or falls below the specified temperature threshold values, the status changes.
	PwrSupAlm	When one of the redundant power supplies becomes inoperable or starts operating again, the status changes.
	PhyHealth	When the status of the LPHD.PwrSupAlm or LPHD.TmpAlm RCB object changes, the status changes.

Class	RCB object	Description
LN LBRI	RstpRoot	When the device takes over or relinquishes the role of the <i>Root bridge</i> , the status changes.
	RstpTopoCnt	When the topology changes due to a change of the <i>Root bridge</i> , the status changes.
LN LCCH	ChLiv	When the link status of the physical port changes, the status changes.
LN LPCP	PhyHealth	When the link status of the physical port changes, the status changes.

Table 50: Statuses of the device that can be monitored with IEC 61850/MMS (cont.)

16.2 Modbus TCP function

Modbus TCP is an application layer messaging protocol providing client/server communication between the client and devices connected in Ethernet TCP/IP networks.

The *Modbus TCP* function lets you install the device in networks already using *Modbus TCP* and retrieve information saved in the registers in the device.

16.2.1 Client/Server Modbus TCP/IP Mode

The device supports the client/server model of Modbus TCP/IP. This device operates as a server in this constellation and responds to requests from a client for information saved in the registers.




Figure 103: Client/Server Modbus TCP/IP Mode

The client / server model uses four types of messages to exchange data between the client and server:

- Modbus TCP/IP Request, the client generates a request for information and sends it to the server.
- Modbus TCP/IP Indication, the server receives a request as an indication that a client requires information.
- Modbus TCP/IP Response, when the required information is available, the server sends a reply containing the requested information. When the requested information is unavailable, the server sends an Exception Response to notify the client of the error detected during the processing. The Exception Response contains an exception code indicating the reason for the detected error.
- Modbus TCP/IP Confirmation, the client receives a response from the server, containing the requested information.

16.2.2 Supported Functions and Memory Mapping

The device supports functions with the public codes 0x03 (Read Holding Registers) and 0x05 (Write Single Coil). The codes let you read the information saved in the registers such as the system information, including the system name, system location, software version, IP address, MAC address. The codes also let you read the port information and port statistics. The 0x05 code lets you reset the port counters individually or globally.

The following list contains definitions for the values entered in the Format column:

- Bitmap: a group of 32-bits, encoded into the Big-endian byte order and saved in 2 registers. Bigendian systems save the most significant byte of a word in the smallest address and save the least significant byte in the largest address.
- ► F1: 16-bit unsigned integer
- ▶ F2: Enumeration power supply alarm
 - 0 = power supply good
 - 1 = power supply failure detected

- ► F3: Enumeration OFF/ON
 - 0 = Off
 - 1 = On
- F4: Enumeration port type
 - 0 = Giga Gigabit Interface Converter (GBIC)
 - 1 = Copper Twisted-Pair (TP)
 - 2 = Fiber 10 Mbit/s
 - 3 = Fiber 100 Mbit/s
 - 4 = Giga 10/100/1000 Mbit/s (triple speed)
 - 5 = Giga Copper 1000 Mbit/s TP
 - 6 = Giga Small Form-factor Pluggable (SFP)
- F9: 32-bit unsigned long
- String: octets, saved in sequence, 2 octets per register.

Modbus TCP/IP Codes

The addresses in the following tables allow the client to reset port counters and retrieve specific information from the device registers.

Address	Qty	Description	Min	Max	Step	Unit	Format
0000	128	System Name	-	-	-	-	String
0080	128	System Contact	-	-	-	-	String
0100	128	System Location	-	-	-	-	String
0180	128	Software Version	-	-	-	-	String
0200	32	OrderCode	-	-	-	-	String
0220	16	Serial Number	-	-	-	-	String
0230	1	IP Address[0]	0	254	1	-	F1
0231	1	IP Address[1]	0	254	1	-	F1
0232	1	IP Address[2]	0	254	1	-	F1
0233	1	IP Address[3]	0	254	1	-	F1
0234	1	NetMask[0]	0	255	1	-	F1
0235	1	NetMask[1]	0	255	1	-	F1
0236	1	NetMask[2]	0	255	1	-	F1
0237	1	NetMask[3]	0	255	1	-	F1
0238	1	GateWay[0]	0	254	1	-	F1
0239	1	GateWay[1]	0	254	1	-	F1
023A	1	GateWay[2]	0	254	1	-	F1
023B	1	GateWay[3]	0	254	1	-	F1
023C	3	MacAddress	-	-	-	-	String
023F	1	PowerAlarm1	0	1	1	-	F2
0240	1	PowerAlarm2	0	1	1	-	F2
0241	1	StpState	0	1	1	-	F1
0242	2	Number of Ports	1	64	1	-	F1
0244	1	Reset Counter (all Counter)	0	1	1	-	F1
0245	4	Port Present Map	-	-	-	-	Bitmap
0249	4	Port Link Map	-	-	-	-	Bitmap
024D	4	Port Stp State Map	-	-	-	-	Bitmap
0251	4	Port Activity Map	-	-	-	-	Bitmap

Table 51: System/Global Information

Address	Qty	Description	Min	Max	Step	Unit	Format
0400	1	Port 1 Type	0	6	1	-	F4
0401	1	Port 2 Type	0	6	1	-	F4
043F	1	Port 64 Type	0	6	1	-	F4
0440	1	Port 1 Link Status	0	1	1	-	F1
0441	1	Port 2 Link Status	0	1	1	-	F1
047F	1	Port 64 Link Status	0	1	1	-	F1
0480	1	Port 1 STP State	0	1	1	-	F1
0481	1	Port 2 STP State	0	1	1	-	F1
04BF	1	Port 64 STP State	0	1	1	-	F1
04C0	1	Port 1 Activity	0	1	1	-	F1
04C1	1	Port 2 Activity	0	1	1	-	F1
04FF	1	Port 64 Activity	0	1	1	-	F1
0500	1	Port 1 Counter Reset	0	1	1	-	F1
0501	1	Port 2 Counter Reset	0	1	1	-	F1
053F	1	Port 64 Counter Reset	0	1	1	-	F1

Table 52: Port Information

Table 53: Port Statistics

Address	Qty	Description	Min	Max	Step	Unit	Format
0800	2	Port1 - Number of bytes received	0	4294967295 (2 ³² -1)	1	-	F9
0802	2	Port1 - Number of bytes sent	0	4294967295	1	-	F9
0804	2	Port1 - Number of frames received	0	4294967295	1	-	F9
0806	2	Port1 - Number of frames sent	0	4294967295	1	-	F9
0808	2	Port1 - Total bytes received	0	4294967295	1	-	F9
080A	2	Port1 - Total frames received	0	4294967295	1	-	F9
080C	2	Port1 - Number of broadcast frames received	0	4294967295	1	-	F9
080E	2	Port1 - Number of multicast frames received	0	4294967295	1	-	F9
0810	2	Port1 - Number of frames with CRC error	0	4294967295	1	-	F9
0812	2	Port1 - Number of oversized frames received	0	4294967295	1	-	F9
0814	2	Port1 - Number of bad fragments rcvd(<64 bytes)	0	4294967295	1	-	F9
0816	2	Port1 - Number of jabber frames received	0	4294967295	1	-	F9
0818	2	Port1 - Number of collisions occurred	0	4294967295	1	-	F9
081A	2	Port1 - Number of late collisions occurred	0	4294967295	1	-	F9
081C	2	Port1 - Number of 64-byte frames rcvd/ sent	0	4294967295	1	-	F9
081E	2	Port1 - Number of 65-127 byte frames rcvd/sent	0	4294967295	1	-	F9
0820	2	Port1 - Number of 128-255 byte frames rcvd/sent	0	4294967295	1	-	F9

Address	Qty	Description	Min	Max	Step	Unit	Format
0822	2	Port1 - Number of 256-511 byte frames rcvd/sent	0	4294967295	1	-	F9
0824	2	Port1 - Number of 512-1023 byte frames rcvd/sent	0	4294967295	1	-	F9
0826	2	Port1 - Number of 1023-MAX byte frames rcvd/sent	0	4294967295	1	-	F9
0828	2	Port1 - Number of Mac Error Packets	0	4294967295	1	-	F9
082A	2	Port1 - Number of dropped received packets	0	4294967295	1	-	F9
082C	2	Port1 - Number of multicast frames sent	0	4294967295	1	-	F9
082E	2	Port1 - Number of broadcast frames sent	0	4294967295	1	-	F9
0830	2	Port1 - Number of <64 byte fragments w/ good CRC	0	4294967295	1	-	F9
0832	2	Port2 - Number of bytes received	0	4294967295	1	-	F9
0834	2	Port2 - Number of bytes sent	0	4294967295	1	-	F9
0836	2	Port2 - Number of frames received	0	4294967295	1	-	F9
0838	2	Port2 - Number of frames sent	0	4294967295	1	-	F9
083A	2	Port2 - Total bytes received	0	4294967295	1	-	F9
083C	2	Port2 - Total frames received	0	4294967295	1	-	F9
083E	2	Port2 - Number of broadcast frames received	0	4294967295	1	-	F9
0840	2	Port2 - Number of multicast frames received	0	4294967295	1	-	F9
0842	2	Port2 - Number of frames with CRC error	0	4294967295	1	-	F9
0844	2	Port2 - Number of oversized frames received	0	4294967295	1	-	F9
0846	2	Port2 - Number of bad fragments rcvd(<64 bytes)	0	4294967295	1	-	F9
0848	2	Port2 - Number of jabber frames received	0	4294967295	1	-	F9
084A	2	Port2 - Number of collisions occurred	0	4294967295	1	-	F9
084C	2	Port2 - Number of late collisions occurred	0	4294967295	1	-	F9
084E	2	Port2 - Number of 64-byte frames rcvd/ sent	0	4294967295	1	-	F9
0850	2	Port2 - Number of 65-127 byte frames rcvd/sent	0	4294967295	1	-	F9
0852	2	Port2 - Number of 128-255 byte frames rcvd/sent	0	4294967295	1	-	F9
0854	2	Port2 - Number of 256-511 byte frames rcvd/sent	0	4294967295	1	-	F9
0856	2	Port2 - Number of 512-1023 byte frames rcvd/sent	0	4294967295	1	-	F9
0858	2	Port2 - Number of 1023-MAX byte frames rcvd/sent	0	4294967295	1	-	F9
085A	2	Port2 - Number of Mac Error Packets	0	4294967295	1	-	F9
085C	2	Port2 - Number of dropped received packets	0	4294967295	1	-	F9
085E	2	Port2 - Number of multicast frames sent	0	4294967295	1	-	F9
0860	2	Port2 - Number of broadcast frames sent	0	4294967295	1	-	F9
0862	2	Port2 - Number of <64 byte fragments w/ good CRC	0	4294967295	1	-	F9
144E	2	Port64 - Number of bytes received	0	4294967295	1	-	F9

Table 53:	Port Statistics	(cont.)
-----------	-----------------	---------

Address	Qty	Description	Min	Max	Step	Unit	Forma
1450	2	Port64 - Number of bytes sent	0	4294967295	1	-	F9
1452	2	Port64 - Number of frames received	0	4294967295	1	-	F9
1454	2	Port64 - Number of frames sent	0	4294967295	1	-	F9
1456	2	Port64 - Total bytes received	0	4294967295	1	-	F9
1458	2	Port64 - Total frames received	0	4294967295	1	-	F9
145A	2	Port64 - Number of broadcast frames received	0	4294967295	1	-	F9
145C	2	Port64 - Number of multicast frames received	0	4294967295	1	-	F9
145E	2	Port64 - Number of frames with CRC error	0	4294967295	1	-	F9
1460	2	Port64 - Number of oversized frames received	0	4294967295	1	-	F9
1462	2	Port64 - Number of bad fragments rcvd(<64 bytes)	0	4294967295	1	-	F9
1464	2	Port64 - Number of jabber frames received	0	4294967295	1	-	F9
1466	2	Port64 - Number of collisions occurred	0	4294967295	1	-	F9
1468	2	Port64 - Number of late collisions occurred	0	4294967295	1	-	F9
146A	2	Port64 - Number of 64-byte frames rcvd/ sent	0	4294967295	1	-	F9
146C	2	Port64 - Number of 65-127 byte frames rcvd/sent	0	4294967295	1	-	F9
146E	2	Port64 - Number of 128-255 byte frames rcvd/sent	0	4294967295	1	-	F9
1470	2	Port64 - Number of 256-511 byte frames rcvd/sent	0	4294967295	1	-	F9
1472	2	Port64 - Number of 512-1023 byte frames rcvd/sent	0	4294967295	1	-	F9
1474	2	Port64 - Number of 1023-MAX byte frames rcvd/sent	0	4294967295	1	-	F9
1476	2	Port64 - Number of Mac Error Packets	0	4294967295	1	-	F9
1478	2	Port64 - Number of dropped received packets	0	4294967295	1	-	F9
147A	2	Port64 - Number of multicast frames sent	0	4294967295	1	-	F9
147C	2	Port64 - Number of broadcast frames sent	0	4294967295	1	-	F9
147E	2	Port64 - Number of <64 byte fragments w/ good CRC	0	4294967295	1	-	F9

Table 53: Port Statistics (cont.)

16.2.3 Application example for the Modbus TCP function

In the following example, you set up the device to respond to client requests. The prerequisite for this configuration is that the client device is set up with an IP address within the given range. The *Write access* function remains inactive for this example. When you activate the *Write access* function, the device lets you reset the port counters only. In the default setting the *Modbus TCP* and *Write access* functions are inactive.

The *Modbus TCP* function does not provide any authentication mechanisms. If the write access for *Modbus TCP* is activated, then every client that can access the device using TCP/IP is capable of changing the settings of the device. As a result, incorrect device settings and potential network interruptions may occur.

NOTICE

RISK OF UNAUTHORIZED ACCESS TO THE DEVICE

Only activate the write access if you have taken additional measures (for example Firewall, VPN, etc.) to reduce possible unauthorized access.

Failure to follow these instructions can result in equipment damage.

Perform the following steps:

- □ Open the Device Security > Management Access > IP Access Restriction dialog.
- \Box Add a table row. To do this, click the $\overset{\blacksquare}{+}$ button.
- □ Specify the IP address range in the table row where the *Index* column has the value 2. To do this, enter the following values:
 - In the Address column: 10.17.1.0
 - In the Netmask column: 255.255.255.248
- □ Verify that the checkbox in the *Modbus TCP* column is marked.
- Activate the IP address range. To do this, mark the checkbox in the Active column.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Diagnostics* > *Status Configuration* > *Security Status* dialog, *Global* tab.
- □ Verify that the checkbox related to the parameter *Modbus TCP active* is marked.
- □ Open the Advanced > Industrial Protocols > Modbus TCP dialog.
- □ The standard *Modbus TCP* listening port, port 502, is the default setting. However, when you wish to listen on another TCP port, enter the value for the listening port in the *TCP port* field.
- □ To enable the function, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

When you enable the *Modbus TCP* function, the *Security Status* function detects the activation and displays an alarm in the *Basic Settings > System* dialog, *Security status* frame.

enable	To change to the Privileged EXEC mode.
network management access add 2	To add the entry for the address range in the network. Number of the next available index in this example: 2.
network management access modify 2 ip 10.17.1.0	To specify the IP address.

```
network management access modify 2 mask 29
                              To specify the netmask.
network management access modify 2 modbus-
                               To specify that the device lets Modbus TCP have
tcp enable
                               access to the device management.
network management access operation
                               To enable the IP access restriction.
configure
                               To change to the Configuration mode.
security-status monitor modbus-tcp-enabled
                               To specify that the device monitors the activation of
                               the Modbus TCP server.
modbus-tcp operation
                               To enable the Modbus TCP server.
modbus-tcp port <1..65535>
                               To specify the TCP port for Modbus TCP
                               communication (optionally). The default setting is
                               port 502.
show modbus-tcp
                               To display the Modbus TCP Server settings.
Modbus TCP/IP server settings
Modbus TCP/IP server operation.....enabled
Write-access.....disabled
Max number of sessions.....5
Active sessions.....0
show security-status monitor
                               To display the security-status settings.
Device Security Settings
Monitor
Password default settings unchanged.....monitored
Write access using HiDiscovery is possible....monitored
Loading unencrypted configuration from ENVM...monitored
IEC 61850 MMS is enabled.....monitored
Modbus TCP/IP server active.....monitored
                              To display occurred security status events.
show security-status event
Time stamp
                Event
                                   Info
-----
2014-01-01 01:00:39 password-change(10)
2014-01-01 01:00:39 ext-nvm-load-unsecure(21)
2014-01-01 23:47:40 modbus-tcp-enabled(23)
                               To display the restricted management access rules
show network management access rules 1
                               for index 1.
Restricted management access settings
-----
Index.....1
HTTP.....yes
SNMP......yes
Telnet.....yes
SSH.....yes
HTTPS.....yes
IEC61850-MMS.....yes
Modbus TCP/IP.....yes
Active.....[x]
```

16.3 EtherNet/IP function

EtherNet/IP is an industrial communication protocol that is deployed worldwide and is maintained by the Open DeviceNet Vendor Association (ODVA). It is based on the protocols *TCP/IP* and *UDP/IP* over Ethernet. *EtherNet/IP* is supported by leading manufacturers, thus providing a wide base for effective data communication in the industry sector.




Figure 104: EtherNet/IP network

EtherNet/IP adds the industry protocol CIP (Common Industrial Protocol) to the standard Ethernet protocols. *EtherNet/IP* implements CIP at the Session layer and above and adapts CIP to the specific *EtherNet/IP* technology at the Transport layer and below. In the case of automation applications, *EtherNet/IP* implements CIP on the application level. Therefore, *EtherNet/IP* is ideally suited to the industrial control technology sector.




Figure 105: IEEE 802.3 EtherNet/IP

In particular, you find *EtherNet/IP* in the USA and in conjunction with Rockwell controllers.

For further information on EtherNet/IP, see the ODVA website at www.odva.org.

16.3.1 Integration into a Control System

Perform the following steps:

- □ Open the *Switching* > *IGMP Snooping* > *Global* dialog. Verify that the *IGMP Snooping* function is enabled.
- □ Open the *Advanced* > *Industrial Protocols* > *EtherNet/IP* dialog. Verify that the *EtherNet/IP* function is enabled.
- □ Open the *Advanced* > *Industrial Protocols* > *EtherNet/IP* dialog.
- To save the EDS as a ZIP archive on your PC, click *Download*. The ZIP archive contains the *EtherNet/IP* configuration file and the icon used to set up the controller to connect to the device.

Configuration of a PLC using the example of Rockwell software

Perform the following steps:

- □ Open the "EDS Hardware Installation Tool" of RSLinx.
- □ Use the "EDS Hardware Installation Tool" to add the EDS file.
- □ Restart the "RSLinx" service so that RSLinx takes over the EDS file of the device.
- Use RSLinx to check if RSLinx has detected the device.
- □ Open your Logix 5000 project.
- Integrate the device into the Ethernet port of the controller as a new module (Generic Ethernet Module).

Table 54: Settings for integrating a Generic Ethernet Module

Setting	I/O connection	Input only	Listen only
Comm Format	Data - DINT	Data - DINT	Input data - DINT - Run/Program
IP address	IP address of the device	IP address of the device	IP address of the device
Input Assembly Instance	2	2	2
Input Size	7	7	7
Output Assembly Instance	1	254	255
Output Size	1	0	0
Configuration Assembly Instance	3	3	3
Configuration Size	0	0	0

□ In the module properties, enter a value of at least 100 ms for the Request Packet Interval (RPI).

Note: Monitoring the I/O connection to the CPU of the device as a detected failure can result in a potential system failure. Therefore, do not consider the I/O connection to the CPU when monitoring.

The I/O connection between the programmable logic controller (PLC) and the device can be interrupted by a management program. For example, a management station can saturate the CPU of the device with higher priority Real Time (RT) data. In this case, the device can still transmit or receive data packets and the system remains operational.

Example of integration from the Sample Code Library

The Sample Code Library is a website from Rockwell. The object of the website is to provide users with a place where they can exchange their best architecture integration applications.

On the website samplecode.rockwellautomation.com, search for catalog number 9701. This is the catalog number of an example for integrating the Hirschmann device into RS Logix 5000 rel. 16, PLC firmware release 16.

16.3.2 EtherNet/IP Entity Parameters

The following paragraphs identify the objects and operations supported by the device.

Supported operations

Service Code	ldentity Object	TCP/IP Interface Object	Ethernet Link Object	Switch Agent Object	Base Switch Object	DLR Object
0x01 Get Attribute All	All attributes	All attributes	All attributes	All attributes	All attributes	All attributes (except attribute 0x9) ¹
0x02 Set Attribute All	_	Settable attributes (0x3, 0x5, 0x6, 0x8, 0x9, 0xA)	Settable attributes (0x6, 0x9)	_	_	_
0x0e Get Attribute Single	All attributes	All attributes	All attributes	All attributes	All attributes	All attributes
0x10 Set Attribute Single	_	Settable attributes (0x3, 0x5, 0x6, 0x8, 0x9, 0xA, 0x64)	Settable attributes (0x6, 0x9, 0x65, 0x67, 0x68, 0x69, 0x6C)	Settable attributes (0x5, 0x7)	_	Settable attributes (0x4, 0x5)
0x05 Reset	Parameter (0x0, 0x1)	-	_	-	_	_
0x35 Save Configuration Vendor specific	_	-	_	Save switch configuration	_	-
0x36 Mac Filter	-	-	-	Add MAC filter STRUCT of:	-	_
Vendor specific				USINT VlanId		
				ARRAY of:	_	
				6 USINT Mac		
				DWORD PortMask	_	
0x4B Verify Fault Location						Verify fault location
0x4C Clear Rapid Faults						Clear rapid faults
0x4D Restart Sign On						Restart Sign On
0x04E Clear Gateway Partial Fault						Clear Gateway Partial Fault

Table 55: Overview of the supported EtherNet/IP requests for the objects instances

1. The DLR participants list (attribute 0x9) is not included in the *Get Attribute All* service. Read it using the *Get Attribute Single* service.

Identity object

The device supports the identity object (*Class Code 0x01*) of *EtherNet/IP*. The Hirschmann manufacturer ID is 634. Hirschmann uses the ID 44 (0x2C) to indicate the product type "Managed Ethernet Switch".

ld	Attribute	Access Rule	Data type	Description
0x1	Vendor ID	Get	UINT	Hirschmann634
0x2	Device Type	Get	UINT	Managed Ethernet Switch 44 (0x2C) (0x2C)
0x3	Product Code	Get	UINT	Product Code: mapping is defined for every device type
0x4	Revision	Get	STRUCT of:	Revision of the EtherNet/IP implementation, 2.1.
			USINT Major	_
			USINT Minor	_
0x5	Status	Get	WORD	Support for the following Bit status only:
				0: Owned (constantly 1)
				2: Configured (constantly 1)
				 4: Extend Device Status 5: 0x3: No I/O connection established 0x7: At least one I/O connection established, 6: all in idle mode. 7:
0x6	Serial number	Get	UDINT	Serial number of the device (contains last 3 Bytes of MAC address).
0x7	Product name	Get	SHORT- STRING	Displayed as "Hirschmann" + product family + product ID + software variant.

Table 56: Instance attributes (only instance 1 is available)

TCP/IP Interface Object

The device supports only Instance 1 of the TCP/IP Interface Object (*Class Code 0xF5*) of *EtherNet/IP*.

Depending on the write access status, the device stores the complete settings in its flash memory. Saving the settings can take up to 10 seconds. If the saving process is interrupted for example, due to an inoperable power supply, then the operation of the device might be impossible.

Note: The device replies to the configuration change Get Request with a Response although the configuration has not yet been saved completely.

ld	Attribute	Access Rule	Data type	Description
0x1	Revision	Get	UINT	Revision of this object: 3
0x2	Max Instance	Get	UINT	Maximum instance number: 1
0x3	Number of instance	Get	UINT	Number of object instances currently added: 1

Table 57:	Class attributes

ld	Attribute	Access Rule	Data type	Description
0x1	Status	Get	DWORD	0: Interface Status (0=Interface not configured, 1=Interface contains valid config)
				6: ACD status (default 0)
				7: ACD fault (default 0)
0x2	Interface Capability	Get	DWORD	0: BOOTP Client
	flags			1: DNS Client
				2: DHCP Client
				3: DHCP-DNS Update
				4: Configuration setable (within CIP) Other bits reserved (0)
				7: ACD capable (0=not capable 1=capable)
0x3	Config Control	Set/Get	DWORD	0: 0x0=using stored config 1: 0x1=using BOOTP 0x2=using DHCP 3:
				4: One device uses DNS for name lookup (constantly 0 because it is unsupported) Other bits reserved (0)
0x4	Physical Link Object	Get	STRUCT of:	Path to the Physical Link Object,
			UINT PathSize	constantly {0x20, 0xF6, 0x24,
			EPATH Path	 0x01} describing instance 1 of the Ethernet Link Object.
0x5	Interface	Set/Get	STRUCT of:	IP Stack Configuration (IP
	Configuration		UDINT IpAddress	address, Netmask, Gateway, 2
			UDINT Netmask	-Name servers (DNS, if supported _and the domain name).
			UDINT GatewayAddress	
			UDINT NameServer1	-
			UDINT NameServer2	-
			STRING DomainName	-
0x6	Hostname	Set/Get	STRING	Hostname (for DHCP DNS Update)
0x7	Safety Network Number			Unsupported
0x8	TTL Value	Get/Set	USINT	Time to live value for IP multicast packets Range 1255 (default 1)

Table 58: Attributes of Instance 1

ld	Attribute	Access Rule	Data type	Description
0x9	Mcast Config	Get/Set	STRUCT of:	Alloc Control = 0
			USINT AllocControl	Number of IP multicast addresses
			USINT reserved	-= 32 Multicast start address =
			UINT NumMcast	239.192.1.0
			UDINT McastStartAddr	-
0xA	Selected Acd	Get/Set	BOOL	0=ACD disable 1=ACD enable (default)
0xB	Last Conflict	Get	STRUCT of:	ACD Diagnostic Parameters
	Detected USINT AcdActivity	-		
			ARRAY of:	-
			6 USINT RemoteMac	-
			ARRAY of:	-
			28 USINT ArpPdu	

Table 58: Attributes of Instance 1 (cont.)

Table 59: Hirschmann extensions to the TCP/IP Interface Object

ld	Attribute	Access Rule	Data type	Description
0x64	Cable Test	Set/Get	STRUCT of:	Interface
			USINT Interface	Status (1=Active, 2=Success,
			USINT Status	- 3=Failure, 4=Uninitialized)
0x65	Cable Pair Size	Get	USINT	Size of the Cable Test Result STRUCT of: 2 Pair for 100BASE
				4 Pair for 1000BASE

ld	Attribute	Access Rule	Data type	Description
0x66	Cable Test Result	Get	STRUCT of:	100BASE:{
			USINT Interface	{Interface, CablePair1,
			USINT CablePair	- CableStatus, CableMinLength, CableMaxLength,
			USINT CableStatus	CableFailureLocation}
			USINT CableMinLength	{Interface, CablePair2, CableStatus, CableMinLength,
			USINT CableMaxLength	-CableMaxLength, CableFailureLocation} }
			USINTCableFailureL ocation	1000BASE:{ {Interface, CablePair1, CableStatus, CableMinLength, CableMaxLength, CableFailureLocation} {Interface, CablePair2, CableStatus, CableMinLength, CableMaxLength, CableFailureLocation} {Interface, CablePair3, CableStatus, CableMinLength, CableFailureLocation} {Interface, CablePair4, CableFailureLocation} {Interface, CablePair4, CableStatus, CableMinLength, CableStatus, CableMinLength, CableStatus, CableMinLength, CableStatus, CableMinLength, CableStatus, CableMinLength, CableFailureLocation} }

Table 59: Hirschmann extensions to the TCP/IP Interface Object (cont.)

Ethernet Link object

The information in the following tables are part of the Ethernet Link Object. To access the information, use the following values:

- Class(####)
- Instance(###)
- Attribute(#)

Specify at least one instance in the device, for example, Instance 1 is the CPU Ethernet interface instance (*Class Code 0xF6*) of *EtherNet/IP*.

	Table 60:	Instance	attributes
--	-----------	----------	------------

ld	Attribute	Access Rule	Data type	Description
0x1	Interface Speed	Get	UDINT	Used interface speed in Mbit/s (10, 100, 1000, …). 0 is used when the speed has not been determined or is invalid because of detected errors.

ld	Attribute	Access Rule	Data type	Description
0x2	Interface Flags	Get	DWORD	Interface Status Flags:
				0: Link State (0=No link, 1=Link)
				1: Duplex mode (0=Half, 1=Full)
				 2: Auto-negotiation Status 3: 0x0=Auto-negotiation in progress 0x1=Auto-negotiation failed 4: 0x2=Failed but speed detected 0x3=Auto-negotiation success 0x4=No Auto-negotiation
				 Manual configuration require reserved (constantly 0 because it is not needed)
				6: Hardware error
0x3	Physical Address	Get	ARRAY of:	MAC address of physical interface
			6 USINT	
0x4	Interface Counters	Get	STRUCT of:	InOctets, InUcastPackets,
			UDINT MibIICounter1 UDINT MibIICounter2	InNUcastPackets, InDiscards, InErrors, InUnknownProtos, OutOctets, OutUcastPackets, OutNUcastPackets, OutDiscards, OutErrors
0x5	Media Counters	Get	STRUCT of: UDINT EthernetMib Counter1 UDINT EthernetMib Counter2	Detected errors: Alignment, FCS, single collision, multiple collision, SQE Test, deferred transmissions, late collisions, excessive collisions, MAC TX, carrier sense, frame too long, MAC RX
0x6	Interface Control	Get/Set	STRUCT of:	Control Bits:
			WORD ControlBits	0: Auto-negotiation enable/disable (0=disable, 1=enable)
				1: Duplex mode (0=Half, 1=Full), if Auto-negotiation disabled
			UINT ForcedInterface Speed	Interface speed in Mbit/s: 10,100,, if Auto-negotiation disabled
0x7	Interface type	Get	USINT	Type of interface: 0: Unknown interface type 1: The interface is internal 2: Twisted-pair 3: Optical fiber

Table 60: Instance attributes (cont.)

ld	Attribute	Access Rule	Data type	Description
0x8	Interface state	Get	USINT	Current state of the interface: 0: Unknown interface state 1: The interface is enabled 2: The interface is disabled 3: The interface is testing
0x9	Admin State	Set/Get	USINT	Administrative state: 1: Enable the interface 2: Disable the interface
0xA	Interface label	Get	SHORT-STRING	Human readable ID

Table 60: Instance attributes (cont.)

Table 61: Hirschmann extensions to the Ethernet Link Object

ld	Attribute	Access Rule	Data type	Descri	iption
0x64	Ethernet Interface Index	Get	USINT	Interfa MIBII)	ace/Port Index (ifIndex out of
0x65	Port Control	Get/Set	DWORD	•	ink state)=link down, 1=link up)
					ink admin state 0=disabled, 1=enabled)
				8: A	access violation alarm (read-only)
				9: U	Itilization alarm (read-only)
0x66	Interface Utilization	Get	USINT	MIB hi Utiliza	xisting Counter out of the private m2IDiagfaceUtilization is used. tion in percentage (Unit 1%=100, 0). RX Interface Utilization.
0x67	Interface Utilization Alarm Upper Threshold	Get/Set	USINT	Within this parameter the variable hm2DiagIfaceUtilizationAlarmUpperT reshold can be accessed. Utilization in percentage (Unit 1%=100). RX Interface Utilization Upper Limit.	
0x68	Interface Utilization Alarm Lower Threshold	Get/Set	USINT	hm2Di reshol percer	this parameter the variable iaglfaceUtilizationAlarmLowerTh d can be accessed. Utilization in ntage (Unit 1%=100). RX ace Utilization Lower Limit.
0x69	Broadcast limit	Get/Set	USINT	(Egres	cast limiter Service ss BC-Frames limitation, abled), Frames/second
0x6A	Ethernet Interface Description	Get/Set	STRING	(from I "Unit: or	ace/Port Description MIB II ifDescr), for example 1 Slot: 2 Port: 1 - 10/100 Mbit TX" ailable", max. 64 Bytes.

ld	Attribute	Access Rule	Data type	Des	cription
0x6B	Port Monitor	Get/Set	DWORD	0:	Link Flap (0=Off, 1=On)
				1:	CRC/Fragment (0=Off, 1=On)
				2:	Duplex Mismatch (0=Off, 1=On)
				3:	Overload-Detection (0=Off, 1=Or
				4:	Link-Speed/ Duplex Mode (0=Off, 1=On)
				5:	Deactivate port action (0=Off, 1=On)
				6:	Send trap action (0=Off, 1=On)
				7:	Active Condition (displays which
				8:	condition caused an action to
				9:	-occur) _00001 _B : Link Flap
				10:	00010 _B : CRC/Fragments
				11:	00100 _B : Duplex Mismatch
					01000 _B : Overload-Detection
					10000 _B : Link-Speed/ Duplex mode
				12:	Reserved (constantly 0)
				13:	Reserved (constantly 0)
				14:	Reserved (constantly 0)
				15:	Reserved (constantly 0)
0x6C	Quick Connect	Get/Set	USINT	(0=0 If yo dev disa	ck Connect on the interface Off, 1=On) ou enable Quick Connect, then the ice sets the port speed to 100FD, ables auto-negotiation, and unning Tree on the interface.
0x6D	SFP Diagnostics	Get	STRUCT of:		
			STRING ModuleType		
			SHORT-STRING		
			SerialNumber		
			USINT Connector		
			USINT Supported	i 04	0
			DINT Temperature		
				in m	
			DINT RxPower	in m	IVV
			DINT RxPower	in d	Dm

Table 61: Hirschmann extensions to the Ethernet Link Object (cont.)

Ethernet Port	Ethernet Link Object Instance
CPU	1
Module 1 / Port 1	2
Module 1 / Port 2	3
Module 1 / Port 3	4
Module 1 / Port 4	5

Table 62: Assignment of ports to Ethernet Link Object Instances

Note: The number of ports depends on the type of hardware used. The Ethernet Link Object only exists, if the module is plugged in and the port is connected.

Switch Agent object

The device supports the Hirschmann specific Ethernet Switch Agent Object (*Class Code 0x95*) for the device settings and information parameters with Instance 1.

Table 63: Class attributes

ld	Attribute	Access Rule	Data type	Desc	ription
0x1	Switch Status	Get	DWORD	0:	Like the signal contact, the value indicates the Device Overall state (0=ok, 1=failed)
				1:	Device Security Status (0=ok, 1=failed)
				2:	Power Supply 1 (0=ok, 1=failed)
				3:	Power Supply 2 (0=ok, 1=failed or not existing
				4-5:	Reserved
				6:	Signal Contact 1 (0=closed, 1=open)
				7:	Signal Contact 2 (0=closed, 1=open or not existing)
				8:	Reserved
				9:	Temperature (0=ok, 1=failure)
				10:	Module removed (1=removed
				11:	ACA21/ACA22 removed (1=removed)
				12:	ACA31 removed (1=removed)
				13- 22:	Reserved
				23:	MRP (0=disabled, 1=enabled
				24:	PRP (0=disabled, 1=enabled)
				25:	HSR (0=disabled, 1=enabled)
				26:	RSTP (0=disabled, 1=enabled
				27:	LAG (0=disabled, 1=enabled)
				28:	DLR (0=disabled, 1=enabled)
				29-	Reserved
				30	
				31:	Connection Error (1=failure)
0x2	Switch	Get	STRUCT of:		
	Temperature		INT TemperatureF	in °F	
			INT TemperatureC	in °C	
0x3	Reserved	Get	UDINT	Rese 0)	erved for future use (constantly
0x4	Switch Max Ports	Get	UINT	Maxi Ports	imum number of Ethernet Switcl s

ld	Attribute	Access Rule	Data type	Description
0x5	Multicast Settings (IGMP Snooping)	Get/Set	WORD	0: IGMP Snooping (0=disabled, 1=enabled) 1: IGMP Querier (0=disabled, 1=enabled) 2: IGMP Querier Mode (read- only) (0=Non-Querier, 1=Querier) 3:
0x6	Switch Existing Ports	Get	ARRAY of: DWORD	Bitmask of existing switch ports Per bit starting with Bit 0 (=Port 1) (0=Port not available, 1=Port existing) Array (bit mask) size is adjusted to the size of maximum number of switch ports (for max. 28 Ports 1 DWORD is used)
0x7	Switch Port Control	Get/Set	ARRAY of: DWORD	Bitmask Link Admin Status switch ports Per bit starting with Bit 0 (=Port 1) (0=Port enabled, 1=Port disabled) Array (bit mask) size is adjusted to the size of maximum number of Switch ports (for max. 28 Ports 1 DWORD is used)
0x8	Switch Ports Mapping	Get	ARRAY of: USINT	Instance number of the Ethernet- Link-Object Starting with Index 0 (=Port 1) All Ethernet Link Object Instances for the existing Ethernet Switch Ports (1N, maximum number of ports). When the entry is 0, the Ethernet Link Object for this port does not exist

Table 63: Class attributes (cont.)

ld	Attribute	Access Rule	Data type	Des	scription
0x9	Switch Action Status	Get	(exa	tus of the last executed action (for imple config save, software late, etc.)
				0:	Flash Save Configuration In Progress/Flash Write In Progress
				1:	Flash Save Configuration Failed/Flash Write Failed
				4:	Configuration changed (configuration not in sync. between running configuration

Table 63: Class attributes (cont.)

The Hirschmann specific Ethernet Switch Agent Object provides you with the additional vendor specific service, with the *Service Code 0x35* for saving the device settings. When you send a request from your PC to save the device settings, the device sends a reply after saving the settings in the flash memory.

Base Switch object

The Base Switch object provides the CIP application-level interface to basic status information for a managed Ethernet switch (revision 1).

Only Instance 1 of the Base Switch (Class Code 0x51) is available.

Table 64:	Instance	attributes
-----------	----------	------------

ld	Attribute	Access Rule	Data type	Description
0x1	Device Up Time	Get	UDINT	Time since the device powered up
0x2	Total port count	Get	UDINT	Number of physical ports
0x3	System Firmware Version	Get	SHORT-STRING	Human readable representation of System Firmware Version
0x4	Power source	Get	WORD	Status of switch power source
0x5	Port Mask Size	Get	UINT	Number of DWORD in port array attributes
0x6	Existing ports	Get	ARRAY of:	Port Mask
			DWORD	_
0x7	Global Port	Get	ARRAY of:	Port Admin Status
	Admin State		DWORD	_
0x8	Global Port link	Get	ARRAY of:	Port Link Status
	Status		DWORD	_
0x9	System Boot Loader Version	Get	SHORT-STRING	Readable System Firmware Version
0xA	Contact Status	Get	UDINT	Switch Contact Closure

ld	Attribute	Access Rule	Data type	Description
0xB	Aging Time	Get	UDINT	Range 101000000 · 1/10 seconds (default 300) 0=Learning off
0xC	Temperature C	Get	DINT	Switch temperature in degrees Celsius
0xD	Temperature F	Get	DINT	Switch temperature in degrees Fahrenheit

Table 64: Instance attributes (cont.)

Message Router

The Message Router object (*Class Code 0x20*) distributes *Explicit Request* messages to the appropriate handler object.

Table 65:	Class attributes
-----------	------------------

ld	Attribute	Access Rule	Data type	Description
1	Revision	Get	UINT	Revision: 1
2	Largest Instance Number	Get	UINT	Largest instance number: 1
3	Number of Instances Currently Existing	Get	UINT	Number of instances currently existing: 1
4	Optional Attribute	Get	ARRAY of:	Optional attribute list: 0
	List		BYTES	Unsupported for Get_single service
5	Optional Service	Get	ARRAY of:	Optional Service List: 0
	List		BYTES	Unsupported for Get_single service
6	Maximum ID Number Class Attributes	Get	UINT	Maximum ID Number Class Attributes: 7
7	Maximum ID Number Instance Attributes	Get	UINT	Maximum ID Number Instance Attributes: 0

Assembly

The Assembly object (*Class Code 0x04*) binds attributes of multiple objects. This property lets the device send or receive data to or from any object over a single connection. You can use Assembly objects to bind *Input* or *Output* data. The terms *Input* and *Output* are specified from the viewpoint of the network. *Input* produces data on the network and *Output* consumes data from the network.

Table 66:	Supported instances	
-----------	---------------------	--

Instance	Description	Service
1	POWER_LINK_ASSEMBLY	Get_single
100	INPUT_ASSEMBLY_NUM	Get_single
150	OUTPUT_ASSEMBLY	Get_single/Set_single
151	CONFIG_ASSEMBLY_NUM	Get_single/Set_single

Instance	Description	Service
152	HEARBEAT_INPUT_ONLY_ASSEMBLY	Get_single/Set_single
153	HEARBEAT_LISTEN_ONLY_ASSEMBLY	Get_single/Set_single
154	EXPLICT_ASSEMBLY	Get_single/Set_single

Table 66: Supported instances (cont.)

Table 67: Class attributes

ld	Attribute	Access rule	Data type	Description
1	Revision	Get	UINT	Revision: 2
2	Largest Instance Number	Get	UINT	Largest instance number: 154
3	Number of Instances Currently Existing	Get	UINT	Number of instances currently existing: 7
4	Optional Attribute List			Unsupported
5	Optional Service List			Unsupported
6	Maximum ID Number Class Attributes	Get	UINT	Maximum ID Number Class Attributes: 7
7	Maximum ID Number Instance Attributes	Get	UINT	Maximum ID Number Instance Attributes: 4

Table 68: Instance attributes

ld	Attribute	Access Rule	Data type	Description
3	Data	Get	ARRAY of:	
			BYTES	-
4	Size	Get	UINT	Number of bytes in Attribute 3

Connection Manager

The Connection Manager Class (*Class Code 0x06*) allocates and manages the internal resources associated with both *I/O* and *Explicit Messaging* connections.

Table 69: Class attributes

ld	Attribute	Access rule	Data type	Description
1	Revision	Get	UINT	Revision: 1
2	Largest Instance Number	Get	UINT	largest instance number: 1
3	Number of Instances Currently Existing	Get	UINT	Number of instances currently existing: 1
4	Optional Attribute List			Unsupported

ld	Attribute	Access rule	Data type	Description
5	Optional Service List			Unsupported
6	Maximum ID Number Class Attributes	Get	UINT	Maximum ID Number Class Attributes: 7
7	Maximum ID Number Instance Attributes	Get	UINT	Maximum ID Number Instance Attributes: 14

Table 69:	Class attributes (cont.)	
-----------	--------------------------	--

Device Level Ring object (depends on hardware)

The Device Level Ring (DLR) object provides the configuration and status information interface for the DLR protocol (revision 2).

Only Instance 1 of the TCP/IP Interface Object (*Class Code 0x47*) is available.

Table 70: Class attributes

ld	Attribute	Access Rule	Data type	Description			
0x1	Network Topology	Get	USINT	0: Linear 1: Ring			
0x2	Network status	Get	USINT	 Current status of the network. 0: normal 1: Ring Fault 2: Unexpected Loop Detection 3: Partial Network Fault 4: Rapid Fault/ Restore Cycle 			
0x3	Ring Supervisor Status	Get ¹	USINT	 Backup Active Ring Supervisor Normal Ring Node Non-DLR topology Device cannot support the Beacon Interval or Timeout 			
0x4	Ring Supervisor	Set ¹	STRUCT of:				
	Config		BOOL SupervisorEnable	default FALSE			
			USINT SupervisorPrece-dence	default 0			
			UDINT BeaconInterval	default 400			
			UDINT BeaconTimeout	default 10000			
			UINT DIrVlanId	default 0			
0x5	Ring Faults Count	Set ¹	UINT	Number of ring faults since power up			
0x6	Last Active Node	Get ¹	STRUCT of:	Last Active node at the end of chain			
	on Port 1		UDINT Devicelp	through port 1 of active ring - supervisor during ring fault			
			ARRAY of:				
			6 USINT Mac				

ld	Attribute	Access Rule	Data type	Description		
0x7	Last Active Node	Get ¹	STRUCT of:	Last Active node at the end of chain		
	on Port 2		UDINT Devicelp	through port 2 of active ring		
			ARRAY of:	 supervisor during ring fault 		
			6 USINT Mac	_		
0x8	Ring Protocol Participants Count	Get ¹	UINT	Number of devices in ring protocol participants list		
0x9	Ring protocol	Get ¹	ARRAY of:	List of devices participating in ring		
	participants list		STRUCT of:	[–] protocol –		
			UDINT Devicelp			
			ARRAY of:	_		
			6 USINT Mac	_		
0xA	Active Supervisor	Get	STRUCT of:	IP and/or MAC address of the		
	Address		UDINT Supervisorlp	active ring supervisor		
			ARRAY of:	_		
			6 USINT SupervisorMac	_		
0xB	Active Supervisor Precedence	Get ¹	USINT	Precedence value of the active ring supervisor		
0xC	Capability Flags	Get	DWORD	Describes the DLR capabilities of the device		

Table 70: Class attributes (cont.)

1. The conditional attributes are implemented for devices capable of functioning in a ring.

QoS object

The QoS object (0x48) provides sending EtherNet/IP messages with non-zero DiffServ code points (DSCP). The QoS object supports one instance.

Table 71:	Class attributes

ld	Attribute	Access Rule	Data type	Description
0x1	Revision	Get	UINT	Revision of this object: 1
0x2	Max Instance	Get	UINT	Maximum instance number: 1
0x3	Number of instance	Get	UINT	Number of object instances currently added: 1
0x4	Optional Attribute List			Unsupported
0x5	Optional Service List			Unsupported
0x6	Maximum ID Number Class Attributes	Get	UINT	Maximum ID Number Class Attributes: 7
0x7	Maximum ID Number Instance Attributes	Get	UINT	Maximum ID Number Instance Attributes: 8

ld	Attribute	Access Rule	Data type	Description
0x1	802.1Q TagEnable			Unsupported
0x2	DSCP PTP Event			Unsupported
0x3	DSCP PTPGeneral			Unsupported
0x4	DSCP Urgent	Get/Set	USINT	DSCP value for CIP transport class 0/1 Urgent priority messages. (default 55)
0x5	DSCP Scheduled	Get/Set	USINT	DSCP value for CIP transport class 0/1 Scheduled priority messages. (default 47)
0x6	DSCP High	Get/Set	USINT	DSCP value for CIP transport class 0/1 High priority messages. (default 43)
0x7	DSCP Low	Get/Set	USINT	DSCP value for CIP transport class 0/1 Low priority messages. (default 31)
0x8	DSCP Explicit	Get/Set	USINT	DSCP value for CIP explicit messages (transport class 2/3 and UCMM) and all other EtherNet/IP encapsulation messages. (default 27)

Table 72: Instance attributes

Services, Connections and I/O Data

The device supports the following connection types and parameters.

Table 73: Settings for integrating a new module

Setting	I/O connection	Input only	Listen only	
Comm Format:	Data - DINT	Data - DINT	Input Data - DINT - Run/Program	
IP address	IP address of the device	IP address of the device	IP address of the device	
Input Assembly Instance	100	100	100	
Input Size	32	32	32	
Output Assembly Instance	150	152	153	
Output Size	32	0	0	
Configuration Assembly Instance	151	151	151	
Data Size	10	10	10	

I/O Data	Value (data types and sizes to be defined)	Direction	Size ¹
Device Status	Bitmask (see Switch Agent Attribute 0x1)	Input	DWORD
Link Status	Bitmask, 1 Bit per port (0=No link, 1=Link up)	Input	DWORD
Output Links Admin State applied	Bitmask (1 Bit per port) to acknowledge output. Link state change can be denied, for example for controller access port. (0=Port enabled, 1=Port disabled)	Input	DWORD
Utilization Alarm ²	Bitmask, 1 Bit per port (0=No alarm, 1=Alarm on port)	Input	DWORD
Access Violation Alarm ³	Bitmask, 1 Bit per port (0=No alarm, 1=Alarm on port)	Input	DWORD
Multicast Connections	Integer, number of connections	Input	DINT
TCP/IP Connections	Integer, number of connections	Input	DINT
Quick Connect Mask	Bitmask (1 Bit per port) (0=Quick Connect disabled, 1=Quick Connec enabled)	Input	DINT
Link Admin State	Bitmask, 1 Bit per port (0=Port enabled, 1=Port disabled)	Output	DWORD

Table 74: Device I/O data structure

1. The default size of the port bit masks is 32 bits (DWORD). For devices with more than 28 ports the port bit masks have been extended to n * DWORD.

2. You specify the utilization alarm settings in the *Basic Settings > Port* dialog, *Ingress Utilization* tab. The upper threshold value is the limit, where the alarm condition becomes active. The lower threshold value is the limit, where an active alarm condition becomes inactive.

3. You specify the Access Violation alarm settings in the *Network Security* > *Port Security* dialog. The upper threshold value is the limit, where the alarm condition becomes active. The lower threshold value is the limit, where an active alarm condition becomes inactive.


Object type	Bit size
BOOL	1 bit
DINT	32 bit
DWORD	32 bit
SHORT-STRING	max. 32 bytes
STRING	max. 64 bytes
UDINT	32 bit
UINT	16 bit
USINT	8 bit
WORD	16 bit

Table 75: Mapping of the data types to bit sizes

16.4 **PROFINET** function

PROFINET is an industrial communication protocol that is deployed worldwide. It is based on the protocols TCP/IP and UDP/IP over Ethernet. This is a crucial aspect in fulfilling the requirements for consistency from the management level right down to the field level.

PROFINET enhances the existing Profibus technology for applications that require fast data communication and the use of industrial IT functions.



PNIO (PROFINET IO cyclic frame) DCP (Discovery and Configuration Protocol)

Figure 106: Communication between the Controller and the device

In particular, you find **PROFINET** in Europe and with Siemens controllers.

PROFINET uses the device description language GSDML (Generic Station Description Markup Language, based on XML) to describe devices and their properties so that they can be processed automatically. You find the device description in the GSD (Generic Station Description) file of the device.

For further information on PROFINET, see the PROFIBUS Organization website at www.profibus.com.

The devices conform to class B for PROFINET.

16.4.1 **Device Models for PROFINET GSDML Version 2.41**

The device generates GSDML files in the GSDML V.2.41 format. Within the GSDML file, the device is modeled according to GSDML standard V.2.4.

Bus Interfa Slot 0						
SubSI 0x8001	SubSI 0x8002	SubSI 0x8003	SubSI 0x8004	SubSI 0x8005	SubSI 0x8006	Compact SubSI =Subslot
Port 1	Port 2	Port 3	Port 4	Port 5	Port 6	

Figure 107: Compact device

Bus Interface									
Slot 0	Slot 1				Slot 2				
	Module 1			Module 2			Modular		
			SubSI						SubSI = Subslot
	0x 8001	0x 8002	0x 80	0x 80.n	0x 8001	0x 8002	0x 80	0x 80.n	Subsidi
	Port 1	Port 2	Port	Port n	Port 1	Port 2	Port	Port n	

Figure 108: Modular device

	us Inter	face										
5	Slot 0					Slo Mod	ot 1 ule 1			Slo Modu		
	SubSl 0x8001	SubSl 0x8002		SubSI	0x	0x	SubSI 0x 80	0x	0x	SubSI 0x 8002	0x	SubSl 0x 80.n
	Port 1	Port 2	Port	Port n	Port 1	Port 2	Port	Port n	Port 1	Port 2	Port	Port n

Figure 109: Mixed device

16.4.2 Graphical User Interface and Command Line Interface

When you set up the device successfully in a *PROFINET* environment, the PROFINET IO controller establishes an Application Relation (AR) with the device.

After the user logs into the device management through the Command Line Interface, the device displays a message that an Application Relation is active. In the *Advanced > Industrial Protocols >* PROFINET dialog, the Graphical User Interface displays equivalent information, for example, the number of running Application Relations.

16.4.3 Integrating the device into a Control System

Preparing the device

First you install, connect and set up the device. Then you integrate the device into a Control System. To do this, perform the following steps:

- □ Open the *Basic Settings* > *System* dialog.
 - □ Verify that a valid system name for the device is specified in the System name field.
 - \Box Apply the settings temporarily. To do this, click the \checkmark button.
 - □ Open the *Basic Settings* > *Network* > *IPv4* dialog.
 - □ In the *Management interface* frame, select the *LocaL* radio button.

- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the *Diagnostics* > *Status Configuration* > *Device Status* dialog, *Global* and *Port* tabs.
- □ Set up the alarms you want to monitor.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ Open the Advanced > Industrial Protocols > PROFINET dialog.
- Download the GSD(ML) file and the icon onto your local computer.
- □ To enable the *PROFINET* function, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

Changing the default values

Functions that directly affect the *PROFINET* function require the following default values to be changed. When you obtain the device as a specially available *PROFINET* variant, the following values are already predefined:

PROFINET	Advanced > Industrial Protocols > PROFINET dialog Operation = 0n Name of station = "" (empty string)
Network	Basic Settings > Network > Global dialog • HiDiscovery protocol v1/v2 Access = readOnLy Basic Settings > Network > IPv4 dialog • IP address assignment = LocaL • IP address = 0.0.0.0 • Netmask = 0.0.0.0 • Gateway address = 0.0.0.0
VLAN	Switching > Global dialog • VLAN-unaware mode = marked
LLDP	Diagnostics > LLDP > Configuration dialog • Transmit interval [s] = 5 • Transmit delay [s] = 1

Configuring the PLC

The following illustrates the configuration of the PLC using the example of the TIA Portal software from Siemens, and assumes that you are familiar with operating the software.

The device also supports engineering stations from other manufacturers, such as PC Worx from Phoenix Contact.

In the PLC default setting, the PLC detects the interruption of the I/O connection to the device and treats the interruption as a failure. The PLC considers 3 consecutive real time packets missing from a partner PLC or from the device as an interruption. According to the default setting, the PLC treats this as a system failure. To change this default setting, you employ TIA Portal programming measures.

Note: Monitoring the I/O connection to the CPU of the device as a detected failure can result in a potential system failure. Therefore, do not consider the I/O connection to the CPU when monitoring.

The device management data packets can interrupt the I/O connection between the PLC and the device. For example, a management station can saturate the CPU of the device with higher priority real time data. In this case, because the device can still transmit or receive data packets, the system remains operational.

Providing the GSDML file

The Hirschmann device provides you with the following option for generating GDSML files and icons:

You can use the Advanced > Industrial Protocols > PROFINET dialog in the GUI to download the GSDML file and the icon of the device.

16.4.4 Incorporating the device in the configuration

Incorporating the GSDML-based device in the network device settings includes the following actions:

- "Incorporating the device" on page 427
- "Renaming the device" on page 432
- "Setting up the IO Cycle" on page 437
- "Setting up Media Redundancy" on page 443
- "Adding modules for modular devices" on page 448
- "Adding digital I/O modules in non-modular devices" on page 452
- "Adding digital I/O modules in modular devices" on page 456
- "Adding an SFP transceiver as a submodule in non-modular devices" on page 460
- "Configuring the port properties" on page 463
- "Configuring the connection options" on page 468
- "Swapping devices" on page 477
- "Topology discovery" on page 477
- "Configuring the topology" on page 478
- "Communication diagnosis" on page 478

Incorporating the device

Perform the following steps:


- □ Open the *TIA Portal* application.
- □ Open your project. To do this, select your project and click the *Open* button.

art			Open existing project		
Devices &		🦲 Open existing project	Recently used		
	11 A	- obtain annound brokers	Project	Fath	Last change
		Create new project		E/iUserstedminiDesktop1HenceshUns_39435	1/20/2023 4:1
		and the second second second	Project3.ap15_1	C/Users/admin/Documents/pnya/Project3	4(21/2022.4.8
programming	1	Migrate project	57601 hns.ap15_1	C:UserstadminiDesktop)Haneesh137801hns	12/21/2022 1 2
			🛅 hns10gsfp.ap15_1	C/IUsers\edminlDesktop\Heneeshlhns10gslp	6/15/2022 3:1
Motion &		Close project	hns_10gstp.ep15_1	C/Usershedmin/Desktop)Heneesh\\hns_10gslp	5/17/2022 3:1
technology			hns_39257.ap15_1	CiUsersiadminiDesktopiHaneeshihna_39257	5/11/2022 12:
			Project2.ap15_1	C/IUsersladminiDacumentslpriyalProject2	2/1/2022 8:13:
			Project1 ap15_1	C/IUserstedminiDocumentstpnyatProject1	1/25/2022 9.5
	1		🚺 demo1.ap15_1	CiUsersiadminiDocumentalpriyaldemo1	7/15/2021 10:
		Welcome Tour	5 3500.ap15_1	C/IUsers)edminlDocuments/Automation)3500	12/30/2021 6:
			Project_38049_nemite.ep15_1	C/UserstedminiDocumentslAutomation?Project_38049_nemite	12/14/2021 2:
	1	First steps	stop_plc_issue.ap15_1	C:IUsersTadminiDocumentsKutomationTstop_plc_issue	9/27/2021 3.4
			Froject1 ap15_1	C/Users/admin/Documents/Automation/Project1	9/21/2021 6:0
			<	-10	>
		 Installed software Help User interface language 	Activate basic integrity check Brawse Berrove		

□ In the *Project view* frame, select the *Open the project view* object.


				Totally Integrated Automation PORTAL
Start			First steps	
Devices & networks	*	Open existing project	Project: "hns_39435" was opened successfully. Please select the next step:	
PLC programming		 Create new project Migrate project 	start.	
Motion & technology	*	Close project	Devices 2	
Visualization	1	Welcome Tour	Devices X g D Configure a device	
Online & Diagnostics	10	First steps	PLC programming Vilte PLC program	
			Hotion & Configure technology objects	
		 Installed software Help 	Visualization D Configure an HMI screen	
		🖏 User interface language	Project view Open the project view	

Install the GSDML file.



- In the menu bar, click the items Options > Manage general station description files (GSD).

 In the Manage general station description files dialog, Installed GSDs tab, Source path field, browse and select the GSD folder for the GSDML file previously saved on your computer. Click the OK button.



Mark the GSDML file and click the *Install* button.

Project Edit View Insert Online						Totally Integrated Auto	mation	
	🗄 🗙 りま (** 圭 🚡 🛄 📅 🚆 📮 💋 Goonline 🧭 Go	offline		-Search	in project>		PORTAL	
Project tree 🛛 📢					=	Tasks	-711►	
	lanage general station description files			×		Options		(I) Tasks
	Installed GSDs GSDs in the project				the state of the s			Tas
	Source path: C:\Users\admin\Desktop\Haneesh\hns_39435\Ad	ditionalFiles\G	SD			✓ Find and replace		ks
• hns_39435						i ind dird replace		
🗄 🔛 🚰 Add new device	Content of imported path					Find:		Libraries
	File	Version	Language	Status			-	ibr
plc_1 [CPU 314C				Not yet install		Whole words only		arie
Geourity settings	GSDML-V2.41-Hirschmann-0130-GRS1040-V910-20220726.xml	V2.41	English, Ge	Not yet install		Match case		S.
Gommon data					A CARL CARL CARD	Find in substructures		
Documentation s						Find in hidden texts		
▶ 🧑 Languages & res						Conservation and the state state		
 Doline access 						Use wildcards		
Y Display/hide inter					1 Diagnostics	Use regular expressions		
▶ 🛄 COM [R5232/РРІ Ма						Down		
Intel(R) Ethernet Realtek PCIe GbE						Olup		
Realtek PCIe GbE	< III			>		Find		
Check Point Virtu			_	1	and the second		-	
PC internal [Local]		Delete	Install	Cancel	not have any displayable	Replace with:		
🕨 🕒 USB [S7USB] 🛛 🔤				/	-		· · ·	
🕨 🛄 TeleService (Auto)			()		(Whole document		
▶ 🋄 COM <3> [RS232/ 🏹				N		O From current position		
COM <16> [RS232 R			1	1		○ Selection		
< III >				\				
✓ Details view			4	F		Replace Replace all		
Name						> Languages & resources		
📢 Portal view 🔚 Overvie	ew				📑 😒 п	he project hns_39435 was saved succ	a	


- After the GSDML file installation is completed, click the *Close* button.

Project Edit View Insert Online Options Tools Window Help 🕂 💁 Gave project 🔒 🗶 🗐 🙃 🗙 🖘 2 CP 2 🚡 🔃 🖸 🔛 🕼 🖉 Ga online 🖉 Ga online 🎄 頂 🚺 🗱 🗴 🚽 🖬 collearch in projects 👍	Totally Integrated Automation PORTAL	L
Project tree II 4	Tasks 🗐 🛙 🕨	Т
Devices Henage general station description files X Installed GSDs GSDs in the project Source path: C:UsersladminDesitap/Haneeshihns_\$9435VddtionalFilesIGSD	Options Find and replace	Tasks
Content of Partices 2 metwork Particles 2 met	Match case Find in substructures Find in hiden texts Use widdands Use regular expressions Down Up Find Replace widt: Whole document From current position Beplace Replace all	Libraries
Name	Languages & resources	
✓ Portal view	e project hns_39435 was saved succ	

You find the new device under the items Other field devices > PROFINET IO > Network Components > Hirschmann Automation and Control GmbH.

ct tree 🛛 🛋 hr	ıs_39435 → Devices & networks		_ # = ×	Hardware catalog	- 1 E
vices		🛃 Topology view 💧 Network	view 📑 Device view	Options	
🔲 🖻 🖬	Network Connections HMI connection	- 2 % H II ' H N	etwork overview		
		~	2 Device	✓ Catalog	
hns_39435		=	 \$7300/ET200M station 1 	<search></search>	(init)
Add new device			> plc_1	Filter Profile: Alb	
Devices of networks	PIC_1 CPU 314C-2 PN/_	-			
plc_1 [CPU 314C-2 PN/		1		Controllers	
Ungrouped devices		<u>*</u>		HMI DC systems	
Security settings				C systems Drives & starters	
Common data	PN/IE_1			Inves & starters Metwork components	
Documentation settings		~		Detecting & Monitoring	
Languages & resources	III > 100%	·	< = >	Distributed VO	
Display/hide interfaces		Properties	Diagnostics	Power supply and distribution	
a and the second met and the second		Seroperdes [3 into 3]	Diagnostics	Field devices	
intel(R) Ethernet Conn	General			Other field devices	
A Realtek PCle GbE Fami				Additional Ethernet devices	
Realtek PCIe GbE Fami				PROFINET IO	
Check Point Virtual Ne	No 'properties' available.			Drives	
PC internal [Local]	No 'properties' can be shown at the moment	There is either no object selected or the s	elected object does	Encoders	
USB [S7USB]	not have any displayable properties.			Gateway	
TeleService (Automati				Network Components	
COM <3> [RS232/PPI m)				- 🔚 Hirschmann Automation and	Control GmbH
COM <16> [RS232/PP1 15				- BOBCAT	
Toma de Incasaler - Mar				- 📑 BRS20-04009999	
II >				▶ 📺 V9.0	
tails view				- U.V.I.	
				with VO data	


Drag the selected device and drop it onto the *Network view* worksheet.



□ Assign the device to the PLC. To do this, click the *Not assigned* link in the device tile, then select the required item.

hns_39435 + Devices & networks		🗙 Hardware catalog 🥔 🖉 I	123
Topology view	A Network view	Options	_
💦 Network 🔡 Connections HMI connection 💌 📰 🗒 🔛 🛄 🔍 ±	Network overview	•	
# 10 system: plc_1.PROFINET IO-System (100)	Device	✓ Catalog	
	 \$7300/ET200M station_1 	144	est.
pic_1 314c2 PW.	 pic_1 G3D device_1 B8320-04009999 	Filter Profile: Alb- Gamma Controllers Gamma Controllers Main Gamma Controllers Main Gamma Controllers Gamma Controller	
< II > 100%	 <td>2</td><td></td>	2	

□ Click the Save project icon.




Renaming the device

Perform the following steps: Click the *Project view* icon.

								Totally Integrated Automation PORTAL	Ļ
Start			First step	-					_
Devices & networks	1	Open existing project	Project: "	hns_:	39435" was opened s	successful	liy. Please select the next step:		
PLC, programming		Create new project Migrate project	Start						
Motion & technology	*	Close project		->		6 Q	Configure a device		
	1	Welcome Tour First steps		÷	PLC programming	Ŷ	Write PLC program		
			ŀ	÷	Mation & Inclinularyy	00	Configure technology objects		
		 Installed software Help 		÷		Ø	Configure an HMI screen		
		🚯 User interface language		÷	> Project view	ſ.	Open the project view		

The dialog displays the *Project view* window.

□ Click the Overview tab in the footer.



The dialog displays the Overview window.

Double-click the *Devices & networks* icon.

Project Edit View Insert Online Options Tools Window Help Project Edit View Insert Online Options Tools Window Help	Ga anline 🖉 Ga affline 🔝 🖪 🗊 🗶 🖃 🛄 🛛 🖾 earch in projects 🛙 🙀	Totally Integrated Automat PC	tion DRTAL
▶ 19642_		- Tasics	111
	Details List Thumbnails	Options	1
Actions		✓ Find and replace	3
Add new Deuter		Find	
device network		Whale words only	quits
Security settings		Find in substructures	- 8
in hr		Thind in hidden texts	- 1
Settings		Thise withouts	- 1
		Cise regular expressions	- 1
Others		(a) cown	
		Out	- 1
E Common Ungrouped Lengueges		Find	- 1
settings data devices & resources			
		Replece with:	
		(ii) Whole doctiments	
		From current position	- 1
	💁 Properties 🚺 🚺 🖬 Diagnostics 👘 👘	C Selection	- 1
General (1) Cross-references Compile		Replace Replace all	- 1
🕲 🔔 🜖 Show all messages 🔹			
1 Path Description	Go to 7 Errors Warnings Time	Activate Windows	
Taxa Marka and		> Languages & resources	15
4 Portal view		Project 19647. created	

The dialog displays the *Devices & networks* window.


□ In the *Network view* tab, click the icon of the device.

39435 ► Devices & networks		Hardware catalog
	🚰 Topology view 🚠 Network view 🔐 Device vi	Options
thvork 🖬 Connections Httll connection 💿 🖭 🖫 🖽 🖬 🕄 🗨 🗉	Network overview	A b
0.10	system: plc_1.PROFINET IO-System (100) 🛆 🦞 Davice	✓ Catalog
	= 7 \$7\$00/ET200M s	tation:
plc_1 grs1040 with IIO data		Filter Profile: Alla
	 GoD device_2 ▶ grs1040 	F Controllers
Not essigned		+ 🔁 HMI
PN/E 1: 192.168.0.1 2 PN/IE 1: 192.168.0.23	1	fC systems fC systems for the statement
Plc_1.PROFINET IO-Syste		In Network components
		Detecting & Monitoring
	· · · ·	🕨 🧰 Distributed 1/0
	\sim	Forwer supply and distribution
		Field devices Generation of the field devices
		of the observes
		✓ Information
	V	
u > 1	10% 💌 🖓 📢 K 1	> Device:
device_2 [Device]	Properties 🖏 Into 🖏 Diagnostics 🗌	- AND
neral IO tags System constants Texts		
ieral		·
General		
H .		and a second sec


39435 ▶ Ungrouped devices ▶ grs1040 [with VO data]					_ # = ×	Hardware catalog	1
	🖉 To	pology vie	w Metwork view	Y Devi	ce view	Options	
grs 1040 (with 1/0 data) 💌 🔛 🕎 🕎 🔂 🖽 🖪 🍕 ±	3	Device	averview		(6	N	
	2		Module	Rack	Slot	Antalog	
	=		▼ grs1040	0	0		14
	100		PTHO	0	0 X1		
State			· GMM-BASE-6T6Z_1	0	1		•
4				0	1 P1	Initiad module	
				0	1 P2		
			10MM DOMM G R/45	0	1 P3	• Media module - copper ports	
6			10MM DOMM G RH5_1	0	1.94	 Media module - Copperlüptical pert 	8
				0	1.65	🕨 🌆 Media module - Gigabit ports	
				0	1 P6	 Media module - input/output Media module - optical ports 	
	3		10N/100N/16 N45_2	0	1 P7	Submodules	
			10N/100M/10 N45_3	0	1 P8	• Carson submodules	
				0	1.P9		
				0	1 P18		
			10MM 00MM G 8/45_4	0	1 P11		
			10M/100M/16 RH45_5	0	1 //12		
				0	Z.		
				0	3		
				0	4	✓ Information	_
	×		Fort data_1	0	5	Device	
1 > 100%.		<	11		>	Uevide:	
	10	Propertie	s Sinfo S Diagon	istics			
eneral IO tags System constants Texts							
Ethernet addresser							
Advanced options							
						4	
Interface options							

Select the *Device view* tab to display the device details.











	hns_39435 + Ungrouped det						- • • ×	Hardware catalog	
Devices		😹 Topology view 🔒 Network view 🛐 Device view							
	🔠 dut (with VO data)	💌 📑 🐂 🗖 🗖	evice averview			-	- 222 (194		-
		^	Module	Rack	Slot	Laddress	Q ad	🛩 Catalog	
" 🔄 hns_39435		=	- dur	0	0		-	- Searcho	144 B
Add new device			PNHO	0	0.×1		-	🖌 Filter Profile: Alla	
Devices & networks Japping 1 [CPU 3140.2 PW/DP]	MR		▼ GMM-BABE-6T6Z_1	0	1			Head module	10018
La Digrouped devices	0			0	1.01			+ Ca Module	
Geounity settings				0	1 /2			+ Submodules	
Chassigned devices			10M/100M/16 RJ45	σ	1 93			Contraction of the second s	
F G Common data		×	10%/100%/16 RI45_1	0	1 P4		~		
Documentation settings	< 11 >		<] II.	۰.	1.00		>		
• 🛅 Languages & resources	Gut [with #0 data] Properties Linfo 2 Diagnostics								
Geline access	The second secon								
🔄 Card Reader/USB memory	General IO tags System constants Texts								
	General Add new subnet								
	Catalog information								
		▼ FROFINET interface (x1) IP protocol							
	General Ethernet addresses		Set IP address in the p						
	Advanced aptions								
	Advanced spaces Interface options		IP eddress: 5					✓ Information	
	Media redundance		Subnet mask: 2	55 255	5 255 1	D			
	+ Real time settings		Synchronize router set	tings with	n IC contro	ller		Device:	
	10 cycle	4 5	. Ose router						
	Diagnostics eddresses	1	N Routereddress: To						
Details view	Identification & Mointenance	~							
	Module peremeters		O IP address from DHCP:	server					
			Client ID.						
	Diagnostics addresses		CINERAL HOUSE						

□ In the *IP protocol* frame, select the Set *IP* address in the project radio button.


□ In the *IP* address field, enter the required IP address.





□ In the *PROFINET* frame, unmark the *Generate PROFINET* device name automatically checkbox.

Enter the same name as specified in the Hirschmann device in the PROFINET device name item.



The device is now included in the configuration.

Setting up the IO Cycle

Perform the following steps: Click the *Project view* icon.

			Totally integrated Automation PORTAL
Start			First steps
Devices & networks	-	Open existing project	Project: "hns_39435" was opened successfully. Please select the next step:
PLC programming	-	Create new project Migrate project	Start Start
Motion & technology Visualization	*	Close project	Devices 2 networks 5 Configure a device
Online & Diagnostics	10	 Welcome Tour First steps 	PLC programming Write PLC program
			Hatlan & Configure Inclinating: 🚓 Configure
		 Installed software Help 	Visualization Configure an HMI screen
		🛞 User interface language	Project view Open the project view

The dialog displays the Project view window.

□ Click the *Overview* tab in the footer.

Hajest Edit View Insert Online Options Tools Window Help 予告日 Sweptrowst 当 X 生 (主 X 当主 (注 石) (注 石) 田 田 国 際 ダ Countine 愛 Goothine 静 問 罪 X 士 () Idealch in project	Totally Integrated Automation PORTAL
	Tasks @ LL ▶
	Options
1 × 1 × 2 × 2	Options
	Find and replace
	Find.
	- E
	Find:
	Match case
- 197 July 198 Feb	Find in substructores
	🖂 Find in hidden texts
	🗌 Use wildcards
	Use regular expressions
	(C) Down
	Cup
	Find
	Replace with:
	(a) Whale document
S Properties S Info 6 2 Dia	Innestica CErram current position
General 2 Cross-references Complie	Concerner
Complete Com	Keplace Replace all
I Path Dropper Dropper Time	Activate Windows
	> Languages & resources
🔹 Portal view 🛛 🖾 Overview 💙	📑 😪 Project 39642_created.

The dialog displays the Overview window.

Double-click the *Devices & networks* icon.

547		- Tasks 🕴 🖡
	Details List Thumbnails	Options
tions		✓ Find and replace
* 1		
		Find
kinew Devices		
		Whole words only
curity settings		Shotch cone
		Tind in substructures
		Find in hidden texts
tings		Line wideards
		Cite regular expressions
iers		() Down
		O 10
iment. Common Ungrouped Longuages		Find
ntings data devices & resources		Replace with:
		Replace with:
		(ii) Whole document
		Prom current position
	🖳 Properties 🛛 🚺 Info 🚺 🖏 Diagnostics 👘 💷	 Selection
eneral 1) Cross-references Compile		Replace Replace all
1 Show all messages		E subace I replace an
Path Description	Go to 7 Errors Warnings Time	Activate Windows
		> Languages & resources

The dialog displays the *Devices & networks* window.


□ In the *Network view* tab, click the icon of the device.

Image: State of the	s_39435 → Devices & networks		_ # = ×	Hardware catalog	
ID system: pk_1 PROFINETIO-System (100) Image: Cru 314C 2 PW Image: Cru 314C		🚰 Topology view 🚮 Networ	k view 🛛 🍸 Device view	Options	
PL: CRUSINCO PNUL PL: CRUSINCO PNUL PNAR T1 192.160.01 2 PNAR T1 192.160.01 2 PN	Network 🚺 Connections Hbll connection 🔹 🖭 🖽 🖽 🖳 🔍 🗉	3	Network overview 4 +		1
PRUE_11		I IO system: plc_1_PROFINET IO-System (100)	W Device	✓ Catalog	
II Device Carbon Constants Texts Carbon Carb	PN/RE_11: 192.168.0.11 2 PN/IE_11: 192.168.0.23	R I	F plc_1 ▼ GSD device_2	Filter Profile: ovlids * filter Profile: ovlids * filter filte	
Name: GSD device_2	D device_2(Device) Seneral IO tags System constants Texts		in the second se		

 \Box Assign the device to the PLC.

Right-click the *Not assigned* link in the device tile.

□ In the context menu, select the Assign to new IO controller item.



The Select IO controller window opens. ☐ Select the required item, then click the OK button.

Froject Edit View Insert Online Options Tools Window Help P 💁 🚼 Save project 🚢 🗶 🖄 😳 🗙 🍤 🖆 (** 🕤 🔃 🔝 📰 🐺 🖉 Go Totally Integrated Automation PORTA Go offlin -37801hns ► Devices & networks = X Devices 🚰 Topology view 📩 Network view Device - W R. . . . Q. : Network Network overview = ŵ. 10 system: plc_1.PROFINET IO-System (100) Catalog Device 37801hns
 Add new device
 Devices & networks
 Top Ic_1 [CPU 3140-2 ... S7SOC/ET200M station_1 init init Systitute:
 plc_1
 GSD device
 brs40 Profile; | <All: • Eilte s40 th IiO data plc_1 CPU 314C-2 PN/. 6 plc_TCRU 31462...
 Drvice cardigura.
 Q. Online & diagno...
 B. Program blocks
 D. External source fi...
 Plc Technology obje...
 Plc Technology obje...
 Plc Technology obje...
 Plc Technology obje...
 Wetch and force ...
 Q. Online backups
 D. Online backups Select IO controller V PNUE 1: 192.168 0.1 2 pic_1 PROFINET I agnostics Contine Dackups
 Device proxy data
 Device proxy data
 Program info
 PrC supervisions .
 PrC alarm text lists
 Local modules
 Distributed VO
 Unangued devices 10 tags Syst General General G Y GSD device_1 Inform Author: 🚂 Ungrouped devices Device = Security settings Comment 5 ✓ Details view with I(O date

As an alternative, click the Not assigned link in the device tile, then select the required item.

is_39435 ▶ Ungrouped devices ▶ grs1040 [with VO data]				_ # = ×	Hardware catalog 🔍 🔍
	🖉 Topology	y view 🔥 Network view	Devis	e viev	Options
🔸 grs 1646 (web illo data) 💌 🔛 🕎 🔛 🔀 🗄 🗄 🔂	📑 De	evice overview		(0	N
		V Module	Rack	Slot	atalog
	-	▼ grs1040	0	0	1
A		PTHO	o	0 X1	
1000		 GMKI-BASE-6T6Z 1 	0	1	
			0	1 P1	Initiad module
			0	1 P2	Media module - copper ports
		10MM DOWN G R/45	0	1 P3	Media module - capper ports Media module - Copper/Optical perts
		10M/100M/16 RH45_1	0	1 P4	Media module - Gigabit ports
6	1		0	1.75	Media module - Gigant ports Media module - input/output
			0	1 P6	Media module - optical ports
		10%/100%/16 RI45_2	0	1.P7	Submodules
		1.0%/1.00%/1.0 RJ45_3	0	1 P8	* C deniodales
			0	1 P9	
			0	1 P10	
		10MA 00MA 8 845_4	0	1 P11	
		10M/100M/16 R045_5	0	1 (*12	
			0	Z	
			0	3	
					✓ Information
			0	4	
		Port dets_1	0	5	
1) 100% v	1 x	Fort dats_1			Device:
		(I	ō	5	
1040 [with 10 data]	A A A A A A A A A A A A A A A A A A A	(I	ō	5	
1040 [with UO data] General IO tags System constants Texts	A A A A A A A A A A A A A A A A A A A	(I	ō	5	
1040 [with UO data] General IO tags System constants Texts Ethernet addresses	A A A A A A A A A A A A A A A A A A A	(I	ō	5	
ID40 (with KD data] General ID tags System constants Texts Ethernet addresses Advanced points Texts	A A A A A A A A A A A A A A A A A A A	(I	ō	5	
s1040 (with VO data) General IO tags System constants Texts	A A A A A A A A A A A A A A A A A A A	(I	ō	5	


\Box Select the *Device view* tab to display the device details.

□ Select the *Properties* tab.


The Properties tab contains additional tabs.

	hns_39435 ► Ungrouped det							. # # X	Hardware catalog		
Devices			21	opology view 🔥	Network	view	Devic	e view	Options		
1 🗐 🕺	🔐 dut (with VO dete)	R 2 ' 2	Device over	view							5
		~	. Modu	le.	Reck	Slot	Faddress	D ad	✓ Catalog		
hns_39485		-	* d		0	0		~	«Search»		est in
Add new device	1	1		PNHO	0	0 >:1		-	Filter Prolile:	Alb	
Devices & networks Jacobia (CPU 3140-2 PM/DP)	Sile -	÷.	• G	WKI BASE 6T6Z_1	0	1		1	+ TH Head module	1.4.60	
Garger Charles	<u> </u>				0	1 P1			+ in Module		
Security settings					0	1 P2			• Submodules		
Coll Unassigned devices				10MM 00MM G RH5	0	1 P3			State The Providence		
Cemmon data		~		10M/100M/16 RJ45_1	0	1 P4		V			
Documentation settings	< 11 >		<	. 11	D.	1.00		>			
Languages & resources	dut [with I/O data]			Q Properties	nfo	8 Diagn	actics	1			
Online access											
📑 Card Reader/USB memory	General IO tags System constants Texts										
		▼ Generol Ethernet addresses									
		Ethernet addresse		(N							
	Catalog information	Ethernet addresses		(h							
	Catalog information FROFINET interface (201)	Ethernet addresses		- (h	>						
	Catalog information • FROFINET interface [X1] General		rked with	()	>						
	Catalog information • FROFINET interface [X1] General Ethernet addresses			PWE1	>			-			
	Caralog information FROFINET interface [21] General Ethernet addresses Advenced aptions		rked with		>						
	Catalog information + FROFINET interface (X1) General Ethermet addresses + Advenced options Interface options		rked with		>				✓ Information		
	Catalog information • FROPINET interface [X1] General Ethernet addresses • Advanced options Interface options Media redundancy		rked with		>				✓ Information Devœ:		
	Catalog information • FROFINET interface [21] General Ethernet addresses • Advenced sptions interface options Modio redundancy • Real time settings	Interface netwo	r ked with Subriet: [Add netwisybriet							
	Catalog information • FROFINET interlese (N1) General Ethernet addresses • Advenced sptions miterface options Modia redundancy • Seal time settings 10 opde	Interface netwo	r ked with Subriet: [S						
Details view	Catalog information • FROFINET interface [21] General Ethermet addresses • Advanced options interface options Notifie vedundancy • field time settings 10 cycle Diagnostus addresses	Interface netwo	r ked with Subriet: [Add netwisybriet	- St.	. 0 . 1	51				
Details view	Catalog information • FROFINET interlace (N1) General Ethermet addresses • Advenced options Interlace options Media redundancy • Seal from settings IO cycle Diagnostica addresses Kentilication & Maniternance	Interface netwo	r ked with Subriet: [Add networkboat Add networkboat Add networkboat Faddress in the p IP address:	92 168						
Details view	Catalog information = FROFINET interface [21] General Lithermet addresses + devended opsigns Interface options Modio redundancy = Seal time settings 10 cycle Diagnostiko addresses Kentilisation & Maintennoe Kedul paremeters	Interface netwo	r ked with Subret: [Add new subnet Bet IP address in the p IP address : 1 Subnet mesk: 2	92 168 255 255	5.255.0					
Details view	Catalog information • FROFINET interlace (N1) General Ethermet addresses • Advenced options Interlace options Media redundancy • Seal from settings IO cycle Diagnostica addresses Kentilication & Maniternance	Interface netwo	rked with Subret: []	Add networkboat Add networkboat Add networkboat Faddress in the p IP address:	92 168 255 255	5.255.0					


□ In the General tab, navigate to the PROFINET interface [X1] > Advanced options > Real time settings > IO cycle item.



□ In the Update time frame, select the Set update time manually radio button.




From the *Update time[ms]* drop-down list, select the desired item.



□ In the *Watchdog time* frame, select the desired item from the *Accepted update cycles without IO data* drop-down list.







Setting up Media Redundancy

Perform the following steps:

□ Click the *Project view* icon.

			Totally Integrated Automation PORTAL
Start			First steps
Devices & networks	1	Open existing project	Project: "Ims_39435" was opened successfully. Please select the next step:
PLC programming		Create new project	Start
Motion & technology Visualization	*	Close project	Devices Z g S Configure a device
Online & Diagnostics	1	 Welcome Tour First steps 	PLC programming Write PLC program
			Mution & Configure technology abjects
		 Installed software Heip 	Visualization Configure an HMI screen
		🖏 User interface language	> Project view Open the project view

The dialog displays the Project view window.

□ Click the *Overview* tab in the footer.

fraject Edit View Insert Online Options Iools Window Hep 近週日 Sweproved 当 X 也 日 X 均定 (4 1 日 旧 田 田 陽 ダ Countine 愛 Gouttime 静 問 田 X 日 山 Lasarch in projects 海	Totally Integrated Automation PORTAL
	Taska 🔊 🖬 🗆 🕨
	Options
	Options
	✓ Find and replace
	ried.
	Find:
	March case
	Find in substructures
	Eind in hidden sexts
	Cae wildcards
	Use regular expressions
	 Corver
	<u>O ue</u>
	Find
	Replace with:
	() Whole document
S Properties Sinfo () Diagnostics	C From current position
General 1 Cross-references Comple	Oselection
3 A 0 Show all messages	Keplace Replace all
i Path Dord Time Go to ? Errors Warnings Time	Activate Windows
	> Languages & resources

The dialog displays the Overview window.

	🎽 Galonline 🍠 Galottine 🛔 🖪 🎼 🛠 🖃 🛄 😢 Search in projects 🛛 🙀	- Tasks d 11
19647_		the service in the se
	Details List Thumbnails	Contraction
2 🛄 🛄 🐻		- T
Actions		✓ Find and replace
Add new Deuter		Find.
device networ		Whole words only
Security settings		Tind in substructures
11 15		Tind in hidden texts
Settings		These wildcards
		Cae regular expressions
Others		Down
Care and Day Day		
🔟 🛐 🖳 🚺		0.00
ocument Common Ungrouped Longueges settings data devices &resources		Find
searings data devices excedutes		Replace with:
		() Whole document
		C From current position
	💁 Properties 🚺 Info 🚺 🖏 Diagnostics 👘	C Selection
General 10 Cross-references Compile		Replace Replace all
A Show all messages		
Path Description	Go to 7 Errors Warnings Time	Activate Windows
Path Description	Go to 7 Errors Warnings Time	> Languages & resources

The dialog displays the *Devices & networks* window.

□ In the *Network view* tab, click the icon of the device.

aven II Connections Holl connection * 世際日日の生活の 4 10 system: plc_1.PROFINET IO-System	A Network		Options	
	1.0			
IO system: plc_1.PROFINET IO-System	and the second sec	Network overview 4 >		5
	(100)	W Device	✓ Catalog	
	=	▼ \$7800/ET200M station		ini in
PNIE_1: 192.168.0.1 2 PNIE_1: 192.168.0.1 2 PNIE_1: 192.168.0.1 2 PNIE_1: 192.168.0.23		 ▶ plc_1 ◆ G80 device_2 ▶ grs1043 	Inter Profile: sells Image: Sector Controllers Image: Sector Controllers Image: Sector Controllers Image: Sector Controllers	
			✓ Information	
1 100% · · · · · · · · ·		<a>1	Device:	
		S Diagnostics		

is_39435 ▶ Ungrouped devices ▶ gis1040 [with VO data]	Topola	gy view	Devi		K Hardware catalog P
🕨 grs1848 (with 1/0 data) 💌 📰 📰 🌠 📰 🖪 🔍 ±	Charles I are	Device overview	BI Devi	6	Dans
				- 4	N
	1224 (<u>1</u>	1 Module	Rack	Slot	atalog
		▼ grs1040	0	0	
(A)		PTHO	U	0 X1	Frolile: Ally
and the second se		GMM+BASE-6T6Z_1	0	1	Y Micad module
			0	1 P1	- In Module
		10MM DOWN G R/45	0	1.P2 1.P3	• 📑 Media module - copper ports
		10M/100M/16 RH5_1	0	1.84	🕨 🕞 🙀 Media module - CopperlOptical parts
6		TOWIT DOWIT & KHOL	0	1.09	🕨 🤙 Media module - Gigabit ports
	2		0	1.P6	🕨 🌆 Media module - inpat/output
	2	10%/100%/16 N45 2		1.P7	Media module - optical ports
		10N/100M/10 8/45 3		1.28	Submodules
			0	1.89	
61 10 10 10 10 10 10 10 10 10 10 10 10 10			0	1.P10	
		10M/100M/16 RH45_4	0	1 P11	
		10M/100M/16 R045_5	0	1 1912	
			0	z	
			0	3	
			0	4	✓ Information
	~	Fort data_1	0	5	
		K I		4	Devise:
1 > 100% -		operties 🛄 Info 🕄 Diag	nostics	1	2
	S Pro				
1D40 [with Wo data]	S Pro	thernes 124 min 128 mind			
1040 [with VO data] General IO tags System constants Texts	3 Pro	dennes 174 mm 175 med			
1040 (with UD data) General 10 tags System constants Texts Ethernet addresses	3 Pro	herres 174 man 175 mad			~
1040 [with VO cata] General IO tags System constants Texts	<u>S</u> Pro	hennes 174 man 174 mad			• •


 \Box Select the *Device view* tab to display the device details.

□ Select the *Properties* tab.

The *Properties* tab contains additional tabs.


	hns_39435 + Ungrouped								_ # = ×	Hardware catalog	
Devices					Topology view	Network	view	Devio	e view	Options	
1 🗌 🖬	🔐 dut (with VO dete)	· ·	3	Devic	e overview						5
			^	-	Module	Rack	Slot	Faddress	Q ad	✓ Catalog	
] hns_89485			-		▼ dut	0	0		2	<searcha< td=""><td>64 6</td></searcha<>	64 6
Add new device			1		PIHO	0	0 >:1		-	Filter Prolile: Alb	-0
Devices diffections [m] plc_1 [CPU 3140-2 PM/DP]	815				 GMM-BASE-6T6Z_1 	0	1		1	• I Head module	
Ungrouped devices		13	*			0	1 P1			• 📺 Module	
🕨 🙀 Security settings					10M0 00M0 G R/45	ŏ	1.83			🕨 🧾 Submodules	
Constigned devices					10M/100M/16 RI45_1	0	1.P4				
Genmon data Goovernmentation settings	< U	3	ě	(1.00		>		
		E 111711	. 14	121			n or		11000	5	
Image and the second	dut [with I/O data]				Properties 1	nto	8 Diagn	ostics	1=-		
Online access		System constan	its T	exts	Q Properties	nto	to Diagn	ostics	UED		
 Canguages & resources Online access Card Reader/USB memory 	General 10 tags ▼ General	Π	10115		Properties 141	nto	's Uragn	ostics			
Online access	General IO tags	Ethernet a	ddresses		R	nto	's Dragn	ostics			
Online access	General 10 tags Catalog information FROFINET interface D(1)	Ethernet a	10115		R	nto	S Dragn	ostics			
Online access	General 10 tags Catalog information FROFINET interface [21] General	Ethernet a	ddresses	ked wit	*	nto I	s Diagn	ostics			
Doline access	General 10 tags Catalog information FROFINET interface D(1)	Ethernet a	ddresses	ked wit		nto	s, Dragn	ostics			
Doline access	General 10 tags Catalog information Catalog information PROFINET interlace [21] General Ethernet addresses Advanced apsions Interlace options	Ethernet a	ddresses	ked wit	*	>	s, Dragn	ostics		✓ Information	
Online access	General 10 tags Cenerol Catalog information ROPINET interface (ph1) General Ethermet addresses Advenced options Interface options Interface options Modine redundance Notion redundance	Ethernet a	ddresses ce networ	ked wit		nto I	s, Diagn	ostics			
Online access	General 10 tags • General Catalog information • ROPINET interface (211) General Litherinet addresses • Advanced appions interface options Netlio redundancy • Set Unres settings	Ethernet a	ddresses ce networ	ked wit		>	s, Diagn	ostics		✓ Information	
Online access	General IO tags Canalog information Catalog information Catalog information Ethernetaldiceses Ethernetaldiceses Advanced options Index de options Index de options Vedia reductiones options Vedia reductiones I control settings I control settings	Ethernet a	ddresses ce networ	ked wit		>	3 Diagn	ostics		✓ Information	
ie Online sccess g Card Reederiùs9 merrary.	General 10 tags ✓ General Catalog information Catalog information PROFINET interface (21) General Ethernet addresses ✓ Advenced options Interface options Interface options Modific incluncings ✓ Seal time settings IO cycle Diagnations addresses Volume	Ethernet a Interfac	ddresses ce networ	ked wit	th anet: PAIE_1 Add new subret	N N N N		ostics a		✓ Information	
je Online sccess g Carl ReaderiùS9 memory:	General IO tags Canalog information Catalog information Catalog information Ethernetaldiceses Ethernetaldiceses Advanced options Index de options Index de options Vedia reductiones options Vedia reductiones I control settings I control settings	Ethernet a Interfac	ddresses ce networ	ked wit	h anet: PAIE_1 Add new subset) roject 92 168	5 0 .5	51		✓ Information	
Online access	General 10 tags General Caralog information Caralog information FROFINET interface [21] General Ethermet addresses Advenced ppions Interface cotions Notific redundancy Seal row settings IO coyle Diagnostics addresses Identifications differences in Mainterance Mainterance	Ethernet a Interfac	ddresses ce networ	ked wit	h anet: Puie_1 Add nexi subset © Set IP address in the p IP address in	roject 92 168 255 255	3 0 . S	51		✓ Information	

□ In the General tab, navigate to the *PROFINET* interface [X1] > Advanced options > Media redundancy item.



From the *Media redundancy role* drop-down list, select the desired item.









	hns_39435 🕨 Ungrouped devices 🕨 dut (with VO data) 🛛 💶 🖬 🗮 🗙								Hardware catalog	
Devices		🛃 Topology view 🛛 🛔 Network view 🛛 🔐 Device view					e view	Options		
11 🗐 🖬 🗐 🖬	dut (with 10 data)) 🖬 ' 🖬 🗍 🗖	Device overvie	v						
		^	W Module		Rack	Slot	l address	Q ad	▼ Catalog	
 hns_\$9185 		-	▼ dut		0	0		1	Searcho	ini init
Add new device			Pr	HO:	0	0.>11			Filter Profile: Alla	
networks	But	2	♥ GMM	BASE-616Z_1	0	1			Hesd module	
plc_1[CPU 314G-2 PN/	\$°	22			0	1 P1			> in Module	
🕨 🔛 Ungrouped devices					0	1.62			> Submodules	
Security settings			10	M/100M/16 RI45	0	1 P3			addinidates	
 Unassigned devices Common data 			10	M/100M/16 RI45_1	0	1 F4				
Documentation settings					0	1.65				
Languages & resources		2 -			0	1 F6			2	
Grine access	6 81 2		<	- (1)		1.00		>		
Card Reader/USB memory	dut [with VO data]		O, P	roperties 强 I	nfo 🔒 🗄	& Diagn	ostics	1		
and needed over methody	General 10 tags Syste	em constants Te	exts						1	
	▼ General	an constants 1 is								
	 General Catalog information 	 Media redunciano 	×							
	PROFINET Interface [X1]							1		
	General		MRP domain	rdonaimT				-		
	Ethernet addresses		ndanogrole: M					-	✓ Information	
	 Advanced options 	mears recu	10	anager						
	Interface options		Ring part 1:	•				Device:	-	
	Media redundancy		Ring port 2:					. /	*	=
<] II >	 Real time settings 		Pt	но раји смасоми но раји смасоми	GRUIS [RD	(\$10(1 PS	IPSRI (C			
✓ Details view	10 cycle		er er	HO [X1](10M100M1	GR045_11	R0/51/X1	P4 KJ P7 R1	6		
and a second second	Diagnostics addresses		P	HO [X1][10M/100M/1	G 845_3	RO/S1/X1	"8 R]			
	Identification & Maintenance			но (ха)(лем/пермя но (ха)(лем/пермя					IN	
	Module parameters		1	co papaino como	or of a s T is is	wacari	r ta nj	_	V	

□ From the *Ring port 2* drop-down list, select the desired item.

□ Mark the *Diagnostics interrupts* checkbox to receive *MRP* ring 0pen/Close alarms.



□ Click the Save project button.



Note: When an Application Relation is already established, do not disable any of the MRP Ring ports using the I/O modules (PROFINET).

Adding modules for modular devices


Perform the following steps:

□ Click the *Project view* icon.

							Totally Integrated Auto	mation PORTAL
Start			First steps					
Devices & networks	1	Open existing project	Project: "hos	_39435" was opened :	successful	lly. Please select the next step:		
PLC programming	۲	 Create new project Migrate project 	Start					
Motion & technology	•	Close project			e G	Configure a device		
		Welcome Tour First steps	_→		¢	Write PLC program		
	100		→	Motion & technology	-	Configure technology objects		
		 Installed software Help 	→		Ø	Configure an HMI screen		
		🚯 User interface language		 Project view 	Ĵ.	Open the project view		

The dialog displays the *Project view* window.

□ Click the Overview tab in the footer.



🔆 🛄 Give project 🍙 🗙 🍬 🗟 🗙 🥱 土 🤁 土 🗄 🕮 🕮 🖉 🖉	entering in the rest of the second se	Totally Integrated Automation PORTA
19642		- Tasks 🖉 🗍 🕨
	Details List Thumbnails	Options
		Options
Actions		✓ Find and replace
📫 📥 <u>~</u>		12.1
		Find.
Add new Devices		Whale words only
Security settings		Tind in substructures
11 45		Find in hidden texts
Settings		These weidenards
		Cise regular expressions
Others		() Down
		Out
1 🖬 🙀 🛄 🔯		Find
Document Common Ungrouped Longuages settings data devices & resources		I
		Replace with:
		Whole document
		C From current position
General (1) Cross-references Compile	Campenes 1 and a Mondatories 1	() Selection
Compile Compile Compile		Replace all
The line is a line of the same of the same same same same same same same sam		
I Path Description	Go to 7 Errors Warnings Time	Activate Windows
		> Languages & resources

The dialog displays the *Devices & networks* window.

- Select the *Network view* tab.
- □ Click the icon of the device that is under test.


nns_39435 🔸 Devices & networks					8 U F
		Topology view 🔥 Network	k view 🛛 🏹 Device view	Options	_
Network 🚺 Connections Hbll connection		=	Network overview		- 0
	IO system:	plc_1.PROFINET IO-System (100)	W Device	✓ Catalog	
		=	▼ 87800/ET200M station.		hil hit
	rs1040		F plc_1	Filter Profile: Alla	-
			 GSD device_2 grs1040 	Controllers	
	lot assigned	1	, giorese	• 🛄 HMI	
PNAE 1: 192.168.0.1 2	N/IE 1: 192.168.0.23			 FC systems Drives & starters 	
Fplc_1.PROFINET IO-Syste				Metwork components	
				• 🬆 Detecting & Monitoring	
	1.5	2		Distributed I/O	
	N			 Forver supply and distribution Field devices 	
				Other field devices	
				-	
		1			
		~		✓ Information	
C 11	> 100%		<1 >	Device:	2
		S Properties	🕄 Diagnostics 🛛 💷 🔻		
	Texts				
General IO tags System constants					
General IO tags System constants General General					

is_39435 ▶ Ungrouped devices ▶ grs1040 [with VO data]				_ # # ×	Hardware catalog 🛛 🔿	
	🖉 Topolo	ogy view 🚮 Network view	TY Devi	ce view	Options	
🕨 grs 1040 (web illo data) 💿 📰 🕎 🖉 🚰 🗐 🍳 ±	3 1	Device overview		(N	
	2	W Module	Rack	Slot	Atalog	
	-	▼ gr31040	U	0		aï
		PTHO	ō	0.01		
10 ¹⁰		GMK+BASE-6T6Z 1	0	1		•
			0	1 P1	+ inead module	
			0	1.P2	- In Module	
		10M/100M/16 R/45	0	1.P3	• 📑 Media module - copper ports	
		10M0 00M0 G R/45_1	0	1.84	Media module - CopperlOptical perts	1
6			0	1.05	🕨 🬆 Media module - Gigabit ports	
			0	1 PG	🖡 🬆 Media module - input/butput	
	1	10N/100N/16 N45_2	0	1.97	Media module - optical ports	
		10N/100M/10 RI45_3	0	1 P8	Submodules	
			0	1.P9		
			0	1 P10		
		10M0 00M0 G RJ45_4	0	1 111		
		10M/100M/16 R045_5	0	1 1912		
			0	z		
			0	3		
			0	4	✓ Information	-
	~	Fort dete_1	0	5		-
1 > 100%	· · · · · · · · · · · · · · · · · · ·	< D	and the second second	>	Device:	
1040 [with #O data]	D Pr	operties 🚺 Info 🕄 Diagr	nstics	1		
General IO taos System constants Texts	3	decision Leaguest Leaguest				
Ethernet addresses				^		
Advanced options						
Interface options						
Media redundanay 🐷					Article no.:	

□ Select the *Device view* tab to display the device details.

Select the *Hardware catalog* tab in the right margin to display the *Catalog* pod.

s_39435 ► Ungrouped devices ► grs1040 [with VO data]			8	_ # # ×	Hardware catalog 🛛 🔿 🛛
	🖉 Topolog	y view 🚮 Network view	IY Devi	e view	Options
grs 1040 (with ifo data) 💌 📰 🔣 🔛 🖪 🔍 🛨	E Di	evice overview			
		/ Module	Rack	Slot .	✓ Catalog
	=	▼ gr31040	U	0	ail a
A CONTRACT OF CONTRACT.		PNHO	0	0 X1	Filter Profile: 41
as an		 GMKI-BASE-6T6Z_1 	0	1) Head module
			0	1 P1	- Intest module
			0	1 P2	• Media module - copper ports
		10MM DOMM G RH5	0	1 P3	Media module - Copper/Optor Corts
		1 GM/1 DGM/1 G RH45_1	0	1.04	Media module - Gigabit port
6			0	1.75	Media module - input/output
	10		0	1 PG	Media module - optical ports
		10N/100N/16 RI45_2	0	1 P7	• 🛅 Submodules
		10N/100N/10 N45_3	0	1 P8	
			0	1 P9 1 P10	
		10M/100M/16 RI45_4	0	1 P11	
		10M/100M/16 R45_5	0	1 (22)	
		Telan bean a loss_c	0	Z	
			0	3	
			0	4	
	×	Fort dets_1	0	5	✓ Information
1 > 100%		(1)	the second s	>	Device:
1040 [with VO data]	S Prop	erties 🔍 Info 🕄 Diago	estics	1	1
		ernes 173 man 175 punder	oouus		
General IO tags System constants Texts				1.11	
Ethernet addresses				•	
Advanced options Externet addresses				-	-
Interface options					



- Totally Integrated Auto mation PORTAL 🐭 🚵 🗷 🗶 📥 🛄 🖂 hns_39435 → Ungrouped devices → grs1040 (with VO data) - T = X 🚰 Topology view 🛛 📩 Network view Device view Options 👉 grs1046 (with I/O data) Device overview -Medule • grs1040 PN-I0 • GMM-BASE-5762_1 Laddress Q address Type with IO data GRS1042-6Te2 GMM-3ASE-61... Y Back Slot Catalog | MA 0 0 X5 Filter Profile: All> -Head module Module Module - copper ports 1 P1 1 P2 1 P3 1 P4 1 P5 1060100601G. 1060100601G 10M/100M/16 R/45 10M/100M/16 R/45_1 Media module - Copper 6 . 1 P6 1 P7 1 P9 1 P9 1 P10 1 P11 4 P12 1 10M/100M/1G RI45_2 10M/100M/1G RI45_3 10M/100M/1G. 10M/100M/1G. GMMSD-UUUUTTT GMMSD-VVMMTTT GMMSD-VVMMTTT GMMSD-VVMTTT GMMSD-VVMTTT GMMS2-KINNKTTT Information 10K/100K/10 RI45_4 10K/100K/10 RI45_5 10601006016 Fort date Port deta_ 5 100% 6 Reperties Linto Diagnostics General GMMBO-RMMMTTT No 'properties' available
- \Box In the tree view, select the required module.

In the Device view tab, the slot which is physically connected to the device is highlighted.

Drag the selected module, and drop it onto the highlighted slot in the *Device view* tab.

				Topology view	LL Me	twark view	Device view	Options
		. margare	C	· i obmody area	(B) (1)	itwark view	Device view	Options
🛫 🔤 grc1646 (with i/O data) 👘 💌		a Devi	ce overview					
		A 18	Module	Rack	Slot	Laddress	Q address Type	✓ Catalog
		-	▼ grs1040	n	0		with VO data in	644
.9		and the second	PN-IO	0	0 ×1		GRS1042-676	Filter Profile: Alla
01000			· GMM-BASE-6162	1 0	1		GMM-BASE-6T	Head medule
G				0	1 F1			• Module
				0	1 F2		-	Media module - copper ports
			10001000010		1 F3		10ΜΠ 00ΜΠ 6	Media module - Copper Optical ports Media module - CopperOptical ports
			10601006010	IRJ45_1 0	1 F4		10M/100M/16	GMMDC-MMMMMT
and the second se	6			n	1 F5			GMX 30-MMNNTTT
	COMPANY AND ADDRESS			0	1 F6			GMM30-NUUNTTI
		¥	10001000014		1 F7		1 0 M/1 0 0 M/1 G	GMMSG-UUMMTTT
			10001000014	3 R/45_3 0	1 F8		∋ nmao nma r	GMMS0-UUNNETT
				IJ	1 /9			GMM30-UUUUTTT
				D	1 F10		and the second second	GMM 20
			106/1006/10	2012 C	1 F11		10M/100M/1	GMM/36-WVNNTTTT
		-	10601006010	RU45_5 0	1 F12		3.0M/1.00M/1.4	
		100	· GMMSD-MMMMTT	0	2	-	GMMSO-MM/	
			100M MM SC		Non		100M MM SC	
			100/1000/16		3.172		DIMO DOMO E V	✓ Information
1 3 100%			. one restricts	N	1		3	Device:
MM30-MMMMTTTT_1 (GMM)	the second s			100 0 00	Thu	Dallar	and the second s	
MWSESWARWATTI L_LEGMM	G-MMMMM11111			Properties	NE	P Dis	ignostics 🔹 🔍 🖃 👻	and the second se
General IO tags Syst	em constants Texts				1 1			IN

Note: The TIA Portal automatically adds the *fixed ports* when you add a module in the *Device view* tab. If the module has SFP slots, you need to set up the SFPs. See section "Adding an SFP transceiver as a submodule in non-modular devices" on page 460.

Adding digital I/O modules in non-modular devices


In non-modular devices, *device data* modules and *port data* modules are available that transfer the I/O data packets in the *PROFINET* network. For inserting a *device data* module or *port data* module, perform the following steps:

Click the *Project view* icon.

			Totally Integrated Automation PORTAL
Start	>	First steps	
Devices & networks	Open existing project	Project: "Ins_39435" was opened successfully. Please select the next step:	
PLC programming	Create new project	start 🔊	
Motion & technology	Close project	Devices 2	
Visualization	💋 👩 Welcome Tour	neverks by Configure a device	
Online & Diagnostics	First steps	PLC programming Write PLC program	
		tordan k. Configure technology abjects	
	 Installed software Help 	Visualization Configure an HMI screen	
	🚯 User interface language	Projectivieor Open the projectiview	

The dialog displays the Project view window.

Click the Overview tab in the footer.



1日 seve project 🚡 🗶 迫 回 🗙 🥱土 (Pi 土 克 田 田 田 田 単 Go online 🎜 Go offline 🛔 547			Totally Integrated Auto	
	Details	List Thumbnails	Options	Internation (Inco
	Details	Tuanunans	- Options	
dons			✓ Find and replace	1.000
			· I mu and reprace	
* h <u>~</u>			Find.	
le new Devices			L	•
EVICE DEEVONUT			Whale words only	
curity settings			C Norch case	
			Tind in substructures	
in 15			Find in hidden texts	
ettings			Use wideards	
			Cise regular expressions	
hers			() Dawn	
🖬 🙀 🛄 🚺			0.49	
ument Common Ungrouped Longuages			Find	
ntings data devices & resources			Replace with:	
			Replace with:	
			(a) Whate document	
			Prom current position	
	🖳 Properties 🔤 🗓 Info 🔒 🕄	Diagnostics -	C Selection	
ieneral 🕦 Cross-references Compile			Replace Replace all	
1 O Show all messages			[websites [] websites and [
			20-140010-0224004-007-0	
Path Description Go to 7	Errors Warnings Time		 Activate Windows 	

The dialog displays the *Devices & networks* window.

□ In the *Network view* tab, click the icon of the device.

	hns_39435 > Devices & networks			_ • • ×	Hardware catalog 🛛 🖬	
Devices		🚰 Topology view	A Network view	Device view	Options	
a 📃 🖬	Network	- W . H . Q +	Sa Netwo	ork overview 4 🕨		C
			^ ¥ 0	evice	✓ Catalog	_
hns_39435				\$7300/ET200M st	<search></search>	-
Add new device	plc_1 BRS20	-04009999		▶ plc_1		
Devices & networks	CPU 314C-2 PN/ with I/C		-	GSD device_1	Controllers	100
Ungrouped devices =	pic_1	0		BRS20-04009	HMI	
Security settings					PC systems	
Common data					Drives & starters	
Documentation settings	PN/IE_1	(7)			Im Network components	
Languages & resources					Detecting & Monitoring	
Online access					Distributed I/O	
Y Displayhide interfaces			2		Power supply and distributio	1
COM [RS232/PPI multi No		91	•		Field devices	
Intel(R) Ethernet Conn Image: Intel(R) Ethernet Conn					• 📑 Other field devices	
🕨 🛄 Realtek PCIe GbE Fami 💹						
🕨 🧾 Realtek PCle GbE Fami 💹						
Check Point Virtual Ne PC internal [Local]						
USB [S7USB]						
TeleService [Automati III						
Details view						
Dectano nen						
	<	100% -	🖸 K 🛙			
Name	S (#	hanne inter-	Linfo 1 Diagnos		> Information	-

- Project Edit View Insert Online Options Tools Window Help 🕐 💁 🔒 Save project 📇 🗶 🗐 🖘 🗙 👘 🛎 (**± 🐁 🖳 🌆 🖉 📓 🖉 Go online 🖉 Go utiline 🎄 🕞 🗊 🛠 🛁 🛄 Go Totally Integrated Automation PORTAL hns_39435 + Ungrouped devices + BRS20-04009999 [with VO data] _ # = X 🚰 Topology view 🛛 🛔 Network view 📑 Device vi Device overview
 Rack
 Slot
 Inddress
 Q addr...
 Type

 0
 0
 2042*
 with I/O data


 0
 0 X1
 2041*
 B8520-04009999

 0
 0 X1 P1
 2040*
 Port 1 10M/100M MJ.


 0
 0 X1 P2
 2039*
 Port 2 10M/100M MJ.

 0
 0 X1 P2
 2038*
 Port 3 10M/100M MJ.

 0
 0 X1 P4
 2037*
 Port 4 10M/100M MJ.
 Article no. BR520-04009999 47 ... Module Firmy Comment Module * BR\$20-04009999 * PN-IO Port 1 10M/100M RJ45 Port 2 10M/100M RJ45 Port 3 10M/100M RJ45 Port 4 10M/100M RJ45 V09.1.00 POnline tools (PTasks] Librarie: 2 Properties 📑 😴 Project hns_39435 opened. Portal view 🔁 Overview 🔒 BRS20-04009...
- Select the *Device view* tab to display the device details.



Device overview Module • BRS20-0009999 • PHIO Port 1 10M100M Port 2 10M100M Port 4 10M100M	RU45 0 RU45 0	Slot 0 0 ×1 0 ×1 P1 0 ×1 P2 0 ×1 P3 0 ×1 P4	2039* 2038*		Topology view Type with I/O data BRS20-04009999 Port 1 10M/100M RJ Port 2 10M/100M RJ.	Article no. BRS20-04009999	Firmware C., V09.1.00	Options ✓ Catalog Filter Profile: ⊲Alb-	(ast) (***
✓ Module ✓ BR520-04009999 ✓ PN+0 Port 1 10W100M Port 2 10W100M Port 3 10W100M	0 0 045 0 045 0 045 0 045 0	0 0 ×1 0 ×1 P1 0 ×1 P2 0 ×1 P3	2042* 2041* 2040* 2039* 2038*	Q addr	with I/O data BRS20-04009999 Port 1 10M/100M RJ				[643] (
BRS20-04009999 FN-IO Port 1 10M/100M Port 2 10M/100M Port 3 10M/100M	0 0 045 0 045 0 045 0 045 0	0 0 ×1 0 ×1 P1 0 ×1 P2 0 ×1 P3	2042* 2041* 2040* 2039* 2038*	Q addr	with I/O data BRS20-04009999 Port 1 10M/100M RJ				
 FN-IO Port 1 10M/100M Port 2 10M/100M Port 3 10M/100M 	0 045 0 045 0 045 0 045 0	0 ×1 0 ×1 P1 0 ×1 P2 0 ×1 P3	2041* 2040* 2039* 2038*		BRS20-04009999 Port 1 10M/100M RJ	BRS20-04009999	V09.1.00	Filter Profile: Allo	
Port 1 10M/100M Port 2 10M/100M Port 3 10M/100M	045 0 045 0 045 0 045 0 0	0 ×1 P1 0 ×1 P2 0 ×1 P3	2040* 2039* 2038*		Port 1 10M/100M RJ			Filter Profile: All>	
Port 2 10M/100M Port 3 10M/100M	045 0 045 0 045 0 0	0 ×1 P2 0 ×1 P3	2039* 2038*						
Port 3 10M/100M	045 0 045 0 0	0 ×1 P3	2038*		D			• Mead module	Tree (
	045 0 0				POR 2 10M0100M R0			• Module	6
Port 4 10M/100M	0	0 X1 P4			Port 3 10M/100M RJ			Media module - input/output	
	17		2037*		Port 4 10M/100M RJ.			r an media module - inpubouput	/
	0								$\boldsymbol{\epsilon}$
		2							7.1
<							>		



					-		Network view	Device view	Options	
					5	Topology view	Network view	Device view	Options	
Devi	ce overview								-	
1	Module	Rack	Slot	I address	Q addr.	Туре	Article no.	Firmware	Catalog	
	 BRS20-04009999 	0	0	2042*		with I/O data	BRS20-04009999	V09.1.00		100
	▼ PN-IO	0	0 X1	2041*		BR520-04009999			Filter Profile: All>	
	Port 1 10M/100M RJ45	0	0 X1 P1			Port 1 10M/100M RJ	4		• 📴 Head module	
	Port 2 10M/100M RJ45	0	0 ×1 P2			Port 2 10M/100M RJ	4		- Module	
	Port 3 10M/100M RJ45	0	0 X1 P3			Port 3 10M/100M RJ			• Media module - input/output	
-	Port 4 10M/100M RJ45	0	0 X1 P4	2037*		Port 4 10M/100M RJ			Device data	
		0	1						Port data	
		0	2							
									1.5	
<									-	

In the *Device view* tab, the slot which is logically connected to the device is highlighted.


- Project Edit View Insert Online Options Tools Window Help P 💁 🔒 Save project 🚔 🗶 🍓 🕞 🗙 🆘 🛨 (주 🗄 🗓 🔛 🔛 🔛 🖉 Go online 🧬 Go offline 🏄 🖪 ዙ 🗶 🖃 💷 Totally Integrated Automation PORTAL - 21 hns_39435 + Ungrouped devices + BRS20-04009999 [with VO data] _ # # X 🚰 Topology view 🛛 🚠 Network view 📑 Device view Options Hare **Device overview** Module • BR\$20-04009999 • PN-IO Port 1 10M/100M R/45 ••••• 2 10M/100M R/45 ✓ Catalog
 Slot
 I address
 Q addr...
 Type

 0
 2042*
 with I/O data

 0X1
 2041*
 BR520-04009999

 0X1 P1
 2040*
 Port 1 10M/100M RJ...
 Article no. BRS20-04009999 Rack Firmware V09.1.00 C. 2 init init atalog Filter Profile: Alb Filter Profile: Alb
 Head module
 Head module
 Media module - input/output
 Media module - input/output
 Device data
 Port data 0 X1 P1 2040 0 X1 P2 2039* 0 X1 P3 2038* 0 X1 P4 2037* Port 2 10M/100M RJ. Port 3 10M/100M RU45 Port 4 10M/100M RU45 Device data_1 Port 3 10M/100M RJ. Port 4 10M/100M RJ. ⇒ Online Device data Port data 2 3...5 Port data_1 0...2 tools Tasks - Libra 🖻 Properties 🚺 Info 🚺 🗓 Diagnostics > Information Portal view 🔁 Overview 🛔 BR520-04009.... 🛃 🔽 Project hns_39435 opened
- □ Drag the selected module, and drop it onto the highlighted slot in the *Device view* tab.

Click the Save project icon.



Adding digital I/O modules in modular devices


In modular devices, *device data* modules and *port data* modules are available that transfer the I/O data packets in the *PROFINET* network. For inserting a *device data* module or *port data* module, perform the following steps:

Click the *Project view* icon.

			Totally Integrated Automation PORTAL
Start	>	First steps	
Devices & networks	Open existing project	Project: "hns_39435" was opened successfully. Please select the next step:	
PLC programming	Create new project	Start	
Motion & d	Close project	Devices &	
Visualization	Welcome Tour	Devices 2 networks & S Configure a device	
Online & Diagnostics	First steps	PLC programming 😵 Write PLC program	
		Hation & Configure technology objects	
	 Installed software Help 	Visualization 💋 Configure an HMI screen	
	🚯 User interface language		

The dialog displays the Project view window.

Click the Overview tab in the footer.




1647_		- Tasks II
	Details List Thumbnails	Options
	The second secon	options
ctions		 Find and replace
		· I no and replace
🛉 🕂 🦰		Eind.
dé new Devices		
issues network N		Whole words only
rawity settings		C Netch case
		Tind in substructores
		Find in hidden texts
ettings		C Lise wildcards
		Cise regular expressions
hers		(Cown
🛅 🙀 🛄 🔯		Olip
ument. Common Ungrouped Longueges		Find
ettings data devices & resources		Replace with.
		Replece with:
		Whole document
		Prom current position
	😔 Properties 🔤 🔂 Info 🔒 😨 Diagnostics 👘 🖃 —	Selemon
General 10 Cross-references Compile		Replace Replace all
1 Show all messages		inspiros in replace an
Path Description	Go to 7 Errors Warnings Time	Activate Windows
		> Languages & resources

The dialog displays the *Devices & networks* window.

 \Box Select the *Device view* tab to display the device details.


Project Edit View Insert Online Options Tools Windo		A2 15		t 📑 🔲 🖂 dearch in project			Totally Integrated Automatic POR	TAL
hns_39435 + Ungrouped devices + grs1040 (with VC						_ # = ×	Hardware catalog 🛛 🔿	
		🖉 Торо	logy vie	w Network view	TY Devi	ce view	Options	_
🏕 [gr:1646 (with 1/0 data) 💌 📰 🖉 🔂 🖽 🖪		311		averview		(0	=N	E
			-		1.00		Atalog	-
		-	u -	Module grs1040	Rack	Slot	No line	-
		-		PIHO	o	0 21		and any
610				 GMKHBASE-6T6Z 1 	0	1		1
				anno a tar a tar ji	0	1 P1	+ Mead module	
					0	1.P2	- In Module	
				10MM DOW/1 G R/45	0	1 P3	• 🔄 Media module - copper ports	
				10MM 00MM G R/45_1	0	1.94	Media module - Copper/Optical perts	
6					0	1.25	Media module - Gigabit ports Media module - inpat/output	
		1			0	1 P6	Media module - impability in	
				10%/100%/16 RI45_2	0	1 P7	> Submodules	
				10N/100N/10 RI45_3	0	1 P8	Californics	
		12			0	1.P9		
					0	1 P10		
		1.5		10MM 00MM G RI45_4	0	1 P11		
				10M/100M/16 RH45_5	0	1 (*12		
					0	2		
					0	4		_
		100		Fort dets_1	0	5	✓ Information	-
< 1	> 100%		<	1		3	Device:	1
grs1040 [with WO data]			ropertie	s 🖄 Info 🕄 Diagno		1		12
		13P	ropentie	is 177 muo 120 maduo	stics	- Little Re		
General IO tags System constants Text	S)							
Ethernet addresses								
 Advanced options 		_	_		_		*	
Interface options	with							
Media redundancy 🐷						1	Attice no :	V
Portal view 🗮 Overview 📥 grs1040							Loading completed (errors: 0: warning	



Select the *Hardware catalog* tab in the right margin to display the *Catalog* pod.


The tree view displays the available media modules.

□ In the tree view, *Media module - input/output* branch, select the required *device data* module or *port data* module.



In the Device view tab, the slot which is logically connected to the device is highlighted.

□ Drag the selected module, and drop it onto the highlighted slot in the *Device view* tab.



Adding an SFP transceiver as a submodule in non-modular devices

In the TIA Portal, you can set up SFP (Small Form-factor Pluggable) transceivers as submodules in the free SFP slots of the device representation. To set up an SFP submodule, perform the following steps: Click the *Project view* icon.

Totally Integrated 1 First steps Project: "hns_39435" was opened successfully. Please select the next step 3.3 1 Motion & technolog -Configure a device P 0 1 Write PLC program 🦲 First steps Configure technology objects Installed softwar Configure an HMI screen Helo 🚯 User interface language Open the project view

The dialog displays the Project view window.

□ Click the Overview tab in the footer.

Find and replace Pind Pind	Project Edit View Insert Online Option	ans Tools Window Hep りょのまう旧旧国際がCountineがCoottine 静	🖪 🕞 🗙 🚽 🔲 cSearch in projects 🛛 🙀	Totally Integrated Automation PORTAL
Tind: Other words only Match case Tind is substructures Information states Use wildow das				
Tind: Other words only Match case Tind is substructures Information states Use wildow das				Options
Tind: Other words only Match case Tind is substructures Information states Use wildow das				
Mouch case Trind in substructure Ind in substructure				✓ Find and replace
Moch ose ☐ Noch ose ☐ Find in Noch oses ☐ Find in Noch oses ☐ Sind in Noch oses ☐ Use wildow day	Start			Find:
Mouch case Trind in substructure Ind in substructure				C Whate words only
Find in hidden stars Use wilden stars				
Use wildow ds				Tind is substructures
				Eind in hidden texts
Lise regular expressions				
				Use regular expressions
⊙ Dwa				C Daven
Cla				Oue
Find	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			Find
Replace with	No. 11			Replace with:
Whale decuments				
Properties 1 Info 3 2 Diagnostics III Concert postor			Properties	
Control On Control Provide	General 31 Cross-references		Carolina 12 min . 13 continuous III	() Selection
Leneral 3 Loss-references Compile Replace all		0		Replace Replace all
1 Path Down Con 17 Errors Warnings Time Activate Windows	T Path Dr	GO 10 1	Errors Warnings Time	
Canguages & resources Canguages & resources	()	C		The second se

		- Tasks 🖉 🚺
	Details List Thumbnails	Options
3 💷 💷 🔤		-
Actions		✓ Find and replace
		Find.
device networ		Whate words only
ecurity settings		Tind in substructures
		Tind is hidden texts
etings		These wildcards
		Cae regular expressions
thers		(*) Dawn
🛅 😭 🖳 🔽		015
ument Cammon Ungrouped Lengueges		Find
ettings data devices & resources		Replace with:
		Replace with:
		(ii) Whate document
		From current position
	😔 Properties 🛛 🚺 Info 🚺 🖏 Diagnostics 🔅 🗆 🖃	Selection .
ieneral 10 Cross-references Compile		Replace Replace all
1 Show all messages		
Path Description	Go to 7 Errors Viamings Time	Activate Windows
		> Languages & resources

The dialog displays the *Devices & networks* window.

□ In the *Network view* tab, click the icon of the device.

astPath_MSP40_GRS1040_CycleFailRerun → Devices & networks	💶 🖬 🖬 🗙 Hardware catalog	a 🗉 🕨
Topology view 🔒 Network view	Device view Options	
🕯 Network 🔢 Connections HMI connection 💌 🕎 📆 🔛 🛄 🍳 🖢		
	Catalog	
	E .	fini Lini
🧐 Properties 🛛 🗓 Info 👔 😨 Diagno	Filter Profile: Allb. Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controllers Controll	iv iµi
General 1 Cross-references Compile		
3 A O Show oll messages	✓ Information	
Path Description Go to ? Errors Wen	nings Time Device:	× =

□ Select the *Device view* tab to display the device details.

stPati	1_MS	P40_GRS1040_CycleFailF								ch in projects		- # =
										Topology view	A Network view	Device view
De	evice	overview										0
	2	Module	Rack	Slot	I address	Q addr	Туре	Article no.	Firmware	Comment		(N)
		 msp40-232 	0	0			with I/O data	MSP40-00200	V09.2.00			
		PN-IO	0	0 X1			MSP40-00200					
		MSM50-Q6Q6Q6Q6_1	0	1			MSM50-Q6Q6Q6Q6	MSM50-Q6Q6Q6Q6				11
		MSM40-T1T1T1T1_1	0	2			MSM40-T1T1T1T1	MSM40-T1T1T1T1				-
		MSM40-C1 C1 C1 C1_1	0	3			MSM40-C1 C1 C1 C1 C1	MSM40-C1 C1 C1 C1 C1				
			0	4								
		MSM40-C1C1C1C1_2	0	5			MSM40-C1C1C1C1	MSM40-C1 C1 C1 C1				
		Device data_1	0	6			Device data					
2		Port data_1	0	7			Port data					
8												
_	-		_	_	_	_				100	1.	
										Q Properties	🗓 Info 追 🔮 Diag	nostics


'ath_h	ISP40_GRS1040_CycleFailf	Rerun 🕨	Ungroup	ed devices	• msp	40-232 [with VO da	ta] 🗕 🗖		Hardware catalog
				a Top	ology vi	ew 🚮 Network	view 📑 Device vie	ew	Options
Devi	ce overview								
-	Module	Rack	Slot	I address	Q addr	Туре	Article no.	Fi	✓ Catalog
	▼ msp40-232	0	0			with I/O data	MSP40-00200	٧	
	PN-IO	0	0 ×1			MSP40-00200			Filter Profile; All>
	MSM50-Q6Q6Q6Q6_1	0	1			MSM50-Q6Q6Q6Q6	MSM50-Q6Q6Q6Q6		Head module
	MSM40-T1T1T1_1	0	2			MSM40-T1T1T1T1	MSM40-T1T1T1T1		Module
	MSM40-C1C1C1C1_1	0	3			MSM40-C1 C1 C1 C1 C1	MSM40-C1 C1 C1 C1 C1		Submodules
		0	4						Combo 1 GTP
	MSM40-C1C1C1C1_2	0	5			MSM40-C1 C1 C1 C1 C1	MSM40-C1 C1 C1 C1 C1		M-FAST SFP-LHLC
	Device data_1	0	6			Device data			M-FAST SFP-LHILC EEC 7
	Port data_1	0	7			Port data			M-FAST SFP-LINCC EEC
									M-FAST SFP-MM/LC EEC
									M-FAST SFP-SM/LC
									M-FAST SFP-SM/LC EEC
									M-FAST SFP-SM+/LC
									M-FAST SFP-SM+/LC EEC
									M-Fast SFP-D/RJ45
									M-Fast SFP-TX/RJ45 EEC
									M-SEP-2.5-LH/LC
									✓ Information
									Device:
									Device:
<				201				1	
			_		ropertie	s 🗓 Info 🕕 🖞		/	4

Select the *Hardware catalog* tab in the right margin to display the available SFP submodules.

 $\hfill\square$ Select the required SFP submodule.


				a Topo	logy vie	w 🔒 Network vi	iew 🕅 Device view	"	Options	
D	Device overview					Tana	141			0
	W Module	Rack	Slot	Iaddress	Q addr	Туре	Article no.		✓ Catalog	
	 msp40-232 	0	0			with I/O data	MSP40-00200	~		and an
	PN-IO	0	0 X1			MSP40-00200			Filter Profile: Alb	
	 MSM50-Q6Q6Q6Q6_1 	0	1			MSM50-Q6Q6Q6Q6	MSM50-Q6Q6Q6Q6		Module	(1)
		0	1 P1					-	Module Submodules	-
		0	1 P2				1		Combo 1G TP	
		0	1 P3						M-FAST SFP-LH/LC	
2		0	1 P4						M-FAST SFP-LH/LC EEC	
	MSM40-T1T1T1T1_1	0	2			MSM40-T1T1T1T1	MSM40-T1T1T1T1		M-FAST SFP-LH/LC EEC	
	MSM40-C1C1C1C1_1	0	3			MSM40-C1 C1 C1 C1 C1	MSM40-C1 C1 C1 C1			
		0	4						M-FAST SFP-MM/LC EEC	
	MSM40-C1C1C1C1_2	0	5			MSM40-C1 C1 C1 C1	MSM40-C1 C1 C1 C1		M-FAST SPP-SM/LC	
	Device data_1	0	6			Device data			M-FAST SFP-SM/LC EEC	
	<			10	-			>	M-FAST SFP-SM+/LC	
	1.11			1	operties	🗓 Info 追 🗓			M-Fast SFP-D/RJ45	
				I S PI	operties	Truto T	Diagnostics	-	M-Fast SFP-D/RJ45 EEC	
Gene	eral 🚯 Cross-references	Compile							MISEP-2 5-LH/LC	
3 4	Show all messages								M-SF 20-1 CEEC	2
									V Inform (in)	
Pati		Description				Con	2 Errors W	emi	Device:	
100		Description				0010		dirin	Device:	

In the Device view tab, the slot which is logically connected to the device is highlighted.



Drag the selected SFP submodule, and drop it onto the highlighted slot in the Device view tab.





Note: Verify that the SFP submodule you added in the TIA Portal and the physically connected SFP submodule are of the same type. Otherwise, the Application Relation may not be set up correctly.

Configuring the port properties

In a modular device with n I/O modules, the I/O modules are represented by the slots 1 through n. The ports of a particular I/O module are represented by subslots in the respective slot. The *device data* module is represented by the next to last slot (n+1) and the *port data* module is represented by the last slot (n+2).


A non-modular device with n ports only has the slot 0. The ports are represented as subslots 1 through n in slot 0. The *device data* module is represented by the next to last subslot (n+1) and the *port data* module is represented by the last subslot (n+2).

Set up the port link monitoring alarm. To do this, perform the following steps: Click the *Project view* icon.

_				Totally Integrated Automation PORTAL
Start			First steps	
Devices & networks	<u>م</u>	Open existing project	Project: "hos_39435" was opened successfully. Please select the next step:	
	-	 Create new project Migrate project 	Start I	
Motion & technology	٠	Close project	Devices 2	
	1	Welcome Tour	nitevorites b N Configure a device	
Online & Diagnostics	10	🥚 First steps	PLC programming Write PLC program	
			Mation 8. Configure Inclinationy Configure	
		 Installed software Help 	Visualization D Configure an HMI screen	
		🛞 User interface language	> hoject view Open the project view	

The dialog displays the *Project view* window.

□ Click the Overview tab in the footer.



642_		- Tasks III
M12		Constant Con
	Details List Thumbnails	Options
dons		✓ Find and replace
🛉 🖕		Find
		-
evice networ		Whale words only
curity settings		T Match case
		Third in substructures
		Thind in hidden texts
tings		These wildcards
		Cse regular expressions
ners		(*) Down
		0.08
1 🖬 🛄 🐻		Find
ment. Common Ungrouped Longuages rings data devices & resources		1
3		Replace with:
		1
		Whole document
	😌 Properties 🛛 📜 Info 👔 🕄 Diagnostics 💷 🖃	Fram current position
	groperties Gunto B Subagnostics	C Selection
eneral 10 Cross-references Compile		Replace Replace all
1 O Show all messages		
Path Description	Go to 7 Errors Warnings Time	Activate Windows
each beachpean	ad a start wantings time	> Languages & resources

The dialog displays the *Devices & networks* window.

□ In the *Network view* tab, click the icon of the device.


39435 ► Devices & networks	-	📲 🗙 Hardware catalog 🖉 🖉
	🚰 Topology view 🚮 Network view 🛛 🏹 Device v	ew Options
etwork 📅 Connections Hbli connection 🔹 📰 🔛 🔛 🔍 2		(d
0.10 sy	stem: plc_1.PROFINET IO-System (100) 🛆 🦞 Device	✓ Catalog
	= 7 \$7\$00/ET200M	station
pic_1 grs1040 (6	F plc_1	Filter Profile: All>
	▼ GSD device_2 ▶ grs1040	Controllers
Not essigned	F gistore	+ 🧮 HMI
PNAE 1: 192.168.0.1 2 PN/IE 1: 192.168.0.23		Gim PC systems Gim Drives & starters
Plc_1.PROFINET IO-syste		In Network components
		Detesting & Monitoring
	2	🕨 🧊 Distributed VO
V		 Fower supply and distribution
		Field devices
		• 🛅 Other field devices
		✓ Information
11 100%	s 🗟 💭 🥵 🖬 📢 🖬	> Device:
device_2 [Device]		lm v
neral IO tags System constants Texts	Cauchana Lana International In	
end		1
Course 1		
General		
, veneral		-

월 🖥 Seve project 🚔 🐰 🥲 😨 🗙 🌖 🖢 (주요 한 월 🕼 🖉 🕼 🍠 Go anii s. 39435 ト Ungrouped devices ⊦ grs1040 [with I/O data]				and the second second	_ # # X	Hardware catalog
	2 1	opology vi	ew 👗 Network view	Devi	ce view	Options
- grs 1040 [with ifO data] 💌 🔜 🕎 🏹 🔂 🖽 🖪 🍳 🛨	3	Devic	e overview		(C	1
	^		Module	Rack	Slet	atalog
	_		▼ grs1046	B	B	
	-		- grs1040	0	0,21	1000
1000			 GMW-BASE-6T6Z_1 	0	1	Profile: wAlly 3
851			dana datas orde_r	0	1.61	r Misad module
				0	1 F2	
			18M/108M/16 RH45	0	1 PS	• 🛄 Media module - copper ports
			10M/100M/16R/45_1	8	1.64	 Media module - Copper/Optical ports
(6)				0	1.FS	🕨 🤙 Media module - Gigebit ports
		-		0	1 16	🕨 🌆 Media module - input/output
		1	10M/100M/16 R045_2	U	1.67	• 📑 Media module - optical ports
			10M/100M/16 RJ45 3	0	1 F8	Submodules
				a	1 F9	
				0	1 P10	
			10M/100M/16R/45_4	0	1 F11	
			1 0M/1 00M/1 G R/45_5	0	1 F12	
				U	2	
				0	3	
				0	4	✓ Information
	×		Port data_1	٥	5	
1 b0%	· · · · · · · · · · · · · · · · ·	4	4		>	Device:
1040 [with VO data]	1	Properti	es 🚺 Info 🛽 🕻 Diagno	stice	THE Y	1
	-	a composite	The second se			
General 10 tags System constants Texts						
Ethernet addresses					^	-
(
interface options Interface networked with						1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Media redundancy 🗸						Avticle no.:

Select the *Device view* tab to display the device details.

Select the *Properties* tab.

The Properties tab contains additional tabs.




□ In the *General* tab, navigate to the *PROFINET interface* [X1] > *Advanced options* item, then click the required port.

Project tree 🛛 🖬 🕯	37801hns → Ungrouped devices → brs40 (with VO data)	🛛 🖬 🗮 🗙 Hardware catalog 👘 💷 🕨
Devices	🧬 Topology view 🛛 👗 Network view 🛛 🙀 Device	e view Options
1 I I I I I I I I I I I I I I I I I I I	👉 br:40 (vith 90 data) 🕞 🔠 🔭 📑 🖉 Device overview	3
	¢ n Nodule Back Slat Laddress	Q od 🗸 🗸 Catalog
17801 hns Add new device	C III > C Module Back Stor Laddress brs40 [with VO data] Properties Line Data Display to Diagnostics	clearcha Mil Mit
Autorices & networks		Filter Profile: Allo
plc_1 [CPU 314C-2 PNU.	General IO tags System constants Texts	> 🚺 Head module
Ungrouped devices	General Port 1 GE SFP Cage [X1 P1 R]	📩 🕨 🛅 Module
Security settings	Catalog internation	-
🕨 🎑 Common data	General Second	
Documentation settings	Ethernet addresses	
Canguages & resources Get Online access	Advanced options PositionNumber: 1	
Card Reader/USB memory	Interface options Rame: Port 1 GE SFP Cage	
a sho headen dea memory	Media redundancy	
	★ Real time settings	0
	10 cycle	
	Port GL SEP Cage (x) P1 8 Port 2 GE SEP Cage (x) P2 8	
	Port S GE SFP Cage (X1 P3 R)	
	Port 4 GE SFF Cage [X1 P4 R] Port interconnection	
	Port 5 GE RUAS [X1 PS R] Non al port:	✓ Information
	Port: 6 GE R/45 [X1 P6 R]	Desice:
	Port 7 GE RU45 [X1 P7 R] Local port: [brs40[P1+0] [X1 P7 R]	
< 11 >	▶ Port 8 GE 8/45 [X1 P8 8]	=
✓ Details view	Port 9 GE RM5 [X1 P9 R] Port 1 g GE RH5 [X1 P10 R] Cable name:	
· Decails view	Port 10 GE RI45 (X1 P10 R) Port 11 GE RI45 (X1 P11 R)	
	Port 12 GE R/45 [X] F12 R	
	Diagnostics addresses	

Project tree 🛛 🗖 🖣	37801hns + Ungrouped devices +	hrs40 [with VO data]			_ # # ×	Hardware catalog	
Devices	-		Topology view	🔒 Network view 🚦	Device view	Options	
1 I I I I I I I I I I I I I I I I I I I	df brs40 (with VO data) 💌 🚆	* 📑 • Device	overview	sterio da			
	< II >		Module	Rack Slot I	address 🛛 ad	✓ Catalog	
S7801 hns Add new device	brs40 [with VO data]	Y		Here a Marine		<search></search>	ant ant
Add new device			Properties	🔄 Info 🚹 🚹 Diagnost	HES LAREN	Filter Profile: Allo	
▶ alc_1 [CPU 314C-2 PNU_	General 10 tags System o		1			+ Tead module	
Ba Ungrouped devices	▼ General	> Port options _				🕨 🕨 Module	
Security settings	Catalog information	Activate				1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
• 🚮 Common data							
F Documentation settings	General	Activate this port	foruse				
Languages & resources	Ethernet addresses						
• De Online access	★ Advanced options	Connection					
Card Reader/USB memory	Interface options	connection					
	Media redundancy	Transmission	ate I duples: Automat	ic.	T		
	Real time settings		Monit		101		
	IO cycle		The second s				
	Port 1 GE SFP Cage [X1 P1 R]		7/J⊻ Enabl	e autoriegotiation			
	▶ Port 2 GE SFP Cage [X1 F2 R]		12				
	▶ Port 3 GE SFP Cage [X1 P3 II]	Boundarie					
	Port 4 GE SFP Cage [X1 P4 R]	v					
	▶ Port 5 GE R/45 [X1 P5 R]	End of detection	of accessible devices			✓ Information	
	▶ Port 6 GE RI45 [X1 P6 R]	End al topology a	appyery.			Device:	^
	Port 7 GE R/45 [X1 P7 R]	End of the syst of			-		
< 11 D	Port 8 GE RJ45 [X1 P8 R]				-		1
the second s	Port 9 GE RI45 [X1 P9 R]						13
✓ Details view	Port 10 GE RH15 [X1 F10 R]	 Diagnostics ad 	uresses				
	Port 11 GE RI45 [X1 F11 R]						
	Port 12 GE RI45 [X1 P12 R]	31	art address: 2040				
	Diagnostics addresses		Notes works and the	1			

□ In the *Port options* section, *Connection* frame, mark the *Monitor* checkbox.

□ Click the Save project button.



Note: To test the port link monitor function, you can temporarily unplug the data cable from the respective port.

Configuring the connection options


Perform the following steps:

□ Click the *Project view* icon.

			Totally Integrated Automation PORTA	L
Start			First steps	_
Devices & networks	÷,	Open existing project	Project: This_39435" was opened successfully. Please select the next step:	
PLC programming	٠	 Create new project Migrate project 	start 🙀	
Motion & technology	*	Close project	Dirvitins & Configure a device	
Visualization	1	💮 Welcome Tour	Action of the second seco	
Diagnostics	15	First steps	Aution & Configure Inclanality technology objects	
		 Installed software Help 	Visconification D Configure on HMI screen	
		🌀 User interface language	Project view Open the project view	

The dialog displays the *Project view* window.

□ Click the *Overview* tab in the footer.



		- Tasks III
	Details List Thumbnails	Options
5 🛄 🕕 ka	100000 1000 1000 1000	- Change -
a clarado caso como como como como como como como co		 Find and replace
		- I nu anu reprace
📫 👝		Find
dé new Devices		•
DEVICE NEEWON UN		Othele words only
ecurity settings		C Netch case
		Tind in substructures
in hs		Find in hidden texts
ttings		Lito wildeards
		Cise regular expressions
hers		(Down
🛅 🙀 🛄 🐻		Out
ument. Common Ungrouped Longueges		Find
ettings data devices & resources		
		Replace with:
		Whole documents
		Prom current position
	🤐 Properties 🛛 📜 😯 Diagnostics 💷 –	C Selection
General 1 Cross-references Compile		Replace Replace all
1 Show all messages		webrack Replace an
Path Description	Go to 7 Errors Warnings Time	Activate Windows
		> Languages & resources

The dialog displays the *Devices & networks* window.

□ In the *Network view* tab, click the icon of the device.


39435 ► Devices & networks	-	📲 🗙 Hardware catalog 🖉 🖉
	🚰 Topology view 🚮 Network view 🛛 🏹 Device v	ew Options
etwork 📅 Connections Hbli connection 🔹 📰 🔛 🔛 🔍 2		(d
0.10 sy	stem: plc_1.PROFINET IO-System (100) 🛆 🦞 Device	✓ Catalog
	= 7 \$7\$00/ET200M	station
pic_1 grs1040 (6	F plc_1	Filter Profile: All>
	▼ GSD device_2 ▶ grs1040	Controllers
Not essigned	F gistore	+ 🧮 HMI
PNAE 1: 192.168.0.1 2 PN/IE 1: 192.168.0.23		Gim PC systems Jim Drives & starters
Plc_1.PROFINET IO-syste		In Network components
		Detesting & Monitoring
	2	🕨 🧊 Distributed VO
V		 Fower supply and distribution
		Field devices
		• 🛅 Other field devices
		✓ Information
11 100%	s 🗟 💭 🥵 🖬 📢 🖬	> Device:
device_2 [Device]		lm v
neral IO tags System constants Texts	Cauchana Lana International In	
end		1
Course 1		²
General		
, veneral		-

है 🔒 Save project 🚔 🐰 ½ कि 🗙 🎝 🖢 (≠ ± 🐔 🔟 📅 🚆 🖓 Go ani s. 39435 + Ungrouped devices + grs1040 [with I/O data]	ne p. openne 1		V T constant a la	and the second second	_ # # X	POR Hardware catalog
	2	Topology	view 🔥 Network view	Devi	the second s	Options
grs 1848 [with 1/0 data] 💌 📰 🔣 🔣 🗄 🗄 🕄 😫	3		ice overview	1	10	N
Restantion and Dig the de main and a					11	N
		× 1		Rack	Slot	atalog
		=	▼ grs1040	0	8	
(a)			PNHO	U	0 X1	Profile: wAlls
as the second			GMN-BASE-6T6Z_1	0	1	ad module
				0	1 F1	
				0	1 P2	• 🔄 Media module - copper ports
			18M/108M/1GR/45	0	1 PS	+ 🚂 Media module - CopperOptical ports
6			1 0M/1 00M/1 G R/15_1	0	1 F4 1 F5	🕨 🧃 Media module - Gigabit ports
		1		0	116	🕨 🏹 Media module - input/output
		2	10M/100M/16 R045_2		1 F7	Media module - optical ports
		£	1 DIM 1 DOM/1 G RU45 3	8	1.F8	🕨 📷 Submodules
			Tane roune round as a	0	1 F9	1000
				0	1 P10	
			1 0M/1 00M/1 G R/45_4	0	1 P11	
			10M/100M/16R/45 5	0	1 F12	
				U	2	
				0	3	
				0	4	✓ Information
		Y	Port data_1	0	5	
1 100%	· · · · · · · · · · · · · · · · · · ·	•	1		>	Device:
1040 [with UO data]		Proper	ties 🛝 Info 🛽 🖁 Diago	astics	Per.	
Seneral 10 tags System constants Texts		Trees of the Party	and become because			
					E.c.	
Ethernet addresses					^	
Advanced options Interface networked with					1	
Media redundancy						101212 P
activity w					v	Article no.:

Select the *Device view* tab to display the device details.

Select the *Properties* tab.

The Properties tab contains additional tabs.



□ In the *General* tab, navigate to the *PROFINET interface* [X1] > *Advanced options* item, then click the required port.

Project tree 🛛 🖬 🖣	37801hns + Ungrouped devices + brs40 [with VO data]	💶 🖬 🗮 🗙 Hardware catalog 🛛 🖬 🗉 🕨
Devices	🖉 Tapology view 🚮 Network view 👔	Device view Options
	👉 brs40 (with VO data) 🕞 📳 🔭 📑 🕐 Device overview	
	K II Nodule Back Slot II	address Q ad 🖌 🗸 Catalog
	Ins40 [with VO data]	Geardo Mi Mi
A Devices & networks		Filter Prolile: Alla
Image: Comparison of the second se	General 10 tags System constants Texts	🔸 📺 Head module
🕨 🔚 Ungrouped devices	General Port 1 GE SFP Cage [X1 P1 R]	📥 🔸 🌆 Module
Security settings	Catalog information PROFINE TIME TO E STP Cage (X11)	
🕨 🏭 Common data	General ···· General	
Decumentation settings Languages & resources	Ethemet addresses	
Online access	Advanced options PositionNumber: 1	
Card Reader/US8 memory	Interface options Name: Port 1 GE SFP Cage	
sine reader oco memory	Kedia redundancy Oppments	
	 Real time settings 	<u></u>
	10 cycle	
	Port I GE SEP Coge (21 P1 R)	
	Port 2 GE SFF Cage [X1 P2 B] Port 3 GE SFF Cage [X1 P3 B]	
	Port 4 GE SEP Coge [X1 P4 R] Port 4 GE SEP Coge [X1 P4 R]	
	Port 5 GE RUAS [X1 PS R]	✓ Information
	Port 6 GE RI45 [X1 P6 R]	Device:
	Port 7 GE RI45 [X1 P7 B] Local port: brs40(PNHO (X1)Port 1 GE SFP Cape	
< u 2	Port 8 GE RMIS (X1 P8 R) Madium: Cooner	
	Port 9 GE RU45 [X1 P9 R]	
✓ Details view	 Factor de lides (VELLA II) 	
	Port 11 GE RM45 [X1 P1 1 R] Port 12 GE RM45 [X1 P1 2 R]	
	Port 12 GE R45 (X1 P12 R) Diagnostics addresses	

□ In the *Port options* section, *Connection* frame, select the desired item from the *Transmission rate/ duplex* drop-down list other than the *Automatic* item.

Project tree 🛛 🖬 🖣	37801hns > Ungrouped devices >	brs40 [with VO data] _ 🖬 🖬 🗙	Hurdware catalog	
Devices	-	🛃 Tapology view 🛛 🚠 Network view 🛛 🔐 Device view	Options	
	trs40 [with (0 data]	Device overview		
		Rack Slot Laddress Q ad	✓ Catalog	
▼ 📑 37801hms	< 1 >		Searche	tei tei
💕 Add new device	brs40 [with VO data]	🖳 Properties 🚺 Info 🌗 🗓 Diagnostics 🔍 – 🗠	Filter Profile:	
h Devices & networks	General 10 tags System	constants Texts	Head module	
• pic_1 [OPU 3146-2 PN/	▼ General	+ > Port options	Module	
Head of the second	Catalog information	Activate	- La Meder	
Gommon data		Activate		
Documentation settings	General	Activate this port for use		
Lenguages & resources	Ethernet addresses			
• 🙀 Online access	★ Advanced aptions	Connection		
Card Reader/USB memory	Interface options	Connection		
	Media redundancy	Transmission rate / dupless Automatic	-	
		TP 100 Mbps full duplex		
	IO cycle Fort 1 GE SFP Cage (X1 P1 R)	PO 100 Mbps full duplex		
	Port 2 GE SFP Cage [X1 F2 R]			
	Port 3 GE SFP Cage [X1 FS R]	Boundaries		
	Port 4 GE SFP Cage [X1 F4 R]	, boundaries		
	Port 5 GE RI45 [X1 PS R]	End of detection of accessible devices	✓ Information	-
	▶ Port 6 GE RI45 [X1 P6 R]			^
	Fort 7 GE RI45 [X1 P7 R]	End of sopology dissavery	Device:	10000
	Port 8 GE RI45 (X1 P8 R)	End of the sync domein		=
< 1 >	 Port 9 GE R045 (201 P9 R) 			1
✓ Details view	Fort 10 GE RU45 [X1 P10 R]	Plagnostics addresses		
	Fort 11 GE 8J45 [X1 P11.8]			
	 Port 12 GE RJ45 [X1 P12 R] 	Start address: 2040		
	Diagnostics addresses			


The device automatically marks the *Monitor* and *Enable autonegotiation* checkboxes.

Project Edit View Insert Online	Options Tools Window Help To X 🍤 2 (P1: To III) 🗗 🗄 🐺 🍠 Geomme 🧬 Geomme 🎝 III asso	ch in projectiva 🛛 🕌	Totally Integrate	d Automation PORTAL
Project tree 🛛 🖬 🖣	37801hns > Ungrouped devices > brs40 [with VO data]	_ # = ×	Hardware catalog	a 🗆 🕨
Devices	💒 Topology view 🔒 Network	view 🔐 Device view	Options	
	# brs40 (with I/O data) 💌 😅 * 📑 🔹 Device overview			9
1	K I	Slot I address Q ad	▼ Catalog	
▼ 37801hns			<search></search>	ast ast
Add new device		Diagnostics Di-S	Filter Profile: Alla	- B
Imple_1 (DRI 314-2 PV Imple_1 (DRI 314-2 PV Stacking settings Stacking settings Imple_1 (DRI 314-2 PV Imple_1 (DRI 31	General 10 tags System constants Texts General Consignificity interviewe proj 1 > Port options General Activate > Activate Tenders options Activate > Activate Hommer oldresses Activate > * Advanced options Interviewe options Connection Medie redundancy * Real manual statistics on rate / duple * Port 1 GE SPF cage [X1 F1 R] =	, , ,	▶ Im Hree module > Im Andule	
 II >> ✓ Details view 	Fort 3 GE SPF Cage [Cr F8 i] Fort 3 GE B45 [Cr F8 i] Fort 1 GE B45 [Cr F8		v Information Device:	× 1

Project tree 🛛 🖬 🖣	37801hns 🕨 Ungrouped devices 🔸 brs40 [with VO data]	PEX	Hardware catalog	a 🗆 🕨
Devices	🖉 Topology view 🛛 🛔 Network view 📑 Device	view	Options	
	👉 [brs40 [with IKO data] 🔹 🔡 * 📑 🕴 Device overview		5	0
			✓ Catalog	
▼ 37801hns	🗶 💷 💦 💦 👔 👔 👔 Madule Rack Slut Faddress	Q 85	<search></search>	est est
💕 Add new device	brs40 (with VC data) 🔍 Properties 🐩 Info 😗 🖞 Diagnostics			and the second second
📥 Devices & networks	General 10 tags System constants Texts		Filter Profile: «All»	• 0
pic_1 [CPU \$14G2 PhV	▼ General A >> Port options	- 12	Fead module	
La Ungrouped devices	Conclusion		Module	
 Security settings Common data 	FROFINET Interface [X1] Activate			
Documentation settings	General Retivete this port for use			
Longuages & resources	Ethemet addresses			
M Online access	Advanced options Connection			
F G Card Reader/USB memory	Interface options			
	Medie redundency Transmission rate / duplex: 11°100 Mbps full duplex	1.		
	★ Real time settings			
	io igae			
	Fort 1 GE SFP Cage (X1 F1 R) Fort 2 GE SFP Cage (X1 F2 R)			
	Fort 3 GE SFP Cage (X1 F3 R) Boundarie			
	Fort 4 GE SFP Cage [X3 P4 R]			
	Port 5 GE 845 [X1 P5 R] End of detection of accessible devices		✓ Information	
	Fort 6 GE NI45 (X1 F6 R) End of teoplogy discovery		Device:	1
	Fort 7 GE RI45 IX1 F7 RI	-	Gevice:	
c)	Fort 8 GE RI45 [X1 F8 R] End of the sync domain	12		-
	 Port 9 GE N45 [X1 F9 R] 			120
✓ Details view	Fert 10 GE RMS [KI P10 R] * Diagnostics addresses			
	Fort 11 GE RV45 [X1 P11 R]			
	Fort 12 GE RI45 [X1 P12 R] Start address: 2040			

Unmark the *Monitor* and *Enable autonegotiation* checkboxes.

Click the Save project button.



If you change the port setting to a value other than Automatic settings, then the device disables the port for a short time. If you have positioned the port on the path between the I/O controller and the I/O device, then this interruption can possibly lead to a failure in establishing the Application Relation. Make the following provisions before changing the port setting:

Note: Before disabling RSTP on certain ports, make sure that this will not result in loops.

Deactivate RSTP on the device ports between the I/O controller and the I/O device.

□ Open the Switching > L2-Redundancy > Spanning Tree > Port dialog, CIST tab.

- □ Unmark the STP active checkbox for the relevant ports.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

Set up the topology monitoring alarm. To do this, perform the following steps: Click the *Project view* icon.

								Totally Integrated Automation PORTAL
Start			First step	s				
Devices & networks	م ر ال	Open existing project Create new project		hns_3	39435" was opened s	success ful	lly. Please select the next step:	
		G Migrate project	start		1			
Motion & technology	•	Close project						
	1	Welcome Tour		7		¢ ¢	Configure a device	
Online & Diagnostics	1	First steps		⇒		Ŷ	Write PLC program	
				⇒	Mation & Inclinuluyy	-	Configure technology objects	
		 Installed software Help 		÷		Ø	Configure an HMI screen	
		🚯 User interface language		+	Project view	ſ.	Open the project view	

The dialog displays the *Project view* window.

□ Click the *Overview* tab in the footer.

🕒 🖬 Save proved 当 🗴 🕾 泊 🗙 約主 (P 生 范) 🕮 囧 里 臨 🖉 Goundine 🖉 Goudfline 🌆 團 璽 🛪 🚽 🛄 Lebearch in projects 👔	23.543.44.0
	Tasks 🖉 💷 🕨
	Options
	✓ Find and replace
	rind
	(
	C Whate words only
	C Narch case
	Find in substructures
	🖂 Find in holden texts
	Cae wildoards
	Use regular expressions
	(Conve
	Cu
	Find
	Beblace with
	· · · · · · · · · · · · · · · · · · ·
	(a) Whate document
	C From current position
🖫 Properties 👘 🗓 Diagnostic	x O Selection
General 1 Cross-references Complie	Replace Replace all
3 A 0 Show all messages	
	Activate Windows
I Path Go to ? Errors Warnings Time	> Languages & resources
Portal view E Overview	Canguages & resources 2 Canguages & resources

3647		- Tasks 0 1
	Details List Thumbnails	Options
	Details List Interioralis	Options
a clinica (%)		
		 Find and replace
💣 th 🚬		Find
udé new Devices		
device networ		🖂 Whale words only
ecurity settings		C teach case
		Tind in substructures
in h5		🗍 Find in hidden texts
lettings		🔄 Lise wildeards
		Cise regular expressions (
thers		(Down
		Qua
🗉 🖬 🛄 🔕		Find
sument Common Ungrouped Longuages ettings data devices &resources		
		Replace with:
		L. I
		(i) Whole document
	🔍 Properties 🚺 Info 🗉 🖏 Diagnostics 👘 🖃 —	C Fram current position
General 🕦 Cross-references Compile	Contraction of Same Site and States	C Selection
A Show all messages		Replace Replace all
I an an intersages		
Path Description	Go to 7 Errors Warnings Time	Activate Windows
Annual Korra	NAMES IN TRADE TRANSFER INCOM	> Languages & resources

The dialog displays the *Devices & networks* window.


□ In the *Network view* tab, click the icon of the device.

_39435 → Devices & networks		_ # = ×	Hardware catalog 👘 🗐	
	🚰 Tapalagy view 🛛 📥 Networ	k view	Options	
Network 🚺 Connections Hill connection 🕒 🖭 🖫 🖼 🖳 🔍 S	: 🖬	Network overview 4 >		4
	# 10 system: plc_1.PROFINET IO-System (100)	W Device	✓ Catalog	
		 \$7800/ET200M station 	244	-
pic_1 grs1040	ĥ	▶ plc_1	Filter Profile. Alla	1
CPU 314C-2 PN	-	▼ GSD device_2	Controllers	12
Not assigned		• grs1040	🔸 🛅 HMI	
	-(2)		🕨 🧰 PC systems	
PN/IE_1: 192.168.0.1 2 PN/IE_1: 192.168.0.23	UN'		Drives & starters	
	1		Im Network components Im Detecting & Monitoring	
			Distributed VO	
			Power supply end distribution	
	~~		• 🛅 Field devices	
			Therfield devices	
			1	
	100		✓ Information	
u	> 100%	 <td>Device:</td><td></td>	Device:	
) device_2 (Device)	A Properties	& Diagnostics		
eneral IO tags System constants Texts	The second secon	an an all the second seco		
eneral				
		Le.		
Name: GSD devic	e 7	1	Article no.:	-
Portal view Devices & ne	577.		Autore no.: Loading completed (errors: 0; werning	2

- Totally Integrated Automation PORTAL Project Edit View Insert Online Options Tools Window Help 🕑 💁 🔒 Seveptroject 🚔 🗶 🐀 🔍 🆘 🗘 🖓 🖉 🔂 🔛 🎧 🖉 Golonline 🖉 Golonli - **b B B X 3 0** 7 -01 hns_39435 + Ungrouped devices + grs1040 [with VO data] _ # = × Topology view 🚮 Network view 🛐 Device vie 🏄 grs 1040 (with 1/0 data) 💌 📰 🖉 🖽 🗄 🖳 🔩 Device ... Y __ Module V grs1040 MHO -**Device overview** 1 Rack st est est = 0.21 Profile: Allo ataro 5 . · GMM-BASE-6T6Z 1 odule 1 P1 Knodule
 Knodule
 Module
 Module
 Module
 Module
 Module
 Module module - capper para
 Module module - Capper/Data
 Module module - Capper/Data
 Module module - optical parts
 Module module - optical parts 1 P2 1 P3 1 P4 1 P5 1 P5 1 P5 1 P5 1 P5 1 P10 1 P11 1 P12 10MM DOMM G RH5 10MM DOMM G RH5_1 Б -----100 10%/100%/16 RI45_2 Submodules 10M/100M/10 RI45_3 10MM 00MM G R/45_4 10MM 00MM G R/45_5 (T) Information Fort dets_ < 1 > 100% -Properties Info 🛛 Diagnostics General IO tags System constants Texts Ethernet addresses Advanced options Interface options Medio redundance Ethernet addresses Rostal View 🗄 Overview 📥 grs1040 A Loading completed i
- Select the *Device view* tab to display the device details.

Select the *Properties* tab.


The Properties tab contains additional tabs.



□ In the *General* tab, navigate to the *PROFINET interface* [X1] > *Advanced options* item, then click the required port.


	37801hns → Ungrouped devices → brs40 (with VO data) _ 🖉 🖬 >	🖬 Hardware catalog 👘 🗉 🕨
Devices	🖉 Tapology view 🛛 🚮 Network view 🛛 🕅 Device view	Options
	👉 brs40 (with VO data) 💌 🔠 📩 🖬 V Device overview	
] 37801 hns 	K II 👂	✓ Catalog
Add new device	brs40 [with VO data]	Kitearcho MI MI
Devices & networks	General 10 tags System constants Texts	Filter Profile: Alb
Gard Reader/US8 memory Gard Reader/US8 memory Gard Reader/US8 memory	Seneral Caselog information FROFINET interface [x1] Seneral Ethernat addresses Advanced options Media redundancy Sealing stimus Norme Norme Tort 1 GE STP Cage Comment: Port 1 GE STP Cage Comment: V Tort 2 GE STP Cage [x1 P1 R] V	Pug Head module Fig Module
	Port 3 GE SIP Cage (x1 P3 R) Port 4 GE SIP Cage (x1 P4 R) Port 4 GE SIP Cage (x1 P4 R)	
	Port5 GE R45 [X1 P5 R] Port6 GE R45 [X1 P6 R]	✓ Information
¢ ⊔ ∥> ∽ Details view	• Fant & Ge ANS (bit 79 ft) Lecel port: brast & Ge ANS (bit 79 ft) • Pant & GE ANS (bit 79 ft) Lecel port: brast@UPHO (x1)Pret 1 dE SPP Cage (x1 Pt R) • Pant & GE ANS (bit 79 ft) Medion: Copper • Pant & GE ANS (bit 19 ft) Cable name: T • Pant & GE ANS (bit 11 R) Cable name: T	Device:

□ In the *Port interconnection* section, *Partner port* frame, *Partner port* field, browse and select the port of the partner device with which the device is connected.





	37801hns + Ungrouped device				C Hardware catalog	
Devices			2 1	opology view 🔒 Network view 🛛 🏹 Device view	Options	
*	👉 brs40 [with I/O data]		Device over	view		
	bes40 [with I/O data]			Properties Info I Diagnostics	✓ Catalog	
• 🔄 37801hns 🔥	General 10 tags Syst	em constants	Texts			tes tes
Add new device	▼ General	>> Port Intercon		6	Filter Profile: Alb	
Devices a networks T [CPU 3140-2	Catalog information				Head module	
Device configura	▼ PROFILIET interface [x1]	Local port:			Module	
V Online & diagno	General			▼ 1 57300/E1200M station_1		1
Program blocks	Ethernet addresses		Local port:	▼ mple_1		
Fight Technology obje	· Advanced options					
Etternel source fi	Interface options			(Post)		
PLC tegs	Media redundancy			Port 2		
F C PLC data types	 Real time settings 					
Watch end force	10 cycle					
Image: Contine backups	▶ Port 1 GE SFP Gage					
Device proxy data	Port 2 GE SFP Cage					
Program info	▶ Port 3 GE SFP Cage					
PLC supervisions	Port 4 GE SFP Cage					
🔄 PLC elarm text lists	Port 5 GE RJ45 [X1 F	Partner port:				
Locel modules	Port 6 GE RJ45 (X1 P	and the second second				-
Distributed VO	Port 7 GE RJ45 [X1 P					-
Ungrouped devices	Port 8 GE RJ45 [X1 P				🖸 Edit 🧹 🗙	<u>^</u>
Security settings	Port 9 GE 8J45 [X1 P			2		- L
C C C C C C C C C C C C C C C C C C C	Port 10 GE R/45 (k1 P		Parmer port:			
✓ Details view	Port 11 GE R/45 [X1 P			Medium:		100
· Decails view	Port 12 GE R/45 [X1 P			 Coble length; 		
	Diagnostics addresses			(=100 m (*)		
	Module parameters			3 annal delac		



Note: *PROFINET* monitors the topology configuration. If you connect the port of the Hirschmann device to a different port of the partner device, then the Hirschmann device generates an alarm with the error message Wrong partner port.

The alarm ceases when you reconnect the port of the Hirschmann device to the set-up port of the partner device.

Swapping devices

Hirschmann devices support the device swapping function with an engineering station.

When identical devices are swapped, the engineering station assigns the parameters of the original device to the new device.

The device swapping function with the TIA Portal has the following prerequisites:

- S7 1511 with software release from v2.6, currently available for CPU 1511 or higher
- Hirschmann device software release from 08.8.00
- The neighboring devices support LLDP.
- ▶ The topology is set up and loaded onto the TIA Portal.

Prerequisites for the replacement device:

- The replacement device is exactly of the same type as the original device.
- The replacement device is connected to the exact same place in the network (same ports and neighboring devices).
- ▶ The replacement device has a *PROFINET* default configuration:
 - System name = "" (empty string)
 - IP address = 0.0.0.0 Netmask = 0.0.0.0 Gateway address = 0.0.0.0 or DHCP is activated
 PROFINET is activated

When these conditions are met, the engineering station automatically assigns the parameters of the original device (device name, IP parameters, and configuration data) to the replacement device.

Perform the following steps:

Make a note of the port assignments on the original device. Remove the original device from the system.

The PLC now detects an error.

- Insert the replacement device in the same position in the network. When you reconnect the ports, verify that the port assignments are the same as for the original device.
 The PLC finds the replacement device and sets it up the same way as the original device.
 The PLC then detects proper operation.
- □ When necessary, reset the PLC to Run.

Topology discovery

After you initialize the Topology discovery, the engineering station looks for connected devices.

Configuring the topology

The TIA Portal gives you the option to set up the topology and monitor it accordingly. The TIA Portal displays the connection parameters (quality and settings) in a colored graphic.

Communication diagnosis

The TIA Portal monitors the communication quality and outputs messages relating to detected communication problems.

16.4.5 PROFINET parameters

Alarms

The device supports alarms on the device and port levels.

Table 76: Alarms supported

Alarms on device level	Change in device status
	Failure of redundant power supply
	Failure/removal of ACA
	Removal of modules
Alarms on port level	Change in link status

Record parameters

The device provides records for:

- Device parameters
- Device status

Port status/parameters

Table 77: Device parameters

Byte	Content	Access	Value	Meaning
0	Send alarm if	rw	0	Do not send an alarm
	status changes		1	Send an alarm if the status of device changes.
1	Power Alarm	rw	0	Do not send an alarm
			1	When a power supply fails, send an alarm.
2	ACA Alarm	rw	0	Do not send an alarm
			1	When the ACA is removed, send an alarm.
3	Module Alarm	rw	0	Do not send an alarm
			1	When the module connections are changed, send an alarm.

Byte	Content	Access	Value	Meaning
0	Device status	ro	0	Unavailable
			1	ОК
			2	Error
1	Power supply unit 1	ro	0	Unavailable
			1	ОК
			2	Error
2	Power supply unit 2	ro	0	OK
			1	Unavailable
			2	Error
3	Power supply unit 3	ro	0	Unavailable
			1	ОК
			2	Error
4	4 Power supply unit 4 ro	ro	0	Unavailable
			1	OK
			2	Error
5	Power supply unit 5	ro	0	Unavailable
			1	ОК
			2	Error
6	6 Power supply unit 6 ro	ro	0	Unavailable
			1	ОК
			2	Error
7	Power supply unit 7	ro	0	Unavailable
			1	OK
			2	Error
8	Power supply unit 8	ro	0	Unavailable
			1	OK
			2	Error
9	Signal contact 1	ro	0	Unavailable
	-		1	Closed
			2	Open
10	Signal contact 2	ro	0	Unavailable
	-		1	Closed
			2	Open
11	Temperature	ro	0	Unavailable
			1	OK
			2	Threshold value for temperature exceeded or not reached
12	Fan	ro	0	Unavailable
		-	1	OK
			2	Fan failure

Table 78: Device status

Byte	Content	Access	Value	Meaning
13	13 Module removal ro 0		0	Unavailable
			1	ОК
			2	A module has been removed.
14	ACA removed	ro	0	Unavailable
			1	ОК
			2	The ACA has been removed.
15	Not used		0	
			1	
			2	
16	Not used		0	
			1	
			2	
17	Connection	ro	0	Unavailable
			1	ОК
			2	Connection failure

Table 78: Device status

Table 79: Port status/parameters

Byte	Content	Access	Value	Meaning
0	Report port error	rw	0	Do not send an alarm
			1	When one of the port alarm reasons represented by bytes 4 10 occurs, send an alarm.
1	Report connection error	rw	0	Do not send an alarm
			1	Send alarm if the connection has failed
2	Transmission rate too high	rw	0	Do not send an alarm
	Note: The configuration of this parameter might not be available in the TIA Portal.		1	When the threshold values for the transmission rate are exceed, send an alarm.
3	Port on	rw	0	Unavailable
			1	Port enabled
			2	Port disabled
4	Link status	ro	0	Unavailable
			1	Connection exists
			2	Connection interrupted
5	Bit rate	ro	0	Unavailable
			1	Unknown
			2	10 Mbit/s
			3	100 Mbit/s
			4	1 Gbit/s
6	Duplex	ro	0	Unavailable
			1	Half-duplex
			2	Full-duplex

Table 79: Port status/parameters

Byte	Content	Access	Value	Meaning
7	Auto-negotiation	ro	0	Unavailable
			1	Disabled
			2	Enabled

I/O Data

You find the bit assignment for the I/O data in the following table.

Table 80: Device I/O data

Direction	Byte	Bit	Meaning
	Bit values:	0	OK or unavailable
		1	Reason for report exists
Input	0	General	
		0	Device status
		1	Signal contact 1
		2	Signal contact 2
		3	Temperature
		4	Fan
		5	Module removal
		6	ACA removed
		7	Not used
Input	1	Pow	er supply status
		0	Power supply unit 1
		1	Power supply unit 2
		2	Power supply unit 3
		3	Power supply unit 4
		4	Power supply unit 5
		5	Power supply unit 6
		6	Power supply unit 7
		7	Power supply unit 8
Input	2	Supp	oly voltage status
		0	Not used
		1	Not used
		2	Connection error
		3	Not used
		4	Not used
		5	Not used
		6	Not used
		7	Not used
Output			Not defined

Direction	Byte	Bit	Meaning
	Bit values:	0	No connection
		1	Active connection
Input	0	Con	nection status for ports 1 to 8
		0	Port 1
		1	Port 2
		2	Port 3
		3	Port 4
		4	Port 5
		5	Port 6
		6	Port 7
		7	Port 8
Input	1	Con	nection status for ports 9 to 16
		0	Port 9
		1	Port 10
		2	Port 11
		3	Port 12
		4	Port 13
		5	Port 14
		6	Port 15
		7	Port 16
Input	n	Con	nection for port (n x 8) + 1 to port (n x 8) + 8
		0	Port (n x 8) + 1
		1	Port (n x 8) + 2
		2	Port (n x 8) + 3
		3	Port (n x 8) + 4
		4	Port (n x 8) + 5
		5	Port (n x 8) + 6
		6	Port (n x 8) + 7
		7	Port (n x 8) + 8

Table 81: Port I/O data (Input)

Table 82:	Port I/O data	(Output)

Direction	Byte	Bit	Meaning
	Bit values:	0	Port activated
		1	Port not activated

Direction	Byte	Bit Meaning	
Output	0	Status "Port activated" for ports 1 to 8	
		0 Port 1 activated	
		1 Port 2 activated	
		2 Port 3 activated	
		3 Port 4 activated	
		4 Port 5 activated	
		5 Port 6 activated	
		6 Port 7 activated	
		7 Port 8 activated	
Output	1	Status "Port activated" for ports 9 to 16	
		0 Port 9 activated	
		1 Port 10 activated	
		2 Port 11 activated	
		3 Port 12 activated	
		4 Port 13 activated	
		5 Port 14 activated	
		6 Port 15 activated	
		7 Port 16 activated	
Output	n	Status "Port activated" for port (n x 8) + 1 to p (n x 8) + 8	ort
		0 Port (n x 8) + 1 activated	
		1 Port (n x 8) + 2 activated	
		2 Port (n x 8) + 3 activated	
		3 Port (n x 8) + 4 activated	
		4 Port (n x 8) + 5 activated	
		5 Port (n x 8) + 6 activated	
		6 Port (n x 8) + 7 activated	
		7 Port (n x 8) + 8 activated	

Table 82: Port I/O data (Output)

16.5 OPC UA Server

The Open Platform Communications United Architecture (OPC UA) is a protocol for industrial communication, and describes a variety of OPC UA information models. The OPC UA protocol is a standardized protocol for the secure and reliable exchange of data in the industrial automation space and in other industries.

The OPC UA protocol provides a very flexible and adaptable mechanism for transferring the data between industrial automation equipment, monitoring devices, and sensors. The OPC UA protocol uses a standard interface, for example, *HTTPS* that makes the protocol simple to integrate into existing management systems. The device operating as an OPC UA server transmits the data of the connected end devices, ranging from simple uptime status to large amounts of complex industrial data.

The following figure displays the *OPC UA* information model data of the connected end devices available to the *OPC UA* client.




Figure 110: OPC UA information model

Object	Description
Power save	Specifies how the port behaves when no cable is connected.
Port on Activates/deactivates the port.	
Power state	Specifies if the port is physically switched on or off when you deactivate the port with the <i>Port on</i> function.
State Displays if the port is currently physically enabled or of	
Port statusDisplays the link status of the port.	

Table 84: Object values in the OPC UA information model

Object	Value	Description
Device Error Reason	1	None
	2	Power supply
	3	Link failure
	4	Temperature
	5	Fan failure
	6	Module removal
	7	External non volatile memory removal
	8	External non volatile memory not in synchronization
	9	Ring redundancy
External Non Volatile Memory 1	1	Not present
Status	2	Removed
	3	Ok
	4	Out of memory
	5	Generic error
External Non Volatile Memory 2	1	Not present
Status	2	Removed
	3	Ok
	4	Out of memory
	5	Generic error
HiDiscovery Protocol Status	1	Enabled
	2	Disabled
MRP Ring Redundancy Status	1	Available
	2	Not available
Power Supply 1	1	Present
	2	Defective
	3	Not installed
	4	Unknown
Power Supply 2	1	Present
	2	Defective
	3	Not installed
	4	Unknown

Object	Value	Description
Auto Power Down	1	Auto power down
	2	No power save
	3	Energy efficient ethernet
	4	Unsupported
Flow Control	1	Enabled
	2	Disabled
Manual Cable Crossing	1	Medium dependent interface
	2	Medium dependent interface crossover
	3	Auto medium dependent interface crossover
	4	Unsupported
Port On	1	Up
	2	Down
	3	Testing
Power State	1	Enabled
	2	Disabled
Send Trap	1	Enabled
	2	Disabled
State	1	Up
	2	Down
Port Status	1	Up
	2	Down
	3	Testing
	4	Unknown
	5	Dormant
	6	Not present
	7	Lower layer down

Table 84: Object values in the OPC UA information model

The device operating as an *OPC UA* server processes the *OPC UA* information model data and transmits it securely to the *OPC UA* client application. The *OPC UA* server and *OPC UA* client communicate through a session.

The device operating as an OPC UA server shares the monitored data of the OPC UA information model. The user of the OPC UA client selects the items to be monitored in the OPC UA client application from a list of the IEC variables. The OPC UA client application requests the OPC UA information model data from the device operating as an OPC UA server using the specified OPC UA user account data.

The device sets up an *OPC UA* session by first negotiating the policy for a secure connection. Over this secure connection, the *OPC UA* client sends the login credentials of the *OPC UA* user account. The *OPC UA* server in the device then authenticates the *OPC UA* client. When the login credentials are valid, the device grants the *OPC UA* client access to its *OPC UA* Server function.

The device offers a role-based authentication and encryption concept to specifically control the access to its *OPC UA* server. The *OPC UA* client can use commands and functions associated with the *OPC UA* user account set up in the device.

16.5.1 Enabling the OPC UA server

In the default setting, the OPC UA Server function is disabled. The Advanced > Industrial Protocols > OPC UA Server dialog lets you enable the OPC UA Server function. You can also specify the max. number of simultaneous OPC UA sessions. In the default setting, the values for the Listening port and Sessions (max.) fields are already specified. You specify the authentication and encryption protocol for OPC UA users at global level.

Perform the following steps:

- □ Open the Advanced > Industrial Protocols > OPC UA Server dialog.
- □ To enable the OPC UA Server function, select the On radio button in the Operation frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ In the *Listening port* field, change the TCP port number, if necessary.
- □ In the Sessions (max.) field, change the number of OPC UA sessions that can be established simultaneously, if necessary.
- □ In the Security policy field, select the authentication and encryption protocol.
- □ Apply the settings temporarily. To do this, click the ✓ button. The dialog displays the *To apply the changes, restart the OPC/UA server. Restart now?* window.
- □ To apply the settings, click the Yes button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
opc-ua operation	To enable the OPC UA Server server.
opc-ua port <165535>	To change the TCP port number, if necessary.
opc-ua sessions <15>	To specify the number of OPC UA connections that can be established simultaneously.
opc-ua security-policy none basic128rsa15 basic256 basic256sha256	To specify the authentication and encryption protocol.
show opc-ua global	To display the OPC UA Server settings.
IEC62541 - OPC/UA server settings	
IEC62541 - OPC/UA server operation	.enabled
Listening port	.4840
Number of concurrent sessions	.5
Configured security-policy	.none

16.5.2 Setting up an OPC UA user account

The device lets you manage the *OPC UA* user accounts required to access the device using a *OPC UA* client application. Every *OPC UA* client user requires an active *OPC UA* user account to gain access to the *OPC UA* server of the device.

In the following example, you set up an *OPC UA* user account for the *OPC UA* client user USER which has read access. Then the user USER is authorized to monitor the *OPC UA* information model data. To do this, perform the following steps:

□ Open the Advanced > Industrial Protocols > OPC UA Server dialog. \Box Click the $\overset{\blacksquare}{+}$ button. The dialog displays the Create window. Enter the name USER in the User name field. Click the Ok button. □ In the *Password* field, enter a password of at least 6 characters. In this example, you give the user account the password SECRET. □ In the Access role column, select the readOnly item. \Box Apply the settings temporarily. To do this, click the \checkmark button. The dialog displays the To apply the changes, restart the OPC/UA server. Restart now? window. □ To apply the settings, click the Yes button. The dialog displays the OPC UA user accounts that are set up. enable To change to the Privileged EXEC mode. configure To change to the Configuration mode. To add the OPC UA user account USER. users add USER opc-ua users modify USER password To enter and confirm the password SECRET for the Enter NEW password: ****** (SECRET) OPC UA user account USER. Enter a password of at Confirm NEW password: ****** (SECRET) least 6 characters. opc-ua users modify USER access-role read-To assign the access role readOnLy to the OPC UA only user account USER. To activate the user account USER. opc-ua users enable USER show opc-ua users To display the user accounts that are set up. User Name Status Access-Role user read-onlv [x]

Note: When you set up a new OPC UA user account, remember to set the password.

16.5.3 Deactivating an OPC UA user account

After you deactivate the *OPC UA* user account, the user cannot access the device using the *OPC UA Server* function. Deactivating an *OPC UA* user account lets you keep the account settings and reuse them in the future. To do this, perform the following steps:

- Open the Advanced > Industrial Protocols > OPC UA Server dialog. The dialog displays the OPC UA user accounts that are set up.
- □ In the table row for the relevant *OPC UA* user account, unmark the checkbox in the *Active* column.
- □ Apply the settings temporarily. To do this, click the ✓ button.
 The dialog displays the *To apply the changes, restart the OPC/UA server. Restart now?* window.
- □ To apply the settings, click the Yes button.

enable		To change to the Privileged EXEC mode.
configure		To change to the Configuration mode.
opc-ua users disable USER		To disable the user account USER.
show opc-ua users		To display the user accounts that are set up.
User Name	Access-Role	Status
user	read-only	[]
save		To save the settings in the non-volatile memory (nvm) in the "Selected" configuration profile.

16.5.4 Deleting an OPC UA user account

To permanently deactivate the OPC UA user account settings, you delete the OPC UA user account. To do this, perform the following steps:

- □ Open the *Advanced* > *Industrial Protocols* > *OPC UA Server* dialog. The dialog displays the *OPC UA* user accounts that are set up.
- □ Select the table row of the relevant OPC UA user account.
- $\hfill\square$ Click the $\hfill\blacksquare$ button.
- □ Apply the settings temporarily. To do this, click the ✓ button.
 The dialog displays the *To apply the changes, restart the OPC/UA server. Restart now?* window.
- □ To apply the settings, click the Yes button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
opc-ua users delete USER	To delete the user account USER.

show opc-ua users		To display the user accounts that are set up.
User Name	Access-Role	Status
save		To save the settings in the non-volatile memory
		(nvm) in the "Selected" configuration profile.

16.6 Service Discovery

Service Discovery is part of a series of technologies summarized by the term Zero-configuration networking (zeroconf). Service Discovery uses multicast DNS (mDNS) and DNS service discovery (DNS-SD) to advertise the services offered by the device to other devices in the network that request the service. The device currently supports the *ITxPT Module Inventory* service. Additional services may follow in future releases.

Devices that support Service Discovery can automatically discover the available services on the network without having information about which devices are available. In public transportation, for example, such devices can be ticketing systems, passenger information systems, or vehicle tracking systems.

Devices that subscribe to the services will detect a new device as soon as you connect it to the network, and read its service data. For example, when you install a ticketing system in the network of a public transportation vehicle, the ticketing system needs to communicate with the existing passenger information system to deliver real-time updates on ticket sales and availability.

16.6.1 ITxPT Module Inventory

The *ITxPT Module Inventory* service is part of the Information Technology for Public Transport (ITxPT) specification.

The intended use of the *ITxPT Module Inventory* service is module inventory in networks of vehicles. The *ITxPT Module Inventory* service lets devices subscribing to the service automatically inventory the modules installed in the on-board IP network of vehicles. Modules in the sense of ITxPT might be other Hirschmann devices or devices from the on-board network of the vehicle. For example, the on-board passenger information system. The service lets you collect information about the modules and monitor their status.

The device provides the information through SRV records and TXT records.

- The SRV record contains the location.
- The device provides the *TXT record* through mDNS. The *TXT record* contains information about the service.
 - version
 Version of the related ITxPT specification release
 Example: 2.1.2
 type
 Short name of the device type
 Example: MESW (Managed Ethernet Switch)
 model
 Name of the device
 For example, the product code
 Example: RSPE20
 manufacturer
 Manufacturer of the device
 Example: Hirschmann Automation and Control GmbH
 serialnumber
 - Serial number of the device Example: 942287999020501939
 - softwareversion
 Software version installed on the device
 Example: RSPE20 Release HiOS-2A-10.0.002024-08-24 16:49

- hardwareversion
 Hardware version of the device
 Example: 0202
- macaddress
 MAC address of the device in hexadecimal format
 Example: CF:DA:98:63:9D:F6
- xstatus
 Detailed device status
 For example, the status of the device ports participating in the *ITxPT Module Inventory* service
 Example: coffffffffffffffffffffffffffffffff
 services
- services
 List of available services on the device
 For example, the *ITxPT Module Inventory* service
 Example: inventory

The device transmits the TXT record once in the following cases:

- After an mDNS query containing the address _itxpt_socket._tcp.local The device transmits the *TXT record* in response to multicast or unicast requests in the network for services offered by the device.
- Without a request
 - As soon as the Service Discovery function and the *ITxPT Module Inventory* service are enabled.
 See the Operation frame.
 - If the Service Discovery function and the *ITxPT Module Inventory* service are enabled, and the device detects changes regarding the global status or the port status of other devices in the network. Other devices might be other Hirschmann devices or devices from the on-board network of the vehicle. For example, the on-board passenger information system.

16.6.2 Application example

The following example illustrates a typical use case in the field of public transportation. The vehicle on-board network contains, in addition to switches and the management station, the on-board passenger information system, the on-board remote diagnostic system, and other devices typical for this application.




Figure 111: Example for ITxPT Module Inventory

Enabling the Service Discovery function on the device

Enable the *Service Discovery* function on every switch in the on-board network. Simultaneously, the device activates the *ITxPT Module Inventory* service to monitor the link status or the PoE status of the device.

Perform the following steps:

- □ Enable the *Service Discovery* function and activate the *ITxPT Module Inventory* service on the device. To do this, in the *Operation* frame, select the *On* radio button.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
service-discovery operation	To enable the Service Discovery function and to activate the <i>ITxPT Module Inventory</i> service.
show service-discovery global	To display the <i>Service Discovery</i> and the <i>ITxPT</i> <i>Module Inventory</i> settings of the device.

Enabling the link status monitoring per port

For each required port, activate the *ITxPT Module Inventory* service to monitor the link status of the port.

Perform the following steps:

□ In the table, in the *Link* column, mark the checkbox for the port.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

er	nable	To change to the Privileged EXEC mode.
с	onfigure	To change to the Configuration mode.
ir	nterface 1/1	To change to the Interface Configuration mode of port 1/1.
se	ervice-discovery monitor link	To activate the <i>ITxPT Module Inventory</i> service to monitor the link status of the port.
sł	now service-discovery port	To display the <i>Service Discovery</i> and the <i>ITxPT</i> <i>Module Inventory</i> settings per port.
ex	xit	To change to the Configuration mode.

Enabling the PoE status monitoring per port

For each required port, activate the *ITxPT Module Inventory* service to monitor the PoE status of the port.

Perform the following steps:

□ In the table, in the *PoE* column, mark the checkbox for the port.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
interface 1/1	To change to the Interface Configuration mode of port 1/1.
service-discovery monitor poe	To activate the <i>ITxPT Module Inventory</i> service to monitor the PoE status of the port.
show service-discovery port	To display the <i>Service Discovery</i> and the <i>ITxPT</i> <i>Module Inventory</i> settings per port.
exit	To change to the Configuration mode.

A Setting up the configuration environment

A.1 Setting up a DHCP/BOOTP server

The following example describes the configuration of a DHCP server using the haneWIN DHCP Server software. This shareware software is a product of IT-Consulting Dr. Herbert Hanewinkel. You can download the software from www.hanewin.net. You can test the software for 30 calendar days from the date of the first installation, and then decide if you want to purchase a license.

Perform the following steps:

- Install the DHCP server on your PC.
 - To carry out the installation, follow the installation assistant.
- Start the *haneWIN DHCP Server* program.

ile _0ptions _₩indo Dbserved MAC addre			
MAC Address/Id	Profile	IP Address	Last request on

Figure 112: Start window of the haneWIN DHCP Server program

Note: When Windows is activated, the installation procedure includes a service that is automatically started in the basic configuration. This service is also active although the program itself has not been started. When started, the service responds to DHCP queries.

- □ In the menu bar, click the items *Options* > *Preferences* to open the program settings window.
- Select the DHCP tab.
- □ Specify the settings displayed in the figure.



Figure 113:DHCP setting

- Click the OK button.
- □ To enter the configuration profiles, click in the menu bar the items Options > Configuration Profiles.

□ Specify the name for the new configuration profile.




Figure 114:Adding configuration profiles

- Click the *Add* button.
- Specify the netmask.

	THOME DIVS NECESIOS	Server Boot 0ther
for:	static Entries	-
Dy	mamic IP Addresses	
	From:	
	Until	
	Lease time (s):	36000
$\left(\right)$	Subnet mask:	255.255.255.0
-	Gateway Address:	
	Backup Gateway 1:	
	Backup Gateway 2:	

Figure 115:Netmask in the configuration profile

- □ Click the *Apply* button.
- Select the Boot tab.
- □ Enter the IP address of your tftp server.
- □ Enter the path and the file name for the configuration file.

Name	149.218.112.159	
File:	/switch/103config.dat	-1
File:	ate File if Vendor-Class-Id is: le Size (in 512 byte blocks):	

Figure 116:Configuration file on the tftp server

- □ Click the *Apply* button and then the *OK* button.
- □ Add a profile for each device type.

When devices of the same type have different configurations, you add a profile for each configuration.

Profile	Туре		
Default Client Pr PowerMICE105 MICE102 RS2_16M101 RS2_7_103	ofile		
RS2_7_103	Add	Edit	<u>R</u> emove

Figure 117: Managing configuration profiles

□ To complete the addition of the configuration profiles, click the *OK* button.

□ To enter the static addresses, in the main window, click the *Static* button.



Figure 118:Static address input

Click the *Add* button.

ile <u>O</u> ptions <u>W</u> ind			
Diserved MAC addre	isses/ld: 2/4		
MAC Address/Id	Profile	IP Address	Last request on
	-		
1			

Figure 119:Adding static addresses

□ Enter the MAC address of the device.

Enter the IP address of the device.

Add static entries
With static entries you can assign clients with known hardware address or identifier a fixed IP address and configuration profile.
The assigned IP addresses must not overlap with the dynamic address ranges.
Identifiers or hardware addresses must be specified byte by byte in hexadecimal notation. For MAC (hardware) addresses the bytes must be separated by a dash or colon.
Cient Identifier 🗖 Circuit Identifier 🗖 Remote Identifier 🛛 or
Hardware address: 00:00:00:51:74:00
IP Address: 149,218.112.105
Optional
Configuration Profile: Switch1
Remark:
Redundant entry (allow entry with an existing IP address)
OK Apply Cancel

Figure 120:Entries for static addresses

- □ Select the configuration profile of the device.
- □ Click the *Apply* button and then the *OK* button.
- □ Add an entry for each device that will get its parameters from the DHCP server.

■ haneWIN DHCP Eile Options Windo			
Observed MAC addres	sses/ld: 2/4		
MAC Address/Id	Profile	IP Address	Last request on
00:80:63:51:74:00 00:80:63:10:9a:d7 00:80:63:14:db:d9 00:80:63:0f:1d:b0	PowerMICE105 MICE102 RS2_16M101 RS2_7_103	149,218,112,105 149,218,112,102 149,218,112,101 149,218,112,103	03.06.05 14:23:22 03.06.05 14:09:58
•	New	static	dynamic ignored

Figure 121:DHCP server with entries

A.2 Setting up a DHCP server with Option 82

The following example describes the configuration of a DHCP server using the haneWIN DHCP Server software. This shareware software is a product of IT-Consulting Dr. Herbert Hanewinkel. You can download the software from www.hanewin.net. You can test the software for 30 calendar days from the date of the first installation, and then decide if you want to purchase a license.

Perform the following steps:

- □ Install the DHCP server on your PC.
 - To carry out the installation, follow the installation assistant.
- Start the *haneWIN DHCP Server* program.



Figure 122: Start window of the haneWIN DHCP Server program

Note: When Windows is activated, the installation procedure includes a service that is automatically started in the basic configuration. This service is also active although the program itself has not been started. When started, the service responds to DHCP queries.



Figure 123: DHCP setting

□ To enter the static addresses, click the *Add* button.




Figure 124: Adding static addresses

- ☐ Mark the *Circuit Identifier* checkbox.
- □ Mark the *Remote Identifier* checkbox.

With static entries you o or identifier a fixed IP ac		ith known hardware address ation profile.
The assigned IP addres ranges.	ses must not overla	p with the dynamic address
Identifiers or hardware a hexadecimal notation. F separated by a dash or	for MAC (hardware)	pecified byte by byte in addresses the bytes must be
Client Identifier	Circuit Identifier	Remote Identifier
Hardware address:		
IP Address:]
Optional		
Configuration Profile:		*
Remark:	-	
E Bedundant entr	(allow entry with an	n existing IP address)
1 Troductuant only		
OK	Apply	Cancel

Figure 125: Default setting for the fixed address assignment

□ In the *Hardware address* field, specify the value *Circuit Identifier* and the value *Remote Identifier* for the switch and port.

The DHCP server assigns the IP address specified in the *IP address* field to the device that you connect to the port specified in the *Hardware address* field.

The hardware address is in the following form:

```
ciclhhvvvvssmmpprirlxxxxxxxxxx
```

```
🕨 ci
   Sub-identifier for the type of the Circuit ID
▶ cl
   Length of the Circuit ID.
hh
   Hirschmann identifier:
   01 when a Hirschmann device is connected to the port, otherwise 00.
vvvv
   VLAN ID of the DHCP request.
   Default setting: 0001 = VLAN 1
► ss
   Socket of device at which the module with that port is located to which the device is
   connected. Specify the value 00.
▶ mm
   Module with the port to which the device is connected.
►
  DD
   Port to which the device is connected.
🕨 ri
   Sub-identifier for the type of the Remote ID
```

▶ rl

Length of the Remote ID.

```
xxxxxxxxxxxxxx
```

Remote ID of the device (for example MAC address) to which a device is connected.

	in assign clients with known hardware address tress and configuration profile.
The assigned IP address ranges	es must not overlap with the dynamic address
	ldresses must be specified byte by byte in r MAC (hardware) addresses the bytes must be olon.
🗖 Client Identifier 🔽	Circuit Identifier 🔽 Remote Identifier or
Hardware address:	00000104008063109ad7
IP Address:	149.218.112.100
Optional	
Configuration Profile:	•
configuration forme.	
Remark:	

Figure 126: Specifying the addresses




Figure 127: Application example of using Option 82

A.3 Preparing access using SSH

You can connect to the device using SSH. To do this, perform the following steps:

- Generate a key in the device.
 - or
- Transfer your own key onto the device.
- Prepare access to the device in the SSH client program.

Note: In the default setting, the key is already existing and access using SSH is enabled.

A.3.1 Generating a key in the device

The device lets you generate the key directly in the device. To do this, perform the following steps:

- □ Open the *Device Security* > *Management Access* > *Server* dialog, *SSH* tab.
- □ To disable the SSH server, select the *0ff* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ To generate a RSA key, in the *Signature* frame, click the *Create* button.
- □ To enable the SSH server, select the *0n* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
ssh key rsa generate	To generate a new RSA key.

A.3.2 Transferring your own key onto the device

OpenSSH gives experienced network administrators the option of generating their own key. To generate the key, enter the following commands on your PC: ssh-keygen -q -t rsa -f rsa.key -C '' -N '' rsaparam -out rsaparam.pem 2048

The device lets you transfer your own SSH key onto the device. To do this, perform the following steps:

- □ Open the Device Security > Management Access > Server dialog, SSH tab.
- □ To disable the SSH server, select the *0ff* radio button in the *Operation* frame.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- When the file is located on your PC or on a network drive, drag and drop it onto the area. As an alternative, click in the area to select the file.

□ To transfer the file to the device, click the *Start* button.

□ To enable the SSH server, select the *0n* radio button in the *Operation* frame.

 \Box Apply the settings temporarily. To do this, click the \checkmark button.

Perform the following steps:

- □ Copy the self-generated key from your PC to the external memory.
- $\hfill\square$ Copy the key from the external memory into the device.

enable copy sshkey envm <file name> To change to the Privileged EXEC mode.

To transfer your own key onto the device from the external memory.

A.3.3 Preparing the SSH client program

The *PuTTY* program lets you access the device using SSH. You can download the software from www.chiark.greenend.org.uk/~sgtatham/putty/.

Perform the following steps:

□ Start the program by double-clicking on it.

🕵 PuTTY Configuration			?	\times
Category:				
Session	Basic options for your PuT	TY ses	sion	
Logging	Specify the destination you want to con	nect to		
- Keyboard	Host <u>N</u> ame (or IP address)		<u>P</u> ort	
- Bell Features	<mark>192.168.1.5</mark>		22	
-Window	Connection type:			
Appearance	<mark>●<u>S</u>SH</mark> ○Se <u>r</u> ial ○Other:	Telnet		\sim
- Behaviour Translation	Load, save or delete a stored session			
	Saved Sessions			
Colours				
Data	Default Settings	•	Load	
Proxy			Load	
			Sa <u>v</u> e	•
Telnet			Delet	е
Rlogin		\sim		
SUPDUP				
	Close window on exit.			
	○ Always ○ Never ● Only	on cle	an exit	
		_		
<u>A</u> bout <u>H</u> elp	Open		<u>C</u> ance	el

Figure 128: PuTTY input screen

- □ In the Host Name (or IP address) field you enter the IP address of your device.
 - The IP address (a.b.c.d) consists of 4 decimal numbers with values from 0 to 255. The 4 decimal numbers are separated by points.
- □ To select the connection type, select the SSH radio button in the Connection type option list.
- □ Click the *Open* button to set up the data connection to your device.

Before the connection is established, the *PuTTY* program displays a security alarm message and lets you check the key fingerprint.

PuTTY Security Alert X		
?	The server's host key is not cached in the registry. You have no guarantee that the server is the computer you think it is.	
	The server's rsa2 key fingerprint is: ssh-rsa 2048 SHA256:1GepSdba8L0wRvKRLvDJ9iVeNEpFOu4sDCWXdYGK14Y	
	If you trust this host, press "Accept" to add the key to PuTTY's cache and carry on connecting.	
	If you want to carry on connecting just once, without adding the key to the cache, press "Connect Once".	
	If you do not trust this host, press "Cancel" to abandon the connection.	
Hel	p More info Accept Connect Once Cancel	

Figure 129: Security alert prompt for the fingerprint

Before the connection is established, the *PuTTY* program displays a security alarm message and lets you check the key fingerprint.

- Check the fingerprint of the key to help ensure that you have actually connected to the desired device.
- □ When the fingerprint matches your key, click the Yes button.

For experienced network administrators, another way of accessing your device through an SSH is by using the OpenSSH Suite. To set up the data connection, enter the following command:

ssh admin@10.0.112.53

admin is the user name.

10.0.112.53 is the IP address of your device.

A.4 HTTPS certificate

Your web browser establishes the connection to the device using the Hypertext Transfer Protocol Secure (HTTPS). The prerequisite is that you enable the *HTTPS server* function in the *Device Security > Management Access > Server* dialog, *HTTPS* tab.

Note: Third-party software applications such as web browsers validate digital certificates based on criteria such as their expiration date and current cryptographic parameter recommendations. Outdated digital certificates may cause issues due to invalid or outdated information. Example: A digital certificate has expired or the cryptographic recommendations have changed. To solve validation conflicts with third-party software applications, transfer your own up-to-date digital certificate onto the device or regenerate a self-signed digital certificate with the latest device software.

A.4.1 HTTPS certificate management

To establish a secure connection, a digital certificate in X.509 format is required. In the default setting, the device uses a self-signed digital certificate.

You can regenerate the self-signed digital certificate. To do this, perform the following steps:

- □ Open the *Device Security* > *Management Access* > *Server* dialog, *HTTPS* tab.
- □ To generate a self-signed digital certificate, in the *Certificate* frame, click the *Create* button.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.
- □ For the changes to take effect after transferring a digital certificate onto the device, disable and re-enable the HTTPS server. Restart the HTTPS server using the Command Line Interface.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
https certificate generate	To generate a digital certificate for the HTTPS server.
no https server	To disable the HTTPS function.
https server	To enable the HTTPS function.

□ The device also lets you transfer an externally generated digital certificate onto the device:

- □ Open the *Device Security > Management Access > Server* dialog, *HTTPS* tab.
- When the file is located on your PC or on a network drive, drag and drop it onto the area. As an alternative, click in the area to select the file.
- □ To transfer the file to the device, click the *Start* button.
- \Box Apply the settings temporarily. To do this, click the \checkmark button.

enable	To change to the Privileged EXEC mode.
copy httpscert envm <file name=""></file>	To transfer the digital certificate for the HTTPS server from the external memory onto the device.
configure	To change to the Configuration mode.
no https server	To disable the HTTPS function.
https server	To enable the HTTPS function.

Note: To activate the digital certificate after the device generated or you transferred it, reboot the device or restart the HTTPS server. Restart the HTTPS server using the Command Line Interface.

A.4.2 Access through HTTPS

The default setting for HTTPS data connection is TCP port 443. If you change the number of the HTTPS port, then reboot the device or the HTTPS server. Thus the change becomes effective. To do this, perform the following steps:

- □ Open the *Device Security > Management Access > Server* dialog, *HTTPS* tab.
- □ To enable the function, select the *0n* radio button in the *Operation* frame.
- □ To access the device by HTTPS, enter HTTPS instead of HTTP in your web browser, followed by the IP address of the device.

enable	To change to the Privileged EXEC mode.
configure	To change to the Configuration mode.
https port 443	To specify the number of the TCP port on which the web server receives HTTPS requests from clients.
https server	To enable the <i>HTTPS</i> function.
show https	To display the status of the <i>HTTPS</i> server and the port number.

When you make changes to the HTTPS port number, disable the HTTPS server and enable it again to make the changes effective.

The device uses Hypertext Transfer Protocol Secure (HTTPS) and establishes a new data connection. When you log out at the end of the session, the device terminates the data connection.

B Appendix

B.1 Literature references

A small selection of books on network topics, ordered by publication date (newest first):

TSN – Time-Sensitive Networking (in German) Wolfgang Schulte VDE Verlag, 2020 ISBN 978-3-8007-5078-8 Time-Sensitive Networking For Dummies, Belden/Hirschmann Special Edition (in English) Oliver Kleineberg, Axel Schneider Wiley, 2018 ISBN 978-1-119-52791-6 (Print), ISBN 978-1-119-52799-2 (eBook) IPv6: Grundlagen - Funktionalität - Integration (in German) Silvia Hagen Sunny Connection, 3rd edition, 2016 ISBN 978-3-9522942-3-9 (Print), ISBN 978-3-9522942-8-4 (eBook) IPv6 Essentials (in English) Silvia Hagen O'Reilly, 3rd edition, 2014 ISBN 978-1-449-31921-2 (Print) TCP/IP Illustrated, Volume 1: The Protocols (2nd Edition) (in English) W. R. Stevens, Kevin R. Fall Addison Wesley, 2011 ISBN 978-0-321-33631-6 Measurement, Control and Communication Using IEEE 1588 (in English) John C. Eidson Springer, 2006 ISBN 978-1-84628-250-8 (Print), ISBN 978-1-84628-251-5 (eBook) TCP/IP: Der Klassiker. Protokollanalyse. Aufgaben und Lösungen (in German) W. R. Stevens Hüthig-Verlag, 2008 ISBN 978-3-7785-4036-7 Optische Übertragungstechnik in der Praxis (in German) **Christoph Wrobel** Hüthig-Verlag, 3rd edition, 2004 ISBN 978-3-8266-5040-6

UM Config RSPE Release 10.0 08/2024

B.2 Maintenance

Hirschmann is continually working on improving and developing their software. Check regularly if there is an updated version of the device software that provides you with additional benefits. You find information and software downloads on the Hirschmann product pages on the Internet at www.hirschmann.com.

B.3 Management Information Base (MIB)

The Management Information Base (MIB) is designed in the form of an abstract tree structure.

The branching points are the object classes. The "leaves" of the MIB are called generic object classes.

When this is required for unique identification, the generic object classes are instantiated, that means the abstract structure is mapped onto reality, by specifying the port or the source address.

Values (integers, time ticks, counters or octet strings) are assigned to these instances; these values can be read and, in some cases, modified. The object description or object ID (OID) identifies the object class. The subidentifier (SID) is used to instantiate them.

Example:

The generic object class hm2PSState (OID = 1.3.6.1.4.1.248.11.11.1.1.1.2) is the description of the abstract information power supply status. However, it is not possible to read any value from this, as the system does not know which power supply is meant.

Definition of the syntax terms used:		
Integer	An integer in the range -2 ³¹ 2 ³¹ -1	
IP address	xxx.xxx.xxx (xxx = integer in the range 0255)	
MAC address	12-digit hexadecimal number in accordance with ISO/IEC 8802-3	
Object Identifier	x.x.x.x (for example 1.3.6.1.1.4.1.248)	
Octet String	ASCII character string	
PSID	Power supply identifier (number of the power supply unit)	
TimeTicks	Stopwatch, Elapsed time = numerical value / 100 (in seconds)	
	numerical value = integer in the range 02^{32} -1	
Timeout	Time value in hundredths of a second	
	time value = integer in the range 02^{32} -1	
Type field	4-digit hexadecimal number in accordance with ISO/IEC 8802-3	
Counter	Integer (0 2^{32} -1), when certain events occur, the value increases by 1.	




Figure 130: Tree structure of the Hirschmann MIB

When you have downloaded updated device software from the product pages on the Internet, the ZIP archive contains not only the device software but also the MIBs.

B.4 List of RFCs

RFC 768	UDP
RFC 783	TFTP
RFC 791	IP
RFC 792	ICMP
RFC 793	TCP
RFC 826	ARP
RFC 854	Telnet
RFC 855	Telnet Option
RFC 951	BOOTP
RFC 1112	IGMPv1
RFC 1157	SNMPv1
RFC 1155	SMIv1
RFC 1212	Concise MIB Definitions
RFC 1213	MIB2
RFC 1493	Dot1d
RFC 1542	BOOTP-Extensions
RFC 1643	Ethernet-like -MIB
RFC 1757	RMON
RFC 1867	Form-Based File Upload in HTML
RFC 1901	Community based SNMP v2
RFC 1905	Protocol Operations for SNMP v2
RFC 1906	Transport Mappings for SNMP v2
RFC 1945	HTTP/1.0
RFC 2068	HTTP/1.1 protocol as updated by draft-ietf-http-v11-spec-rev-03
RFC 2131	DHCP
RFC 2132	DHCP-Options
RFC 2233	The Interfaces Group MIB using SMI v2
RFC 2236	IGMPv2
RFC 2246	The TLS Protocol, Version 1.0
RFC 2346	AES Ciphersuites for Transport Layer Security
RFC 2365	Administratively Scoped IP Multicast
RFC 2474	Definition of the Differentiated Services Field (DS Field) in the IPv4 and IPv6 Headers
RFC 2475	An Architecture for Differentiated Service
RFC 2578	SMIv2
RFC 2579	Textual Conventions for SMI v2
RFC 2580	Conformance statements for SMI v2
RFC 2613	SMON
RFC 2618	RADIUS Authentication Client MIB
RFC 2620	RADIUS Accounting MIB

RFC 2674	Dot1p/Q
RFC 2818	HTTP over TLS
RFC 2851	Internet Addresses MIB
RFC 2863	The Interfaces Group MIB
RFC 2865	RADIUS Client
RFC 2866	RADIUS Accounting
RFC 2868	RADIUS Attributes for Tunnel Protocol Support
RFC 2869	RADIUS Extensions
RFC 2869bis	RADIUS support for EAP
RFC 2933	IGMP MIB
RFC 3164	The BSD syslog protocol
RFC 3376	IGMPv3
RFC 3410	Introduction and Applicability Statements for Internet Standard Management Framework
RFC 3411	An Architecture for Describing Simple Network Management Protocol (SNMP) Management Frameworks
RFC 3412	Message Processing and Dispatching for the Simple Network Management Protocol (SNMP)
RFC 3413	Simple Network Management Protocol (SNMP) Applications
RFC 3414	User-based Security Model (USM) for version 3 of the Simple Network Management Protocol (SNMPv3)
RFC 3415	View-based Access Control Model (VACM) for the Simple Network Management Protocol (SNMP)
RFC 3418	Management Information Base (MIB) for the Simple Network Management Protocol (SNMP)
RFC 3580	802.1X RADIUS Usage Guidelines
RFC 3584	Coexistence between Version 1, Version 2, and Version 3 of the Internet- standard Network Management Framework
RFC 3621	Power Ethernet MIB
RFC 4022	Management Information Base for the Transmission Control Protocol (TCP)
RFC 4113	Management Information Base for the User Datagram Protocol (UDP)
RFC 4188	Definitions of Managed Objects for Bridges
RFC 4251	SSH protocol architecture
RFC 4291	IPv6 Addressing Architecture
RFC 4252	SSH authentication protocol
RFC 4253	SSH transport layer protocol
RFC 4254	SSH connection protocol
RFC 4293	Management Information Base for the Internet Protocol (IP)
RFC 4318	Definitions of Managed Objects for Bridges with Rapid Spanning Tree Protocol
RFC 4330	Simple Network Time Protocol (SNTP) Version 4 for IPv4, IPv6 and OSI
RFC 4363	Definitions of Managed Objects for Bridges with Traffic Classes, Multicast Filtering, and Virtual LAN Extensions
RFC 4541	Considerations for Internet Group Management Protocol (IGMP) and Multicast Listener Discovery (MLD) Snooping Switches
RFC 4836	Definitions of Managed Objects for IEEE 802.3 Medium Attachment Units (MAUs)

RFC 4861	Neighbor Discovery for IPv6
RFC 5321	Simple Mail Transfer Protocol
RFC 6221	Leightweight DHCPv6 Relay Agent
RFC 8200	IPv6 Specification
RFC 8415	DHCPv6

B.5 Underlying IEEE Standards

IEEE 802.1AB	Station and Media Access Control Connectivity Discovery
IEEE 802.1D	MAC Bridges (switching function)
IEEE 802.1Q	Virtual LANs (VLANs, MRP, Spanning Tree)
IEEE 802.1X	Port Authentication
IEEE 802.3	Ethernet
IEEE 802.3ac	VLAN Tagging
IEEE 802.3x	Flow Control
IEEE 802.3af	Power over Ethernet

B.6 Underlying IEC Norms

IEC 62439	High availability automation networks HSR – High-availability Seamless Redundancy
	MRP – Media Redundancy Protocol based on a ring topology PRP – Parallel Redundancy Protocol

B.7 Underlying ANSI Norms

ANSI/TIA-1057 Link Layer Discovery Protocol for Media Endpoint Devices, April 2006

B.8 Technical Data

16.6.3 Switching

Size of the MAC address table (forwarding database) (incl. static filters)	16384
Max. number of statically set-up MAC address filters	100
Max. number of MAC address filters learnable through IGMP Snooping	1024
Max. number of MAC address entries (MMRP)	512
Number of priority queues	8 Queues
Port priorities that can be set	07
MTU (Max. allowed length of packets a port can receive or transmit)	12288 Bytes

16.6.4 VLAN

VLAN ID range	14042
Number of VLANs	max. 256 simultaneously per device max. 256 simultaneously per port

16.6.5 Access Control Lists (ACL)

Max. number of ACLs	50
Max. number of rules per ACL	511
Max. number of rules per port	511
Number of total configurable rules	4088 (8 × 511)
Max. number of VLAN assignments	24
Max. number of rules which log an event	128
Max. number of Ingress rules	768

B.9 Copyright of integrated Software

The product contains, among other things, Open Source Software files developed by third parties and licensed under an Open Source Software license.

You can find the license terms in the Graphical User Interface in the Help > Licenses dialog.

B.10 Abbreviations used

ACA	Name of the external memory
ACL	Access Control List
BOOTP	Bootstrap Protocol
CLI	Command Line Interface
DHCP	Dynamic Host Configuration Protocol
DHCPv6	Dynamic Host Configuration Protocol for IPv6
DUID	DHCP Unique Identifier
EUI	Extended Unique Identifier
FDB	Forwarding Database
GUI	Graphical User Interface
HTTP	Hypertext Transfer Protocol
HTTPS	Hypertext Transfer Protocol Secure
ICMP	Internet Control Message Protocol
IEEE	Institute of Electrical and Electronics Engineers
IGMP	Internet Group Management Protocol
IP	Internet Protocol
IPv6	Internet Protocol version 6
LDRA	Lightweight DHCPv6 Relay Agent
LED	Light Emitting Diode
LLDP	Link Layer Discovery Protocol
MAC	Media Access Control
MIB	Management Information Base
MRP	Media Redundancy Protocol
MSTP	Multiple Spanning Tree Protocol
NDP	Neighbor Discovery Protocol
NMS	Network Management System
PC	Personal Computer
PTP	Precision Time Protocol
QoS	Quality of Service
RFC	Request For Comment
RM	Redundancy Manager
RSTP	Rapid Spanning Tree Protocol
SCP	Secure Copy
SFP	Small Form-factor Pluggable
SFTP	SSH File Transfer Protocol
SNMP	Simple Network Management Protocol
SNTP	Simple Network Time Protocol
TCP	Transmission Control Protocol
TFTP	Trivial File Transfer Protocol
TP	Twisted-pair

UDP	User Datagram Protocol
URL	Uniform Resource Locator
UTC	Coordinated Universal Time
VLAN	Virtual Local Area Network

C Index

0-9	
2-Switch coupling, Primary device	. 286
2-Switch coupling, Stand-by device	. 288
802.1X	66

Α	
Access roles	. 69
Access security	125
Advanced Information, HIPER Ring	216
Advanced Information, MRP	205
Advanced Information, RCP	297
Advanced Information, Ring/Network Coupling	277
Advanced Information, Sub Ring	265
Advanced mode	207
AF	176
Aging time	159
Alarm	478
Alarm messages	309
Alarm setting	425
Alternate port	254
APNIC	. 44
ARIN	. 44
ARP	. 46
Assured Forwarding	176
Authentication list	. 66
Automatic configuration	126

в

Backup port	254
andwidth	179
Sest Master Clock algorithm	, 97
BOOTP	43
oundary clock (PTP)	. 94
PDU	243
PDU guard	254
Bridge Identifier	240
Bridge Protocol Data Unit	243

С

CA (Certification Authority)	. 76,	346
Certificate		346
Certification Authority (CA)	. 76,	346
CIDR		
CIP		403
Class Selector		176
Classless inter domain routing		. 46
Closed circuit		321
Command Line Interface		
Command tree		
Common Industrial Protocol		403
Configuration file		. 60
Configuration modifications		309
Conformity class		423

D

DAN (depends on hardware)	
Data stream monitoring Port Mirroring	349
Data stream monitoring VLAN Mirroring	351
Data stream monitoring, RSPAN	
Delay (PTP)	
Delay measurement (PTP)	. 95
Delay time (MRP)	
Denial of Service	141
Designated bridge	248
Designated port	, 253
Destination table	309
Device description language	423
Device Level Ring	
Device replacement	. 17
Device status	
DHCP	. 43
DHCP L2 Relay	378
DHCP server	, 498
DHCPv6	. 61
Diameter (Spanning Tree)	242
Differentiated services	176
DiffServ	165
DiffServ Codepoint	176
Digital certificate	
Disabled port	249
DLR - EtherNet/IP compatibility	238
DoS	
DSCP	

Ε

Edge port	. 248, 253
EDS	403
EF	176
Email notification	336
Engineering Station	477
Engineering system	425
EtherNet/IP website	403
Event log	344
Expedited Forwarding	176

F

FAQ	529
Fast MRP	200
FDB (MAC address table)	155
First installation	. 43
Flow control	179

G

NRP
teway
neric Ethernet Module
neric object classes
bbal Config mode
/RP
andmaster (PTP)
D
D file
DML

н

н	
HaneWin	495, 498
Hardware reset	
HiDiscovery	
HIPER Ring	215
HIPER Ring Advanced Information	216
HIPER Ring Packet Prioritization	217
HIPER Ring Packets	216
HiView	65
Host address	44
HSR and PRP network connections (depends on hardware)	
HSR (depends on hardware)	200, 224
HSR Network structure (depends on hardware)	225

I

IANA	44
IAS	
lcon	
IEC 61850	. 392
IEEE MAC address	. 330
IEEE 802.1X	
IGMP snooping	9, 403
Industrial HiVision	15
Instantiation	. 509
Integrated Authentication Server	66
Interface status	. 303
Interface tracking	3, 306
Interface tracking object	. 303
IP address	53, 60
IP header	7, 176
IPv6 address	48
IPv6 address types	49
ISO/OSI layer model	

L	
	44
LDAP	
Leave message	
Link Aggregation	
Link Aggregation interface	
Link down delay	. 304
Link monitoring	3, 321
Link up delay	. 304
Logical tracking	
Login dialog	
Loop guard	
Loops	
LRE functionality (depends on hardware)	. 219
M	
MAC address filter	. 155
MAC destination address	46
MAC address table (forwarding database)	
MaxAge	
Memory (RAM)	
Message	
MMS	
Mode	. 126
MRP	3, 204
MRP Advanced Information	. 205
MRP over LAG	. 211
MRP Packet Prioritization	
MRP Packets	
Multicast	. 159
Ν	
Netmask	44, 53
Network load	9, 240
Network management	60
Network structure	
Network structure (HSR) (depends on hardware)	
Network structure (PRP) (depends on hardware)	
Non-volatile memory (NVM)	
NVM (non-volatile memory)	. 101
0	
Object classes	509

Object classes	
Object ID	
ODVA	 403
ODVA website	
OpenSSH-Suite	
Operation monitoring	
Operators	
Option 82	
Ordinary clock (PTP)	 95

•

Password 22, 24 Path costs 241, 244
,
PC Worx
PHB
Polling
Port Identifier
Port Mirroring
Port Mirroring peculiarities in connection with redundancy protocols (depends on hardware) 349
Port priority
Port roles (RSTP)
Port State
Precedence
Prefix length
Primary ring (RCP)
Priority
Priority queue
Priority tagged frames
Privileged Exec mode
PROFIBUS Organization
Protection functions (guards)
PRP example configuration (depends on hardware) 221
PRP RedBox (Example HSR) (depends on hardware) 228
PRP (depends on hardware)
PRP Network structure (depends on hardware) 220
PTP
PTP domain
PuTTY
Q
QoS
Query

	_
	R
•••	••

RADIUS			
RAM (memory)			101
Rapid Spanning Tree	200,	201, 1	248
RCP			200
RCP Advanced Information			297
RCP packets			298
RCP prerequisites			296
RCP topology requirements			
RCP, Topology of Two-Switch Redundant Coupling			297
RCP, Topology Overview			
Real time			
Reconfiguration			
Reconfiguration time (MRP)			
Record			
RedBox (depends on hardware)			
Redundancy			
Reference time source	,	,	,
Relay contact			
Remote diagnostics			
Remote Switch Port Analyzer			
Report			
Report message			
Request Packet Interval			
RFC			
Ring		,	
Ring Manager			
Ring/Network coupling			
Ring/Network Coupling Advanced Information			
Ring/Network Coupling packet prioritization			
Ring/Network Coupling packets			
Ring/Network coupling, Link Topology of 1-Switch coupling			
Ring/Network coupling, Link Topology of 2-Switch coupling			
Ring/Network coupling, Link Topology of 2-Switch coupling with Control Line			
Ring/Network Coupling, Topology requirements			
RIPE NCC			
RM (Ring Manager)			
Root bridge			
Root guard			
Root path			
Root path cost			
Root port			
Router			
Router Advertisement Daemon			
RPI			
RSPAN			
RSPAN combined source/intermediate role			
RSPAN destination role			
RSPAN device roles			
RSPAN example with reflector port			
RSPAN example without reflector port			
RSPAN example, starting point			
RSPAN example, starting point			
RSPAN interaction with Link Aggregation			361
RSPAN interaction with Link Aggregation			
RSPAN interaction with Link Aggregation	· · · · ·		358
RSPAN interaction with Link Aggregation	· · · · · ·		358 354
RSPAN interaction with Link Aggregation	· · · · · · · · · · · · · · · · · · ·	· · · · ·	358 354 360

RSPAN peculiarities in connection with redundancy protocols	
RSPAN purpose	
RSPAN Reflector port properties	
RSPAN ring topology	
RSPAN source role	
RSPAN topologies	
RSPAN tree topology	
RSPAN uplink properties	
RSPAN VLAN properties	
RSPAN with redundancy	
RST BPDU	,
RSTP	 . 251
e e e e e e e e e e e e e e e e e e e	
SAN (for HSR) (depends on hardware)	225
SAN (IOLITISK) (depends on hardware)	
Secondary ring (RCP)	
Secure Shell (SSH)	
Segmentation	
Serial interface	
Service	
Service Shell	
Service Shell deactivation	
Setting the time	
SFP module	
Signal contact	
SNMP	
SNMP trap	
SNTP	
Software version	
SSH (Secure Shell)	
Starting the graphical user interface	
Static routing	
Store-and-forward	
STP-BPDU	
Strict Priority	
Sub Ring	
Sub Ring Advanced Information	
Sub Ring Manager	
Sub Ring Packet Prioritization	
Sub Ring Packets	
Sub Ring Redundant Manager	
Subidentifier	
Subnet	
Symbol	
Syslog over TLS	
System requirements (Graphical User Interface)	
System time	

т

Tab Completion	. 35
TCN guard	
TCP/IP	
Technical questions	
Threshold value	
TIA Portal	
Topology Change flag	
ToŚ	
Tracking (VRRP)	303
Traffic class	173
Traffic shaping	174
Training courses	
Transmission reliability	309
Transparent clock (PTP)	. 94
Trap	311
Trap destination table	309
Tree structure (Spanning Tree) 244,	247
Type of Service	167
U	
UDP/IP	423
User Exec mode	
User name	, 23

.,

/ideo	8
/LAN	1
(LAN (HIPER Ring)	5
/LAN Mirroring	1
/LAN mode	
/LAN priority	
/LAN router interface	
/LAN tag	1
/oIP	8
/RRP Tracking	3
/T100	3
V	_

••	
Weighted Fair Queuing	168
Weighted Round Robin	168

D Technical support

Technical questions

For technical questions, please contact any Hirschmann dealer in your area or Hirschmann directly. You find the addresses of our partners on the Internet at www.belden.com.

For technical support, visit hirschmann-support.belden.com. This site also includes a free of charge knowledge base and a software download section.

Technical Documents

The current manuals and operating instructions for Hirschmann products are available at doc.hirschmann.com.

Customer Innovation Center

The Customer Innovation Center is ahead of its competitors on three counts with its complete range of innovative services:

- Consulting incorporates comprehensive technical advice, from system evaluation through network planning to project planning.
- Training offers you an introduction to the basics, product briefing and user training with certification. You find the training courses on technology and products currently available at www.belden.com/solutions/customer-innovation-center.
- Support ranges from the first installation through the standby service to maintenance concepts.

With the Customer Innovation Center, you decide against any compromise in any case. Our clientcustomized package leaves you free to choose the service components you want to use.

E Readers' Comments

What is your opinion of this manual? We are constantly striving to provide as comprehensive a description of our product as possible, as well as important information to assist you in the operation of this product. Your comments and suggestions help us to further improve the quality of our documentation.

Your assessment of this manual:

	Very Good	Good	Satisfactory	Mediocre	Poor
Precise description	0	0	0	0	0
Readability	0	0	0	0	0
Understandability	0	0	0	0	0
Examples	0	0	0	0	0
Structure	0	0	0	0	0
Comprehensive	0	0	0	0	0
Graphics	0	0	0	0	0
Drawings	0	0	0	0	0
Tables	0	0	0	0	0

Did you discover any errors in this manual? If so, on what page?

Suggestions for improvement and additional information:

General comments:

Sender:

Company / Department:

Name / Telephone number:

Street:

Zip code / City:

E-mail:

Date / Signature:

Dear User,

Please fill out and return this page

- as a fax to the number +49(0)7127/14-1600 or
- per mail to
 - Hirschmann Automation and Control GmbH Department IRD-NT Stuttgarter Str. 45-51 72654 Neckartenzlingen Germany

